



Functional description | EN

## TF5200 | TwinCAT 3 CNC

Axis compensation





# Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

## Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

## Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

## Patent Pending

The EtherCAT technology is patent protected, in particular by the following applications and patents:  
EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702  
with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

## Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

# General and safety instructions

## Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

### Icons in explanatory text

1. Indicates an action.
- ⇒ Indicates an action statement.

#### DANGER

##### **Acute danger to life!**

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.

#### CAUTION

##### **Personal injury and damage to machines!**

If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.

#### NOTICE

##### **Restriction or error**

This icon describes restrictions or warns of errors.



##### **Tips and other notes**

This icon indicates information to assist in general understanding or to provide additional information.

### General example

Example that clarifies the text.

### NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.



##### **Specific version information**

Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

# Table of contents

|   |    |
|---|----|
| Notes on the documentation .....  | 3  |
| General and safety instructions .....   | 4  |
| 1 Overview .....  | 7  |
| 2 Backlash compensation .....   | 8  |
| 2.1 Overview .....  | 8  |
| 2.2 Description .....   | 9  |
| 2.3 Parameterisation .....  | 11 |
| 2.3.1 Overview .....  | 11 |
| 2.3.2 Description .....   | 11 |
| 2.3.3 CNC objects .....   | 11 |
| 2.4 Error messages .....  | 13 |
| 2.5 Parameterisation example .....  | 13 |
| 3 Temperature compensation .....  | 14 |
| 3.1 Overview .....  | 14 |
| 3.2 Parameterisation .....  | 16 |
| 3.2.1 Overview .....  | 20 |
| 3.2.2 Description .....   | 20 |
| 3.2.3 CNC objects .....   | 21 |
| 3.3 Example .....   | 24 |
| 4 Axis compensations with compensation value lists .....                      | 25 |
| 4.1 Compensation value lists .....  | 25 |
| 4.2 Leadscrew error compensation .....  | 28 |
| 4.2.1 Parameter .....   | 30 |
| 4.2.2 Example - Non-equidistant bilateral SSFK .....                          | 38 |
| 4.2.3 Error messages .....  | 39 |
| 4.3 Cross compensation .....  | 40 |
| 4.3.1 Parameter .....   | 42 |
| 4.3.2 Example of a compensation value list .....                              | 47 |
| 4.3.3 Error messages .....  | 49 |
| 4.4 Plane compensation .....  | 50 |
| 4.4.1 Parameter .....   | 53 |
| 4.4.2 Examples of compensation value lists .....                              | 61 |
| 4.4.3 Error messages .....  | 63 |
| 4.5 Crosstalk compensation .....  | 64 |
| 4.5.1 Overview .....  | 65 |
| 4.5.2 Parameterisation .....  | 67 |
| 4.5.3 Example of a compensation value list .....                              | 70 |
| 4.5.4 Error messages .....  | 70 |
| 5 Other configuration options for axis compensation .....                     | 71 |
| 5.1 Selecting/deselecting axis compensation in the NC program .....           | 71 |
| 5.2 Checking the states of axis compensation in the NC program .....          | 73 |
| 5.3 Monitoring of effectiveness of axis compensations in automatic mode ..... | 74 |

|                             |    |
|-----------------------------|----|
| 6 Support and Service ..... | 76 |
| Index .....                 | 77 |

# 1 Overview

## Task

Axis compensations rectify inaccuracies in tool guidance caused by mechanical errors such as backlash, errors in spindle pitch or temperature fluctuations.

A distinction is made between 5 programming modes:

- Backlash compensation
- Temperature compensation
- Leadscrew error compensation
- Cross compensation
- Plane compensation

## Properties

In general, each axis compensation can be activated for all:

- axis types
- drive types

The conditions required for their effectiveness are described in the related sections on compensation types.

## Parametrisation

Specific parameters must be configured for each axis compensation in order to activate them. They are described for each compensation type in the section "Parameterisation".

## Programming

Axis compensations can be activated and deactivated in the NC program with the command X[COMP...].

### ***Mandatory note on references to other documents***

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons, these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.

The friction compensation functionality is described in FCT-C25.

## 2 Backlash compensation

### 2.1 Overview

#### Task

Backlash compensation has the purpose of compensating for the deviation between the real and calculated actual position of an axis caused by mechanical backlash.

#### Effectiveness

Backlash compensation can be activated for **all** axis types.

The effect of backlash can be compensated for **all** drive types.

#### Parameterisation

With regard to backlash compensation,

- the type of mechanical backlash P-AXIS-00021
- the amount of mechanical backlash P-AXIS-00103
- the distribution of mechanical backlash P-AXIS-00243

can be parameterised in the axis parameter record [AXIS].

## 2.2 Description

### Mechanical backlash

The play between the

- the drive and a moving machine part or
- between a sensor and a moving machine part is referred to as mechanical backlash.

For a moving machine part, mechanical backlash results in a deviation between the commanded position and the actual position. This especially has an effect when the direction of motion is reversed.

A distinction is made between the following kinds of mechanical backlash:

- Positive backlash
- Negative backlash

### Positive backlash

Positive backlash occurs in systems in which

- the measuring system is connected directly to the drive and
- the backlash occurs between the drive and the moving mechanical part.

When the direction of movement reverses, the measuring system will detect a position change although the machine part is not yet moving due to the backlash.

This leads to a situation in which the machine part does not reach the commanded position, but travels too short by the backlash amount because the sensor that indirectly measures the position of the machine part is ahead of the machine part's **actual position**.




Fig. 1: Positive backlash

### Negative backlash

Negative backlash is encountered in systems in which the backlash occurs between the moving machine part and the measuring system. When the direction is reversed, the machine part directly moves in the new direction without the measuring system detecting a position change.

In this case, the machine part moves further by the backlash amount than is required by the command because the sensor that directly measures the position of the machine part **lags behind** the position of the machine part.




Fig. 2: Negative backlash

### Backlash compensation

The size of the backlash P-AXIS-00103 during on position control is taken into consideration depending on the type of mechanical backlash P-AXIS-00021 and acts on the calculation of the command variables.

- i** The display of the absolute command position or actual position of the moving machine part does **not** include the compensation values and therefore represents the position of an ideal machine.

### Effectiveness

When backlash compensation is selected, it is active directly after controller start-up, regardless of whether homing has taken place [FCT-M1//Description].

The algorithm compensates for the backlash in the 1st cycle of the path motion. A large backlash can cause strong excitation in the machine. To prevent this, the backlash can be distributed over several position control cycles P-AXIS-00243.

## 2.3 Parameterisation

### 2.3.1 Overview

| ID           | Parameter       | Description                               |
|--------------|-----------------|---|
| P-AXIS-00021 | anwahl_losekomp | Selection and type of mechanical backlash |
| P-AXIS-00103 | lose            | Size of mechanical backlash               |
| P-AXIS-00243 | n_backlash_cyc  | Distribution of mechanical backlash       |

### 2.3.2 Description

|                     |  |           |
|---------------------|--|-----------|
| <b>P-AXIS-00021</b> | <b>Selection of backlash compensation</b>  |           |
| Description         | <p>The selection of backlash compensation is done using this parameter.</p> <p>The type of backlash (the backlash between the table and the drive or the backlash between the drive and the measuring system) depends on the mathematical sign of P-AXIS-00103 (getriebe[i].lose).</p> |           |
| Parameter           | lr_param.anwahl_losekomp   |           |
| Data type           | UNS16  |           |
| Data range          | 0: No backlash compensation<br>1: Last axis motion occurred in pos. direction.<br>2: Last axis motion occurred in neg. direction.  |           |
| Axis types          | T, R, S  |           |
| Dimension           | T: ----  | R,S: ---- |
| Default value       | 0  |           |
| drive types.        | ----   |           |
| Remarks             |  |           |

|                     |  |               |
|---------------------|--|---------------|
| <b>P-AXIS-00103</b> | <b>Size of backlash</b>                                  |               |
| Description         | The parameter defines the size of backlash.              |               |
| Parameter           | getriebe[i].lose   |               |
| Data type           | SGN16  |               |
| Data range          | SGN16 range 0 < backlash: backlash betw. drive and slide |               |
| Axis types          | T, R, S  |               |
| Dimension           | T: 0.1µm   | R,S: 0.0001 ° |
| Default value       | 0  |               |
| drive types.        | ----   |               |
| Remarks             |  |               |

### 2.3.3 CNC objects

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | BC::actual backlash  |                     |                          |
| <b>Description</b> | This object reads the current effective compensation offset of backlash compensation |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0093 |
| <b>Data type</b>   | SGN32  | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | BC::conf. backlash   |                     |                          |
| <b>Description</b> | This object reads the configured value for backlash compensation.<br>The parameter <a href="#">P-AXIS-00103 [▶ 11]</a> defines this value. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >00AF |
| <b>Data type</b>   | SGN32  | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | BC::delta backlash   |                     |                          |
| <b>Description</b> | This object reads the change in compensation value in the current backlash compensation cycle. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0095 |
| <b>Data type</b>   | SGN32  | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ $\cdot$ ]              |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | BC::sum backlash   |                     |                          |
| <b>Description</b> | This object reads the compensation value of the backlash compensation at the current position without filters. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0094 |
| <b>Data type</b>   | SGN32  | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ $\cdot$ ]              |
| <b>Remarks</b>     |  |                     |                          |

## 2.4 Error messages

Errors in the configuration of batch compensation result in deactivation of the function for the axis affected and an error message (warning) is output:

P-ERR-110392

## 2.5 Parameterisation example

### Excerpt from the axis parameter list

```
getriebe[0].lose          1000  #0,1 µm backlash
lr_param.anwahl_losekomp 1      #Positive direction
lr_param.n_backlash_cyc 10     #Number of filter cycles
```

## 3 Temperature compensation

### 3.1 Overview

#### Deformation and its effect

Temperature changes cause an expansion or contraction of machine parts.

Deformations cause offsets in the axis positions that are not detected by the machine's position measuring system and lead to inaccuracies in the finished workpiece.




Fig. 3: Temperature-dependent falsification of the axis position

## Compensation

Temperature compensation provides a function to correct the command variable of the axis depending on the current temperature and axis position.

The compensation values are determined according to the following equation:

$$\Delta s(T,s) = \text{offset}_0(T) + \text{coefficient}(T) * [s - s_0]$$

where:

$s$  = current position of the axis

$T$  = current reference temperature

$s_0$  = reference position of the axis

$\text{Offset}_0(T)$  = temperature-dependent deviation from reference position

Coefficient = temperature-dependent ratio of deviation to distance from reference position




Fig. 4: Parameter of temperature compensation for a temperature  $T$

## Effectiveness

The temperature compensation is effective if:

- it was activated for the axis and
- the axis is homed.

## 3.2 Parameterisation

### Activate

Temperature compensation is activated in the axis machine data record [AXIS] of the required axis using P-AXIS-00271:

```
kopf.achs_nr           1  
#  
# temperature compensation on/off  
lr_param.temp_comp     1
```

Compensation can also be activated using a write access to the CNC object via the GEO task:

TEMPC::is\_active      Index group = 0x120300, Index offset = 0x10041

### Reference measurement

Before specifying the parameters of temperature compensation, a reference measurement must first be carried out using an external position measuring system. It determines the deviations of the axis positions between the internal and external measuring system at different temperatures.




Fig. 5: Reference measurement at different temperatures

## Determine parameters

The parameters reference position, offset and coefficient can be taken from the measurement curves. The values at a given temperature can be set later from the curves. Temperatures that are not measured can be interpolated or extrapolated from the measured temperature curves.

If the virtual intersection of the approximated linear curves is chosen as the reference position, the offset is independent of temperature. In this case, only the coefficient must be reset for different temperatures.

## Influence of temperature

The individual parameters can be set by the PLC depending on the current temperature. To do this, a corresponding temperature signal (sensor) is transmitted to the PLC which then derives the parameters from it.

## Explicit activation in NC program

```
lr_param.temp_comp_manual_activation      0
```

- 0 (default): The CNC activates temperature compensation automatically as soon as the required preconditions are met (e.g. the axis is homed).
- 1: Temperature compensation must be activated manually in the NC program using the COMP command (see Section “[Selecting and deselecting axis compensations in the NC program \[▶ 71\]](#)”).

Compensation is deselected:

- at the end of the NC program
- at CNC reset and
- on release of the axis.

## Change parameters

Each of the parameters can be changed by downloading the axis list:

```
kopf.achs_nr                                1
#
# temperature compensation on/off
lr_param.temp_comp          1
# reference position
lr_param.temp_comp_position_0    100  [0.1µm]
# reference offset
lr_param.temp_comp_offset_0     40   [0.1µm]
lr_param.temp_comp_coefficient 4000  [µm/m]
#
```

In addition to the download option, there is also the option of writing and reading the parameters via direct access to the GEO task via CNC objects. For example, the first axis can be addressed via the following index group and index offset:




Fig. 6: Access to CNC objects of temperature compensation

### Monitoring and coupling/decoupling

The compensation values are recalculated for each interpolation cycle. If the change per cycle exceeds the given maximum axis acceleration, this change can be output filtered over multiple cycles.

For this the number of cycles of the  $\sin^2$  filter can be defined in the axis parameter list. By default, this is set to one cycle.

```
kopf.achs_nr           1
#
# Cycle of the sin2 filter
lr_param.temp_comp_n_cycles 20
```




Fig. 7: Deactivating compensation values with a  $\sin^2$  filter over 20 cycles by deactivating temperature compensation temporarily

### Display the compensation

In addition to the download option, there is also the option of writing and reading the parameters via direct access to the CNC objects of the GEO task. For example, the 1st axis can be addressed using the following index group and index offset:

|                  |  |
|------------------|--|
| TEMPC::is_active | Index group = 0x120300, Index offset = 0x10041 |
| TEMPC::is_active | Index group = 0x120300, Index offset = 0x10042 |

### Display the axis position

When temperature compensation is activated, the normal command and actual positions of the axis are displayed unchanged.

The corrections are only calculated and included before output to the drive bus and can therefore be viewed in the position values of the drive bus (dig\_cmd\_pos, dig\_act\_pos).

### 3.2.1 Overview

| ID           | Parameter          | Description                     |
|--------------|--------------------|---------------------------------|
| P-AXIS-00789 | lr_param.crosstalk | Activate crosstalk compensation |

| ID           | Parameter                      | Description                             |
|--------------|--------------------------------|---|
| P-COMP-00063 | kw.crosstalk.master_ax_nr      | Log. Axis number of the master axis     |
| P-COMP-00064 | kw.crosstalk.n_cycles          | Number of cycles for 'smooth switching' |
| P-COMP-00065 | kw.crosstalk.last_index        | Last index of compensation value table  |
| P-COMP-00066 | kw.crosstalk.acceleration      | Accelerations of the master axis        |
| P-COMP-00067 | kw.crosstalk.correction        | Compensation values for the slave axis  |
| P-COMP-00073 | kw.crosstalk.manual_activation | Manual activation                       |

### 3.2.2 Description

| P-AXIS-00271  | Selection of temperature compensation               |           |
|---------------|---|-----------|
| Description   | The parameter selects the temperature compensation. |           |
| Parameter     | lr_param.temp_comp                                  |           |
| Data type     | BOOLEAN   |           |
| Data range    | 0/1   |           |
| Axis types    | T, R, S   |           |
| Dimension     | T: ----   | R,S: ---- |
| Default value | 0   |           |
| Drive types   | ----  |           |
| Remarks       |   |           |

| P-AXIS-00272  | Parameterisation of temperature compensation (Basic position)  |              |
|---------------|--|--------------|
| Description   | The compensation values are approximated by a linear straight line. This straight line is defined by a basic position, an offset at this position and a geometrical pitch. Depending on the temperature, these parameters can be adjusted e.g. by the PLC. |              |
| Parameter     | lr_param.temp_comp_position_0  |              |
| Data type     | SGN32  |              |
| Data range    | MIN(SGN32) < temp_comp_position_0 < MAX(SGN32)   |              |
| Axis types    | T, R, S  |              |
| Dimension     | T: 0.1 µm  | R,S: 0.0001° |
| Default value | 0  |              |
| Drive types   | ----   |              |
| Remarks       |  |              |

| P-AXIS-00273  | Parameterisation of temperature compensation (Offset)  |              |
|---------------|--|--------------|
| Description   | The compensation values are approximated by a linear straight line. This straight line is defined by a basic position, an offset at this position and a geometrical pitch. Depending on the temperature, these parameters can be adjusted e.g. by the PLC. |              |
| Parameter     | lr_param.temp_comp_offset_0  |              |
| Data type     | SGN32  |              |
| Data range    | MIN(SGN32) < temp_comp_offset_0 < MAX(SGN32)   |              |
| Axis types    | T, R, S  |              |
| Dimension     | T: 0.1 µm  | R,S: 0.0001° |
| Default value | 0  |              |
| Drive types   | ----   |              |

|         |  |
|---------|--|
| Remarks |  |
|---------|--|

| <b>P-AXIS-00274 Parameterisation of temperature compensation (Geometrical pitch)</b> |  |           |
|--|--|-----------|
| Description  | The compensation values are approximated by a straight line. This straight line is defined by a basic position, an offset at this position and a geometrical pitch. Depending on the temperature these parameters can be adjusted e.g. by the PLC. |           |
| Parameter  | lr_param.temp_comp_coefficient   |           |
| Data type  | REAL64   |           |
| Data range   | -10000 ≤ temp_comp_coefficient ≤ 10000   |           |
| Axis types   | T, R, S  |           |
| Dimension  | T: μm/m  | R,S: ---- |
| Default value  | 0  |           |
| Drive types  | ----   |           |
| Remarks  |  |           |

| <b>P-AXIS-00275 Distribution of the temperature compensation on several cycles</b> |   |                                     |
|--|---|-------------------------------------|
| Description  | The compensation values are recalculated for each interpolation cycle. If the change per cycle exceeds the given maximum axis acceleration, this change can be output filtered over multiple cycles.<br>For this the number of cycles of the sin <sup>2</sup> filter can be defined in the axis parameter list. |                                     |
| Parameter  | lr_param.temp_comp_n_cycles   |                                     |
| Data type  | UNS16   |                                     |
| Data range   | 0 < temp_comp_n_cycles < 20   |                                     |
| Axis types   | T, R, S   |                                     |
| Dimension  | T: Number of interpolation cycles   | R,S: Number of interpolation cycles |
| Default value  | 0   |                                     |
| Drive types  | ----  |                                     |
| Remarks  |   |                                     |

| <b>P-AXIS-00482 Manual activation of the temperature compensation</b> |  |           |
|---|--|-----------|
| Description   | The CNC turns the temperature compensation on when it is selected in the axis parameter list (P-AXIS-00271) and the required preconditions are met (e.g. the axis is homed).<br>If the parameter is set to 1, the temperature compensation must be manually turned on in the NC program via an NC command (see [PROG//Switching axis compensation on/off in the NC program]). In addition, the compensation is turned off at the end of the NC program, during CNC reset and axis release. |           |
| Parameter   | lr_param.temp_comp_manual_activation   |           |
| Data type   | BOOLEAN  |           |
| Data range  | 0: Automatic activation (default).<br>1: Manual activation in NC program.  |           |
| Axis types  | T, R, S  |           |
| Dimension   | T: ----  | R,S: ---- |
| Default value   | 0  |           |
| Drive types   | ----   |           |
| Remarks   |  |           |

### 3.2.3 CNC objects

|      |                   |
|------|-------------------|
| Name | TEMPC:: activated |
|------|-------------------|

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Description</b> | This object reads whether temperature compensation is activated via <a href="#">P-AXIS-00271 [▶ 20]</a> . |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0041 |
| <b>Data type</b>   | BOOLEAN   | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read/ write   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     | TRUE/FALSE  |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | TEMPC::f_is_active  |                     |                          |
| <b>Description</b> | This object reads whether temperature compensation is activated .<br>This means that all preconditions, such as axis is referenced and all necessary enables are on, must be fulfilled. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >01D8 |
| <b>Data type</b>   | BOOLEAN   | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |   |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | TEMPC::actual_offset  |                     |                          |
| <b>Description</b> | This object reads the current offset of the temperature compensation. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0042 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | TEMPC::coefficient   |                     |                          |
| <b>Description</b> | This object reads and writes the required geometrical pitch for temperature compensation.<br><br>See also <a href="#">P-AXIS-00274 [▶ 21]</a>                                  |                     |                          |
|                    | The temperature compensation values are approximated by a straight line. The straight line is defined by a basic position, an offset at this position and a geometrical pitch. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0043 |
| <b>Data type</b>   | REAL64   | <b>Length</b>       | 8                        |
| <b>Attributes</b>  | read/ write  | <b>Unit</b>         | [μm/m]                   |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | TEMPC::offset_0  |                     |                          |
| <b>Description</b> | This object reads and writes the required offset for temperature compensation.<br><br>See also <a href="#">P-AXIS-00273 [▶ 20]</a>   |                     |                          |
|                    | The temperature compensation values are approximated by a straight line. The straight line is defined by a basic position, an offset at this position and a geometrical pitch. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0044 |
| <b>Data type</b>   | SGN32  | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read/ write  | <b>Unit</b>         | [0.1 μm]                 |
| <b>Remarks</b>     |  |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | TEMPC::position_0   |                     |                          |
| <b>Description</b> | <p>This object reads and writes the required reference position for temperature compensation.</p> <p>See also <a href="#">P-AXIS-00272 [► 20]</a></p> <p>The temperature compensation values are approximated by a straight line. The straight line is defined by a basic position, an offset at this position and a geometrical pitch.</p> |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0045 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read/ write   | <b>Unit</b>         | [0.1 μm]                 |
| <b>Remarks</b>     |   |                     |                          |

## 3.3 Example

### Initialisation

Compensation is activated in the X axis by the following settings:

```
lr_param.temp_comp           1
lr_param.temp_comp_position_0 100 [0.1µm]
lr_param.temp_comp_offset_0   40 [0.1µm]
lr_param.temp_comp_coefficient 4000 [µm/m]
lr_param.temp_comp_n_cycles   20
```

### NC program

The following NC program was used for the test:

```
N10: G90 G01 X0 F1000
G04 1
N10 X100
G04 1
N10 X80
G04 1
N10 X50
G04 1
N20 X-200
G04 1

$GOTO [N10]
M30
```




Fig. 8: Logged compensation values dependent on axis position.

## 4 Axis compensations with compensation value lists

### 4.1 Compensation value lists

#### Storing compensation values

Data for the compensation processes

- leadscrew error compensation
- cross compensation and
- plane compensation

are stored for each axis in so-called compensation value lists that are loaded when the controller starts up. It is also possible to update the lists at a later date.



It is possible to activate all the compensation processes (cross, plane, leadscrew error and temperature compensation) for an axis simultaneously.

When you use leadscrew error compensation, it is recommended to include a possible backlash directly in the compensation table of the leadscrew error compensation (double-sided compensation P-COMP-00021).



**As of CNC Build V3.1.3079.06 you can adjust the size of the compensation value lists.**

#### Providing the compensation value lists

The following entries must be present in the start-up description [STUP] in order to signal the compensation table to the controller:

| Variable name        | Type   | Meaning  |
|----------------------|--------|--|
| zahl_kw              | UNS16  | Number of offset value lists   |
| achs_kw[i]           | String | Name of datafile   |
| achs_kw_log_ax_nr[i] | UNS16  | Logical number of axis for which the compensation value list is valid. |

#### NOTICE

If the compensation value list is configured by the TwinCAT System Manager, these entries are assigned automatically in the start-up description.

Excerpt from the start-up list *hochlauf.lis*:

```
:  
zahl_kw          3  
#  
achs_kw_log_ax_nr[0] 1  
achs_kw[0]        ..\listen\achs_kw1.lis  
#  
achs_kw_log_ax_nr[1] 2  
achs_kw[1]        ..\listen\achs_kw2.lis  
#  
achs_kw_log_ax_nr[2] 6  
achs_kw[2]        ..\listen\achs_kw6.lis  
:
```

### Structure of the compensation value list

The compensation value list consists of

- a list header containing general data and
- the body of the list where the compensation algorithms are configured and containing the actual compensation tables.

#### List header

The list header is identified in the list by the structure variable **kopf**. It contains the following elements:

| Variable name      | Type   | Meaning  |
|--------------------|--------|--|
| kopf.achs_nr       | UNS16  | Logical number of compensation value list                    |
| kopf.log_achs_name | String | Name of the axis, which is only used for diagnostic purposes |

#### NOTICE

If the compensation value list is configured by the TwinCAT System Manager, these entries are made automatically in the compensation value list.

## Body of the list

The list body contains general data and the compensation tables. The entries in the list body are identified by the structure variable **kw**. It contains the following substructures for the specific compensation processes:

| Variable name | Meaning  |
|---------------|--|
| kw.ssfk.      | Data structure for leadscrew error compensation                          |
| kw.crosscomp. | Data structure for cross compensation                                    |
| kw.crosscomp2 | Data structure for plane compensation (2-dimensional cross compensation) |

## Updating the compensation table

The compensation table can be updated while the controller is running, provided the conditions for the effectiveness of a compensation are fulfilled.

### NOTICE

After start-up, updating or re-initialisation, it is “almost” not permissible to command a rapid program start or exchange an axis without requesting axis positions.

First, the NC channel must be synchronised in relation to axis positions.

## 4.2 Leadscrew error compensation

### Compensation process

Leadscrew error compensation (referred to below as LSEC) is an axial compensation. The position setpoint of the compensated axis is changed by a compensation value in the position controller cycle in order to compensate for leadscrew errors, for instance.

This compensation is cancelled by computation for the measured actual position values so that the compensation performed does not appear in the display data of the controller.

### Compensation table

The compensation values are taken from a table in which the profile of the compensation curve is stored as a function of the axis position. The axis positions entered in the table are called interpolation points and the corresponding values of the compensation curve are called compensation values.

The compensation value is linearly interpolated for axis positions that lie between interpolation points.

The table containing compensation values is referred to in the following as the compensation table.

### Bilateral/unilateral LSEC

You can specify a separate compensation table for each direction of axis motion; this type of compensation is called bilateral compensation.

With bilateral leadscrew error compensation, any backlash that may be present can also be compensated for; additional backlash compensation (see Section “[Backlash compensation \[▶ 8\]](#)“) is therefore not necessary.

With bilateral leadscrew error compensation, the parameter [P-AXIS-00243 \[▶ 33\]](#) specifies the number of cycles for distribution of the compensation offset in case of a reversal in direction.

If a table is used for both directions of axis motion, it is referred to as unilateral compensation.

- The compensation tables are stored to a file for each axis (compensation value list).
- Axis dynamics are not taken into account in the output of compensation values.

The graphic below shows an example of a compensation value curve. The meaning of the parameters used in the graphic will be explained later.




Fig. 9: Compensation table with equidistant interpolation point grid and unilateral compensation

## Properties

Leadscrew error compensation (LSEC) has the following characteristics:

- When bilateral compensation is used, the same interpolation point positions must be used for both value tables.
- You can define a compensation table only for a partial motion range of an axis. For axis positions outside the compensation table, the value at either end of the table continues to be used.
- Any compensation value other than 0 can be present at the reference point.
- The distance between interpolation points in the value tables can be selected either equidistant or non-equidistant.
- As of CNC Build V3.1.3079.06 you can adjust the size of the compensation table. The parameter P-COMP-00059 [▶ 33] defines the maximum number of table entries. The actual number of entries used by P-COMP-00020 [▶ 34]

## Effectiveness

The LSEC is effective under the following conditions:

- The LSEC was activated for the slave axis.
- A compensation table for the axis must be transferred to the controller.
- The axis was referenced or uses an absolute measuring system.

## 4.2.1 Parameter

### 4.2.1.1 Overview

#### Activation

Leadscrew error compensation (LSEC) is activated in the axis machine data record of the corresponding slave axis by P-AXIS-00175:

| Variable name           | Type    | Meaning   |
|-------------------------|---------|---|
| lr_param.ssfk           | BOOLEAN | 0: no LSEC<br>1: LSEC active  |
| P-AXIS-00243 [► 33]     | UNS16   | Number of cycles with bilateral leadscrew error compensation with reversal of direction |
| lr_param.n_backlash_cyc |         |   |

#### Excerpt from the axis parameter list:

```
:  
lr_param.ssfk      1  
:
```

## Management data of the LSEC table

The general data of the list body parameterises the operation mode of the compensation, e.g. unilateral or bilateral. General data is entered in the structure **kw:ssfk..\*** and contains the following elements.

### Management data elements

| Variable name        | Type    | Meaning   |
|----------------------|---------|---|
| unit                 | BOOLEAN | Unit of the length entries:<br>0: Encoder increments<br>1: metric (in 0.1 µm)   |
| interval             | SGN32   | Distance between interpolation points of the compensation table for use if using equidistant interpolation points. If this parameter is = 0, the position of each interpolation point must be specified separately.   |
| kw_startpos          | SGN32   | Start position of the compensation table (with equidistant interpolation points)  |
| kw_nr_max            | SGN32   | Number of entries in the compensation table<br><br>As of CNC Build V3.1.3079.06, the maximum possible number of entries can be defined in <a href="#">P-COMP-00059 [▶ 33]</a> . In previous builds the default value is 1500.   |
| bilateral            | BOOLEAN | 0: Unilateral compensation<br>1: Bilateral compensation   |
| modulo               | BOOLEAN | Compensation for a modulo axis take place   |
| manual_activation    | BOOLEAN | 0 (default): The CNC activates leadscrew error compensation automatically as soon as the required conditions are met (e.g. the master axis is referenced)<br><br>1: Leadscrew error compensation must be activated explicitly in the NC program by the COMP command (see Section <a href="#">"Selecting/deselecting axis compensations in the NC program"</a> ) [▶ 71]. Compensation is deactivated at the end of the NC program, when the CNC is reset or when the axis is released.   |
| set_pos_without_comp | BOOLEAN | By default, leadscrew error compensation also considers the compensation values generated from other axis compensations, e.g. cross and plane compensation. Direction-dependent leadscrew error compensation (see <a href="#">P-COMP-00021 [▶ 30]</a> ) may result in undesired backlash cover. The parameter set_pos_without_comp can disable the inclusion of other compensation values in the calculation.<br><br>0: Compensation values of other compensations are considered in the leadscrew error compensation.<br>1: Compensation values of other compensations are not considered. |

## LSEC compensation values

The compensation values are specified in the table **kw.ssfk.table[i].\***.

The field index i can then assume the value 0 to **kw.ssfk.kw\_nr\_max -1**. The maximum number of entries is specified in [SYSP//Number 2.23].

The compensation values are specified as absolute position errors in the unit specified in **kw.ssfk.unit** (metric in 0.1 µm or incremental). Where:

|                             |  |
|-----------------------------|--|
| <b>[Delta]<sub>si</sub></b> | i-th compensation value  |
| <b>s<sub>soll, i</sub></b>  | i-th command value (interpolation point of the compensation table) |
| <b>s<sub>ist, i</sub></b>   | i-th actual value (measured with reference measuring system)       |

## Compensation value table

| Variable name | Type  | Meaning   |
|---------------|-------|---|
| pos           | SGN16 | Compensation value for motion in a positive direction (bilateral compensation) and compensation value for use with unilateral compensation. |
| neg           | SGN16 | Compensation value for motion in a negative direction. Not used with unilateral SSKF.   |
| setpoint      | SGN32 | Interpolation point of the axis (programmed value). Only with non equidistant interpolation points.   |

For use with bilateral compensation, enter position errors for motion in a position direction in the **pos** entry, The interpolation points specified are valid for both directions.

For use with unilateral compensation, also enter position errors in the **pos** Entry. The **neg** entry is omitted.

As opposed to the entry of individual interpolation points for the compensation table, a grid structure can also be used. Entries for interpolation points can then be omitted in the **setpoint** variable in this case.

To use an interpolation point grid, enter the increment of the interpolation point grid in the **kw.ssfk.interval** variable. The interpolation points are then calculation internally from the start position (**kw.ssfk.kw\_startpos**) and the increment.

## Special features applicable to modulo axes

If a compensation table is configured for a modulo axis (**kw.ssfk.modulo = 1**), a modulo transition also occurs in the compensation table at the modulo transition of the axis position.

This can be used in order to compensate for position errors caused by gears or transmissions for instance.

The following special aspects must be noted:

- The position values of the first and last entries in the compensation list must be identical.
- The number of compensation values is also equal here to the number of entries in the compensation value table.

### 4.2.1.2 Description

| <b>P-AXIS-00175 Activation of SSFK</b> |   |         |
|--|---|---------|
| Description                            | This parameter activates the lead screw error compensation. |         |
| Parameter                              | lr_param.ssfk   |         |
| Data type                              | BOOLEAN   |         |
| Data range                             | 0/1   |         |
| Axis types                             | T, R  |         |
| Dimension                              | T: ----   | R: ---- |
| Default value                          | 0   |         |
| Drive types                            | ----  |         |
| Remarks                                |   |         |

| <b>P-AXIS-00243 Distribution of the backlash on multiple cycles</b> |  |                                     |
|---|--|-------------------------------------|
| Description   | The parameter defines a number of position control cycles on which the backlash is distributed. The distribution is done according to a $\sin^2$ function.<br>The parameter is also used for bi-directional lead screw error compensation if a change of direction is executed.                                      |                                     |
| Parameter   | lr_param.n_backlash_cyc  |                                     |
| Data type   | UNS16  |                                     |
| Data range  | 0 < n_backlash_cyc < 20  |                                     |
| Axis types  | T, R, S  |                                     |
| Dimension   | T: Number of interpolation cycles  | R,S: Number of interpolation cycles |
| Default value   | 0  |                                     |
| Drive types   | ----   |                                     |
| Remarks   | For the values 0 or 1 the output of the backlash to the drive is done abruptly within one cycle. A value larger than 1 creates a distribution according to the $\sin^2$ function<br>The use of this feature avoids increasing errors at the workpiece, because for large backlash the machine excitation is reduced. |                                     |

| <b>P-COMP-00059 Maximum number of table entries for leadscrew error compensation</b> |  |
|--|--|
| Description  | This leadscrew error compensation parameter ( <a href="#">FCT-C5 [▶ 28]</a> ) sets the memory space required for a particular number of table entries.<br><br>The size of the actually used compensation table is defined by `kw_nr_max` (P-COMP-00020) and `kw_nr_max` must be smaller than `max_points`. |
| Parameter  | kw.ssfk.max_points   |
| Data type  | UNS32  |
| Data range   | 0 <= P-COMP-00059  |
| Axis types   | T, R, S  |

|               |  |           |
|---------------|--|-----------|
| Dimension     | T: ----  | R,S: ---- |
| Default value | 1500   |           |
| Remarks       | <p>The parameter value can no longer be changed after start-up or after lists are reloaded. Otherwise error ID 110638 is output.</p> <p>If P-COMP-00059 is not specified (or assigned the value 0), the default value is assigned to P-COMP-00059 for downward compatibility reasons.</p> <p>To avoid the default assignment, memory can be saved for an axis that does not use <u>leadscrew error compensation</u> [▶ 28] by assigning the value 1 to P-COMP-00059.</p> <p>This parameter is available as of CNC Build V3.3079.06</p> |           |

| <b>P-COMP-00017</b> <b>Unit of the length entries</b> |   |           |
|---|---|-----------|
| Description   | This parameter defines the unit of the length / position entries. |           |
| Parameter   | kw.ssfk.unit  |           |
| Data type   | BOOLEAN   |           |
| Data range  | 0: Encoder increments<br>1: Metric (in 0.1 µm)                    |           |
| Axis types  | T, R, S   |           |
| Dimension   | T: ----   | R,S: ---- |
| Default value   | 0   |           |
| Remarks   |   |           |

| <b>P-COMP-00018</b> <b>Distance between interpolation points</b> |  |                            |
|--|--|----------------------------|
| Description  | The parameter defines the distance between interpolation points of the compensation table when equidistant interpolation points are used. If this parameter is = 0, the position of each interpolation point must be specified separately. |                            |
| Parameter  | kw.ssfk.interval   |                            |
| Data type  | SGN32  |                            |
| Data range   | 0 ≤ interval < MAX(SGN32)  |                            |
| Axis types   | T, R, S  |                            |
| Dimension  | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value  | 0  |                            |
| Remarks  |  |                            |

| <b>P-COMP-00019</b> <b>Start position of compensation values</b> |  |                            |
|--|--|----------------------------|
| Description  | This parameter determines the position of the axis at which the compensation table starts. |                            |
| Parameter  | kw.ssfk.kw_startpos  |                            |
| Data type  | SGN32  |                            |
| Data range   | MIN(SGN32) ≤ kw_startpos < MAX(SGN32)  |                            |
| Axis types   | T, R, S  |                            |
| Dimension  | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value  | 0  |                            |
| Remarks  |  |                            |

| <b>P-COMP-00020</b> <b>Number of compensation values</b> |   |  |
|--|---|--|
| Description  | This parameter defines the number of entries in the compensation table. |  |
| Parameter  | kw.ssfk.kw_nr_max   |  |
| Data type  | SGN32   |  |

|               |  |           |
|---------------|--|-----------|
| Data range    | $0 \leq kw\_nr\_max < P\text{-COMP-00059} [▶ 33]$          |           |
| Axis types    | T, R, S  |           |
| Dimension     | T: ----  | R,S: ---- |
| Default value | 0  |           |
| Remarks       | P-COMP-00059 [▶ 33] is available as of Build V3.1.3079.06. |           |

| P-COMP-00021  | Operation mode of compensation  |           |
|---------------|---|-----------|
| Description   | This parameter defines whether compensation is unilateral or bilateral. |           |
| Parameter     | kw.ssfk.bilateral   |           |
| Data type     | BOOLEAN   |           |
| Data range    | 0: Unilateral compensation<br>1: Bilateral compensation                 |           |
| Axis types    | T, R, S   |           |
| Dimension     | T: ----   | R,S: ---- |
| Default value | 0   |           |
| Remarks       |   |           |

| P-COMP-00022  | Compensation of a modulo axis  |           |
|---------------|--|-----------|
| Description   | This parameter defines the compensation table for a modulo axis. A modulo transition also takes place in the compensation table on the modulo transition of the axis position.<br><br>The number of compensation values must then be equal to the number of entries in the compensation value table. |           |
| Parameter     | kw.ssfk.modulo   |           |
| Data type     | BOOLEAN  |           |
| Data range    | 0: Compensation without modulo handling<br>1: Compensation for a modulo axis   |           |
| Axis types    | T, R, S  |           |
| Dimension     | T: ----  | R,S: ---- |
| Default value | 0  |           |
| Remarks       |  |           |

| P-COMP-00023  | Compensation value in positive direction  |                            |
|---------------|---|----------------------------|
| Description   | This parameter defines a compensation value in case of movement in positive direction at interpolation point 'i'. |                            |
| Parameter     | kw.ssfk.table[i].pos  |                            |
| Data type     | SGN32   |                            |
| Data range    | $\text{MIN(SGN32)} \leq pos < \text{MAX(SGN32)}$  |                            |
| Axis types    | T, R, S   |                            |
| Dimension     | T: 0.1 μm or increments   | R,S: 0.0001° or increments |
| Default value | 0   |                            |
| Remarks       |   |                            |

| P-COMP-00024 | Compensation value in negative direction  |  |
|--------------|---|--|
| Description  | This parameter defines a compensation value in case of movement in negative direction at interpolation point 'i'. |  |
| Parameter    | kw.ssfk.table[i].neg  |  |
| Data type    | SGN32   |  |
| Data range   | $\text{MIN(SGN32)} \leq neg < \text{MAX(SGN32)}$  |  |
| Axis types   | T, R, S   |  |

|               |                         |                            |
|---------------|-------------------------|----------------------------|
| Dimension     | T: 0.1 µm or increments | R,S: 0.0001° or increments |
| Default value | 0                       |                            |
| Remarks       |                         |                            |

| <b>P-COMP-00025</b> <b>Interpolation points of the axis</b> |  |                            |
|---|--|----------------------------|
| Description   | This parameter determines the interpolation points of the axis for which the axis must be corrected. |                            |
| Parameter   | kw.ssfk.table[i].setpoint  |                            |
| Data type   | SGN64  |                            |
| Data range  | MIN(SGN64) ≤ setpoint < MAX(SGN64)   |                            |
| Axis types  | T, R, S  |                            |
| Dimension   | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value   | 0  |                            |
| Remarks   | In CNC Builds V2.11.20xx and higher, the data type is SGN32 and so is the related data range.        |                            |

| <b>P-COMP-00028</b> <b>Manual activation</b> |  |           |
|--|--|-----------|
| Description                                  | Leadscrew error compensation is automatically activated by the CNC if it selected in the axis parameters (P-AXIS-00175) and the required conditions are met (e.g. axis is homed).<br><br>If the parameter is set to value 1, leadscrew error compensation must be explicitly activated by an NC command (see [PROG/Selecting/deselecting axis compensations in the NC program]). In addition, compensation is deselected at the end of the NC program, at CNC reset and on axis release. |           |
| Parameter                                    | kw.ssfk.manual_activation  |           |
| Data type                                    | BOOLEAN  |           |
| Data range                                   | 0: Automatic activation<br>1: Manual activation in NC program  |           |
| Axis types                                   | T, R, S  |           |
| Dimension                                    | T: ----  | R,S: ---- |
| Default value                                | 0  |           |
| Remarks                                      |  |           |

| <b>P-COMP-00057</b> <b>Consideration of other axis compensations</b> |   |           |
|--|---|-----------|
| Description  | By default, leadscrew error compensation also considers the compensation values generated from other axis compensations, e.g. cross and plane compensation. With direction-dependent spindle leadscrew error compensation (see P-COMP-00021) this may result in the undesirable occurrence of backlash under certain circumstances.<br><br>The parameter <b>set_pos_without_comp</b> can disable the inclusion of other compensation values in the calculation. |           |
| Parameter  | kw.ssfk.set_pos_without_comp  |           |
| Data type  | BOOLEAN   |           |
| Data range   | 0: Compensation values of other compensations are considered in the leadscrew error compensation.<br>1: Compensation values of other compensations are not considered.  |           |
| Axis types   | T, R, S   |           |
| Dimension  | T: ----   | R,S: ---- |
| Default value  | 0   |           |
| Remarks  |   |           |

### 4.2.1.3 CNC objects

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | ssfk activated   |                     |                          |
| <b>Description</b> | This object reads whether leadscrew error compensation (LSEC) is activated via <a href="#">P-Axis-00175 [▶ 33]</a> . |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >0038 |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | LSEC::active   |                     |                          |
| <b>Description</b> | This object reads whether leadscrew error compensation is active.<br>This means that all preconditions must be met, such as the axis is homed and all necessary enables are on.<br>(leadscrew error compensation - LSEC) |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >00D0 |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | LSEC::epsilon   |                     |                          |
| <b>Description</b> | This object reads the change in compensation value of leadscrew error compensation in the current cycle.<br>(leadscrew error compensation - LSEC) |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >001C |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | LSEC::sum epsilon   |                     |                          |
| <b>Description</b> | This object reads the leadscrew error compensation of the current compensation value, i.e. the sum of all compensation values.<br>(leadscrew error compensation - LSEC) |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >001D |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

## 4.2.2 Example - Non-equidistant bilateral SSFK

The diagram below shows a compensation value table with the properties:

- Non-equidistant interpolation points (kw.ssfk.interval = 0)
- Bilateral compensation table (kw.ssfk.bilateral = 1)
- Position specifications in metric system (kw.ssfk.unit = 1)
- Compensation value table with 140 entries (kw.ssfk.kw\_nr\_max = 140). The index of the position and setpoint entries goes from 0 to 139.

The following values were measured at the third gauged position (table[3]):

| Programmed Position<br>$s_{soll,i}$ ith setpoint | pos measurement<br>value<br>$s_{ist,i}$ ith actual value<br>(pos direction) | neg measurement<br>value<br>$s_{ist,i}$ ith actual value<br>(neg direction) | computed<br>pos compensation<br>value<br>$\Delta s_i = s_{ist,i} - s_{soll,i}$ | Computed<br>neg compensation<br>value<br>$\Delta s_i = s_{ist,i} - s_{soll,i}$ |
|--|---|---|--|--|
| 19866.7 µm                                       | 19856.5 µm  | 19874.7 µm  | -102 x 0.1 µm  | 80 x 0.1 µm  |

### Non-equidistant bilateral SSFK

```

kopf.achs_nr          2
kopf.log_achs_name   Y AXIS
kw.ssfk.interval      0
kw.ssfk.kw_startpos   -200000
kw.ssfk.kw_nr_max     140
kw.ssfk.unit          1
kw.ssfk.bilateral     1
kw.ssfk.table[0].setpoint -200000
kw.ssfk.table[1].setpoint -199306
kw.ssfk.table[2].setpoint -198667
kw.ssfk.table[3].setpoint -198001
...
kw.ssfk.table[138].setpoint 334488
kw.ssfk.table[139].setpoint 335591
kw.ssfk.table[0].pos    0
kw.ssfk.table[1].pos    24
kw.ssfk.table[2].pos    -102
...
kw.ssfk.table[139].pos  -55
kw.ssfk.table[0].neg    0
kw.ssfk.table[1].neg    67
kw.ssfk.table[2].neg    80
...
kw.ssfk.table[139].neg  114

```

## 4.2.3 Error messages

Errors in the configuration of leadscrew error compensation result in deactivation of the function for the affected axis and to the output of an error message (warning message).

The following error messages then appear:

- ID 110217
- ID 110218
- ID 110392
- ID 110474
- ID 110476
- ID 110477
- ID 110478
- ID 110479
- ID 110480
- ID 110590
- ID 110638

## 4.3 Cross compensation

Cross compensation permits the compensation of rectangularity errors or errors that arise due to deflection of the axis.

### Compensation process

Cross compensation (also called sag compensation) permits the compensation of an axis position depending on the command position of another axis.

The axis whose command positions influences the compensation value is called the master axis. The axis for which compensation is active is called the slave axis.

A master axis can also be the slave axis of another master axis.



Cross compensation data is specified in the compensation value list of the **slave axis**.




Fig. 10: Application example for cross compensation (Y: Master, Z: Slave).

## Properties

- A master axis has one or several slave axes.
- A slave has only one master axis.
- Cross compensation can also be used for the master and slave axes of a gantry combination.
- A compensation value can be specified for each interpolation point.
- Interpolation between interpolation points is linear.
- Cross compensation is available for all drive types.
- Compensations can only be viewed in the positions directly output to the drive (not in the normal display data) since compensation takes place outside normal calculations.
- As of CNC Build V3.1.3079.06 you can adjust the size of the compensation table. The parameter P-COMP-00060 [▶ 44] defines the maximum number of table entries. The actual number of entries used by P-COMP-00004 [▶ 44]

## Effectiveness

Cross compensation is only effective if all the following conditions are fulfilled:

- The function was activated for the slave axis.
- The compensation value table was provided.
- Master and slave axes are linear axes. As of CNC Build v263.1504, cross compensation can also be used for rotary axes or spindles.
- The master axis was referenced. Therefore there is no need to reference the slave axis.

## 4.3.1 Parameter

### 4.3.1.1 Overview

#### Activation

Cross compensation is activated in the axis machine data record of the slave axis by P-AXIS-00047:

| Variable name      | Type    | Meaning  |
|--------------------|---------|--|
| lr_param.crosscomp | BOOLEAN | 0: no cross compensation<br>1: Cross compensation active |

Excerpt from the axis parameter list:

```
:  
lr_param.crosscomp      1  
:
```



Cross compensation can also be used for a gantry axis group. A compensation value table must then be specified for each individual axis in the gantry combination (cross compensation slave).

Compensation value tables can therefore have different settings for each gantry axis.

#### Activating/deactivating

Cross compensation (ON if master axis is referenced and compensation is activated) can be switched on or off at any time when the slave axis is at standstill. The slave axis command positions displayed are offset with the offset values.

#### Filter:

When the master axis is referenced, inconsistencies may occur when compensation values are calculated for a moved slave axis. These inconsistencies can be smoothed by using a  $\sin^2$  filter. The parameter P-COMP-00026 (n\_cycles) switches the filter order to activate it.

## Management data of the cross compensation table

General data of the list body is entered in the structure **kw.crosscomp..\***. It contains the following elements.

### Management data elements

| Variable name     | Type    | Meaning  |
|-------------------|---------|--|
| unit              | BOOLEAN | Unit of the length entries:<br>0: Encoder increments<br>1: metric (in 0.1 µm)  |
| last_index        | SGN32   | Last valid index in the slave axis table.<br><br>As of CNC Build V3.1.3079.06 the maximum possible of table entries can be defined in <a href="#">P-COMP-00060 [▶ 44]</a> . In previous Builds the default value is 1000.<br><br>The table always starts with index 0  |
| master_ax_nr      | UNS16   | Axis number of the master axis; its command position acts as the input variable of the compensation table.   |
| n_cycles          | UNS16   | Number of cycles of $\sin^2$ filter.   |
| manual_activation | BOOLEAN | 0: (Default) The CNC activates cross compensation automatically as soon as the required conditions are met (e.g. the master axis is referenced).<br><br>1: Cross compensation must be activated explicitly in the NC program by the COMP command (see section <a href="#">"Selecting/deselecting axis compensations in the NC program") [▶ 71]</a> . Compensation is deactivated at the end of the NC program, when the CNC is reset or when the axis is released. |

### Compensation values for cross compensation

The corresponding compensation value of the slave axis is entered in the table **kw.crosscomp.table[i].\*** for every interpolation point. The compensation table is valid for positive and negative directions of motion.

### Compensation value table

| Variable name          | Type  | Meaning  |
|------------------------|-------|--|
| table[i].setpoint      | SGN32 | Interpolation point of master axis for which the slave axis must be compensated. |
| table[j][i].correction | SGN32 | Relative compensation value for the slave axis at interpolation point i          |

### Special feature for rotary master axis

As of CNC Build v263.1504, cross compensation can also be used for rotary axes or spindles. A modulo calculation of the axis position is carried out in the position controller for these axis types.

If a cross compensation master axis is a modulo axis, a "modulo transition" also takes place in the compensation table in the modulo transition of the axis position of this master axis. To prevent a jump from occurring at this point of the compensation value process of the slave axis, the same compensation value must be specified in the compensation table at the modulo transition.

### 4.3.1.2 Description

| P-AXIS-00047 | Activation of cross compensation                 |
|--------------|--|
| Description  | This parameter activates the cross compensation. |
| Parameter    | lr_param.crosscomp                               |
| Data type    | BOOLEAN  |

|               |         |  |
|---------------|---------|--|
| Data range    | 0/1     |  |
| Axis types    | T       |  |
| Dimension     | T: ---- |  |
| Default value | 0       |  |
| Drive types   | ----    |  |
| Remarks       |         |  |

| <b>P-COMP-00060 Maximum number of table entries for cross compensation</b> |   |           |
|--|---|-----------|
| Description  | <p>This cross compensation parameter (<a href="#">FCT-C5 [▶ 40]</a>) saves the memory space required for a particular number of table entries.</p> <p>The size of the actually used compensation table is defined by `last_index` (P-COMP-00004) and `last_index` must be smaller than `max_points`.</p>  |           |
| Parameter  | kw.crosscomp.max_points   |           |
| Data type  | UNS32   |           |
| Data range   | 0 <= P-COMP-00060   |           |
| Axis types   | T, R, S   |           |
| Dimension  | T: ----   | R,S: ---- |
| Default value  | 1001  |           |
| Remarks  | <p>The parameter value can no longer be changed after start-up or after lists are reloaded. Otherwise error ID 110639 is output.</p> <p>If P-COMP-00060 is not specified (or assigned the value 0), the default value is assigned to P-COMP-00060 for downward compatibility reasons.</p> <p>To avoid the default assignment, memory can be saved for an axis that does not use <a href="#">cross compensation [▶ 40]</a> by assigning the value 1 to P-COMP-00060.</p> <p>This parameter is available as of CNC Build V3.3079.06</p> |           |

| <b>P-COMP-00003 Unit of the length entries</b> |  |           |
|--|--|-----------|
| Description                                    | The parameter defines the unit to be used for the length entries of compensation values. |           |
| Parameter                                      | kw.crosscomp.unit  |           |
| Data type                                      | BOOLEAN  |           |
| Data range                                     | 0: Encoder increments<br>1: Metric (in 0.1 μm)   |           |
| Axis types                                     | T, R, S  |           |
| Dimension                                      | T: ----  | R,S: ---- |
| Default value                                  | 0  |           |
| Remarks  |  |           |

| <b>P-COMP-00004 Last index of compensation value table</b> |  |           |
|--|--|-----------|
| Description  | This parameter determines the last valid index in the table of the master axis. The table always starts with index 0 |           |
| Parameter  | kw.crosscomp.last_index  |           |
| Data type  | SGN32  |           |
| Data range   | 0 ≤ last_index < P-COMP-00060 [ <a href="#">▶ 44</a> ]   |           |
| Axis types   | T, R, S  |           |
| Dimension  | T: ----  | R,S: ---- |
| Default value  | 0  |           |

|         |  |
|---------|--|
| Remarks | P-COMP-00060 [▶ 44] is available as of Build V3.1.3079.06. The upper limit in previous CNC versions is 1000. |
|---------|--|

| <b>P-COMP-00005 Logical axis number of the master axis</b> |   |           |
|--|---|-----------|
| Description  | This parameter determines the logical number of the master axis whose command position is used to calculate the input variable of the compensation value table of the slave axis. |           |
| Parameter  | kw.crosscomp.master_ax_nr   |           |
| Data type  | UNS16   |           |
| Data range   | 1 ≤ master_ax_nr ≤ MAX (UNS16)  |           |
| Axis types   | T, R, S   |           |
| Dimension  | T: ----   | R,S: ---- |
| Default value  | 0   |           |
| Remarks  |   |           |

| <b>P-COMP-00026 Number of cycles for 'smooth switching'</b> |  |           |
|---|--|-----------|
| Description   | This parameter determines the number of cycles for which cross compensation is activated/deactivated smoothly.           |           |
| Parameter   | kw.crosscomp.n_cycles  |           |
| Data type   | UNS16  |           |
| Data range  | 0 ≤ n_cycles ≤ 20 (maximum number of cycles for which cross compensation is activated/deactivated, application-specific) |           |
| Axis types  | T, R, S  |           |
| Dimension   | T: ----  | R,S: ---- |
| Default value   | 0  |           |
| Remarks   |  |           |

| <b>P-COMP-00029 Manual activation</b> |   |           |
|---------------------------------------|---|-----------|
| Description                           | Cross compensation is automatically activated by the CNC if it selected in the axis parameters (P-AXIS-00047) and the required conditions are met (e.g. axis is homed).<br>If the parameter is set to the value 1, cross compensation must be activated explicitly by an NC command (see [PROG//Selecting/deselecting axis compensations in the NC program]). In addition, compensation is deselected at the end of the NC program, at CNC reset and on axis release. |           |
| Parameter                             | kw.crosscomp.manual_activation  |           |
| Data type                             | BOOLEAN   |           |
| Data range                            | 0: Automatic activation<br>1: Manual activation in NC program   |           |
| Axis types                            | T, R, S   |           |
| Dimension                             | T: ----   | R,S: ---- |
| Default value                         | 0   |           |
| Remarks                               |   |           |

| <b>P-COMP-00006 Interpolation point of the master axis</b> |  |
|--|--|
| Description  | This parameter determines the interpolation points of the master axis on which the slave axis has to be corrected. |
| Parameter  | kw.crosscomp.table[i].setpoint   |
| Data type  | SGN32  |
| Data range   | MIN(SGN32) ≤ setpoint < MAX(SGN32)   |
| Axis types   | T, R, S  |

|               |                         |                            |
|---------------|-------------------------|----------------------------|
| Dimension     | T: 0.1 µm or increments | R,S: 0.0001° or increments |
| Default value | 0                       |                            |
| Remarks       |                         |                            |

| <b>P-COMP-00007 Compensation values for the slave axis</b> |  |                            |
|--|--|----------------------------|
| Description  | This parameter determines the relative compensation values for the slave axis at interpolation points 'i'. |                            |
| Parameter  | kw.crosscomp.table[i].correction   |                            |
| Data type  | SGN32  |                            |
| Data range   | MIN(SGN32) ≤ correction < MAX(SGN32)   |                            |
| Axis types   | T, R, S  |                            |
| Dimension  | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value  | 0  |                            |
| Remarks  |  |                            |

### 4.3.1.3 CNC objects

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::f_is_active  |                     |                          |
| <b>Description</b> | This object reads whether cross compensation is activated.<br>This means that all preconditions, such as axis is referenced and all necessary enables are on, must be fulfilled. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >004F |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::activated  |                     |                          |
| <b>Description</b> | This object reads whether cross compensation is activated via P-AXIS-00047 [▶ 43]. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >01D6 |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::actual_offset   |                     |                          |
| <b>Description</b> | This object reads the current effective offset of cross compensation. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0035 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::delta_offset  |                     |                          |
| <b>Description</b> | This object reads the change in compensation value in the current cross compensation cycle. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0034 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

### 4.3.2 Example of a compensation value list

#### Example of a compensation value list for cross compensation

```

# ****
# Axis compensation data for Z-axis
# ****

kopf.achs_nr           3
kopf.log_achs_name      Z
kw.crosscomp.last_index 99 /*Last valid index of the table*/
kw.crosscomp.master_ax_nr 1 /*Log. ax. number of the master axis*/
kw.crosscomp.unit         1 /*0:Incr. 1:Metric in 0.1 µm*/
kw.crosscomp.n_cycles    20
#
kw.crosscomp.table[0].setpoint 10735
kw.crosscomp.table[0].correction 3

```

```
kw.crosscomp.table[1].setpoint      11523
kw.crosscomp.table[1].correction    5
:
:
kw.crosscomp.table[99].setpoint     10000000 /*at 1000 mm of axis 3*/
kw.crosscomp.table[99].correction   1000    /*corr. of 0.1 mm for axis 1*/
```

### 4.3.3 Error messages

Errors in the configuration of the cross compensation result in deactivation of the function for the affected axis and to the output of an error message (warning message).

The following error messages then appear:

- ID 110639
- ID 70242
- ID 70244
- ID 70245
- ID 70246
- ID 70247
- ID 70248
- ID 70249
- ID 70250
- ID 70432

## 4.4 Plane compensation

With plane compensation, axis misalignments can be compensated for as a function of the position of two master axes. One application case, for example, is the compensation of the Z axis depending on X and Y.

### Compensation process

Plane compensation allows the compensation of an axis position depending on the command positions of two axes.

The two axes whose command positions influence the compensation value are called master axes. The axis for which compensation is active is called the slave axis.

One of the master axes can also be a slave axis itself.



Cross compensation data is specified in the compensation value list of the **slave axis**.




Fig. 11: Schematic of the compensation value calculation for plane compensation

### Properties

- The two master axes form a 2-axis coordinate system; in the simplest case it is the X-Y plane (master axis 1 = X axis, master axis 2 = Y axis).
- This coordinate system is divided into squares or rectangles like a chessboard.
- The edge length of the squares or the edge lengths of the rectangles can be parameterised.
- The corners of the squares or rectangles form the interpolation points of the table (see figure below).
- A compensation value can be specified for each interpolation point.
- Interpolation between interpolation points is linear (see 2nd figure below).
- Outside the table, the compensation values at the edge of the table remain effective.
- As of CNC Build V3.1.3079.06 you can adjust the size of the compensation table. The maximum number of table entries can be set by [P-COMP-00061](#) [▶ 56] and The actual number of entries used is specified by [P-COMP-00010](#) [▶ 57] and [P-COMP-00011](#) [▶ 57].




Fig. 12: Specify compensation values at the interpolation points




Fig. 13: Linear interpolation between the 4 interpolation points of a square

#### Effectiveness

- Plane compensation is only effective if all the following conditions are fulfilled:
- The function was activated for the slave axis.
- The compensation value table was provided.
- Master and slave axes are linear axes. As of CNC Build v263.1504, plane compensation can also be used for rotary axes or spindles.
- Master axes have an absolute measuring system or were referenced.

## 4.4.1 Parameter

### 4.4.1.1 Overview

#### Activation

Plane compensation is activated in the axis machine record of the slave axis by P-AXIS-00174:

| Variable name       | Type    | Meaning  |
|---------------------|---------|--|
| lr_param.crosscomp2 | BOOLEAN | 0: no plane compensation<br>1: Plane compensation active |

#### Excerpt from the axis parameter list:

```
:  
lr_param.crosscomp2      1  
:
```

#### Activating/deactivating

Plane compensation (ON if master axes are referenced and compensation is activated) can be switched on or off at any time when the slave axis is at standstill. The slave axis command positions displayed are offset with the offset values.

#### Filter:

When master axes are referenced, inconsistencies may occur when compensation values are calculated for a moved slave axis. These inconsistencies can be smoothed by using a  $\sin^2$  filter. The parameter P-COMP-00027 [▶ 59] (n\_cycles) switches the filter order to activate it.

#### Special feature for rotary master axes

As of CNC Build v263.1504, plane compensation can also be used for rotary axes or spindles. A modulo calculation of the axis position is carried out in the position controller for these axis types.

If a plane compensation master axis is a modulo axis, a "modulo transition" also takes place in the compensation table in the modulo transition of the axis position of this master axis. To prevent a jump from occurring at this point of the compensation value process of the slave axis, the same compensation value must be specified in the compensation table at the modulo transition.

## Management data of the plane compensation table

The general data of the list body parameterise the axes involved, the limits of the compensation range, etc. General data is entered in the structure **kw.crosscomp2.\***. It contains the following elements.

### Management data elements

| Variable name          | Type    | Meaning   |
|------------------------|---------|---|
| unit                   | BOOLEAN | Unit of the length entries:<br>0: Encoder increments<br>1: metric (in 0.1 µm)   |
| grid                   | STRING  | Type of interpolation point sample grid:<br>QUADRATIC: Identical grid structure, interval for both master axes<br>RECTANGULAR: Different grid structure, interval1 and interval2 for both master axes   |
| interval               | UNS32   | Interval between 2 interpolation points in 0.1 µm for the two master axes (grid = QUADRATIC)  |
| interval1              | UNS32   | Interval of the first master axis between 2 interpolation points in 0.1 µm<br>(grid = RECTANGULAR)  |
| interval2              | UNS32   | Interval of 2nd master axis between 2 interpolation points in 0.1 µm<br>(grid = RECTANGULAR)  |
| last_index_master1     | SGN32   | Last valid index in the table for master axis 1 (see <a href="#">Limits of compensation table [▶ 54]</a> ).<br>The table always starts with index 0   |
| last_index_master2     | SGN32   | Last valid index in the table for master axis 2 (see <a href="#">Limits of compensation table [▶ 54]</a> ).<br>The table always starts with index 0   |
| start_position_master1 | SGN32   | Position of master axis 1 at which the compensation table starts  |
| start_position_master2 | SGN32   | Position of master axis 2 at which the compensation table starts  |
| master1_ax_nr          | UNS16   | Log. axis number of master axis 1   |
| master2_ax_nr          | UNS16   | Log. axis number of master axis 2   |
| n_cycles               | UNS16   | Number of cycles of sin <sup>2</sup> filter.  |
| manual_activation      | BOOLEAN | 0: Default: The CNC activates plane compensation automatically as soon as the required conditions are met (e.g. the master axes are referenced)<br>1: Plane compensation must be activated explicitly in the NC program by the COMP command (see section <a href="#">“Selecting/deselecting axis compensations in the NC program [▶ 71]”</a> ). Compensation is deactivated at the end of the NC program, when the CNC is reset or when the axis is released. |

### Limits of compensation table

As of CNC Build V3.1.3079.06 the maximum possible of table entries can be defined in [P-COMP-00061 \[▶ 56\]](#). In previous builds, the entries “last\_index\_master1” ([P-COMP-00010 \[▶ 57\]](#)) and “last\_index\_master2” ([P-COMP-00011 \[▶ 57\]](#)) are limited to 100 entries.

This rigid limitation non longer applies. Note only that:

$$\text{P-COMP-00010 [▶ 57]} \times \text{P-COMP-00011 [▶ 57]} \leq \text{P-COMP-00061 [▶ 56]}$$

## Compensation values of plane compensation

The corresponding compensation value of the slave axis is entered in the table `kw.crosscomp2.table[j][i].*` for every interpolation point.

### Compensation value table

| Variable name                       | Type  | Meaning   |
|-------------------------------------|-------|---|
| <code>table[j][i].correction</code> | SGN32 | Compensation value of slave axis at interpolation point [j][i], see figure below. |




When interpolation points are indexed in the compensation value table, the **1.** index j always refers to the **2.** master axis (see figure below).

Index j -> master axis 2

Index i -> master axis 1



Unassigned interpolation points are assigned the value 0 in the compensation value table. This value is also used in the calculation.



|   |         |
|---|---------|
| <code>kw.crosscomp2.interval</code>               | 100000  |
| <code>kw.crosscomp2.last_index_master1</code>     | 7       |
| <code>kw.crosscomp2.last_index_master2</code>     | 6       |
| <code>kw.crosscomp2.start_position_master1</code> | 220000  |
| <code>kw.crosscomp2.start_position_master2</code> | -160000 |
| <code>kw.crosscomp2.unit</code>                   | 1       |
| <code>kw.crosscomp2.master1_ax_nr</code>          | 1       |
| <code>kw.crosscomp2.master2_ax_nr</code>          | 2       |
| <br>  |         |
| <code>kw.crosscomp2.table[0][0].correction</code> | 0       |
| <br>  |         |
| <code>kw.crosscomp2.table[6][7].correction</code> | 324     |

Fig. 14: Compensation value list parameters

#### 4.4.1.2 Description

| P-AXIS-00174  | Activation of plane compensation  |  |
|---------------|---|--|
| Description   | This parameter activates the plane compensation (2-dimensional cross compensation). |  |
| Parameter     | lr_param.crosscomp2   |  |
| Data type     | BOOLEAN   |  |
| Data range    | 0/1   |  |
| Axis types    | T   |  |
| Dimension     | T: ----   |  |
| Default value | 0   |  |
| Drive types   | ----  |  |
| Remarks       |   |  |

| P-COMP-00061  | Maximum number of table entries for plane compensation   |           |
|---------------|--|-----------|
| Description   | <p>This plane compensation parameter (FCT-C5 [► 50]) saves the memory space required for a particular number of table entries.</p> <p>The size of the actually used compensation table is defined by `last_index:master1` (P-COMP-00010) and `last_index_master2` (P-COMP-00011) and the following must apply:</p> $(\text{`last\_index\_master1`} + 1) * (\text{`last\_index\_master2`} + 1) \leq \text{'max\_points'}$ <p>If `max_points` is not specified (or assigned the value 0), the previous restrictions apply to `last_index_master1` and `last_index_master2`.</p> <ul style="list-style-type: none"> <li>• <math>0 \leq \text{`last\_index\_master1`} \leq 100</math></li> <li>• <math>0 \leq \text{`last\_index\_master2`} \leq 100</math></li> </ul> |           |
| Parameter     | kw.crosscomp2.max_points   |           |
| Data type     | UNS32  |           |
| Data range    | 0 <= P-COMP-00061  |           |
| Axis types    | T, R, S  |           |
| Dimension     | T: ----  | R,S: ---- |
| Default value | 10201 (*)  |           |
| Remarks       | <p>The parameter value can no longer be changed after start-up or after lists are reloaded. Otherwise error ID 110640 is output.</p> <p>If P-COMP-00061 is not specified (or assigned the value 0), the default value is assigned to P-COMP-00061 for downward compatibility reasons.</p> <p>To avoid the default assignment, memory can be saved for an axis that does not use <u>plane compensation</u> [► 50] by assigning the value 1 to P-COMP-00061.</p> <p>* composition of the default value: <math>101 * 101 = 10201</math></p> <p>This parameter is available as of CNC Build V3.3079.06</p>   |           |

| P-COMP-00008 | Unit of the length entries  |  |
|--------------|---|--|
| Description  | This parameter defines the unit of the length / position entries. |  |
| Parameter    | kw.crosscomp2.unit  |  |
| Data type    | BOOLEAN   |  |

|               |  |           |
|---------------|--|-----------|
| Data range    | 0: Encoder increments<br>1: Metric (in 0.1 µm) |           |
| Axis types    | T, R, S  |           |
| Dimension     | T: ----  | R,S: ---- |
| Default value | 0  |           |
| Remarks       |  |           |

| <b>P-COMP-00009 Distance between interpolation points</b> |  |                            |
|---|--|----------------------------|
| Description   | This parameter defines the distance between two interpolation points if both axes use an identical grid (P-COMP-000031(grid) = QUADRATIC). |                            |
| Parameter   | kw.crosscomp2.interval   |                            |
| Data type   | UNS32  |                            |
| Data range  | 0 < interval < MAX(UNS32)  |                            |
| Axis types  | T, R, S  |                            |
| Dimension   | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value   | 0  |                            |
| Remarks   |  |                            |

| <b>P-COMP-00010 Last index of master axis 1</b> |  |           |
|---|--|-----------|
| Description                                     | This parameter determines the last valid index in the table of master axis 1 (maximum value is 100). The table always starts with index 0.   |           |
| Parameter                                       | kw.crosscomp2.last_index_master1   |           |
| Data type                                       | SGN32  |           |
| Data range                                      | 0 ≤ P-COMP-00010 <= 100  |           |
| Axis types                                      | T, R, S  |           |
| Dimension                                       | T: ----  | R,S: ---- |
| Default value                                   | 0  |           |
| Remarks   | <p>As of Build V3.1.3079.06, P-COMP-00010 is freely assignable. There is no upper limit. However, the condition of P-COMP-00061 [▶ 56] must be complied with.</p> <p>P-COMP-00010 * P-COMP-00011 [▶ 57] &lt;= P-COMP-00061 [▶ 56]</p> <p><b>Attention:</b></p> <p>If this parameter is re-interpreted, all the values in the compensation value table (P-COMP-00016 [▶ 58]) must be read in again.</p> |           |

| <b>P-COMP-00011 Last index of master axis 2</b> |  |           |
|---|--|-----------|
| Description                                     | This parameter determines the last valid index in the table of the two master axes (maximum 100 values). The table always starts with index 0.   |           |
| Parameter                                       | kw.crosscomp2.last_index_master2   |           |
| Data type                                       | SGN32  |           |
| Data range                                      | 0 ≤ P-COMP-00011 <= 100  |           |
| Axis types                                      | T, R, S  |           |
| Dimension                                       | T: ----  | R,S: ---- |
| Default value                                   | 0  |           |
| Remarks   | <p>As of Build V3.1.3079.06, P-COMP-00011 is freely assignable. There is no upper limit. However, the condition of P-COMP-00061 [▶ 56] must be complied with.</p> <p>P-COMP-00010 [▶ 57] * P-COMP-00011 &lt;= P-COMP-00061 [▶ 56]</p> <p><b>Attention:</b></p> <p>If this parameter is re-interpreted, all the values in the compensation value table (P-COMP-00016 [▶ 58]) must be read in again.</p> |           |

| <b>P-COMP-00012 Start position of master axis 1</b> |  |                            |
|---|--|----------------------------|
| Description   | This parameter determines the start position of master axis 1 in the compensation table. |                            |
| Parameter   | kw.crosscomp2.start_position_master1   |                            |
| Data type   | SGN32  |                            |
| Data range  | MIN(SGN32) ≤ start_position_master1 < MAX(SGN32)   |                            |
| Axis types  | T, R, S  |                            |
| Dimension   | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value                                       | 0  |                            |
| Remarks   |  |                            |

| <b>P-COMP-00013 Start position of master axis 2</b> |  |                            |
|---|--|----------------------------|
| Description   | This parameter determines the start position of master axis 2 in the compensation table. |                            |
| Parameter   | kw.crosscomp2.start_position_master2   |                            |
| Data type   | SGN32  |                            |
| Data range  | MIN(SGN32) ≤ start_position_master2 < MAX(SGN32)   |                            |
| Axis types  | T, R, S  |                            |
| Dimension   | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value                                       | 0  |                            |
| Remarks   |  |                            |

| <b>P-COMP-00014 Logical axis number of the master axis 1</b> |  |           |
|--|--|-----------|
| Description  | This parameter defines the logical axis number of the first master axis. |           |
| Parameter  | kw.crosscomp2.master1_ax_nr  |           |
| Data type  | UNS16  |           |
| Data range   | 1 ≤ master1_ax_nr ≤ MAX(UNS16)   |           |
| Axis types   | T, R, S  |           |
| Dimension  | T: ----  | R,S: ---- |
| Default value  | 0  |           |
| Remarks  |  |           |

| <b>P-COMP-00015 Logical axis number of the master axis 2</b> |   |           |
|--|---|-----------|
| Description  | This parameter defines the logical axis number of the second master axis. |           |
| Parameter  | kw.crosscomp2.master2_ax_nr   |           |
| Data type  | UNS16   |           |
| Data range   | 1 ≤ master2_ax_nr ≤ MAX(UNS16)  |           |
| Axis types   | T, R, S   |           |
| Dimension  | T: ----   | R,S: ---- |
| Default value  | 0   |           |
| Remarks  |   |           |

| <b>P-COMP-00016 Compensation values for the slave axis</b> |   |
|--|---|
| Description  | This parameter defines the relative compensation values of the slave axis at interpolation points $[j][i]$ . When indexing the interpolation points in the compensation list, the first index j refers to the second master axis. |
| Parameter  | kw.crosscomp2.table[j][i].correction  |
| Data type  | SGN32   |
| Data range   | MIN(SGN32) ≤ correction < MAX(SGN32)  |
| Axis types   | T, R, S   |

|               |                         |                            |
|---------------|-------------------------|----------------------------|
| Dimension     | T: 0.1 µm or increments | R,S: 0.0001° or increments |
| Default value | 0                       |                            |
| Remarks       |                         |                            |

|                     |  |           |
|---------------------|--|-----------|
| <b>P-COMP-00027</b> | <b>Number of cycles for ‘smooth switching’</b>   |           |
| Description         | This parameter determines the number of cycles for which plane compensation is activated/deactivated smoothly.           |           |
| Parameter           | kw.crosscomp2.n_cycles   |           |
| Data type           | UNS16  |           |
| Data range          | 0 ≤ n_cycles ≤ 20 (maximum number of cycles for which cross compensation is activated/deactivated, application-specific) |           |
| Axis types          | T, R, S  |           |
| Dimension           | T: ----  | R,S: ---- |
| Default value       | 0  |           |
| Remarks             |  |           |

|                     |  |           |
|---------------------|--|-----------|
| <b>P-COMP-00030</b> | <b>Manual activation</b>   |           |
| Description         | Plane compensation is automatically activated by the CNC if it selected in the axis parameters (P-Axis-00174) and the required conditions are met (e.g. axis is homed).<br><br>If the parameter is set to value 1, plane compensation must be activated explicitly by an NC command (see [PROG//Selecting/deselecting axis compensations in the NC program]. In addition, compensation is deselected at the end of the NC program, at CNC reset and on axis release. |           |
| Parameter           | kw.crosscomp2.manual_activation  |           |
| Data type           | BOOLEAN  |           |
| Data range          | 0: Automatic activation<br>1: Manual activation in NC program  |           |
| Axis types          | T, R, S  |           |
| Dimension           | T: ----  | R,S: ---- |
| Default value       | 0  |           |
| Remarks             |  |           |

|                     |  |                            |
|---------------------|--|----------------------------|
| <b>P-COMP-00032</b> | <b>Distance between the interpolation points of the first master axis</b>  |                            |
| Description         | The parameter defines the interval between two interpolation points for the first master axis if both master axes use a different grid (P-COMP-00031(grid) = RECTANGULAR). |                            |
| Parameter           | kw.crosscomp2.interval1  |                            |
| Data type           | UNS32  |                            |
| Data range          | 0 < interval1 < MAX(UNS32)   |                            |
| Axis types          | T, R, S  |                            |
| Dimension           | T: 0.1 µm or increments  | R,S: 0.0001° or increments |
| Default value       | 0  |                            |
| Remarks             |  |                            |

|                     |  |  |
|---------------------|--|--|
| <b>P-COMP-00033</b> | <b>Distance between the interpolation points on the second master axis</b>   |  |
| Description         | The parameter defines the interval between two interpolation points for the first master axis if both master axes use a different grid (P-COMP-00031(grid) = RECTANGULAR). |  |
| Parameter           | kw.crosscomp2.interval2  |  |
| Data type           | UNS32  |  |

|               |                            |                            |  |
|---------------|----------------------------|----------------------------|--|
| Data range    | 0 < interval2 < MAX(UNS32) |                            |  |
| Axis types    | T, R, S                    |                            |  |
| Dimension     | T: 0.1 µm or increments    | R,S: 0.0001° or increments |  |
| Default value | 0                          |                            |  |
| Remarks       |                            |                            |  |

#### 4.4.1.3 CNC objects

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::f_is_active  |                     |                          |
| <b>Description</b> | This object reads whether cross compensation is activated.<br>This means that all preconditions, such as axis is referenced and all necessary enables are on, must be fulfilled. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >004F |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CROSSC::delta_offset  |                     |                          |
| <b>Description</b> | This object reads the change in compensation value in the current cross compensation cycle. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0034 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CC2::correction   |                     |                          |
| <b>Description</b> | This object reads the current effective offset of plane compensation. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >0052 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     |   |                     |                          |

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | CC2::activated   |                     |                          |
| <b>Description</b> | This object reads whether plane compensation is activated via <a href="#">P-AXIS-00174</a> [▶ 56]. |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >01D7 |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     |  |                     |                          |

## 4.4.2 Examples of compensation value lists

### Compensation value list for plane compensation

Available as of Build V3.1.3079.06

The parameterisation example below reserved a maximum number of table entries of 50000 entries. The actual number of entries used is defined by the product of "last\_index\_master1" and "last\_index\_master2".

```
# ****
# Axis compensation data X axis
# ****

kopf.achs_nr           1
kopf.log_achs_name      X

# Reserve maximum number of table entries
kw.crosscomp2.max_points      50000
kw.crosscomp2.last_index_master1 1000
kw.crosscomp2.last_index_master2 20

kw.crosscomp2.table[ 0][ 0].correction   -3
kw.crosscomp2.table[ 0][ 1].correction   -1

...
kw.crosscomp2.table[ 20][ 999].correction 58
kw.crosscomp2.table[ 20][1000].correction 49
```

### Compensation value list for plane compensation

```
# ****
# Axis compensation data X axis
# ****

kopf.achs_nr           1
kopf.log_achs_name      X
kw.crosscomp2.interval  100000 /* 10 mm */
kw.crosscomp2.last_index_master1 100
kw.crosscomp2.last_index_master2 200
kw.crosscomp2.start_position_master1 -400000 /* -40 mm */
kw.crosscomp2.start_position_master2 -700000 /* -70 mm */
kw.crosscomp2.unit        1 /* 0.1 my */
kw.crosscomp2.master1_ax_nr 2
kw.crosscomp2.master2_ax_nr 3
kw.crosscomp2.n_cycles   20

kw.crosscomp2.table[ 0][ 0].correction   -3
kw.crosscomp2.table[ 0][ 1].correction   -1
kw.crosscomp2.table[ 0][ 2].correction   4
kw.crosscomp2.table[ 0][ 3].correction   9
kw.crosscomp2.table[ 0][ 4].correction   13
kw.crosscomp2.table[ 0][ 5].correction   17
kw.crosscomp2.table[ 0][ 6].correction   42
kw.crosscomp2.table[ 0][ 7].correction   53
kw.crosscomp2.table[ 0][ 8].correction   33
kw.crosscomp2.table[ 0][ 9].correction   42
kw.crosscomp2.table[ 0][ 10].correction  19
kw.crosscomp2.table[ 0][ 11].correction  7
kw.crosscomp2.table[ 0][ 12].correction  2
kw.crosscomp2.table[ 0][ 13].correction  0
kw.crosscomp2.table[ 0][ 14].correction  5
kw.crosscomp2.table[ 0][ 15].correction  -3
kw.crosscomp2.table[ 0][ 16].correction  -7
kw.crosscomp2.table[ 0][ 17].correction  -11
kw.crosscomp2.table[ 0][ 18].correction  -13
kw.crosscomp2.table[ 0][ 19].correction  -22
kw.crosscomp2.table[ 0][ 20].correction  -34
kw.crosscomp2.table[ 0][ 21].correction  -29
kw.crosscomp2.table[ 0][ 22].correction  -99
...
kw.crosscomp2.table[200][ 71].correction  45
kw.crosscomp2.table[200][ 72].correction  68
kw.crosscomp2.table[200][ 73].correction  71
kw.crosscomp2.table[200][ 74].correction  90
kw.crosscomp2.table[200][ 75].correction  111
kw.crosscomp2.table[200][ 76].correction  123
kw.crosscomp2.table[200][ 77].correction  134
```

```
kw.crosscomp2.table[200][ 78].correction      147
kw.crosscomp2.table[200][ 79].correction      156
kw.crosscomp2.table[200][ 80].correction      176
kw.crosscomp2.table[200][ 81].correction      167
kw.crosscomp2.table[200][ 82].correction      148
kw.crosscomp2.table[200][ 83].correction      132
kw.crosscomp2.table[200][ 84].correction      123
kw.crosscomp2.table[200][ 85].correction      111
kw.crosscomp2.table[200][ 86].correction      101
kw.crosscomp2.table[200][ 87].correction      97
kw.crosscomp2.table[200][ 88].correction      88
kw.crosscomp2.table[200][ 89].correction      83
kw.crosscomp2.table[200][ 90].correction      82
kw.crosscomp2.table[200][ 91].correction      77
kw.crosscomp2.table[200][ 92].correction      68
kw.crosscomp2.table[200][ 93].correction      63
kw.crosscomp2.table[200][ 94].correction      61
kw.crosscomp2.table[200][ 95].correction      59
kw.crosscomp2.table[200][ 96].correction      57
kw.crosscomp2.table[200][ 97].correction      52
kw.crosscomp2.table[200][ 98].correction      56
kw.crosscomp2.table[200][ 99].correction      58
kw.crosscomp2.table[200][100].correction      49
#
End
```

#### 4.4.3 Error messages

Errors in the configuration of the plane compensation result in deactivation of the function for the affected axis and to the output of an error message (warning message).

The following error messages then appear:

- ID 110640
- ID 70182
- ID 70183
- ID 70184
- ID 70185

## 4.5 Crosstalk compensation

Crosstalk compensation is used to compensate for position errors caused by an acceleration in another axis.

### Compensation process

Crosstalk compensation is used to compensate an axis position depending on the acceleration of another axis.

The axis whose acceleration affects the compensation value is called the master axis. The axis for which compensation is active is called the slave axis.

A master axis can also be the slave axis of another master axis.



**The data for crosstalk compensation is specified in the compensation value list of the slave axis.**




Fig. 15: Overview of crosstalk compensation

## Properties

- A master axis has one or several slave axes.
- A slave has only one master axis.
- Crosstalk compensation can also be used for the master and slave axes of a gantry combination.
- A compensation value can be specified for each acceleration.
- Interpolation between accelerations is linear.
- Crosstalk compensation is available for all drive types.
- Compensations can only be viewed in the accelerations directly output to the drive (not in the normal display data) since compensation takes place outside normal calculations.

## Effectiveness

Crosstalk compensation is only effective if all the following conditions are fulfilled:

- The function was activated for the slave axis.
- The compensation value table was provided.
- Master and slave axes include linear axes, rotary axes or spindles.

### 4.5.1 Overview

#### Activation

Crosstalk compensation is activated in the axis machine data record of the slave axis by [P-AXIS-00789](#) [▶ 67] (lr\_param.crosstalk)

#### Excerpt from the axis parameter list:

```
:  
lr_param.crosstalk      1  
:
```



**Crosstalk compensation can also be used for a gantry axis group. A compensation value table must then be specified for each axis in the gantry combination (crosstalk compensation slave).**

**Compensation value tables can therefore have different settings for each gantry axis.**

#### Activating/deactivating

Crosstalk compensation (ON if compensation is activated) can be switched on or off at any time when the slave axis is at standstill. The slave axis command positions displayed are offset with the offset values.

#### Filter:

These compensation values can be smoothed by using a sine-square filter. The parameter [P-COMP-00064](#) [▶ 68] selects the filter order and its activation.(n\_cycles).

#### Management data of the crosstalk compensation table

General data of the list body is entered in the structure kw.crosstalk.\* It contains the following elements.

#### Management data elements

| Variable name | Type  | Meaning                                   |
|---------------|-------|---|
| last_index    | SGN32 | Last valid index in the slave axis table. |

|                   |         |  |
|-------------------|---------|--|
| master_ax_nr      | UNS16   | Logical axis number of the master axis whose acceleration is used as the input variable of the compensation table. |
| n_cycles          | UNS16   | Number of cycles of the sine-square filter.  |
| manual_activation | BOOLEAN | 0: (Default) The CNC activates crosstalk compensation automatically as soon as the required preconditions are met. |

### Compensation values of crosstalk compensation

The corresponding compensation value of the slave axis is entered in the table **kw.crosstalk.table[i].\*** for every acceleration. The compensation table is valid for positive and negative directions of acceleration.

### Compensation value table

| Variable name          | Type  | Meaning   |
|------------------------|-------|---|
| table[i].acceleration  | SGN32 | Acceleration of the master axis for which the slave axis must be compensated. |
| table[j][i].correction | SGN32 | Compensation value for the slave axis with acceleration i                     |

## 4.5.2 Parameterisation

### 4.5.2.1 Overview

| ID           | Parameter          | Description                     |
|--------------|--------------------|---------------------------------|
| P-AXIS-00789 | lr_param.crosstalk | Activate crosstalk compensation |

| ID           | Parameter                          | Description                                     |
|--------------|------------------------------------|---|
| P-COMP-00063 | kw.crosstalk.master_ax_nr          | Logical axis number of the master axis          |
| P-COMP-00064 | kw.crosstalk.n_cycles              | Number of cycles for 'smooth switching'         |
| P-COMP-00065 | kw.crosstalk.last_index            | Last index of compensation value table          |
| P-COMP-00066 | kw.crosstalk.table[i].acceleration | Accelerations of the master axis                |
| P-COMP-00067 | kw.crosstalk.table[i].correction   | Compensation values for the slave axis          |
| P-COMP-00073 | kw.crosstalk.manual_activation     | Manual activation of the crosstalk compensation |

### 4.5.2.2 Description

#### Axis parameters

|                     |   |
|---------------------|---|
| <b>P-AXIS-00789</b> | <b>Activate crosstalk compensation</b>                        |
| Description         | This parameter activates the crosstalk compensation function. |
| Parameter           | lr_param.crosstalk  |
| Data type           | BOOLEAN   |
| Data range          | 0/1   |
| Axis types          | T   |
| Dimension           | T: ----   |
| Default value       | 0   |
| Drive types         |   |
| Remarks             | Parameter available as of CNC Build V3.1.3079.32 and higher   |

**Compensation parameters**

| <b>P-COMP-00063</b> | <b>Logical axis number of the master axis</b>   |           |
|---------------------|---|-----------|
| Description         | This parameter determines the logical number of the master axis whose acceleration is used as the input variable of the compensation value table of the slave axis. |           |
| Parameter           | kw.crosstalk.master_ax_nr   |           |
| Data type           | UNS16   |           |
| Data range          | 1 ≤ P-COMP-00063 ≤ MAX (UNS16)  |           |
| Axis types          | T, R, S   |           |
| Dimension           | T: ----   | R,S: ---- |
| Default value       | 0   |           |
| Remarks             | Parameter available as of CNC Build V3.1.3079.32 and higher   |           |

| <b>P-COMP-00064</b> | <b>Number of cycles for ‘smooth switching’</b>   |           |
|---------------------|--|-----------|
| Description         | This parameter determines the number of cycles for which crosstalk compensation is coupled/decoupled softly. |           |
| Parameter           | kw.crosstalk.n_cycles  |           |
| Data type           | UNS16  |           |
| Data range          | 0 ≤ P-COMP-00064 ≤ 20 (maximum number of cycles above which coupling or decoupling is to occur,              |           |
| Axis types          | T, R, S  |           |
| Dimension           | T: ----  | R,S: ---- |
| Default value       | 0  |           |
| Remarks             | Parameter available as of CNC Build V3.1.3079.32 and higher  |           |

| <b>P-COMP-00065</b> | <b>Last index of compensation value table</b>  |           |
|---------------------|--|-----------|
| Description         | This parameter determines the last valid index in the table of the master axis. The table always starts with index 0 |           |
| Parameter           | kw.crosstalk.last_index  |           |
| Data type           | SGN32  |           |
| Data range          | 0 ≤ P-COMP-00065 < 5   |           |
| Axis types          | T, R, S  |           |
| Dimension           | T: ----  | R,S: ---- |
| Default value       | 0  |           |
| Remarks             | Parameter available as of CNC Build V3.1.3079.32 and higher  |           |

| <b>P-COMP-00066</b> | <b>Accelerations of the master axis</b>   |          |
|---------------------|---|----------|
| Description         | This parameter defines the accelerations of the master axis requiring a correction of the slave axis. |          |
| Parameter           | kw.crosstalk.table[i].acceleration  |          |
| Data type           | SGN32   |          |
| Data range          | MIN(SGN32) ≤ P-COMP-00066 < MAX(SGN32)  |          |
| Axis types          | T   |          |
| Dimension           | T: mm/s^2   | R,S: --- |
| Default value       | 0   |          |
| Remarks             | Parameter available as of CNC Build V3.1.3079.32 and higher   |          |

| <b>P-COMP-00067</b> | <b>Correction values for the slave axis</b>  |
|---------------------|--|
| Description         | This parameter determines the correction values for the slave axis at accelerations 'i'. |
| Parameter           | kw.crosstalk.table[i].correction   |

|               |   |          |
|---------------|---|----------|
| Data type     | SGN32   |          |
| Data range    | MIN(SGN32) ≤ P-COMP-00067 < MAX(SGN32)                      |          |
| Axis types    | T, R, S   |          |
| Dimension     | T: 0.1 μm   | R,S: --- |
| Default value | 0   |          |
| Remarks       | Parameter available as of CNC Build V3.1.3079.32 and higher |          |

| <b>P-COMP-00073</b> <b>Manual activation of crosstalk compensation</b> |   |
|--|---|
| Description  | The CNC enables crosstalk compensation automatically if it is selected in the axis parameters ( <a href="#">P-AXIS-00789 [▶ 67]</a> ) and if the necessary conditions are fulfilled.<br>If parameter P-COMP-00073 is set to the value 1, crosstalk compensation must be explicitly activated by an NC command.<br>[PROG// Selecting/deselecting axis compensations in the NC program (COMP)].<br>Compensation is deactivated at the end of the NC program, when the CNC is reset or when the compensating axis is released. |
| Parameter  | kw.crosstalk.manual_activation  |
| Data type  | BOOLEAN   |
| Data range   | 0: Automatic activation<br>1: Explicit activation in NC program   |
| Axis types   |   |
| Dimension  | T, R, S   |
| Default value  | 0   |
| Remarks  | Parameter available as of CNC Build V3.1.3079.32 and higher   |

#### 4.5.2.3 CNC objects

|                    |  |                     |                          |
|--------------------|--|---------------------|--------------------------|
| <b>Name</b>        | CROSSTALK::activated   |                     |                          |
| <b>Description</b> | This object reads whether crosstalk compensation is activated by <a href="#">P-AXIS-00789 [▶ 67]</a> . |                     |                          |
| <b>Task</b>        | GEO (Port 551)   |                     |                          |
| <b>Index group</b> | 0x120300   | <b>Index offset</b> | 0x<A <sub>ID</sub> >01F4 |
| <b>Data type</b>   | BOOLEAN  | <b>Length</b>       | 1                        |
| <b>Attributes</b>  | read   | <b>Unit</b>         | [ - ]                    |
| <b>Remarks</b>     | Available as of CNC Build V3.1.3079.32   |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CROSSTALK::actual_offset  |                     |                          |
| <b>Description</b> | This object reads the current effective offset of crosstalk compensation. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >01/7 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     | Available as of CNC Build V3.1.3079.32                                    |                     |                          |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Name</b>        | CROSSTALK::delta_offset   |                     |                          |
| <b>Description</b> | This object reads the change in compensation value in the current crosstalk compensation cycle. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >01F6 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |

|                    |   |                     |                          |
|--------------------|---|---------------------|--------------------------|
| <b>Remarks</b>     | Available as of CNC Build V3.1.3079.32  |                     |                          |
| <b>Name</b>        | CROSSTALK::end_offset   |                     |                          |
| <b>Description</b> | This object reads the compensation value of crosstalk compensation at the current position without filters. |                     |                          |
| <b>Task</b>        | GEO (Port 551)  |                     |                          |
| <b>Index group</b> | 0x120300  | <b>Index offset</b> | 0x<A <sub>ID</sub> >01F8 |
| <b>Data type</b>   | SGN32   | <b>Length</b>       | 4                        |
| <b>Attributes</b>  | read  | <b>Unit</b>         | [Incr.]                  |
| <b>Remarks</b>     | Available as of CNC Build V3.1.3079.32  |                     |                          |

## 4.5.3 Example of a compensation value list

### Parameterisation of a compensation value list for crosstalk compensation

```
# ****
# Axis compensation data for Z axis
# ****

kopf.achs_nr          3
kopf.log_achs_name    Z
kw.crosstalk.last_index 2 /*Last valid index of the table*/
kw.crosstalk.master_ax_nr 1 /*Log. ax. number of the master axis*/
kw.crosstalk.n_cycles   20

#
kw.crosstalk.table[0].acceleration -10000
kw.crosstalk.table[0].correction   -1000
kw.crosstalk.table[1].acceleration 10000
kw.crosstalk.table[1].correction   1000
```

## 4.5.4 Error messages

Errors in the configuration of crosstalk compensation result in deactivation of the function for the affected axis and to the output of an error message or warning message.

Overview of error messages:

- ID 70622
- ID 70625
- ID 70626
- ID 70627
- ID 70629
- ID 70630
- ID 70631
- ID 70632

## 5 Other configuration options for axis compensation

### 5.1 Selecting/deselecting axis compensation in the NC program



Axis compensations switched off by the COMP command has a global NC program effect, i.e. compensations are not automatically activated at program end. They must be switched back on explicitly using the COMP command in the subsequent NC program.

Syntax:

```
<axis_name> [ COMP [[ ON | OFF [ CROSS PLANE LEAD TEMP FRICT ] ]| OFF_ALL ][ NO_MOVE ] { \ } ]
```

|             |  |
|-------------|--|
| <axis_name> | Name of the axis   |
| COMP        | Identifier to select/deselect axis-specific compensation. Must always be programmed as the <u>first</u> keyword. |
| ON          | Activates programmed compensation(s)   |
| OFF         | Deactivates programmed compensation(s)   |
| CROSS       | Keyword for cross compensation   |
| PLANE       | Keyword for plane compensation   |
| LEAD        | Keyword for spindle leadscrew error compensation   |
| TEMP        | Keyword for temperature compensation   |
| FRICT       | Keyword for friction compensation [as of Build V2.11.2022.05]  |
| CROSSTALK   | Keyword for crosstalk compensation [as of Build V3.1.3079.32]  |
| OFF_ALL     | Switch off all active compensations. No further compensation keywords may be programmed after the keyword.       |

**NO\_MOVE**

By default the position offset occurring when axis compensations are switched on/off is driven out before the NC program processing is continued. The keyword NO\_MOVE suppresses this motion. The channel is initialised with the changed axis position. The position offset is only deactivated at the next axis motion programmed in the NC program.

\

Separator ("backslash") for clear programming of the command over multiple lines.

**Axis-specific programming**

```
;Deactivate cross and plane compensation in the X axis  
N10 X[COMP OFF CROSS PLANE]  
  
;Compensation programming of multiple axes in an NC block  
N50 X[COMP OFF CROSS] Y[COMP ON LEAD TEMP]  
  
;Deactivate all compensations in the Z axis  
N100 Z[COMP OFF_ALL]  
  
;Deactivate all compensations of the Y axis without axis motion  
N200 Y[COMP OFF_ALL NO_MOVE]
```

## 5.2 Checking the states of axis compensation in the NC program

### V.A variables

The following V.A. variables can be used to check from the NC program whether a compensation programmable via the COMP command is initialised or already active for a specific axis.

#### Initialisation check

*V.A.Compensation name\_INIT[Achsindex]* or

*V.A.Compensation name\_INIT.Achsname*

#### Activation check

*V.A.Compensation name\_ACTIVE[Achsindex]* or

*V.A.Compensation name\_ACTIVE.Achsname*

The following identifiers are available for compensation name.

**CROSS\_COMP** for cross compensation

**PLANE\_COMP** for plane compensation

**LEAD\_COMP** for leadscrew error compensation

**TEMP\_COMP** for temperature compensation

#### Check the states of the axis compensation

```
N010 G74 X1 Y2 Z3
N020 $IF V.A.CROSS_COMP_INIT.X != TRUE
N030 #MSG ["Cross_Comp for X not init."]
N040 $ENDIF
N050 $IF V.A.TEMP_COMP_INIT.X != TRUE
N060 #MSG ["Temp_Comp for X not init."]
N070 $ENDIF
N080 X [ COMP ON CROSS TEMP ]
N090 $IF V.A.CROSS_COMP_ACTIVE[0] != TRUE
N100 #MSG ["Cross_Comp for X not active"]
N110 $ENDIF
N120 $IF V.A.TEMP_COMP_ACTIVE[0] != TRUE
N130 #MSG ["Temp_Comp for X not active"]
N140 $ENDIF
N150 ...
```

## 5.3 Monitoring of effectiveness of axis compensations in automatic mode

Some axis compensations must fulfil certain preconditions before they can be active. To ensure that the selected axis compensations are operative in automatic mode, the required compensations for processing the NC program can be specified bit-encoded in the parameter 'lr\_param.prog\_movement\_requires\_compensations' (see P-AXIS-00465).

The CNC then outputs the error message P-ERR-70435 if the axis is moved in automatic mode and the specified axis compensations are not active. However, in manual mode or during homing [FCT-M1// Description], the axis can be moved without compensations.

For example, this monitoring function may be practical to prevent the production of an inaccurate workpiece if there are errors in the compensation table.

### Prerequisites

The following conditions exist for the effectiveness of axis compensations:

1. The compensation table may contain no errors, see [COMP].
2. The axis must be referenced for spindle leadscrew error compensation and temperature compensation.
3. The master axes must be referenced for cross and plane compensation..
4. The drive releases must be set for cross and plane compensation before NC program start.

### Activating the monitoring function in the axis parameter list

| Variable name                                     | Type  | Meaning  |
|---|-------|--|
| lr_param.prog_movement_requires_com<br>pensations | UNS32 | Bit-encoded specification of the required<br>compensations |



The CNC only generates error messages for compensations which are also enabled in the axis parameter list.

## Bit encoding

The table below contains the bit encoding for axis compensations. The bit identifier can also be used to specify the required compensations:

| Bit  | Identifier | Axis compensation            |
|------|------------|------------------------------|
| 0x1  | BACKLASH   | Backlash compensation        |
| 0x2  | LEAD       | Leadscrew error compensation |
| 0x4  | TEMP       | Temperature compensation     |
| 0x8  | CROSS      | Cross compensation           |
| 0x10 | PLANE      | Plane compensation           |

## Monitoring the effectiveness of axis compensations in automatic mode

The following entry is required in the axis parameter list to monitor spindle leadscrew error compensation and cross compensation:

**lr\_param.prog\_movement\_requires\_compensations LEAD | CROSS**

The two compensations must be selected so that the CNC outputs an error message in automatic mode when the conditions are no longer met.

|                    |   |
|--------------------|---|
| lr_param.ssfk      | 1 |
| lr_param.crosscomp | 1 |

## 6 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

### Download finder

Our download finder contains all the files that we offer you for downloading. You will find application reports, technical documentation, technical drawings, configuration files and much more.

The downloads are available in various formats.

### Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on our internet page: [www.beckhoff.com](http://www.beckhoff.com)

You will also find further documentation for Beckhoff components there.

### Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963-157  
e-mail: support@beckhoff.com

### Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963-460  
e-mail: service@beckhoff.com

### Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20  
33415 Verl  
Germany

Phone: +49 5246 963-0  
e-mail: info@beckhoff.com  
web: [www.beckhoff.com](http://www.beckhoff.com)

# Index

## B

|                       |    |
|-----------------------|----|
| backlash              |    |
| Compensation          | 10 |
| mechanical            | 9  |
| negative              | 10 |
| positive              | 9  |
| Backlash compensation | 10 |

|                   |    |
|-------------------|----|
| P-COMP-00032      | 59 |
| P-COMP-00033      | 59 |
| P-COMP-00057      | 36 |
| P-COMP-00059      | 33 |
| P-COMP-00060      | 44 |
| P-COMP-00061      | 56 |
| P-COMP-00063      | 68 |
| P-COMP-00064      | 68 |
| P-COMP-00065      | 68 |
| P-COMP-00066      | 68 |
| P-COMP-00067      | 68 |
| P-COMP-00073      | 69 |
| Positive backlash | 9  |

## M

|                     |   |
|---------------------|---|
| Mechanical backlash | 9 |
|---------------------|---|

## N

|                   |    |
|-------------------|----|
| Negative backlash | 10 |
|-------------------|----|

## P

|              |    |
|--------------|----|
| P-AXIS-00021 | 11 |
| P-AXIS-00047 | 43 |
| P-AXIS-00103 | 11 |
| P-AXIS-00174 | 56 |
| P-AXIS-00175 | 33 |
| P-AXIS-00243 | 33 |
| P-AXIS-00271 | 20 |
| P-AXIS-00272 | 20 |
| P-AXIS-00273 | 20 |
| P-AXIS-00274 | 21 |
| P-AXIS-00275 | 21 |
| P-AXIS-00482 | 21 |
| P-AXIS-00789 | 67 |
| P-COMP-00003 | 44 |
| P-COMP-00004 | 44 |
| P-COMP-00005 | 45 |
| P-COMP-00006 | 45 |
| P-COMP-00007 | 46 |
| P-COMP-00008 | 56 |
| P-COMP-00009 | 57 |
| P-COMP-00010 | 57 |
| P-COMP-00011 | 57 |
| P-COMP-00012 | 58 |
| P-COMP-00013 | 58 |
| P-COMP-00014 | 58 |
| P-COMP-00015 | 58 |
| P-COMP-00016 | 58 |
| P-COMP-00017 | 34 |
| P-COMP-00018 | 34 |
| P-COMP-00019 | 34 |
| P-COMP-00020 | 34 |
| P-COMP-00021 | 35 |
| P-COMP-00022 | 35 |
| P-COMP-00023 | 35 |
| P-COMP-00024 | 35 |
| P-COMP-00025 | 36 |
| P-COMP-00026 | 45 |
| P-COMP-00027 | 59 |
| P-COMP-00028 | 36 |
| P-COMP-00029 | 45 |
| P-COMP-00030 | 59 |



More Information:  
[www.beckhoff.com/TF5200](http://www.beckhoff.com/TF5200)

Beckhoff Automation GmbH & Co. KG  
Hülsorstweg 20  
33415 Verl  
Germany  
Phone: +49 5246 9630  
[info@beckhoff.com](mailto:info@beckhoff.com)  
[www.beckhoff.com](http://www.beckhoff.com)

