



Manual | EN

TF5200 | TwinCAT 3 CNC

Volumetric compensation parameters



Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT technology is patent protected, in particular by the following applications and patents:
EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702
with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

General and safety instructions

Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

Icons in explanatory text

1. Indicates an action.
- ⇒ Indicates an action statement.

DANGER

Acute danger to life!

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.

CAUTION

Personal injury and damage to machines!

If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.

NOTICE

Restriction or error

This icon describes restrictions or warns of errors.

Tips and other notes

This icon indicates information to assist in general understanding or to provide additional information.

General example

Example that clarifies the text.

NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.

Specific version information

Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

Table of contents

| | |
|--|-----------|
| Notes on the documentation | 3 |
| General and safety instructions | 4 |
| Overview of compensation parameters | 8 |
| 1 General description | 9 |
| 1.1 Links to other documents | 9 |
| 1.2 Structure and classification of configuration data..... | 9 |
| 1.3 Syntax and interpretation of ASCII list file | 9 |
| 1.4 Comments in the ASCII list file..... | 10 |
| 2 Description of elements | 11 |
| 2.1 Logical axis numbers of the participating axes (P-VOLC-00001 to P-VOLC-00006)..... | 11 |
| 2.2 Type of kinematic chain (P-VOLC-00007) | 13 |
| 2.3 Number of workpiece axes (P-VOLC-00008)..... | 13 |
| 2.4 Negating compensation values (P-VOLC-00009) | 13 |
| 2.5 Setting compensation values to zero (P-VOLC-00010) | 13 |
| 2.6 Alternative calculation rule (P-VOLC-00011) | 14 |
| 2.7 Paths and names of parameter files (P-VOLC-00012) | 14 |
| 2.8 Parameter file formats (P-VOLC-00013) | 14 |
| 2.9 Interpolation method for error parameters (P-VOLC-00014) | 15 |
| 2.10 Adaptation of error parameters (P-VOLC-00015) | 15 |
| 2.11 Manual activation (P-VOLC-00017) | 15 |
| 2.12 Filter size (P-VOLC-00018)..... | 16 |
| 2.13 Associate compensation to channel (P-VOLC-00019)..... | 16 |
| 2.14 Consider axis offsets (P-VOLC-00020)..... | 16 |
| 3 Support and Service | 18 |
| Index | 19 |

List of figures

Overview of compensation parameters

The overview of compensation parameters is sorted into a 4-column table.

- Column 1 contains the unambiguous identifier of the axis parameter called the “ID”. which consists of the prefix “P-VOLC” and a unique 5-digit number,
e.g. P-VOLC-00001.
- Column 2 represents the data structure which defines the parameter
The structure is a categorisation aid and is described in the following section (irrelevant for compensation parameters). If an entry is missing in ‘structure’, this is not an error. The parameter in column 3 “parameter” is then only valid on its own.
- Column 3 contains the “parameter” with its exact description,
e.g. x
- Column 4 contains the “functionality” in a summarised term/short description
e.g. Logical axis number of the participating X axis

| ID | Structure | Parameter | Functionality/short description |
|---------------------|-----------|----------------------|---|
| P-VOLC-00001 [► 11] | | x | Logical axis number of the participating X axis |
| P-VOLC-00002 [► 11] | | y | Logical axis number of the participating Y axis |
| P-VOLC-00003 [► 11] | | z | Logical axis number of the participating Z axis |
| P-VOLC-00004 [► 11] | | a | Logical axis number of the participating A axis |
| P-VOLC-00005 [► 12] | | b | Logical axis number of the participating B axis |
| P-VOLC-00006 [► 12] | | c | Logical axis number of the participating C axis |
| P-VOLC-00007 [► 13] | | Chain | Type of kinematic chain |
| P-VOLC-00008 [► 13] | | workpiece_axes | Number of workpiece axes |
| P-VOLC-00009 [► 13] | | negate | Negate compensation values |
| P-VOLC-00010 [► 13] | | set_to_zero | Setting the compensation values to zero |
| P-VOLC-00011 [► 14] | | alternative_model | Alternative calculation rule |
| P-VOLC-00012 [► 14] | | file[j] | Paths and names of parameter files |
| P-VOLC-00013 [► 14] | | file_format[j] | Parameter file formats |
| P-VOLC-00014 [► 15] | | interpolation | Interpolation method for error parameters |
| P-VOLC-00015 [► 15] | | enable_splicing | Adaptation of error parameters |
| P-VOLC-00016 | | diagnosis_file | Path to the diagnosis file |
| P-VOLC-00017 [► 15] | | manual_activation | Manual activation |
| P-VOLC-00018 [► 16] | | filter_steps | Number of steps in the compensation value list. |
| P-VOLC-00019 [► 16] | | associate_to_channel | Associate compensation to channel |
| P-VOLC-00020 [► 16] | | use_axis_offsets | Consider axis offsets |

1 General description

1.1 Links to other documents

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.

1.2 Structure and classification of configuration data

A maximum of 5 volumetric compensations can be configured on the controller. Configuration of the ith volumetric compensation is split between a startup list and the list file:

- 2 parameters are listed in the controller startup list ('hochlauf.lis'):
 1. The parameter "vol_comp[i].max_records" (P-STUP-00100) specifies an upper limit for the expected error parameter blocks.
 2. The parameter "vol_comp[i].file_name" (P-STUP-00101) refers to the list file in which the related volumetric compensation is configured as detailed below. This means that there are maximum 5 list files containing the assigned configuration data.
- The file which is named in the start-up parameter "vol_comp[i].file_name" (P-STUP-00101) contains all the configuration data for the ith volumetric compensation with the exception of "max_records". These parameters are explained in this documentation.

1.3 Syntax and interpretation of ASCII list file

An interpreter copies the entries in the ASCII list file into identical internal structures which are then checked for plausibility. To ensure reliable controller start-up every time, defective entries found by the plausibility check are replaced by default values.

Unknown entries are not taken over. These irregularities are displayed by warning messages. We advise you to investigate the cause for these warning messages and remove defective entries from the ASCII list file.



The following agreement applies to BOOLEAN data:

| Value | Meaning |
|-------|---------------------|
| 0 | Definition of FALSE |
| 1 | Definition of TRUE |

1.4 Comments in the ASCII list file

Comments can be in an entire line or can be added at the end of a line.

With a comment spanning an entire line, the comment character "#" must be placed at the start of the line and followed by a blank.

If a comment is to be inserted at the end of a line, only a blank is required before the comment. However, if a string was defined in the line, the comment must be preceded by the comment character "(".

Blank lines are also possible.

Comments in the ASCII list file

```
# ****
# Data
# ****
#
# Listing

dummy[1] 1 Comment
dummy[2] 1 # Comment
dummy[3] 1 ( Comment
dummy[4] 1 /* Comment
...
...
beispiel[0].bezeichnung STRING_2 (Comment: comment brackets required here!)
```

2 Description of elements

2.1 Logical axis numbers of the participating axes (P-VOLC-00001 to P-VOLC-00006)

| P-VOLC-00001 | Logical axis number of the participating X axis |
|---------------|---|
| Description | This parameter defines the X axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | x |
| Data type | UNS16 |
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The row x 1 defines that the axis with the logical axis number 1 is to be interpreted as the X axis (as specified in the ISO 230 model). |

| P-VOLC-00002 | Logical axis number of the participating Y axis |
|---------------|---|
| Description | This parameter defines the Y axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | y |
| Data type | UNS16 |
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The row y 2 defines that the axis with the logical axis number 2 is to be interpreted as the Y axis (as specified in the ISO 230 model). |

| P-VOLC-00003 | Logical axis number of the participating Z axis |
|---------------|---|
| Description | This parameter defines the Z axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | z |
| Data type | UNS16 |
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The row z 3 defines that the axis with the logical axis number 3 is to be interpreted as the Z axis (as specified in the ISO 230 model). |

| P-VOLC-00004 | Logical axis number of the participating A axis |
|--------------|---|
| Description | This parameter defines the A axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | a |
| Data type | UNS16 |

| | |
|---------------|--|
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | <p>Parameterisation example: The row a 4</p> <p>defines that the axis with the logical axis number 4 is to be interpreted as the A axis (as specified in the ISO 230 model).</p> |

| P-VOLC-00005 Logical axis number of the participating B axis | |
|---|--|
| Description | This parameter defines the B axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | b |
| Data type | UNS16 |
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | <p>Parameterisation example: The row b 5</p> <p>defines that the axis with the logical axis number 5 is to be interpreted as the B axis (as specified in the ISO 230 model).</p> |

| P-VOLC-00006 Logical axis number of the participating C axis | |
|---|--|
| Description | This parameter defines the C axis participating in this Volumetric Compensation. The axis is identified by its logical axis number. |
| Parameter | c |
| Data type | UNS16 |
| Data range | 0 ... MAX(UNS16) |
| Dimension | ---- |
| Default value | - |
| Remarks | <p>Parameterisation example: The row c 6</p> <p>defines that the axis with the logical axis number 6 is to be interpreted as the C axis (as specified in the ISO 230 model).</p> |

2.2 Type of kinematic chain (P-VOLC-00007)

| P-VOLC-00007 | Type of kinematic chain |
|---------------|--|
| Description | This parameter specifies the kinematic chain to be used. For details of how to define the kinematic chain, see [FCT-C26]. The 6 axes available X, Y, Z, A, B and C can be used in any order. |
| Parameter | chain |
| Data type | STRING |
| Data range | <Order of axis names in the chain> |
| Dimension | ---- |
| Default value | XYZ |
| Remarks | Parameterisation example: The row chain XYZCA defines the kinematic chain for a conventional CA machine. |

2.3 Number of workpiece axes (P-VOLC-00008)

| P-VOLC-00008 | Number of workpiece axes |
|---------------|--|
| Description | This parameter specifies how many axes in the kinematic chain lie on the workpiece side. Use of this parameter depends on the measurement strategy. See [FCT-C26]. |
| Parameter | workpiece_axes |
| Data type | UNS16 |
| Data range | 0 ≤ workpiece_axes < 6* |
| Dimension | ---- |
| Default value | 0 |
| Remarks | * Volumetric compensation is possible for maximum 6 axes |

2.4 Negating compensation values (P-VOLC-00009)

| P-VOLC-00009 | Negate compensation values |
|---------------|--|
| Description | This parameter specifies the Cartesian axes for which the compensation value is to be negated. See [FCT-C26]. A notation based on sets is used. For example, the value "XY" means that the compensation values for X and Y are to be negated, but not for Z. |
| Parameter | negate |
| Data type | STRING |
| Data range | <Name of the axes to be negated> |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The row negate XY specifies that the compensation values are to be negated for the X axis and Y axis. |

2.5 Setting compensation values to zero (P-VOLC-00010)

| P-VOLC-00010 | Setting the compensation values to zero |
|--------------|---|
| Description | This parameter specifies the Cartesian axes in which the compensation value is to be zeroed. See [FCT-C26]. A notation based on sets is used. |
| Parameter | set_to_zero |
| Data type | STRING |

| | |
|---------------|--|
| Data range | <Names of the axes to be zeroed> |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The row set_to_zero Z specifies that the compensation value are to be zeroed for the Z axis. |

2.6 Alternative calculation rule (P-VOLC-00011)

| P-VOLC-00011 | Alternative calculation rule |
|---------------|---|
| Description | This parameter enables use of an alternative calculation rule for the ISO 230 error model. Use of this parameter depends on the interpretation of the measurement strategy which is possibly used. See [FCT-C26]. |
| Parameter | alternative_model |
| Data type | BOOLEAN |
| Data range | 0/1 |
| Dimension | ---- |
| Default value | 0 |
| Remarks | |

2.7 Paths and names of parameter files (P-VOLC-00012)

| P-VOLC-00012 | Paths and names of parameter files |
|---------------|--|
| Description | This parameter contains the paths and names of the error parameter files which are read in for the Volumetric Compensation. The corresponding parameter <u>P-VOLC-00013</u> [▶ 14] (file_format[j]) should be configured for every entry in file[j]. |
| Parameter | file[j] where $0 \leq j < 10$ (application-specific) |
| Data type | STRING |
| Data range | <Paths and names of parameter files> |
| Dimension | ---- |
| Default value | - |
| Remarks | Parameterisation example: The rows file[0] C:\volcomp\vc_001.csv file[1] C:\volcomp\vc_002.csv specify the error parameters from which the two specified CVS files should be read. |

2.8 Parameter file formats (P-VOLC-00013)

| P-VOLC-00013 | Parameter file formats |
|---------------|--|
| Description | This parameter defines the formats of the error parameter files <u>P-VOLC-00012</u> [▶ 14] (file[j]). An incorrect file format setting results in a syntax error when the file is read in. |
| Parameter | file_format[j] where $0 \leq j < 10$ (application-specific) |
| Data type | STRING |
| Data range | {ISG_CSV, ETALON_EXCHANGE} |
| Dimension | ---- |
| Default value | ISG_CSV |

| | |
|---------|--|
| Remarks | <p>Parameterisation example: The rows</p> <p>file[0] C:\volcomp\vc_001.csv file_format[0] ISG_CSV</p> <p>file[1] C:\volcomp\vc_002.exc file_format[1] ETALON_EXCHANGE</p> <p>specify that an error parameter file is to be read in in CVS format and a file in Etalon Exchange Format.</p> |
|---------|--|

2.9 Interpolation method for error parameters (P-VOLC-00014)

| P-VOLC-00014 | Interpolation method for error parameters |
|---------------|--|
| Description | This parameter specifies the interpolation method to be used for the error parameters. See [FCT-C26]. |
| Parameter | interpolation |
| Data type | STRING |
| Data range | GRID: The data is given on a grid, linear interpolation. An error is issued if the GRID mode is configured, but the data in the parameter files is not given on a grid. SCATTER: The data is specified irregularly by means of Shepard interpolation. AUTO: If the data is specified on a grid, linear interpolation is used. If not, Shepard interpolation is applied. PATH: Error parameters are specified at the corner points of a polygon. Interpolation takes place in linear sections along the polygon. PATH_XY: Error parameters are specified at the corner points of a polygon in the XY plane. |
| Dimension | ---- |
| Default value | GRID |
| Remarks | |

2.10 Adaptation of error parameters (P-VOLC-00015)

| P-VOLC-00015 | Adaptation of error parameters |
|---------------|--|
| Description | This parameter specifies whether error parameters are to be adjusted for rotary axes to avoid jumps in the compensation values in the event of modulo passages (e.g. 360°). See [FCT-C26]. |
| Parameter | enable_splicing |
| Data type | BOOLEAN |
| Data range | 0/1 |
| Dimension | ---- |
| Default value | 0 |
| Remarks | |

2.11 Manual activation (P-VOLC-00017)

| | |
|--------------|-------------------|
| P-VOLC-00017 | Manual activation |
|--------------|-------------------|

| | |
|---------------|---|
| Description | By default, Volumetric Compensation is automatically enabled on start-up or reset as soon as the participating axes meet all the necessary conditions. See [FCT-C26]. This parameter can prevent this automated feature. In this case, Volumetric Compensation can only be enabled by the NC command #VOLCOMP ON / OFF. |
| Parameter | manual_activation |
| Data type | BOOLEAN |
| Data range | 0: Volumetric Compensation is enabled either automatically on start-up or reset or manually, i.e. with #VOLCOMP ON/OFF. 1: Volumetric Compensation can be enabled only manually, i.e. with #VOLCOMP ON/OFF. |
| Unit | ---- |
| Default value | 0 |
| Remarks | |

2.12 Filter size (P-VOLC-00018)

| P-VOLC-00018 | Number of steps in the compensation value list. |
|---------------|--|
| Description | If compensation with axis motion is enabled or disabled (NOT via position controller setpoint correction), the correction value is built up and reduced by a filer to move the axis with jerk limiting. This parameter defines the number of steps/cycles. |
| Parameter | filter_steps |
| Data type | UNS32 |
| Data range | 0 ... MAX(UNS32) |
| Dimension | ---- |
| Default value | 20 |
| Remarks | |

2.13 Associate compensation to channel (P-VOLC-00019)

| P-VOLC-00019 | Associate compensation to channel |
|---------------|--|
| Description | This parameter specifies whether compensation is to be linked to the channel in which it was enabled. This flag impacts on the behaviour of the compensation at the end of the program, among other things. See [FCT-C26]. |
| Parameter | associate_to_channel |
| Data type | BOOLEAN |
| Data range | 0/1 |
| Dimension | ---- |
| Default value | 0 |
| Remarks | |

2.14 Consider axis offsets (P-VOLC-00020)

| P-VOLC-00020 | Consider axis offsets |
|---------------|--|
| Description | This parameter specifies whether compensation should consider axis offsets when the correction values are defined. |
| Parameter | use_axis_offsets |
| Data type | BOOLEAN |
| Data range | 0/1 |
| Dimension | ---- |
| Default value | 0 |

| | |
|---------|--|
| Remarks | |
|---------|--|

3 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Download finder

Our download finder contains all the files that we offer you for downloading. You will find application reports, technical documentation, technical drawings, configuration files and much more.

The downloads are available in various formats.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on our internet page: www.beckhoff.com

You will also find further documentation for Beckhoff components there.

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963-157

e-mail: support@beckhoff.com

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963-460

e-mail: service@beckhoff.com

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963-0
e-mail: info@beckhoff.com
web: www.beckhoff.com

Index

P

| | |
|--------------|----|
| P-VOLC-00001 | 11 |
| P-VOLC-00002 | 11 |
| P-VOLC-00003 | 11 |
| P-VOLC-00004 | 11 |
| P-VOLC-00005 | 12 |
| P-VOLC-00006 | 12 |
| P-VOLC-00007 | 13 |
| P-VOLC-00008 | 13 |
| P-VOLC-00009 | 13 |
| P-VOLC-00010 | 13 |
| P-VOLC-00011 | 14 |
| P-VOLC-00012 | 14 |
| P-VOLC-00013 | 14 |
| P-VOLC-00014 | 15 |
| P-VOLC-00015 | 15 |
| P-VOLC-00017 | 15 |
| P-VOLC-00018 | 16 |
| P-VOLC-00019 | 16 |
| P-VOLC-00020 | 16 |

More Information:
www.beckhoff.com/TF5200

Beckhoff Automation GmbH & Co. KG
Hülsorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

