


Documentation | EN

# KL2502/KS2502, KL2512/KS2512

Dual Channel Pulse Width Output Terminals, 24 V DC





# Table of contents

<b>1 Foreword .....</b>	<b>5</b>
1.1 Notes on the documentation.....	5
1.2 Safety instructions .....	6
1.3 Documentation issue status .....	7
1.4 Beckhoff Identification Code (BIC) .....	8
<b>2 Product overview.....</b>	<b>10</b>
2.1 KL2502/KS2502 - Introduction .....	10
2.1.1 KL2502-0010 .....	11
2.2 KL2512/KS2512 - Introduction .....	12
2.3 Technical data .....	13
2.4 Basic Function Principles .....	14
2.5 Operation modes .....	14
<b>3 Mounting and wiring.....</b>	<b>16</b>
3.1 Instructions for ESD protection.....	16
3.2 Installation on mounting rails .....	17
3.3 Connection .....	20
3.3.1 Connection system .....	20
3.3.2 Wiring.....	22
3.3.3 Shielding .....	23
3.4 Contact assignment and LEDs .....	24
3.5 ATEX - Special conditions (standard temperature range).....	25
3.6 IECEx - Special conditions .....	26
3.7 Continuative documentation for ATEX and IECEx .....	27
3.8 cFMus - Special conditions.....	28
3.9 Continuative documentation for cFMus .....	29
3.10 Disposal.....	29
<b>4 Configuration Software KS2000.....</b>	<b>30</b>
4.1 KS2000 - Introduction.....	30
<b>5 Access from the user program .....</b>	<b>32</b>
5.1 Terminal configuration .....	32
5.2 Mapping in the Bus Coupler .....	33
5.2.1 KL2502 .....	33
5.3 Control and status byte.....	35
5.3.1 Register communication .....	35
5.4 Examples of Register Communication .....	37
5.4.1 Example 1: reading the firmware version from Register 9.....	37
5.4.2 Example 2: Writing to an user register.....	37
5.5 Register overview .....	40
5.6 Register description.....	41
<b>6 Appendix .....</b>	<b>44</b>
6.1 Support and Service .....	44



# 1 Foreword

## 1.1 Notes on the documentation

### Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

### Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

### Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

### Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

### Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

## 1.2 Safety instructions

### Safety regulations

Please note the following safety instructions and explanations!  
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

### Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

### Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

### Description of instructions

In this documentation the following instructions are used.  
These instructions must be read carefully and followed without fail!

#### **DANGER**

##### **Serious risk of injury!**

Failure to follow this safety instruction directly endangers the life and health of persons.

#### **WARNING**

##### **Risk of injury!**

Failure to follow this safety instruction endangers the life and health of persons.

#### **CAUTION**

##### **Personal injuries!**

Failure to follow this safety instruction can lead to injuries to persons.

#### **NOTE**

##### **Damage to environment/equipment or data loss**

Failure to follow this instruction can lead to environmental damage, equipment damage or data loss.



##### **Tip or pointer**

This symbol indicates information that contributes to better understanding.

### 1.3 Documentation issue status

Version	Comment
4.4.0	<ul style="list-style-type: none"> <li>• KL2502-0010 added</li> </ul>
4.3.0	<ul style="list-style-type: none"> <li>• Technical data updated</li> <li>• Ex markings added to technical data</li> <li>• Chapter <i>IECEEx - Special conditions</i> added</li> <li>• Chapter <i>cFMus - Special conditions</i> added</li> <li>• Chapter <i>Disposal</i> added</li> <li>• New title page</li> </ul>
4.2	<ul style="list-style-type: none"> <li>• Chapter <i>Instructions for ESD protection</i> updated</li> <li>• Chapter <i>Beckhoff Identification Code (BIC)</i> added</li> </ul>
4.1	<ul style="list-style-type: none"> <li>• Structure update</li> <li>• Technical data updated</li> <li>• Revision status updated</li> </ul>
4.0	<ul style="list-style-type: none"> <li>• Migration</li> <li>• Document structure updated</li> <li>• Technical data updated</li> <li>• Revision status updated</li> </ul>

#### Firmware and hardware versions

Documentation Version	KL/KS2502-0000		KL2502-0010		KL/KS2512-0000	
	Firmware	Hardware	Firmware	Hardware	Firmware	Hardware
4.4.0	3F	09	3F	05	3F	02
4.3.0	3F	09	-	-	3F	02
4.2	3F	08	-	-	3F	02
4.1	3F	08	-	-	3F	02
4.0	3F	08	-	-	3F	02

The firmware and hardware versions (delivery state) of the terminal can be found in the serial number printed on the side.

#### Syntax of the serial number

Structure of the serial number: WW YY FF HH

WW - week of production (calendar week)

YY – year of production

FF - firmware version

HH - hardware version

Example with serial number 12 06 3A 02:

12 - week of production 12

06 - year of production 2006

3A - firmware version 3A

02 - hardware version 02

## 1.4 Beckhoff Identification Code (BIC)

The Beckhoff Identification Code (BIC) is increasingly being applied to Beckhoff products to uniquely identify the product. The BIC is represented as a Data Matrix Code (DMC, code scheme ECC200), the content is based on the ANSI standard MH10.8.2-2016.




Fig. 1: BIC as data matrix code (DMC, code scheme ECC200)

The BIC will be introduced step by step across all product groups.

Depending on the product, it can be found in the following places:

- on the packaging unit
- directly on the product (if space suffices)
- on the packaging unit and the product

The BIC is machine-readable and contains information that can also be used by the customer for handling and product management.

Each piece of information can be uniquely identified using the so-called data identifier (ANSI MH10.8.2-2016). The data identifier is followed by a character string. Both together have a maximum length according to the table below. If the information is shorter, spaces are added to it. The data under positions 1 to 4 are always available.

The following information is contained:

Item no.	Type of information	Explanation	Data identifier	Number of digits incl. data identifier	Example
1	Beckhoff order number	<b>Beckhoff order number</b>	1P	8	<b>1P</b> 072222
2	Beckhoff Traceability Number (BTN)	<b>Unique serial number, see note below</b>	S	12	<b>S</b> BTNk4p562d7
3	Article description	<b>Beckhoff article description, e.g. EL1008</b>	1K	32	<b>1K</b> EL1809
4	Quantity	<b>Quantity in packaging unit, e.g. 1, 10, etc.</b>	Q	6	<b>Q</b> 1
5	Batch number	Optional: Year and week of production	2P	14	<b>2P</b> 401503180016
6	ID/serial number	Optional: Present-day serial number system, e.g. with safety products or calibrated terminals	51S	12	<b>51S</b> 678294104
7	Variant number	Optional: Product variant number on the basis of standard products	30P	32	<b>30P</b> F971, 2*K183
...					

Further types of information and data identifiers are used by Beckhoff and serve internal processes.

**Structure of the BIC**

Example of composite information from item 1 to 4 and 6. The data identifiers are marked in red for better display:

**BTN**

An important component of the BIC is the Beckhoff Traceability Number (BTN, item no. 2). The BTN is a unique serial number consisting of eight characters that will replace all other serial number systems at Beckhoff in the long term (e.g. batch designations on IO components, previous serial number range for safety products, etc.). The BTN will also be introduced step by step, so it may happen that the BTN is not yet coded in the BIC.

<b>NOTE</b>
This information has been carefully prepared. However, the procedure described is constantly being further developed. We reserve the right to revise and change procedures and documentation at any time and without prior notice. No claims for changes can be made from the information, illustrations and descriptions in this information.

## 2 Product overview

### 2.1 KL2502/KS2502 - Introduction




Fig. 2: KL2502 - Two-channel pulse width output terminal 24 V<sub>DC</sub>

The KL2502/KS2502 output terminals modulate the pulse width of a binary signal, and outputs it electrically isolated from the K-bus. The mark/space ratio is prescribed by a 16 bit value from the automation device. The output stage is protected against overload and short-circuit. The Bus Terminal contains two channels that indicate its signal state by means of light emitting diodes. The LEDs are driven in time with the outputs and show the duty factor by their brightness.

## 2.1.1 KL2502-0010

Pulse direction setting for controlling a stepper motor power unit with active interpolation.

The output terminal KL2502-0010 has the Frq-Cnt pulse mode with active interpolation as factory setting. It differs from the KL2502-0000 by a processor that is faster by a factor of four, so that all frequencies that are specified are provided with the same factor. That means:

PWML mode:	from 8 Hz to 1 kHz
PWMH mode:	from 1 kHz to 80 kHz
Cnt-Cnt-PWM mode:	from 1 kHz to 32 kHz
Register <a href="#">R2 [▸ 43]</a> und <a href="#">R35 [▸ 43]</a> :	Period duration, 1 digit corresponds to 250 ns
Register <a href="#">R37 [▸ 43]</a> :	Pulse duration, 1 digit corresponds to 2 µs

In addition, the power range for controlling a stepper motor has been extended:

Frq-Cnt-PWM mode:	from 8 Hz to 32,7 kHz
Frq-Cnt-Impuls mode:	from 8 Hz to 32,7 kHz

### Interpolation

During interpolation, a start frequency  $F_{start}$  ([R39 \[▸ 43\]](#)) is specified, from which this starts. Above  $F_{start}$ , frequency steps specified by the controller are interpolated with the gradient specified via the maximum frequency step size  $F_{delta}$  ([R38 \[▸ 43\]](#)) and the time base  $T_{delta}$  ([R40 \[▸ 43\]](#)).  $F_{delta}$  and  $T_{delta}$  define the maximum acceleration of the drive.

### Key data for stepper motor operating mode

Maximum frequency:	32.7 kHz
Resolution:	8 Hz / Digit
Impulse with:	R37 x 2 µs

### Process data

DOUT of the termina:

Number of output pulses. If the frequency setting is positive, the pulses are counted forward, if it is negative, the pulses are counted backward.

DIN of the terminal:

Frequency setting with 8 Hz/digit and sign as direction setting.

## 2.2 KL2512/KS2512 - Introduction




Fig. 3: KL2512 - Two-channel pulse width output terminal 24 V<sub>DC</sub>, ground switching

The KL2512/KS2512 output terminals enable direct connection of different ohmic loads. The output signal is a pulse-width modulated voltage. The typical load of an LED group or an incandescent lamp is connected between the positive side of the supply voltage and the output of the KL2512/KS2512. Via the fieldbus the output can be set independently for two channels with a resolution of more than 30,000 steps. The PWM frequency can be changed. The power transistors switch the ground connection and are electrically isolated from the internal K-bus.

## 2.3 Technical data

Technical data	KL2502-0000/ KS2502-0000	KL2502-0010	KL2512-0000/ KS2512-0000
Number of outputs	2		
Rated load voltage	24 V <sub>DC</sub> (20 V ... 29 V)		
Connected potential	24 V		0 V
Load type	resistive, inductive		resistive
Max. output current (per channel)	0.1 A (short-circuit proof, 1 A driver component)		1.5 A
Base frequency	1 ... 20 kHz, default: 250 Hz		
Duty factor	0 ... 100 % (T <sub>ON</sub> > 750 ns, T <sub>OFF</sub> > 500 ns)		0 ... 100 %
Resolution	max. 10 bit		
Electrical isolation	500 V (K-bus/field voltage)		
Current consumption from the K-bus	typ. 18 mA	typ. 22 mA	typ. 18 mA
Load voltage current consumption	typ. 10 mA		
Bit width in process image	48 I/O: 2 x 16 bit data (2 x 8 bit control/status)		
Configuration	No address setting, configuration via the Bus Coupler or the controller		
Pluggable wiring	for all KSxxxx Bus Terminals		
Weight	app. 50 g		
Permissible ambient temperature range during operation	0 °C ... + 55°C		
Permissible ambient temperature range during storage	-25 °C ... + 85°C		
Permissible relative air humidity	95 %, no condensation		
Dimensions (H x W x D)	app. 15 mm x 100 mm x 70 mm (aligned width: 12 mm)		
<a href="#">Mounting</a> <a href="#">▶ 17</a>	on 35 mm mounting rail according to EN 60715		
Vibration / shock resistance	conforms to EN 60068-2-6 / EN 60068-2-27		
EMC immunity / emission	conforms to EN 61000-6-2 / EN 61000-6-4		
Protection class	IP20		
Installation position	variable		
Approvals / markings	CE, UKCA, cULus, EAC, ATEX <a href="#">▶ 25</a> , IECEx <a href="#">▶ 26</a> , cFMus <a href="#">▶ 28</a>	CE, UKCA, EAC	CE, UKCA, EAC, ATEX <a href="#">▶ 25</a>

### Ex markings

Standard	KL2502-0000/ KS2502-0000	KL2502-0010	KL2512-0000/ KS2512-0000
ATEX	II 3 G Ex nA IIC T4 Gc II 3 D Ex tc IIIC T135 °C Dc	-	II 3 G Ex nA IIC T4 Gc
IECEX	Ex nA IIC T4 Gc Ex tc IIIC T135 °C Dc	-	-
cFMus	Class I, Division 2, Groups A, B, C, D Class I, Zone 2, AEx/Ex ec IIC T4 Gc	-	-

## 2.4 Basic Function Principles

The KL2502 output terminal modulates the pulse width of a binary signal. The peripheral side of the electronics is electrically isolated from the internal K-bus, and therefore also from the fieldbus. The cycle (base frequency) and the pulse/pause ratio are configurable. 16-bit values can be specified for setting purposes via the process image of the controller.

In the delivery state the KL2502 terminal occupies 6 bytes in the process image. The mapping of the KL2502 can be set by means of the controller or by the Bus Coupler's configuration interface using the Beckhoff KS2000 configuration software.

In addition to PWM mode, the KL2502 can also be operated in FM mode (frequency modulation), or with pulse direction setting for stepper motor control (Frq-Cnt pulse mode).

The default setting of the terminal in delivery state is PWM mode with a base frequency of 250 Hz and a resolution of 10 bit.

The LEDs indicate the operating state of the associated terminal channels.

- green Run LED:
  - On: normal operation
  - Off: Watchdog timer overflow has occurred. If no process data are transmitted by the Bus Coupler for 100 ms, the green LEDs go out. The output assumes a user-specified voltage (see Feature register).

### Process data

Input format:

KL2502: Two's complement representation (integer -1 corresponds to 0xFFFF)  
The ratio of duty cycle/period is specified with a maximum resolution of 10 bit.

KL2512: 16 bit unsigned integer

Output value	Process data		
	KL2502	KL2512*	
0 % Duty Cycle	0x0000 (0 <sub>dec</sub> )	0x7FFF (32767 <sub>dec</sub> )	0xFFFF (65535 <sub>dec</sub> )
50 % Duty Cycle	0x3FFF (16383 <sub>dec</sub> )	0x3FFF (16383 <sub>dec</sub> )	0xBFFF (49151 <sub>dec</sub> )
100 % Duty Cycle	0x7FFF (32767 <sub>dec</sub> )	0x0000 (0 <sub>dec</sub> )	0x8000 (32768 <sub>dec</sub> )


\*) The KL2512 passes through the output values (0...100 % duty cycle) twice.

## 2.5 Operation modes

The operating mode of the terminal is set via feature register [R32 \[► 43\]](#).

### PWM mode

2 channels can be operated in the PWMx modes. Note that the operating mode and the cycle duration for both channels are identical.



## PWMH

In PWM mode, the ratio of duty cycle to cycle duration is determined by the process data.

100 % duty cycle corresponds to process record 0x7FFF. The cycle duration can be specified during operation via register [R2 \[► 41\]](#). It is loaded after a system start-up from register [R35 \[► 43\]](#) (SEEROM) and entered into R2.

The frequency range covers 245 Hz to 20 kHz (0xFA0 in R2 corresponds to 250 Hz) with a resolution of 10 bit at 245 Hz, 976 Hz and 3.9 kHz.

## PWML

In PWM mode, the ratio of duty cycle to cycle duration is determined by the process data. 100 % duty cycle corresponds to process record 0x7FFF (32767). The cycle duration can be specified during operation via register [R2 \[► 41\]](#). It is loaded after a system start-up from register [R35 \[► 43\]](#) (SEEROM) and entered into R2.

The frequency range is from 2 Hz to 250 Hz (250 Hz corresponds to 0x01F4 in R2).

## Frq-Cnt PWM mode

The frequency is specified in 2 Hz per digit via the process output data of the control. The controller receives the number of periods that are output by the terminal as process input data. In this operating mode, the count direction is determined via the sign of the output data. 2 Hz corresponds to the value 0x0001, -2 Hz corresponds to the value 0xFFFF (signed integer). The frequency range is 2 Hz to 2 kHz. The pulses are issued at output A1, the count direction at output A2. *Down* corresponds to signal level GND, *up* corresponds to signal level Vcc (24 V).

With rising edge of control bit 0 the counter is set to the value of the output data (control byte in process data mode, i.e. bit 7=0).

The pulse width ratio is specified via [R36 \[► 43\]](#).

## Frq-Cnt pulse mode

The frequency is specified in 2 Hz per digit via the process output data of the control. The controller receives the number of pulses that are output by the terminal as process input data. In this operating mode, the count direction is determined via the sign of the output data. 2 Hz corresponds to the value 0x0001, -2 Hz corresponds to the value 0xFFFF (signed integer). The pulses are issued at output A1, the count direction at output A2. *Down* corresponds to signal level GND, *up* corresponds to signal level Vcc. The frequency range is 2 Hz to 2 kHz.

With rising edge of control bit 0 the counter is set to the value of the output data. (Control byte in process data mode, i.e. bit7=0).

The pulse width is fixed for all frequencies and is specified via [R37 \[► 43\]](#).

## Cnt-Cnt PWM mode

The number of pulses is specified via the process output data. The controller receives the number of output periods as process input data. The pulse width ratio is specified via [R36 \[► 43\]](#), the cycle duration via [R35 \[► 43\]](#). The output is started with a positive edge of control bit 0. It can be triggered with each additional edge. The pulses are issued at output A1, output A2 can be set via control bit 2. In status bit 0 the controller receives the transfer and the simultaneous start of the pulse output as status information. Status bit 1 remains set as long as the output is active and status bit 2 returns the status of channel 1.

## 3 Mounting and wiring

### 3.1 Instructions for ESD protection

#### NOTE

##### **Destruction of the devices by electrostatic discharge possible!**

The devices contain components at risk from electrostatic discharge caused by improper handling.

- Please ensure you are electrostatically discharged and avoid touching the contacts of the device directly.
- Avoid contact with highly insulating materials (synthetic fibers, plastic film etc.).
- Surroundings (working place, packaging and personnel) should be grounded probably, when handling with the devices.
- Each assembly must be terminated at the right hand end with a KL9010 bus end terminal, to ensure the protection class and ESD protection.



Fig. 4: Spring contacts of the Beckhoff I/O components

## 3.2 Installation on mounting rails

### ⚠ WARNING

#### Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the bus terminals!

#### Assembly




Fig. 5: Attaching on mounting rail

The bus coupler and bus terminals are attached to commercially available 35 mm mounting rails (DIN rails according to EN 60715) by applying slight pressure:

1. First attach the fieldbus coupler to the mounting rail.
2. The bus terminals are now attached on the right-hand side of the fieldbus coupler. Join the components with tongue and groove and push the terminals against the mounting rail, until the lock clicks onto the mounting rail.

If the terminals are clipped onto the mounting rail first and then pushed together without tongue and groove, the connection will not be operational! When correctly assembled, no significant gap should be visible between the housings.

#### **i** Fixing of mounting rails

The locking mechanism of the terminals and couplers extends to the profile of the mounting rail. At the installation, the locking mechanism of the components must not come into conflict with the fixing bolts of the mounting rail. To mount the mounting rails with a height of 7.5 mm under the terminals and couplers, you should use flat mounting connections (e.g. countersunk screws or blind rivets).

## Disassembly




Fig. 6: Disassembling of terminal

Each terminal is secured by a lock on the mounting rail, which must be released for disassembly:

1. Pull the terminal by its orange-colored lugs approximately 1 cm away from the mounting rail. In doing so for this terminal the mounting rail lock is released automatically and you can pull the terminal out of the bus terminal block easily without excessive force.
2. Grasp the released terminal with thumb and index finger simultaneous at the upper and lower grooved housing surfaces and pull the terminal out of the bus terminal block.

## Connections within a bus terminal block

The electric connections between the Bus Coupler and the Bus Terminals are automatically realized by joining the components:

- The six spring contacts of the K-Bus/E-Bus deal with the transfer of the data and the supply of the Bus Terminal electronics.
- The power contacts deal with the supply for the field electronics and thus represent a supply rail within the bus terminal block. The power contacts are supplied via terminals on the Bus Coupler (up to 24 V) or for higher voltages via power feed terminals.

### **i** Power Contacts

During the design of a bus terminal block, the pin assignment of the individual Bus Terminals must be taken account of, since some types (e.g. analog Bus Terminals or digital 4-channel Bus Terminals) do not or not fully loop through the power contacts. Power Feed Terminals (KL91xx, KL92xx or EL91xx, EL92xx) interrupt the power contacts and thus represent the start of a new supply rail.

## PE power contact

The power contact labeled PE can be used as a protective earth. For safety reasons this contact mates first when plugging together, and can ground short-circuit currents of up to 125 A.




Fig. 7: Power contact on left side

### NOTE

#### Possible damage of the device

Note that, for reasons of electromagnetic compatibility, the PE contacts are capacitatively coupled to the mounting rail. This may lead to incorrect results during insulation testing or to damage on the terminal (e.g. disruptive discharge to the PE line during insulation testing of a consumer with a nominal voltage of 230 V). For insulation testing, disconnect the PE supply line at the Bus Coupler or the Power Feed Terminal! In order to decouple further feed points for testing, these Power Feed Terminals can be released and pulled at least 10 mm from the group of terminals.

### ⚠ WARNING

#### Risk of electric shock!

The PE power contact must not be used for other potentials!

## 3.3 Connection

### 3.3.1 Connection system

#### ⚠ WARNING

#### Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the bus terminals!

#### Overview

The bus terminal system offers different connection options for optimum adaptation to the respective application:

- The terminals of ELxxxx and KLxxxx series with standard wiring include electronics and connection level in a single enclosure.
- The terminals of ESxxxx and KSxxxx series feature a pluggable connection level and enable steady wiring while replacing.
- The High Density Terminals (HD Terminals) include electronics and connection level in a single enclosure and have advanced packaging density.

#### Standard wiring (ELxxxx / KLxxxx)



Fig. 8: Standard wiring

The terminals of ELxxxx and KLxxxx series have been tried and tested for years. They feature integrated screwless spring force technology for fast and simple assembly.

#### Pluggable wiring (ESxxxx / KSxxxx)



Fig. 9: Pluggable wiring

The terminals of ESxxxx and KSxxxx series feature a pluggable connection level. The assembly and wiring procedure is the same as for the ELxxxx and KLxxxx series. The pluggable connection level enables the complete wiring to be removed as a plug connector from the top of the housing for servicing. The lower section can be removed from the terminal block by pulling the unlocking tab. Insert the new component and plug in the connector with the wiring. This reduces the installation time and eliminates the risk of wires being mixed up.

The familiar dimensions of the terminal only had to be changed slightly. The new connector adds about 3 mm. The maximum height of the terminal remains unchanged.

A tab for strain relief of the cable simplifies assembly in many applications and prevents tangling of individual connection wires when the connector is removed.

Conductor cross sections between 0.08 mm<sup>2</sup> and 2.5 mm<sup>2</sup> can continue to be used with the proven spring force technology.

The overview and nomenclature of the product names for ESxxxx and KSxxxx series has been retained as known from ELxxxx and KLxxxx series.

### High Density Terminals (HD Terminals)



Fig. 10: High Density Terminals

The terminals from these series with 16 terminal points are distinguished by a particularly compact design, as the packaging density is twice as large as that of the standard 12 mm bus terminals. Massive conductors and conductors with a wire end sleeve can be inserted directly into the spring loaded terminal point without tools.

---

#### ● Wiring HD Terminals



The High Density Terminals of the ELx8xx and KLx8xx series doesn't support pluggable wiring.

---

### Ultrasonically “bonded” (ultrasonically welded) conductors

---

#### ● Ultrasonically “bonded” conductors



It is also possible to connect the Standard and High Density Terminals with ultrasonically “bonded” (ultrasonically welded) conductors. In this case, please note the tables concerning the wire-size width!

---

### 3.3.2 Wiring

#### ⚠ WARNING

#### Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the bus terminals!

#### Terminals for standard wiring ELxxxx/KLxxxx and for pluggable wiring ESxxxx/KSxxxx




Fig. 11: Connecting a cable on a terminal point

Up to eight terminal points enable the connection of solid or finely stranded cables to the bus terminal. The terminal points are implemented in spring force technology. Connect the cables as follows:

1. Open a terminal point by pushing a screwdriver straight against the stop into the square opening above the terminal point. Do not turn the screwdriver or move it alternately (don't toggle).
2. The wire can now be inserted into the round terminal opening without any force.
3. The terminal point closes automatically when the pressure is released, holding the wire securely and permanently.

See the following table for the suitable wire size width.

Terminal housing	ELxxxx, KLxxxx	ESxxxx, KSxxxx
Wire size width (single core wires)	0.08 ... 2.5 mm <sup>2</sup>	0.08 ... 2.5 mm <sup>2</sup>
Wire size width (fine-wire conductors)	0.08 ... 2.5 mm <sup>2</sup>	0,08 ... 2.5 mm <sup>2</sup>
Wire size width (conductors with a wire end sleeve)	0.14 ... 1.5 mm <sup>2</sup>	0.14 ... 1.5 mm <sup>2</sup>
Wire stripping length	8 ... 9 mm	9 ... 10 mm

#### High Density Terminals (HD Terminals [[▶ 21](#)]) with 16 terminal points

The conductors of the HD Terminals are connected without tools for single-wire conductors using the direct plug-in technique, i.e. after stripping the wire is simply plugged into the terminal point. The cables are released, as usual, using the contact release with the aid of a screwdriver. See the following table for the suitable wire size width.

Terminal housing	High Density Housing
Wire size width (single core wires)	0.08 ... 1.5 mm <sup>2</sup>
Wire size width (fine-wire conductors)	0.25 ... 1.5 mm <sup>2</sup>
Wire size width (conductors with a wire end sleeve)	0.14 ... 0.75 mm <sup>2</sup>
Wire size width (ultrasonically "bonded" conductors)	only 1.5 mm <sup>2</sup>
Wire stripping length	8 ... 9 mm

### 3.3.3 Shielding



#### Shielding

Encoder, analog sensors and actors should always be connected with shielded, twisted paired wires.

### 3.4 Contact assignment and LEDs

**⚠ WARNING**

**Risk of injury through electric shock and damage to the device!**

Bring the Bus Terminal system into a safe, voltage-free state before starting mounting, disassembly or wiring of the Bus Terminals!




Fig. 12: KL2502, KL2512 - Contact assignment and LEDs

KL2502/KS2502, KL2512/KS2512 Contact assignment		
Terminal point	No.	Comment
Output 1	1	Output 1
+24V	2	+24 V (internally connected to terminal point 6 and positive power contact)
0V	3	0 V (internally connected to terminal point 7 and negative power contact)
PE	4	PE connection
Output 2	5	Output 2
+24V	6	+24 V (internally connected to terminal point 2 and positive power contact)
0V	7	0 V (internally connected to terminal point 3 and negative power contact)
PE	8	PE connection

KL2502/KS2502, KL2512/KS2512 LED display		
LED	Color	Description
Signal LED 1.2	green	On: normal operation Off: Watchdog timer overflow has occurred. If no process data is transferred from the Bus Coupler for 100 ms, the green LED goes out and the outputs are set to 0% duty cycle.

### 3.5 ATEX - Special conditions (standard temperature range)

#### ⚠ WARNING

**Observe the special conditions for the intended use of Beckhoff fieldbus components with standard temperature range in potentially explosive areas (directive 2014/34/EU)!**

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60079-15! The environmental conditions during use are thereby to be taken into account!
- For dust (only the fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9): The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to EN 60079-31 for group IIIA or IIIB and IP6X for group IIIC, taking into account the environmental conditions under which the equipment is used!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of 0 to 55°C for the use of Beckhoff fieldbus components standard temperature range in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

#### Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010
- EN 60079-31:2013 (only for certificate no. KEMA 10ATEX0075 X Issue 9)

#### Marking

The Beckhoff fieldbus components with standard temperature range certified according to the ATEX directive for potentially explosive areas bear one of the following markings:



**II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: 0 ... +55°C**

II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: 0 ... +55°C  
(only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

or



**II 3G KEMA 10ATEX0075 X Ex nA nC IIC T4 Gc Ta: 0 ... +55°C**

II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: 0 ... +55°C  
(only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

## 3.6 IECEx - Special conditions

### ⚠ WARNING

#### Observe the special conditions for the intended use of Beckhoff fieldbus components in potentially explosive areas!

- For gas: The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to IEC 60079-15, taking into account the environmental conditions under which the equipment is used!
- For dust (only the fieldbus components of certificate no. IECEx DEK 16.0078X Issue 3):  
The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to EN 60079-31 for group IIIA or IIIB and IP6X for group IIIC, taking into account the environmental conditions under which the equipment is used!
- The equipment shall only be used in an area of at least pollution degree 2, as defined in IEC 60664-1!
- Provisions shall be made to prevent the rated voltage from being exceeded by transient disturbances of more than 119 V!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range for the use of Beckhoff fieldbus components in potentially explosive areas!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The front hatch of certified units may only be opened if the supply voltage has been switched off or a non-explosive atmosphere is ensured!

### Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2011
- EN 60079-15:2010
- EN 60079-31:2013 (only for certificate no. IECEx DEK 16.0078X Issue 3)

### Marking

Beckhoff fieldbus components that are certified in accordance with IECEx for use in areas subject to an explosion hazard bear the following markings:

Marking for fieldbus components of certificate no. IECEx DEK 16.0078X Issue 3:	<b>IECEx DEK 16.0078 X</b>
	<b>Ex nA IIC T4 Gc</b>
	<b>Ex tc IIIC T135°C Dc</b>

Marking for fieldbus components of certificates with later issues:	<b>IECEx DEK 16.0078 X</b>
	<b>Ex nA IIC T4 Gc</b>

## 3.7 Continulative documentation for ATEX and IECEx

---



### Continulative documentation about explosion protection according to ATEX and IECEx

Pay also attention to the continuative documentation

#### **Ex. Protection for Terminal Systems**

Notes on the use of the Beckhoff terminal systems in hazardous areas according to ATEX and IECEx

that is available for [download](#) on the Beckhoff homepage [www.beckhoff.com](http://www.beckhoff.com)!

---

## 3.8 cFMus - Special conditions

### ⚠ WARNING

#### Observe the special conditions for the intended use of Beckhoff fieldbus components in potentially explosive areas!

- The equipment shall be installed within an enclosure that provides a minimum ingress protection of IP54 in accordance with ANSI/UL 60079-0 (US) or CSA C22.2 No. 60079-0 (Canada).
- The equipment shall only be used in an area of at least pollution degree 2, as defined in IEC 60664-1.
- Transient protection shall be provided that is set at a level not exceeding 140% of the peak rated voltage value at the supply terminals to the equipment.
- The circuits shall be limited to overvoltage Category II as defined in IEC 60664-1.
- The Fieldbus Components may only be removed or inserted when the system supply and the field supply are switched off, or when the location is known to be non-hazardous.
- The Fieldbus Components may only be disconnected or connected when the system supply is switched off, or when the location is known to be non-hazardous.

#### Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

M20US0111X (US):

- FM Class 3600:2018
- FM Class 3611:2018
- FM Class 3810:2018
- ANSI/UL 121201:2019
- ANSI/ISA 61010-1:2012
- ANSI/UL 60079-0:2020
- ANSI/UL 60079-7:2017

FM20CA0053X (Canada):

- CAN/CSA C22.2 No. 213-17:2017
- CSA C22.2 No. 60079-0:2019
- CAN/CSA C22.2 No. 60079-7:2016
- CAN/CSA C22.2 No.61010-1:2012

#### Marking

Beckhoff fieldbus components that are certified in accordance with cFMus for use in areas subject to an explosion hazard bear the following markings:

FM20US0111X (US):      **Class I, Division 2, Groups A, B, C, D**  
                                   **Class I, Zone 2, AEx ec IIC T4 Gc**

FM20CA0053X (Canada):      **Class I, Division 2, Groups A, B, C, D**  
                                   **Ex ec T4 Gc**

### 3.9 Continulative documentation for cFMus

---

#### **i** Continulative documentation about explosion protection according to cFMus

Pay also attention to the continuative documentation

#### **Control Drawing I/O, CX, CPX**

Connection diagrams and Ex markings

that is available for [download](#) on the Beckhoff homepage [www.beckhoff.com](http://www.beckhoff.com)!

---

### 3.10 Disposal



Products marked with a crossed-out wheeled bin shall not be discarded with the normal waste stream. The device is considered as waste electrical and electronic equipment. The national regulations for the disposal of waste electrical and electronic equipment must be observed.

## 4 Configuration Software KS2000

### 4.1 KS2000 - Introduction

The KS2000 configuration software permits configuration, commissioning and parameterization of bus couplers, of the affiliated bus terminals and of Fieldbus Box Modules. The connection between bus coupler / Fieldbus Box Module and the PC is established by means of the serial configuration cable or the fieldbus.



Fig. 13: KS2000 configuration software

#### Configuration

You can configure the Fieldbus stations with the Configuration Software KS2000 offline. That means, setting up a terminal station with all settings on the couplers and terminals resp. the Fieldbus Box Modules can be prepared before the commissioning phase. Later on, this configuration can be transferred to the terminal station in the commissioning phase by means of a download. For documentation purposes, you are provided with the breakdown of the terminal station, a parts list of modules used and a list of the parameters you have modified. After an upload, existing fieldbus stations are at your disposal for further editing.

#### Parameterization

KS2000 offers simple access to the parameters of a fieldbus station: specific high-level dialogs are available for all bus couplers, all intelligent bus terminals and Fieldbus Box modules with the aid of which settings can be modified easily. Alternatively, you have full access to all internal registers of the bus couplers and intelligent terminals. Refer to the register description for the meanings of the registers.

## Commissioning

The KS2000 software facilitates commissioning of machine components or their fieldbus stations: Configured settings can be transferred to the fieldbus modules by means of a download. After a *login* to the terminal station, it is possible to define settings in couplers, terminals and Fieldbus Box modules directly *online*. The same high-level dialogs and register access are available for this purpose as in the configuration phase.

The KS2000 offers access to the process images of the bus couplers and Fieldbus Box modules.

- Thus, the coupler's input and output images can be observed by monitoring.
- Process values can be specified in the output image for commissioning of the output modules.

All possibilities in the *online mode* can be used in parallel with the actual fieldbus mode of the terminal station. The fieldbus protocol always has the higher priority in this case.

## 5 Access from the user program

### 5.1 Terminal configuration

The terminal can be configured and parameterized via the internal register structure. Each terminal channel is mapped in the Bus Coupler. Mapping of the terminal data in the Bus Coupler memory may differ, depending on the Bus Coupler type and the set mapping configuration (e.g. Motorola/Intel format, word alignment etc.). In contrast to the analog input and output terminals, in the KL2502 the control byte and the status byte are **always** mapped, irrespective of the fieldbus system used.

#### BK2000 Lightbus coupler

With the BK2000 Lightbus coupler, the control/status byte is always mapped in addition to the data bytes (i.e. for all analog terminals). This is always located in the low byte at the offset address of the terminal channel.




Fig. 14: Mapping in the Lightbus coupler – example for KL2502

#### Profibus coupler BK3000

With the BK3000 Profibus coupler, the KL2502 is represented by 6 bytes of input data and 6 bytes of output data (3 bytes per channel) as standard. Thus, 2 bytes of user data and 1 byte control/status data are mapped per channel.




Fig. 15: Mapping in the Profibus coupler – example for KL2502

#### BK4000 Interbus Coupler

In delivery state, the BK4000 Interbus Coupler maps the terminals with 6 bytes of input data and 6 bytes of output data. Parameterization via the fieldbus is not possible. If the control and status byte is to be used, the KS2000 configuration software is required.




Fig. 16: Mapping in the Interbus coupler – example for KL2502

**Other Bus Couplers and further information**

Further information about the mapping configuration of Bus Couplers can be found in the Appendix of the respective Bus Coupler manual under *Master configuration*.

The chapter on Mapping in the Bus Coupler contains an overview of possible mapping configurations, depending on the configurable parameters.

**● Parameterization with KS2000**

**i** The KS2000 configuration software can be used for parameterizations via the serial interface of the Bus Coupler, independent of the fieldbus system.

**5.2 Mapping in the Bus Coupler**

As already described in the Terminal Configuration chapter, each Bus Terminal is mapped in the Bus Coupler. This mapping is usually done with the default setting in the Bus Coupler / Bus Terminal. The KS2000 configuration software or a master configuration software (e.g. ComProfibus or TwinCAT System Manager) can be used to change this default setting.

If the terminals are fully evaluated, they occupy memory space in the input and output process image.

The following tables provide information about how the terminals map themselves in the Bus Coupler, depending on the parameters set.

The KL2502 is mapped with 6 bytes of input and output data.

**5.2.1 KL2502**

**Default mapping for: CANopen, CANCAL, DeviceNet, ControlNet, Modbus, RS232 and RS485 coupler**

Conditions	Word offset	High byte	Low byte
Complete evaluation: any	0	Ch1 D0	Ch1 CB/SB
Motorola format: no	1	Ch2 CB/SB	Ch1 D1
Word alignment: no	2	Ch2 D1	Ch2 D0
	3	-	-

**Default mapping for: Profibus and Interbus Coupler**

Conditions	Word offset	High byte	Low byte
Complete evaluation: any	0	Ch1 D1	Ch1 CB/SB
Motorola format: yes	1	Ch2 CB/SB	Ch1 D0
Word alignment: no	2	Ch2 D0	Ch2 D1
	3	-	-

### Default mapping for: Lightbus, EtherCAT and Ethernet coupler as well as Bus Terminal Controller (BCxxxx, BXxxxx)

Conditions	Word offset	High byte	Low byte
Complete evaluation: any Motorola format: no Word alignment: yes	0	res.	Ch1 CB/SB
	1	Ch1 D1	Ch1 D0
	2	res.	Ch2 CB/SB
	3	Ch2 D1	Ch2 D0

Conditions	Word offset	High byte	Low byte
Complete evaluation: any Motorola format: yes Word alignment: yes	0	res.	Ch1 CB/SB
	1	Ch1 D0	Ch1 D1
	2	res.	Ch2 CB/SB
	3	Ch2 D0	Ch2 D1

### Key

Complete evaluation	The terminal is mapped with control and status byte.
Motorola format	Motorola or Intel format can be set.
Word alignment	The terminal is positioned on a word boundary in the Bus Coupler.
Ch n CB	Control byte for channel n (appears in the process image of the outputs).
Ch n SB	Status byte for channel n (appears in the process image of the inputs).
Ch n D0	Channel n, data byte 0 (byte with the lowest value)
Ch n D1	Channel n, data byte 1 (byte with the highest value)
"-"	This byte is not used or occupied by the terminal.
res.	Reserved: this byte is assigned to the process data memory, although it has no function.

### 5.3 Control and status byte

The control and status byte is transmitted from the controller to the terminal. It can be used

- at register communication [▶ 35] ( $REG = 1_{bin}$ ) or
- in process data exchange ( $REG = 0_{bin}$ ).

#### 5.3.1 Register communication

##### Register access via process data exchange

- **Bit 7=1: Register mode**  
If bit 7 of the control byte is set, the first two bytes of the user data are not used for process data exchange but written into the register set of the terminal or read from it.
- **Bit 6=0: read, bit 6=1: write**  
Bit 6 of the control bytes is used to specify whether a register should be read or written.
  - **Bit 6=0:** a register is read without changing it. The value can be found in the input process image.
  - **Bit 6=1:** the user data are written to a register. The process is complete once the status byte in the input process image has returned an acknowledgment (see example).
- **Bit 0 to 5: Address**  
The address of the register to be addressed is entered in bits 0 to 5 of the control byte.

##### Control byte in register mode (REG=1)

MSB

REG=1	W/R	A5	A4	A3	A2	A1	A0
-------	-----	----	----	----	----	----	----

$REG = 0_{bin}$ : Process data exchange  
 $REG = 1_{bin}$ : Access to register structure

$W/R = 0_{bin}$ : Read register  
 $W/R = 1_{bin}$ : Write register

A5..A0 = register address  
 Addresses A5...A0 can be used to address a total of 64 registers.




Fig. 17: Register mode control byte

The control or status byte occupies the lowest address of a logical channel. The corresponding register values are located in the following 2 data bytes. (The BK2000 is an exception: here, an unused data byte is inserted after the control or status byte, and the register value is therefore placed on a word boundary).

**Example 1:****Reading of register 8 in the BK2000 with a KL3022 and the end terminal:**

If the following bytes are transferred from the controller to the terminal,

Byte	Byte 3	Byte 2	Byte 1	Byte 0
<b>Name</b>	Data out, low byte	Data out, high byte	Not used	Control byte
<b>Value</b>	0xXX	0xXX	0xXX	0x88

the terminal returns the following type identifier (0x0BBA corresponds to unsigned integer 3022).

Byte	Byte 3	Byte 2	Byte 1	Byte 0
<b>Name</b>	Data in, low byte	Data in, high byte	Not used	Status byte
<b>Value</b>	0xCE	0x0B	0x00	0x88

**Example 2:****Write register 31 in the BK2000 with an intelligent and the end terminal:**

If the following bytes (code word [▶ 42]) are transferred from the controller to the terminal,

Byte	Byte 3	Byte 2	Byte 1	Byte 0
<b>Name</b>	Data out, low byte	Data out, high byte	Not used	Control byte
<b>Value</b>	0x35	0x12	0xXX	0xDF

The code word [▶ 42] is set, and the terminal returns the register address with bit 7 for register access as acknowledgment.

Byte	Byte 3	Byte 2	Byte 1	Byte 0
<b>Name</b>	Data in, low byte	Data in, high byte	Not used	Status byte
<b>Value</b>	0x00	0x00	0x00	0x9F

## 5.4 Examples of Register Communication

The numbering of the bytes in the examples corresponds to the display without word alignment.

### 5.4.1 Example 1: reading the firmware version from Register 9

#### Output Data

Byte 0: Control byte	Byte 1: DataOUT1, high byte	Byte 2: DataOUT1, low byte
0x89 (1000 1001 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 9 with 00 1001<sub>bin</sub>.
- The output data word (byte 1 and byte 2) has no meaning during read access. To change a register, write the required value into the output word.

#### Input Data (answer of the Bus Terminal)

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0x89	0x33	0x41

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the firmware version 0x3341 in the input data word (byte 1 and byte 2). This is to be interpreted as an ASCII code:
  - ASCII code 0x33 represents the digit 3
  - ASCII code 0x41 represents the letter A
 The firmware version is thus 3A.

### 5.4.2 Example 2: Writing to a user register



#### Code word

In normal mode all user registers are read-only with the exception of Register 31. In order to deactivate this write protection you must write the code word (0x1235) into Register 31. If a value other than 0x1235 is written into Register 31, write protection is reactivated. Please note that changes to a register only become effective after restarting the terminal (power-off/power-on).

#### I. Write the code word (0x1235) into Register 31.

#### Output Data

Byte 0: Control byte	Byte 1: DataOUT1, high byte	Byte 2: DataOUT1, low byte
0xDF (1101 1111 <sub>bin</sub> )	0x12	0x35

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111<sub>bin</sub>.

- The output data word (byte 1 and byte 2) contains the code word (0x1235) for deactivating write protection.

### Input Data (answer of the Bus Terminal)

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0x9F (1001 1111 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

## II. Read Register 31 (check the set code word)

### Output Data

Byte 0: Control byte	Byte 1: DataOUT1, high byte	Byte 2: DataOUT1, low byte
0x9F (1001 1111 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111<sub>bin</sub>.
- The output data word (byte 1 and byte 2) has no meaning during read access.

### Input Data (answer of the Bus Terminal)

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0x9F (1001 1111 <sub>bin</sub> )	0x12	0x35

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the current value of the code word register in the input data word (byte 1 and byte 2).

## III. Write to Register 32 (change contents of the feature register)

### Output data

Byte 0: Control byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0xE0 (1110 0000 <sub>bin</sub> )	0x00	0x02

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000<sub>bin</sub>.
- The output data word (byte 1 and byte 2) contains the new value for the feature register.

**⚠ CAUTION**

**Observe the register description!**

The value of 0x0002 given here is just an example!

The bits of the feature register change the properties of the terminal and have a different meaning, depending on the type of terminal. Refer to the description of the feature register of your terminal (chapter *Register description*) regarding the meaning of the individual bits before changing the values.

**Input data (response from the Bus Terminal)**

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0xA0 (1010 0000 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

**IV. Read Register 32 (check changed feature register)**

**Output Data**

Byte 0: Control byte	Byte 1: DataOUT1, high byte	Byte 2: DataOUT1, low byte
0xA0 (1010 0000 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000<sub>bin</sub>.
- The output data word (byte 1 and byte 2) has no meaning during read access.

**Input Data (answer of the Bus Terminal)**

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0xA0 (1010 0000 <sub>bin</sub> )	0x00	0x02

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the current value of the feature register in the input data word (byte 1 and byte 2).

**V. Write Register 31 (reset code word)**

**Output Data**

Byte 0: Control byte	Byte 1: DataOUT1, high byte	Byte 2: DataOUT1, low byte
0xDF (1101 1111 <sub>bin</sub> )	0x00	0x00

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111<sub>bin</sub>.
- The output data word (byte 1 and byte 2) contains 0x0000 for reactivating write protection.

**Input Data (answer of the Bus Terminal)**

Byte 0: Status byte	Byte 1: DataIN1, high byte	Byte 2: DataIN1, low byte
0x9F (1001 1111 <sub>bin</sub> )	0xXX	0xXX

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

## 5.5 Register overview

These registers exist once for each channel.

Register	Designation	Default value	R/W	Storage medium
R0	reserved	0x0000 (0 <sub>dec</sub> )	R	
R1	reserved	0x0000 (0 <sub>dec</sub> )	R	
R2 [▶ 41]	Cycle duration	variable	R/W	RAM
R3 [▶ 41]	Base frequency	variable	R/W	RAM
R4	reserved	0x0000 (0 <sub>dec</sub> )	R	
R5 [▶ 41]	PWM raw value	variable	R	RAM
R6	Diagnostic register not used	0x0000 (0 <sub>dec</sub> )	R	
R7	Command register - reserved	0x0000 (0 <sub>dec</sub> )	R/W	
R8 [▶ 41]	Terminal type	0x09C6 (2502 <sub>dec</sub> ), 0x09D0 (2512 <sub>dec</sub> )	R	ROM
R9 [▶ 41]	Software version number	0x????	R	ROM
R10 [▶ 41]	Multiplex shift register	0x0218 (536 <sub>dec</sub> ), 0x0130 (304 <sub>dec</sub> )	R	ROM
R11 [▶ 41]	Signal channels	0x0218 (536 <sub>dec</sub> )	R	ROM
R12 [▶ 41]	Minimum data length	0x1818 (6468 <sub>dec</sub> )	R	ROM
R13 [▶ 42]	Data structure	0x0000 (0 <sub>dec</sub> )	R	ROM
R14	reserved	0x0000 (0 <sub>dec</sub> )	R	
R15 [▶ 42]	Alignment register	variable	R/W	RAM
R16 [▶ 42]	Hardware version number	0x????	R/W	EEPROM
R17, R18	reserved	0x0000 (0 <sub>dec</sub> )	R/W	EEPROM
R19 [▶ 42]	Manufacturer scaling: Offset	0x0000 (0 <sub>dec</sub> )	R/W	EEPROM
R20 [▶ 42]	Manufacturer scaling: Gain	0x0100 (256 <sub>dec</sub> )	R/W	EEPROM
R21...R30	reserved	0x0000 (0 <sub>dec</sub> )	R	EEPROM
R31 [▶ 42]	Code word register	variable	R/W	RAM
R32 [▶ 43]	Feature register	0x0004 (4 <sub>dec</sub> ) <sup>1</sup> 0xA0B4 (41140 <sub>dec</sub> ) <sup>2</sup>	R/W	EEPROM
R33 [▶ 43]	User offset	0x0000 (0 <sub>dec</sub> )	R/W	EEPROM
R34 [▶ 43]	User gain	0x0100 (256 <sub>dec</sub> )	R/W	EEPROM
R35 [▶ 43]	Cycle duration PWM	0x0FA0 (4000 <sub>dec</sub> )	R/W	EEPROM
R36 [▶ 43]	Duty cycle	0x4000 (16384 <sub>dec</sub> )	R/W	EEPROM
R37 [▶ 43]	Pulse duration (T_impulse)	0x0005 (5 <sub>dec</sub> )	R/W	EEPROM
R38...R63 <sup>1</sup>	reserved	0x0000 (0 <sub>dec</sub> )	R/W	EEPROM
R38 [▶ 43] <sup>2</sup>	Maximum frequency step size (F_delta)	0x0010 (16 <sub>dec</sub> )	R/W	EEPROM
R39 [▶ 43] <sup>2</sup>	Start frequency (F_start)	0x0080 (128 <sub>dec</sub> )	R/W	EEPROM
R40 [▶ 43] <sup>2</sup>	Time base (T_delta)	0x0010 (16 <sub>dec</sub> )	R/W	EEPROM

<sup>1</sup>) for KL2502-0000 and KL2512-0000

<sup>2</sup>) for KL2502-0010

## 5.6 Register description

The registers can be read or written via the register communication. They are used for the parameterization of the terminal.

### R0 to R7: Registers in the internal RAM of the terminal

The process variables can be used in addition to the actual process image. Their function is specific to the terminal.

- **R0, R1: no function**
- **R2 cycle duration**  
In PWM mode, you can specify the cycle duration for ongoing operation. Following a power-on reset, the cycle duration is taken from [R35](#) [[▶ 43](#)] (cycle duration for PWM mode).
  - PWMH mode, Cnt-Cnt PWM mode:  
1 digit corresponds to 1  $\mu$ s  
Example: 250 Hz => 4000  $\mu$ s = 0xFA0  
4 KHz => 250  $\mu$ s = 0xFA
  - PWML mode, Frq-Cnt PWM mode, Frq-Cnt pulse mode:  
1 digit corresponds to 8  $\mu$ s  
Example: 2 Hz => 500 ms = 0xF424  
200 Hz => 5 ms = 0x271
- **R3 base frequency**  
In PWM mode the base frequency can be specified here. [R/W]  
1 digit corresponds to 1 Hz
- **R4: Reserved**
- **R5: PWM raw value**  
The raw value of the processor PWM unit is stored in this register. This value can be used to calculate the maximum resolution at a specified frequency.
- **R6: Diagnostic register**  
not used
- **R7: Command register**  
High-Byte\_Write = function parameter  
Low-Byte\_Write = function number  
High-Byte\_Read = function result  
Low-Byte\_Read = function number

### R8 to R15: Registers in the internal ROM of the terminal

The type and system parameters are hard programmed by the manufacturer, and the user can read them but cannot change them.

- **R8: Terminal type**  
The terminal type in register R8 is needed to identify the terminal.
- **R9: Software version (X.y)**  
The software version can be read as a string of ASCII characters.
- **R10: Data length**  
R10 contains the number of multiplexed shift registers and their length in bits.  
The Bus Coupler sees this structure.
- **R11: Signal channels**  
Related to R10, this contains the number of channels that are logically present. Thus for example a shift register that is physically present can perfectly well consist of several signal channels.
- **R12: Minimum data length**  
The particular byte contains the minimum data length for a channel that is to be transferred. If the MSB is set, the control and status byte is not necessarily required for the terminal function and is not transferred to the control, if the Bus Coupler is configured accordingly.

- **R13: Data type register**

Data type register	Meaning
0x00	Terminal with no valid data type
0x01	Byte array
0x02	Structure 1 byte n bytes
0x03	Word array
0x04	Structure 1 byte n words
0x05	Double word array
0x06	Structure 1 byte n double words
0x07	Structure 1 byte 1 double word
0x08	Structure 1 byte 1 double word
0x11	Byte array with variable logical channel length
0x12	Structure 1 byte n bytes with variable logical channel length (e.g. 60xx)
0x13	Word array with variable logical channel length
0x14	Structure 1 byte n words with variable logical channel length
0x15	Double word array with variable logical channel length
0x16	Structure 1 byte n double words with variable logical channel length

- **R14: reserved**
- **R15: Alignment bits (RAM)**  
The alignment bits are used to place the analog terminal in the Bus Coupler on a byte boundary.

### R16 to R30: Manufacturer parameter area (SEEROM)

The manufacturer parameters are specific for each type of terminal. They are programmed by the manufacturer, but can also be modified by the controller. The manufacturer parameters are stored in a serial EEPROM in the terminal, and are retained in the event of voltage drop-out.

These registers can only be altered after a code word has been set in R31 [▶ 42].

- **R16: Hardware version number**  
Register R16 contains the hardware version of the terminal.
- **R19: Manufacturer scaling - offset (B<sub>h</sub>)**  
16 bit signed integer  
Line equation:  $Y = A_h X + B_h$   
This register contains the offset of the manufacturer's linearization equation. The line equation is enabled via feature register R32 [▶ 43].
- **R20: Manufacturer scaling - gain (A<sub>h</sub>)**  
16 bit signed integer\*2<sup>-8</sup>  
This register contains the scale factor of the manufacturer's linearization equation. The line equation is enabled via feature register R32 [▶ 43].  
1 corresponds to register value 0x0100.

### R31 to R47: User parameter area (SEEROM)

The user parameters are specific for each type of terminal. They can be modified by the programmer. The user parameters are stored in a serial EEPROM in the terminal, and are retained in the event of voltage drop-out. The user area is write-protected by a code word.

### R31: Code word register in RAM

#### ● **Functionality of the code word register**

**i** The code word **0x1235** must be entered here so that parameters in the user area can be modified. If any other value is entered into this register, the write-protection is active. When write protection is not active, the code word is returned when the register is read. If the write protection is active, the register contains a zero value.

- **R32: Feature register**

[0x0004] for KL2502-0000 and KL2512-0000

[0xA0B4] for KL2502-0010

This register specifies the operation mode of the terminal. Thus, for instance, a user-specific scaling can be enabled for the analog I/Os.

Feature bit no.		Description of the operation mode	
Bit 0	1	User scaling active [0]	
Bit1	1	Manufacturer scaling active [0]	
Bit 2	0	[0] watchdog timer active; the PWM signal is set to 0 % duty cycle if the terminal does not receive any data for 100 ms.	
Bit 3*	1	Jitter-free pulse output has priority over K-bus cycle	
Bit 4*	1	Interpolation is active	
Bit 5...12	0	Reserved, do not modify!	
Bit 13...15		<b>Operation mode</b>	<b>Range of values</b>
	000	PWMH mode	250 Hz ... 20 kHz
	001	PWML mode	2 Hz ... 250 Hz
	011	Frq-Cnt PWM mode	2 Hz ... 2 kHz
	101	Frq-Cnt pulse mode	2 Hz ... 2 kHz
	111	Cnt-Cnt PWM mode	250 Hz ... 8 kHz

\*) KL2502-0010 only

- **R33: User scaling - offset (B\_w)**

16 bit signed integer

Line equation:  $Y = A_w X + B_w$

This register contains the offset of the user linearization equation. The line equation is enabled via feature register [R32](#) [[▶ 43](#)].

- **R34: User scaling - gain (A\_w)**

16 bit signed integer\*2<sup>-8</sup>

This register contains the scale factor of the user linearization equation. The line equation is enabled via feature register [R32](#) [[▶ 43](#)].

- **R35: Cycle duration for PWM mode**

[0x0FA0]

After a processor restart, the cycle duration of [R35](#) [[▶ 43](#)] is entered in R2.

During operation it can be modified via [R2](#) [[▶ 41](#)] (cycle duration) or [R3](#) [[▶ 41](#)] (base frequency).

The input takes place as described under R2.

- **R36: Duty cycle**

[0x4000]

The ratio of duty cycle to cycle duration in Frq-Cnt PWM mode and Cnt-Cnt PWM mode is determined by this register.

0x2000 corresponds to 25 % duty cycle

0x4000 corresponds to 50 % duty cycle.

- **R37: Pulse duration for Frq-Cnt pulse mode (T\_impulse)**

[0x0005]

This register is used to enter the pulse duration in Frq-Cnt pulse mode.

KL2502-0000, KL2512-0000: 1 digit corresponds to 8 µs.

KL2502-0010: 1 digit corresponds to 2 µs

- **R38: Maximum frequency step size (F\_delta), KL2502-0010 only**

Sets the maximum frequency step size for interpolation.

1 digit corresponds to 8 Hz

- **R39: Start frequency (F\_start), KL2502-0010 only**

[0x0080]

Above the start frequency the interpolation starts with the maximum frequency step size.

- **R40: Time base (T\_delta), KL2502-0010 only**

[0x0010]

Time base for frequency interpolation in 64 µs/digit

Value range: 0 ... 255

Values smaller than 250 µs are not possible.

## 6 Appendix

### 6.1 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

#### **Beckhoff's branch offices and representatives**

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages: <https://www.beckhoff.com>

You will also find further documentation for Beckhoff components there.

#### **Beckhoff Support**

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963 157  
Fax: +49 5246 963 9157  
e-mail: [support@beckhoff.com](mailto:support@beckhoff.com)

#### **Beckhoff Service**

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963 460  
Fax: +49 5246 963 479  
e-mail: [service@beckhoff.com](mailto:service@beckhoff.com)

#### **Beckhoff Headquarters**

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20  
33415 Verl  
Germany

Phone: +49 5246 963 0  
Fax: +49 5246 963 198  
e-mail: [info@beckhoff.com](mailto:info@beckhoff.com)  
web: <https://www.beckhoff.com>

## Table of figures

Fig. 1	BIC as data matrix code (DMC, code scheme ECC200).....	8
Fig. 2	KL2502 - Two-channel pulse width output terminal 24 VDC .....	10
Fig. 3	KL2512 - Two-channel pulse width output terminal 24 VDC, ground switching .....	12
Fig. 4	Spring contacts of the Beckhoff I/O components.....	16
Fig. 5	Attaching on mounting rail .....	17
Fig. 6	Disassembling of terminal.....	18
Fig. 7	Power contact on left side.....	19
Fig. 8	Standard wiring.....	20
Fig. 9	Pluggable wiring .....	20
Fig. 10	High Density Terminals.....	21
Fig. 11	Connecting a cable on a terminal point .....	22
Fig. 12	KL2502, KL2512 - Contact assignment and LEDs .....	24
Fig. 13	KS2000 configuration software.....	30
Fig. 14	Mapping in the Lightbus coupler – example for KL2502.....	32
Fig. 15	Mapping in the Profibus coupler – example for KL2502 .....	32
Fig. 16	Mapping in the Interbus coupler – example for KL2502 .....	33
Fig. 17	Register mode control byte.....	35



More Information:  
[www.beckhoff.com/KL2xxx](http://www.beckhoff.com/KL2xxx)

Beckhoff Automation GmbH & Co. KG  
Hülshorstweg 20  
33415 Verl  
Germany  
Phone: +49 5246 9630  
[info@beckhoff.com](mailto:info@beckhoff.com)  
[www.beckhoff.com](http://www.beckhoff.com)

