



Installation and Operating instructions for
Control Cabinet PCs C63xx - 0020

Version: 1.4
Date: 2009-08-20

BECKHOFF

Table of contents

1. General instructions	3
Notes on the Documentation	3
Liability Conditions	3
Description of safety symbols	3
Basic safety measures	4
Operator's obligation to exercise diligence	5
Operator requirements	5
2. Product Description	6
Appropriate Use	6
Structure C63x5 – 0020	6
Structure C63x0 – 0020	7
Interfaces	9
USB interfaces	9
Network connection	9
DVI interface	9
USB interface	9
Serial interface	9
Additional plug-in cards (optional)	9
3. Installation Instructions	10
Transport and Unpacking	10
Transport	10
Unpacking	10
Installation of the PC in the control cabinet	11
Power Supply Connection	12
Electrical data	12
Pin assignment of the connector	12
Fitting the cable	13
Material for assembling the connectors	13
Assembling the connectors	13
Connecting Power Supply	14
Cable Cross Sections	14
PC_ON, Power-Status	14
Wiring diagram	14
Connecting devices	15
Connecting cables	15
Check voltage rating and connect	15
4. Operating Instructions	16
Switching the Industrial PC on and off	16
First switching on and driver installation	16
Maintenance	17
Cleaning the Industrial PC	17
Replacing the battery on the motherboard	17
Servicing	17
Shutting down	17
Disposal	17
5. UPS Software Components (optional)	18
Installation on the PC	18
Help files	18

6. Troubleshooting	19
Fault correction	19
Beckhoff Support & Service	20
Beckhoff branches and partner companies	20
Beckhoff Headquarters	20
Beckhoff Support	20
Beckhoff Service	20
7. Assembly dimensions	21
8. Appendix	27
Technical data	27
Approvals	27
FCC: Federal Communications Commission Radio Frequency Interference Statement	27
FCC: Canadian Notice	27

General instructions

Notes on the Documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards. It is essential that the following notes and explanations are followed when installing and commissioning these components.

Liability Conditions

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

The documentation has been prepared with care. The products described are, however, constantly under development. For that reason the documentation is not in every case checked for consistency with performance data, standards or other characteristics. None of the statements of this manual represents a guarantee (Garantie) in the meaning of § 443 BGB of the German Civil Code or a statement about the contractually expected fitness for a particular purpose in the meaning of § 434 par. 1 sentence 1 BGB. In the event that it contains technical or editorial errors, we retain the right to make alterations at any time and without warning. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

© This documentation is copyrighted. Any reproduction or third party use of this publication, whether in whole or in part, without the written permission of Beckhoff Automation GmbH, is forbidden.

Description of safety symbols

The following safety symbols are used in this operating manual. They are intended to alert the reader to the associated safety instructions.



Danger

This symbol is intended to highlight risks for the life or health of personnel.



Warning

This symbol is intended to highlight risks for equipment, materials or the environment.



Note

This symbol indicates information that contributes to better understanding.

Basic safety measures

Only switch the PC off after closing the software

Before the Industrial PC is switched off, software that is running must be properly closed.

Otherwise it is possible that data on the hard disk is lost. Please read the section on [Switching the Industrial PC on and off](#).



Warning

Switch off all parts of the equipment, then uncouple the fieldbus!

Before opening the housing of the PC, and whenever the PC is being used for purposes other than plant control, such as during functional tests following repair, all parts of the equipment must first be switched off, after which the Industrial PC can be uncoupled from the plant.

Pulling out the fieldbus connection plug uncouples the PC (optional).

Items of equipment that have been switched off must be secured against being switched on again.

The Industrial PC's power supply unit must be supplied with 24 V_{DC}.



Danger

Do not exchange any parts when under power!

When components are being fitted or removed, the supply voltage must be switched off.

Fitting work on the Industrial PC can result in damage:

- If metal objects such as screws or tools fall onto operating circuit boards.
- If connecting cables internal to the PC are removed or inserted during operation.
- If plug-in cards are removed or inserted when the PC is switched on.

Operator's obligation to exercise diligence

The operator must ensure that

- the Industrial PC is only used for its intended use (see also [Product Description](#) chapter).
- the Industrial PC is in a sound condition and in working order during operation.
- the operation manual is in good condition and complete, and always available for reference at the location of the Industrial PC.
- the Industrial PC is operated, maintained and repaired only by sufficiently qualified and authorized personnel.
- the personnel is instructed regularly about relevant occupational safety and environmental protection aspects, and is familiar with the operating manual and in particular the safety notes contained herein.
- none of the safety and warning notes attached to the Industrial PC are removed, and that all notes remain legible.

National regulations depending on the machine type

Depending on the type of machine and plant in which the Industrial PC is being used, there will be national regulations for the control of such machines and plant that the operator must observe. These regulations cover, amongst other things, the intervals between inspections of the controller.

The operator must initiate such inspections in good time.



Warning

Only trained persons may open the Industrial PC housing!

The operator is responsible for ensuring that only trained electrical staff opens the housing of the Industrial PC.

Procedure in the event of a fault

In the event of a fault in the Industrial PC, appropriate measures can be determined with the aid of the list in the [Fault correction](#) section.

Operator requirements

Read the operating instructions

Every user of the Industrial PC must have read these operating instructions.

Software knowledge

Every user must be familiar with any of the functions of the software installed on the PC that he can reach.

Product Description

Appropriate Use

The C63xx – 0020 series Industrial PCs in connection with a DVI / USB-Control-Panel CP68xx or CP78xx are designed for mounting in control cabinets for machine and plant engineering applications.

Structure C63x5 – 0020

Example: Front view of Industrial PC C6335 – 0020 in basic configuration



Opening the housing


To open the PC housing, release the screw (1) by one turn using a screwdriver. The plastic cap (2) can then be pulled forward, thereby releasing the lid (3).

Top view of the open housing



The aluminium lid can now be lifted off. The heatsink (1) enables the fanless operation up to an ambient air temperature of 45 °C.

*View of the open PC
C6335 – 0020*




The computer chassis can now be removed from the housing. The power supply and the hard disk are located in the lower part of the chassis (1) of the C6335 – 0020. The C6325–0020 is equipped with a flash-disk instead of the hard disk, through which this PC makes do without mechanically agitated parts.

The slot motherboard (2) is located in the second slot of the housing.

The Slim Line CD-ROM drive (3) is visible right on the picture (only C6335–0020).

Structure C63x0 – 0020


*Example: Front view of
Industrial PC C6350 – 0020
in basic configuration*



Opening the housing


To open the PC housing, release the screw (1) by one turn using a screwdriver. The plastic cap (2) can be then be pulled forward, thereby releasing the lid (3).

Top view of the open housing



The aluminium lid can now be lifted off. Avoid damaging the electrical supply line to the fan (1)!

View of the open PC C6350 – 0020




The computer chassis can now be removed from the housing. The power supply and the hard disk are located in the lower part of the chassis (1). The slot motherboard (2) is located in the second slot of the housing.

The Slim Line CD-ROM drive (3) is visible right on the picture (only C6330 – 0020 and C6350 – 0020).

Interfaces

*Interfaces to the
C63xx-0020 Industrial PCs*



USB interfaces

USB1 – USB2

The two USB interfaces (1) and (2) are used for connecting the Control Panel CP68xx or CP78xx. USB2.0 standard is supported.

Alternatively, peripheral devices with USB port may be connected.

Network connection

Network

The PC is connected with the local network via the 10/100 Base-T RJ-45 connectors (3) and (4) of the On-Board Ethernet adapter.

DVI interface

DVI-I

The DVI interface (5) is used for connecting the Control Panel CP68xx or CP78xx. Alternatively, a monitor with DVI input or VGA input can be connected.

For connecting a monitor with VGA input the adapter C9900-Z411 or C9900-Z413 is required additionally:

- C9900-Z411: Adapter plug DVI-I to VGA
- C9900-Z413: Adapter cable DVI-I to DVI and VGA, 15cm

USB interface

USB3

An additional USB-interface (6) is used for connecting peripheral devices with USB port. USB2.0 standard is supported.

Serial interface

*RS 232
COM2*

The basic version of the C63xx - 0020 Industrial PC has one serial interface COM2, using the type RS232, which is brought to a 9 pin SUB-D plug connector. The COM1 interface is internally connected to the power supply unit.



Additional plug-in cards (optional)

Type plate

A type plate is located at the plastic cap of the PC housing, providing information about the Industrial PC equipment as delivered.

Installation Instructions

Please also refer to chapter [General instructions](#).

Transport and Unpacking

The specified storage conditions must be observed (see chapter [Technical data](#)).

Transport

Despite the robust design of the unit, the components are sensitive to strong vibrations and impacts. During transport, your Industrial PC should therefore be protected from excessive mechanical stress. Therefore, please use the original packaging.



Warning

Danger of damage to the unit!

If the device is transported in cold weather or is exposed to extreme variations in temperature, make sure that moisture (condensation) does not form on or inside the device.

Prior to operation, the unit must be allowed to slowly adjust to room temperature. Should condensation occur, a delay time of approximately 12 hours must be allowed before the unit is switched on.

Unpacking

Proceed as follows to unpack the unit:

1. Remove packaging.
2. Do not discard the original packaging. Keep it for future relocation.
3. Check the delivery for completeness by comparing it with your order.
4. Please keep the associated paperwork. It contains important information for handling the unit.
5. Check the contents for visible shipping damage.
6. If you notice any shipping damage or inconsistencies between the contents and your order, you should notify Beckhoff Service.

Installation of the PC in the control cabinet

The C63xx - 0020 Industrial PCs are designed for mounting in control cabinets for machine and plant engineering applications.

The ambient conditions specified for operation must be observed (see chapter [Technical data](#)).

Preparation of the control cabinet

Four holes for the fixing bolts have to be provided in the control cabinet according to the dimensions of the PC (see chapter [Assembly dimensions](#)).



Note

When the unit is installed in an enclosure, adequate space for ventilation and for opening the PC must be provided.



Warning

Extreme environmental conditions should be avoided as far as possible. Protect the PC from dust, moisture and heat.

The ventilation slots of the PC must not be covered.

Earthing measures

Earthing connections dissipate interference from external power supply cables, signal cables or cables to peripheral equipment.



Establish a low-impedance connection from the earthing point on the PC housing to the central earthing point on the control cabinet wall, in which the computer is being installed. The earthing connection is located at the top of the housing (see photograph on the left).

Power Supply Connection

Supplied mains power unit

The Industrial PC is fitted with a 24 V_{DC} power supply unit .

Optional an uninterruptible power supply (UPS) can be realized using the battery pack C9900-U330.



Danger

Danger of Explosion if using other battery packs!

Electrical data

Input voltage: 22 – 30 V DC
 Current consumption: 10 A (22 V)
 Power consumption: 150 W (max.)

Current carrying capacity of the 24 V power supply unit


Output voltages from the 24 V power supply unit	Current loading maximum
+ 5 V	10 A
- 5 V	0.2 A
+ 12 V	8 A
- 12 V	0.4 A
+ 3.3 V	12 A
5 V VSB	1.5 A

Pin assignment of the connector

The Industrial PC becomes switched on and off with an external circuit. Therefore, a 5-pole plug connector (pin 1–pin 5) is located at the PC housing.

The Industrial PC is connected to the power supply via the lower 5-pole plug connector (Pin 6 – Pin 10).

Pin assignment for connecting the switch, the power supply and the battery pack (optional)



Upper Connector	
Pin	Function
1	PC_ON
2	Power-Status
3	⊕
4	-
5	+
24 V DC Power supply	
Lower Connector	
Pin	Function
6	-
7	+
8	⊕
9	-
10	+
24 V DC Power supply	


Fitting the cable

Wiring in accordance with wiring diagram


Fit the cables for the power supply of the Industrial PC, the connection of the battery pack as well as the connection of the power-switch in accordance with the wiring diagram, using the included material for assembling the connectors.

Material for assembling the connectors

Material for assembling the connectors



Plug connector 5-pole



Strain relief housing with lacing cord

Assembling the connectors

Conductive cross-section

The connector is specified for 16 A and can lift conductive cross-sections until 1,5 mm².

Fitting the connector to the cable

So the connector is fitted to the cable:


1. Strip insulation from the cable ends (Length of stripped conductor is 8 – 9 mm).
2. Screw together the cable ends in the 5-pole plug connector in accordance with wiring diagram.

Applying the strain relief




Thread the lacing cord into that lower part of the strain relief housing.

Putting in the plug connector



Put the plug connector into that lower part of the strain relief housing. Tighten the lacing cord and pinch off the plastic strap.

Fixing the upper part of the strain relief housing



Fix the upper part of the strain relief housing by snapping it onto the lower part.

Connecting Power Supply

The external wiring consists of the connection of the power supply, the battery pack (optional) and the connection of customised components for shutting down the PC.

Cable Cross Sections

Note cable cross sections, avoid voltage drop!

For the connection of the power supply, wiring with a cable-cross-section of 1,5 mm² must be used.

With bigger distances between voltage source and PC, you take the voltage drop as a function of the cable-cross-section as well as voltage fluctuations of your distribution voltage into account, so that is secured that the voltage doesn't fall under 22 V at the power supply.

Insert Fuse

The power supply must be protected with 16 A.

PC_ON, Power-Status



The circuit for shutting down the Industrial PC is realized using the input-signal **PC_ON** and the output-signal **Power-Status**:

- The PC starts shutting down if 24 V exists at **PC_ON**, for example using a switch.
- After shutting down, the output-voltage of 24 V at **Power-Status** is switched to 0 V. This allows for example connecting an air gap switch for disconnecting the system from power supply.

Wiring diagram

Wiring according to the wiring diagram (the circuit of PC_ON and Power-Status is symbolical):

Wiring diagram external switch and power supply



Connecting devices



Warning

The power supply plug must be withdrawn!

Please read the documentation for the external devices prior to connecting them.

During thunderstorms, plug connector must neither be inserted nor removed.

When disconnecting a plug connector, always handle it at the plug. Do not pull the cable!

Connecting cables

The connections are located at the top of the Industrial PC and are documented in the product description chapter.

When connecting the cables to the Industrial PC, proceed according to the following sequence:

- Switch off all the devices that are to be connected.
- Disconnect all the devices that are to be connected from the power supply.
- Connect all the cables between the Industrial PC and to the devices that are to be connected.
- Connect all data transfer cables (if present) to the appropriate plug-in receptacles of the data/telecommunication networks.
- Reconnect all devices to the power supply.

Check voltage rating and connect

Fitted with the 24 V_{DC} power supply unit:

1. Check that the external power supply is providing the correct voltage.
2. Insert the power supply cable that you have assembled (see the section [Fitting the cable](#)) into the Industrial PC's power supply socket. Then connect it to your external 24 V power supply.



Warning

If a 24 V UPS is installed, the same type of rechargeable battery must be used.

Operating Instructions

Please also refer to chapter [General instructions](#).

Switching the Industrial PC on and off

Switch on

The Industrial PC does not have its own mains switch. The Industrial PC will start when the equipment is switched on, or when it is connected to the power supply.

Shutting down and switching off

When the plant is switched off, or when it is disconnected from its power supply, the Industrial PC will be switched off.

Control software such as is typically used on Industrial PCs permits various users to be given different rights. A user who may not close software may also not switch the Industrial PC off, since data can be lost from the hard disk by switching off while software is running.



Warning

First shut down, then switch off the PC!

If the Industrial PC is switched off as the software is writing a file to the hard disk, the file will be destroyed. Control software typically writes something to the hard disk every few seconds, so that the probability of causing damage by switching off while the software is running is very high.



Warning

When you have shut down the Industrial PC, you have to switch off power supply for at least 10 seconds before rebooting the system. After resetting power supply the PC will start booting automatically.

First switching on and driver installation

When you switch on the Industrial PC for the first time, the pre-installed operating system (optional) will be started. In this case, all the required drivers for any additional, optional hardware components ordered with the PC will already have been installed.

If the PC was ordered without operating system, you have to install the operating system and the driver software for any auxiliary hardware yourself. Please follow the instructions in the documentation for the operating system and the additional devices.

Maintenance

Please also refer to chapter [General instructions](#).



Danger

Cleaning the Industrial PC

Switch off the Industrial PC and all connected devices, and disconnect the Industrial PC from the power supply.

The Industrial PC can be cleaned with a soft, damp cloth. Do not use any aggressive cleaning materials, thinners, scouring material or hard objects that could cause scratches.



Danger

Replacing the battery on the motherboard

A used battery on the motherboard has to be replaced according to the rules of the board manufacturer.

Danger of Explosion if battery is incorrectly replaced. Replace only with same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Servicing

The Industrial PC requires no maintenance.

Shutting down

Disposal

Dismantling the Industrial PC

The device must be fully dismantled in order to dispose of it. The housing can be sent for metal recycling.

Observe national electronics scrap regulations

Electronic parts such as disk drives and circuit boards must be disposed of in accordance with national electronics scrap regulations.

UPS Software Components (optional)

Installing the UPS driver software

For operating the power supply unit as a UPS, the UPS driver software and the associated UPS driver must be installed on the Industrial PC.

On delivery of the Beckhoff Industrial PC with operating system the software is already installed. Should the software not be installed on your PC, the drivers can be installed from the driver CD provided.

Installation on the PC

Installation

To install the UPS driver software, execute file **Beckhoff_UPS_vx.xx.xx.exe** from the subdirectory of **UPS\...** from the CD provided on the Industrial PC (Driver-archive for the Industrial-PC, C9900-S700-xxxx).

The program is self-extracting and will guide the user through the installation routine.

Help files

Beckhoff Information System

The driver software comes with a detailed help function. The help files can be called up either directly from the configuration register by clicking the Help button, or under via *Start > Programs > Beckhoff > UPS software components*.

Troubleshooting

Please also refer to chapter [General instructions](#).

Fault correction

Fault	Cause	Procedure
Nothing happens after the Industrial PC has been switched on	No power supply to the Industrial PC.	Check power supply cable.
	Other cause.	Call Beckhoff Service.
The Industrial PC does not boot fully	Floppy disk or CD in the drive.	Remove floppy disk or CD and press any key.
	Setup settings are incorrect.	Check the setup settings.
	Other cause.	Call Beckhoff Service.
Computer boots, software starts, but control does not operate correctly	Cause of the fault is either in the software or in parts of the plant outside the Industrial PC.	Call the manufacturer of the machine or the software.
Floppy disk or CD access error	Faulty disk or CD.	Check disk or CD in another drive.
	Faulty disk drive.	Call Beckhoff Service.
The Industrial PC functions only partially or only part of the time, e.g. no or dark picture, but disk drive responds when switching on	Defective components in the Industrial PC.	Call Beckhoff Service.

Beckhoff Support & Service

Beckhoff and their partners around the world offer comprehensive support and service, guaranteeing fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff branches and partner companies

Please contact your Beckhoff branch office or partner company for [local support and service](#) on Beckhoff products!

The contact addresses for your country can be found in the list of Beckhoff branches and partner companies: www.beckhoff.com

You will also find further [documentation](#) for Beckhoff components there.

Beckhoff Headquarters

Beckhoff Automation GmbH
Eiserstraße 5
33415 Verl
Germany

Phone: +49(0)5246/963-0
Fax: +49(0)5246/963-198
e-mail: info@beckhoff.com

Beckhoff Support

Beckhoff offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with wide-ranging services:

- worldwide support
- design, programming and commissioning of complex automation systems
- training program for Beckhoff system components

Hotline: +49(0)5246/963-157
Fax: +49(0)5246/963-9157
e-mail: support@beckhoff.com

Beckhoff Service

The Beckhoff service center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49(0)5246/963-460
Fax: +49(0)5246/963-479
e-mail: service@beckhoff.com

Quote the project number If servicing is required, please quote the **project number** of your product.

Assembly dimensions


The following pages show diagrams of the Industrial PCs, with dimensions in mm.



The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6320-0020


Mounting plate at the side panel



front view

side view

Mounting plate at the rear panel



front view

side view




Warning


The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6325-0020

Mounting plate at the side panel




front view




side view

Mounting plate at the rear panel



front view



side view




Warning

The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6330-0020


Mounting plate at the side panel



front view

side view

Mounting plate at the rear panel



front view

side view




Warning

The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6335-0020


Mounting plate at the side panel



front view

side view

Mounting plate at the rear panel



front view

side view




Warning


The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6340-0020

Mounting plate at the side panel




front view




side view

Mounting plate at the rear panel



front view



side view




Warning

The assembly of the unit must take place with the orientation diagrammed here.

Industrial-PC C6350-0020


Mounting plate at the side panel



front view

side view

Mounting plate at the rear panel



front view

side view

Appendix

Technical data

<i>Industrial-PC C6320-0020</i>	Dimensions (W x H x D):	93 x 196 x 226 mm (without mounting plate)
	Weight:	4,0 kg (basic configuration)
<i>Industrial-PC C6325-0020</i>	Dimensions (W x H x D):	133 x 196 x 226 mm (without mounting plate)
	Weight:	6,0 kg (basic configuration)
<i>Industrial-PC C6330-0020</i>	Dimensions (W x H x D):	107 x 196 x 226 mm (without mounting plate)
	Weight:	4,6 kg (basic configuration)
<i>Industrial-PC C6335-0020</i>	Dimensions (W x H x D):	147 x 196 x 226 mm (without mounting plate)
	Weight:	6,6 kg (basic configuration)
<i>Industrial-PC C6340-0020</i>	Dimensions (W x H x D):	134 x 196 x 226 mm (without mounting plate)
	Weight:	4,5 kg (basic configuration)
<i>Industrial-PC C6350-0020</i>	Dimensions (W x H x D):	148 x 196 x 226 mm (without mounting plate)
	Weight:	5,1 kg (basic configuration)

Do not use the PC in areas of explosive hazard

The Industrial PC may not be used in areas of explosive hazard.

Environmental conditions

The following conditions must be observed during operation:

Ambient temperature: 0 to 55°C
Atmospheric humidity: Maximum 95%, non-condensing

Shock resistance

Sinusoidal vibration:
(EN 60068-2-6) 10 to 58 Hz: 0.035 mm
 58 to 500 Hz: 0.5 G (~ 5 m/ s²)
During reading of CD-ROM: 10 to 58 Hz: 0.019 mm
 58 to 500 Hz: 0.25 G (~ 2.5 m/ s²)

Impact:
(EN 60068-2-27/ -29) 5 G (~ 50 m/ s²), duration: 30 ms
During reading of CD-ROM: 5 G (~ 50 m/ s²), duration: 11 ms

Protection class

Protection class: IP20

Power supply
24 V_{DC} power pack

Supply voltage: 22–30V V_{DC}
Power consumption: 150 W for the basic version

Electromagnetic Compatibility (EMC)

Interference resistance: according to EN 61000-6-2
Emitted resistance: according to EN 61000-6-4

Transport and storage

The same values for atmospheric humidity and shock resistance are to be observed during transport and storage as in operation. The shock resistance during transport can be improved by means of suitably packing the Industrial PC. The ambient temperature during storage and transport must be between -20°C and +65°C.

Approvals

FCC: Federal Communications Commission Radio Frequency Interference Statement

FCC Approval for USA

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC: Canadian Notice

FCC Approval for Canada

This equipment does not exceed the Class A limits for radiated emissions as described in the Radio Interference Regulations of the Canadian Department of Communications.