

Documentation | EN

EP9576-1032

Brake chopper box



Table of contents

| | |
|---|-----------|
| 1 Foreword | 5 |
| 1.1 Notes on the documentation | 5 |
| 1.2 Safety instructions | 6 |
| 1.3 Documentation issue status | 7 |
| 2 EtherCAT Box - Introduction | 8 |
| 3 Product overview | 10 |
| 3.1 Introduction | 10 |
| 3.2 Block diagram | 11 |
| 3.3 Technical data | 11 |
| 3.4 Scope of supply..... | 12 |
| 3.5 Process image | 13 |
| 3.6 Technology..... | 15 |
| 4 Mounting and connections | 16 |
| 4.1 Mounting | 16 |
| 4.1.1 Dimensions | 16 |
| 4.1.2 Fixing..... | 17 |
| 4.1.3 Functional earth (FE) | 17 |
| 4.2 Connections | 18 |
| 4.2.1 Supply voltages..... | 18 |
| 4.2.2 EtherCAT | 20 |
| 4.3 Disposal | 22 |
| 5 Commissioning and configuration | 23 |
| 5.1 Integrating into a TwinCAT project..... | 23 |
| 5.2 Open the parameter directory (CoE)..... | 23 |
| 5.3 Chopper | 24 |
| 5.4 Measured values | 25 |
| 5.4.1 Temperatures..... | 25 |
| 5.4.2 Current and voltage..... | 27 |
| 5.5 Protective functions | 28 |
| 5.5.1 Overtemperature protection | 28 |
| 5.5.2 Overcurrent protection | 28 |
| 5.6 Restoring the delivery state..... | 29 |
| 5.7 Decommissioning..... | 30 |
| 6 CoE parameters | 31 |
| 6.1 Object directory | 31 |
| 6.2 Object description | 32 |
| 6.2.1 Objects for parameterization..... | 32 |
| 6.2.2 Objects for information and diagnostics | 33 |
| 6.2.3 Standard objects | 34 |
| 6.2.4 PDO Mapping and PDO Assignment..... | 36 |
| 6.2.5 Sync manager objects..... | 38 |
| 7 Appendix | 40 |
| 7.1 General operating conditions | 40 |

| | | |
|-------|--|----|
| 7.2 | Accessories | 41 |
| 7.3 | Version identification of EtherCAT devices | 42 |
| 7.3.1 | General notes on marking..... | 42 |
| 7.3.2 | Version identification of IP67 modules | 43 |
| 7.3.3 | Beckhoff Identification Code (BIC)..... | 44 |
| 7.3.4 | Electronic access to the BIC (eBIC)..... | 46 |
| 7.4 | Support and Service..... | 48 |

1 Foreword

1.1 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

The qualified personnel is obliged to always use the currently valid documentation.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 Safety instructions

Safety regulations

Please note the following safety instructions and explanations!
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

Personal injury warnings

⚠ DANGER

Hazard with high risk of death or serious injury.

⚠ WARNING

Hazard with medium risk of death or serious injury.

⚠ CAUTION

There is a low-risk hazard that could result in medium or minor injury.

Warning of damage to property or environment

NOTICE

The environment, equipment, or data may be damaged.

Information on handling the product



This information includes, for example:
recommendations for action, assistance or further information on the product.

1.3 Documentation issue status

| Version | Comment |
|---------|---|
| 1.1 | <ul style="list-style-type: none">• Added warning notices |
| 1.0 | <ul style="list-style-type: none">• First release |

Firmware and hardware versions

This documentation refers to the firmware and hardware version that was applicable at the time the documentation was written.

The module features are continuously improved and developed further. Modules having earlier production statuses cannot have the same properties as modules with the latest status. However, existing properties are retained and are not changed, so that older modules can always be replaced with new ones.

The firmware and hardware version (delivery state) can be found in the batch number (D-number) printed on the side of the EtherCAT Box.

Syntax of the batch number (D-number)

D: WW YY FF HH

WW - week of production (calendar week)

YY - year of production

FF - firmware version

HH - hardware version

Example with D no. 29 10 02 01:

29 - week of production 29

10 - year of production 2010

02 - firmware version 02

01 - hardware version 01

Further information on this topic: [Version identification of EtherCAT devices \[► 42\]](#).

2 EtherCAT Box - Introduction

The EtherCAT system has been extended with EtherCAT Box modules with protection class IP67. Through the integrated EtherCAT interface the modules can be connected directly to an EtherCAT network without an additional Coupler Box. The high-performance of EtherCAT is thus maintained into each module.

The extremely low dimensions of only 126 x 30 x 26.5 mm (h x w x d) are identical to those of the Fieldbus Box extension modules. They are thus particularly suitable for use where space is at a premium. The small mass of the EtherCAT modules facilitates applications with mobile I/O interface (e.g. on a robot arm). The EtherCAT connection is established via screened M8 connectors.




Fig. 1: EtherCAT Box Modules within an EtherCAT network

The robust design of the EtherCAT Box modules enables them to be used directly at the machine. Control cabinets and terminal boxes are now no longer required. The modules are fully sealed and therefore ideally prepared for wet, dirty or dusty conditions.

Pre-assembled cables significantly simplify EtherCAT and signal wiring. Very few wiring errors are made, so that commissioning is optimized. In addition to pre-assembled EtherCAT, power and sensor cables, field-configurable connectors and cables are available for maximum flexibility. Depending on the application, the sensors and actuators are connected through M8 or M12 connectors.

The EtherCAT modules cover the typical range of requirements for I/O signals with protection class IP67:

- digital inputs with different filters (3.0 ms or 10 μ s)
- digital outputs with 0.5 or 2 A output current
- analog inputs and outputs with 16 bit resolution
- Thermocouple and RTD inputs
- Stepper motor modules

XFC (eXtreme Fast Control Technology) modules, including inputs with time stamp, are also available.



Fig. 2: EtherCAT Box with M8 connections for sensors/actuators



Fig. 3: EtherCAT Box with M12 connections for sensors/actuators

● Basic EtherCAT documentation

i You will find a detailed description of the EtherCAT system in the Basic System Documentation for EtherCAT, which is available for download from our website (www.beckhoff.com) under Downloads.

3 Product overview


3.1 Introduction

NOTICE

Damage if operated without parameterization

If the chopper threshold is set too low, the braking resistor may be permanently active. This causes the box to overheat. Material damage is possible.

- Only apply U_p to the box after parameterization.
- Set the chopper parameters according to the specifications in the chapter [Chopper](#) [► 24].



The EP9576-1032 EtherCAT Box contains high-performance capacitors for stabilizing supply voltages. In connection with drive applications, reverse currents are stored and thus overvoltages are prevented. If the energy fed back exceeds the buffer capacity, it is dissipated.

The EP9576-1032 EtherCAT Box contains an integrated brake resistor for the dissipation of drive-related overvoltages. The brake resistor converts excess energy, generated when braking, motors into heat. The EP9576-1032 can be used in conjunction with the EP70xx stepper motor modules, the EP7211 servo motor modules or the EP7342 DC motor output stage.


The EP9576 features internal diagnostic functions. Warnings or error messages, e.g. on reaching/exceeding the permissible limit temperature values are signalled via EtherCAT.

Quick links

- [Technical data](#) [► 11]
- [Process image](#) [► 13]
- [Connections](#) [► 18]
- [Commissioning](#) [► 23]

3.2 Block diagram

The block diagram shows the distribution of the voltages U_S and U_P inside the EP9576-1032.



3.3 Technical data

All values are typical values over the entire temperature range, unless stated otherwise.

| EtherCAT | |
|----------------------|---|
| Connection | 2 x M8 socket, 4-pin, A-coded, shielded |
| Electrical isolation | 500 V |

| Supply voltages | |
|--------------------------------|--|
| Connection | Input: 7/8" plug, 5-pin, 16-UN thread Downstream connection: 7/8" socket, 5-pin, 16-UN thread |
| U_S nominal voltage | 24 V _{DC} (-15 % / +20 %) |
| U_S sum current $I_{S,sum}$ | max. 16 A at 40 °C |
| Current consumption from U_S | 120 mA |
| Rated voltage U_P | any up to 72 V |
| U_P Sum current $I_{P,sum}$ | max. 16 A at 40 °C |
| Current consumption from U_P | Chopper current in case of overvoltage. |

| U_P voltage stabilization | |
|---------------------------------------|-----------------------|
| Capacitance (internal) | 155 µF |
| Brake resistor (internal) | 11 Ω, 60 W |
| Chopper switch-on threshold | Can be set as desired |
| Brake resistor overcurrent switch-off | 15.5 A |
| Ripple current | max. 10 A |

| Housing data | |
|-----------------------|--|
| Dimensions W x H x D | 60 mm x 150 mm x 26.5 mm (without connector, without heat sink) |
| Material | PA6 (polyamide) |
| Installation position | variable |

| Environmental conditions | |
|--------------------------------------|--|
| Ambient temperature during operation | -25 ... +60 °C |
| Ambient temperature during storage | -40 ... +85 °C |
| Vibration / shock resistance | conforms to EN 60068-2-6 / EN 60068-2-27 |
| EMC immunity / emission | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP65, IP66, IP67 conforms to EN 60529 |

| Approvals / markings | |
|-----------------------------|--------------------------|
| Approvals / markings *) | CE, UL under preparation |

*) Real applicable approvals/markings see type plate on the side (product marking).

3.4 Scope of supply

Make sure that the following components are included in the scope of delivery:

- 1x EP9576-1032
- 2x protective cap for EtherCAT socket, M8, green (pre-assembled)
- 1x Protective cap for supply voltage output, 7/8", black (pre-fitted)
- 10x labels, blank (1 strip of 10)
















● Pre-assembled protective caps do not ensure IP67 protection

i Protective caps are pre-assembled at the factory to protect connectors during transport. They may not be tight enough to ensure IP67 protection.

Ensure that the protective caps are correctly seated to ensure IP67 protection.

3.5 Process image

TwinCAT displays the process image in a tree structure.

- ▲  Box 1 (EP9576-1032)
 - ▲  BCT Inputs
 -  Terminal Overtemperature
 -  I2T error
 -  I2T warning
 -  Overvoltage
 -  Undervoltage
 -  Chopper on
 -  Overcurrent Protection
 -  Input cycle counter
 -  DC link voltage
 -  Resistor Current
 -  Duty Cycle
 - ▶  WcState
 - ▶  InfoData

Terminal overtemperature

If TRUE: The internal temperature [[▶ 26](#)] is higher than the limit value:

- Factory setting: 80 °C
- Parameter 8000:14

I2T error

If TRUE: The temperature of the brake resistor [[▶ 25](#)] is higher than the limit value:

- Factory setting: 120 °C
- Parameter 8000:19

The chopper is disabled if the overtemperature protection [[▶ 28](#)] has not been disabled.

I2T warning

If TRUE: The temperature of the brake resistor [[▶ 25](#)] is higher than the limit value:

- Factory setting: 100 °C
- Parameter 8000:18

Overvoltage

If TRUE: The voltage U_p is higher than the overvoltage limit value:

- Factory setting: 50 V
- Parameter 8000:11

The chopper is active if it is not being inhibited by a protective function [[▶ 28](#)].

Undervoltage

If TRUE: The voltage U_p is lower than the undervoltage limit value:

- Factory setting: 22 V
- Parameter 8000:12

Chopper on

If TRUE: The chopper [[▶ 24](#)] is active. The brake resistor is currently converting electrical energy into thermal energy.

Overcurrent Protection

If TRUE: The chopper was disabled by the overcurrent protection [[▶ 28](#)].

Input cycle counter

DC link voltage

The measured value [[▶ 27](#)] of the voltage U_p . Unit: mV

Resistor Current



The measured value [[▶ 27](#)] of the current through the brake resistor. Unit: mA.

Duty Cycle

The current mark-to-space ratio of the chopper [[▶ 24](#)]. Unit: %.

Optional process data objects

You can [add a further process data object \[► 25\]](#) to the process image:


- ▲  BCT Load
 -  I2T load factor

I2T load factor

The current temperature of the brake resistor. Unit: °C.

3.6 Technology

The following figure shows an example of a voltage curve that illustrates the operation of EP9576-1032. The upper diagram shows the voltage U_p in mV, the lower diagram shows the activity of the chopper.



In this example, a motor output stage is supplied with $U_p = 24$ V. The overvoltage limit is set to 28 V.

Electrical energy is generated when the motor brakes or when the motor shaft is moved by an external torque. The voltage U_p increases.

If U_p exceeds the overvoltage limit, the brake chopper is switched on. The brake chopper controls the current through the braking resistor. In the braking resistor the excess energy is dissipated and converted to heat. The voltage U_p drops again.

4 Mounting and connections

4.1 Mounting


⚠ CAUTION

Hot surfaces.

Risk of burns.

- Do not touch the device during operation.
- Allow the device to cool down after operation before touching it.
- When installing, ensure that neighboring components are not damaged by heat.

4.1.1 Dimensions



All dimensions are given in millimeters.
The drawing is not true to scale.

Housing features

| | |
|------------------------|---|
| Housing material | PA6 (polyamide) |
| Sealing compound | polyurethane |
| Mounting | two mounting holes Ø 4.5 mm for M4 |
| Metal parts | brass, nickel-plated |
| Contacts | CuZn, gold-plated |
| Power feed through | max. 16 A at 40°C (according to IEC 60512-3) |
| Installation position | variable |
| Protection class | IP65, IP66, IP67 (conforms to EN 60529) when screwed together |
| Dimensions (H x W x D) | approx. 150 x 60 x 26.5 mm (without connectors) |

4.1.2 Fixing

NOTICE

Dirt during assembly

Dirty connectors can lead to malfunctions. Protection class IP67 can only be guaranteed if all cables and connectors are connected.


- Protect the plug connectors against dirt during the assembly.

Mount the module with two M4 screws in the centrally located mounting holes.

4.1.3 Functional earth (FE)

The [Fixing](#) [17](#) also serve as connections for the functional earth (FE).

Make sure that the box is earthed with low impedance via both fastening screws. You can achieve this, for example, by mounting the box on a grounded machine bed.



4.2 Connections


4.2.1 Supply voltages

NOTICE

Damage if operated without parameterization

If the chopper threshold is set too low, the braking resistor may be permanently active. This causes the box to overheat. Material damage is possible.

- Only apply U_p to the box after parameterization.
- Set the chopper parameters according to the specifications in the chapter [Chopper](#) [▶ 24].



4.2.1.1 Connectors

NOTICE

No functionality without U_s .

Overtages on U_p are not discharged if U_s is missing. Defect possible.

- Connect not only U_p but also U_s .

NOTICE

The permitted sum current must not be exceeded.

Risk of defect.

- Ensure that the maximum permitted sum current of 16 A at 40 °C flows through each pin.
- Incorporate the transmitted supply current into the calculation.


| Input X60 7/8" connector | Downstream con- nection X61 7/8" socket | Pin | Symbol | Description |
|--------------------------------|--|-----|---------|---------------------------------------|
| | | 1 | GND_P | GND for U_p |
| | | 2 | GND_S | GND for U_s |
| | | 3 | FE | Functional earth |
| | | 4 | U_s | Supply voltage 24 V _{DC} |
| | | 5 | U_p | Supply voltage 0...72 V _{DC} |

Ground the core "FE" at the other end of the cable.

The pin "FE" is directly connected to the [connections for the functional earth](#) [▶ 17].

4.2.1.2 Status LEDs



The status of the supply voltages is signaled by two LEDs. A Status LED lights up green when the respective supply voltage is present on the supply voltage input.



4.2.1.3 Conductor losses

Take into account the voltage drop on the supply line when planning a system. Avoid the voltage drop being so high that the supply voltage at the box lies below the minimum nominal voltage. Variations in the voltage of the power supply unit must also be taken into account.

Voltage drop on the supply line



4.2.2 EtherCAT

4.2.2.1 Connectors

NOTICE

Risk of confusion: supply voltages and EtherCAT

Defect possible through incorrect insertion.

- Observe the color coding of the connectors:
 black: Supply voltages
 green: EtherCAT

EtherCAT Box Modules have two green M8 sockets for the incoming and downstream EtherCAT connections.



Fig. 4: EtherCAT connectors

Connection




Fig. 5: M8 socket

| EtherCAT | M8 socket | Core colors | | |
|----------|-----------|---|---|--------------|
| Signal | Contact | ZB9010, ZB9020, ZB9030, ZB9032, ZK1090-6292, ZK1090-3xxx-xxxx | ZB9031 and old versions of ZB9030, ZB9032, ZK1090-3xxx-xxxx | TIA-568B |
| Tx + | 1 | yellow ¹⁾ | orange/white | white/orange |
| Tx - | 4 | orange ¹⁾ | orange | orange |
| Rx + | 2 | white ¹⁾ | blue/white | white/green |
| Rx - | 3 | blue ¹⁾ | blue | green |
| Shield | Housing | Shield | Shield | Shield |

¹⁾ Core colors according to EN 61918

i Adaptation of core colors for cables ZB9030, ZB9032 and ZK1090-3xxxx-xxxx

For standardization, the core colors of the ZB9030, ZB9032 and ZK1090-3xxx-xxxx cables have been changed to the EN61918 core colors: yellow, orange, white, blue. So there are different color codes in circulation. The electrical properties of the cables have been retained when the core colors were changed.

4.2.2.2 Status LEDs



Fig. 6: EtherCAT Status LEDs

L/A (Link/Act)

A green LED labelled "L/A" is located next to each EtherCAT socket. The LED indicates the communication state of the respective socket:

| LED | Meaning |
|---------|---|
| off | no connection to the connected EtherCAT device |
| lit | LINK: connection to the connected EtherCAT device |
| flashes | ACT: communication with the connected EtherCAT device |

Run

Each EtherCAT slave has a green LED labelled "Run". The LED signals the status of the slave in the EtherCAT network:

| LED | Meaning |
|----------------------|--------------------------------------|
| off | Slave is in "Init" state |
| flashes uniformly | Slave is in "Pre-Operational" state |
| flashes sporadically | Slave is in "Safe-Operational" state |
| lit | Slave is in "Operational" state |

Description of the EtherCAT slave states

4.2.2.3 Cables

For connecting EtherCAT devices only shielded Ethernet cables that meet the requirements of at least category 5 (CAT5) according to EN 50173 or ISO/IEC 11801 should be used.

EtherCAT uses four wires for signal transmission.

Thanks to automatic line detection ("Auto MDI-X"), both symmetrical (1:1) or cross-over cables can be used between Beckhoff EtherCAT.

Detailed recommendations for the cabling of EtherCAT devices

4.3 Disposal



Products marked with a crossed-out wheeled bin shall not be discarded with the normal waste stream. The device is considered as waste electrical and electronic equipment. The national regulations for the disposal of waste electrical and electronic equipment must be observed.

5 Commissioning and configuration

NOTICE

Damage if operated without parameterization


If the chopper threshold is set too low, the braking resistor may be permanently active. This causes the box to overheat. Material damage is possible.

- Only apply U_p to the box after parameterization.
- Set the chopper parameters according to the specifications in the chapter [Chopper](#) [▶ 24].

5.1 Integrating into a TwinCAT project

The procedure for integration in a TwinCAT project is described in this [Quick start guide](#).

5.2 Open the parameter directory (CoE)



1. In the Solution Explorer: Double-click EP9576-1032.
 2. Click on the "CoE - Online" tab.
- ⇒ You will see the CoE directory of the EP9576-1032. Here you can check and change parameter values.

i Resetting parameters to factory settings

If you do not know whether parameters have already been changed by the present EP9576-1032, you can [reset all parameters to the factory settings](#) [▶ 29].

5.3 Chopper

NOTICE

Damage if operated without parameterization

If the chopper threshold is set too low, the braking resistor may be permanently active. This causes the box to overheat. Material damage is possible.

- Only apply U_p to the box after parameterization.
- Set the parameters so that the following condition is always met:

$$V_{th} - V_{hyst} > U_{p,max}$$

V_{th} : 8000:11 "Chopper threshold overvoltage".

V_{hyst} : 8000:13 "Chopper hysteresis voltage".

$U_{p,max}$: Nominal voltage U_p plus the maximum tolerance upwards.

NOTICE

The chopper is disabled in case of overtemperature [▶ 28]

Overtages are no longer dissipated in case of overtemperature. Defect possible due to overvoltage.

- Monitor the bit I2T warning [▶ 13] in order to recognize a temperature increase in good time.
- If necessary, disable the drive if the bit I2T error [▶ 13] is TRUE.


The chopper is automatically activated when the voltage U_p exceeds the limit value "Chopper threshold overvoltage". The chopper controls the current through the braking resistor such that the voltage U_p does not increase further.

The chopper is automatically deactivated when the voltage U_p has dropped again by the "Chopper hysteresis voltage".

Parameter

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|-------------------------------|--|-----------|-------|----------------------|
| 8000:11 | Chopper threshold overvoltage | The Chopper is switched on if the voltage U_p exceeds this value. Unit: mV. | UINT32 | RW | 50000 _{dec} |
| 8000:13 | Chopper hysteresis voltage | Hysteresis voltage for switching off the Chopper. Unit: mV. | UINT32 | RW | 1000 _{dec} |

The following diagram shows the influence of the parameters on an exemplary curve of the voltage U_p :



5.4 Measured values

5.4.1 Temperatures

5.4.1.1 Temperature of the brake resistor

The temperature of the brake resistor is not measured directly. It is calculated internally from the time curve of the [measured current value](#) [► 27].

Configuring the temperature calculation

The ambient temperature must be known in order to calculate the temperature of the brake resistor. Enter the ambient temperature in the following CoE parameter:

8000:15 "Ambient temperature offset"

Factory setting: 50 °C


Overtemperature protection

If the temperature of the brake resistor is too high, the [overtemperature protection](#) [► 28] disables the [chopper](#) [► 24].

Activating process data

You can display the temperature of the braking resistor in the process data. To do this, activate the process data object 0x1A01.

Procedure in TwinCAT 3:



1. Double-click on EP9576-1032 in Solution Explorer.
 2. Select the "Process data" tab.
 3. In the "Sync Manager" field, click on "Inputs".
 4. In the "PDO Assignment (0x1C13)" field, check "0x1A01".
- ⇒ The process data object [BCT Load](#) [► 14] is added to the process data.

5.4.1.2 Internal temperature

The current internal temperature is located in the CoE parameter A000:11 "Temperature".

The internal temperature is purely informative. It is not monitored by any protective function [▶ 28].

5.4.2 Current and voltage

The process data [▶ 13] contains the measured values of two electrical variables:

- The voltage U_p : "DC link voltage"
- The current through the brake resistor: "Resistor current"

5.4.2.1 Measured value filter

The measured values "DC Link voltage" and "Resistor current" can be filtered with a digital filter.

The measured value filter is already enabled in the factory setting.

Parameter

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|-----------------|---|-----------|-------|---------|
| 8000:02 | Enable filter | Enables the <u>measured value filter</u> [▶ 27]. | BOOL | RW | TRUE |
| 8000:1A | Filter Settings | Measured value filter type: 0: FIR 50 Hz 1: FIR 60 Hz 2: IIR1 3: IIR2 4: IIR3 5: IIR4 6: IIR5 7: IIR6 8: IIR7 9: IIR8 | UINT16 | RW | 0 |

5.5 Protective functions

5.5.1 Overtemperature protection

The [chopper](#) [▶ 24] is disabled if the [temperature of the brake resistor](#) [▶ 25] exceeds the limit value "I2T error level". The bit "I2T error" in the [process data](#) [▶ 13] is set to TRUE.

The chopper is re-enabled when the temperature of the brake resistor falls below the limit value "I2T warn level". (Hysteresis)

Parameter

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|-----------------|--|-----------|-------|--------------------|
| 8000:18 | I2T warn level | If the internal temperature exceeds this value, the bit "I2T warning" is set to TRUE. Unit: °C. | UINT16 | RW | 100 _{dec} |
| 8000:19 | I2T error level | The chopper is disabled if the internal temperature exceeds this value. The bit "I2T error" is set to TRUE. Unit: °C. | UINT16 | RW | 120 _{dec} |

Overtemperature warning

The bit "I2T warning" in the [process data](#) [▶ 13] serves as an early warning system.

The bit is set to TRUE if the temperature of the brake resistor exceeds the limit value "I2T warn level". However, the chopper is not yet disabled. Therefore, you can still react to the warning.

Deactivate

You can disable the overtemperature protection by setting the parameter 8000:01 "Disable chopper on overtemperature" to FALSE.

5.5.2 Overcurrent protection

The overcurrent protection disables the [chopper](#) [▶ 24] if the current through the brake resistor exceeds 15.5 A. The bit "Overcurrent Protection" in the [process data](#) [▶ 13] is set to TRUE.

The chopper remains disabled until you apply a positive edge to the parameter 8000:03 "Overcurrent Protection Reset": set the parameter from FALSE to TRUE.

5.6 Restoring the delivery state

To restore the delivery state for backup objects in ELxxxx terminals / EPxxxx- and EPPxxxx box modules, the CoE object *Restore default parameters, SubIndex 001* can be selected in the TwinCAT System Manager (Config mode).




Fig. 7: Selecting the Restore default parameters PDO

Double-click on *SubIndex 001* to enter the Set Value dialog. Enter the value **1684107116** in field *Dec* or the value **0x64616F6C** in field *Hex* and confirm with OK.

All backup objects are reset to the delivery state.




Fig. 8: Entering a restore value in the Set Value dialog

i Alternative restore value

In some older terminals / boxes the backup objects can be switched with an alternative restore value:

Decimal value: 1819238756

Hexadecimal value: 0x6C6F6164

An incorrect entry for the restore value has no effect.

5.7 Decommissioning

⚠ WARNING**Risk of electric shock!**

Bring the bus system into a safe, de-energized state before starting disassembly of the devices!

6 CoE parameters

6.1 Object directory

| Index (hex) | Name |
|-------------|---|
| 1000 | Device Type [▶ 34] |
| 1008 | Device name [▶ 34] |
| 1009 | Hardware version [▶ 34] |
| 100A | Software version [▶ 34] |
| 1011 | Restore default parameters [▶ 34] |
| 1018 | Identity [▶ 34] |
| 10F0 | Backup parameter handling [▶ 34] |
| 1A00 | BCT TxPDO-Map Inputs [▶ 36] |
| 1A01 | BCT TxPDO-Map Load [▶ 36] |
| 1C00 | Sync manager type [▶ 38] |
| 1C12 | RxPDO assign [▶ 36] |
| 1C13 | TxPDO assign [▶ 37] |
| 1C33 | SM input parameter [▶ 39] |
| 6000 | BCT Inputs [▶ 37] |
| 6001 | BCT Load Factor [▶ 37] |
| 8000 | BCT Settings [▶ 32] |
| 800F | BCT Vendor data [▶ 33] |
| A000 | BCT Diag data [▶ 33] |
| B000 | BCT Command [▶ 35] |
| F000 | Modular Device Profile [▶ 35] |
| F008 | Code word [▶ 35] |
| F081 | Download revision [▶ 35] |

6.2 Object description

6.2.1 Objects for parameterization

Index 8000: BCT Settings

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|------------------------------------|--|-----------|-------|------------------------------|
| 8000:0 | BCT Settings | | UINT8 | RO | 0x1A (26 _{dec}) |
| 8000:01 | Disable chopper on overtemperature | Disable <u>overtemperature protection</u> [► 28]. | BOOL | RW | TRUE |
| 8000:02 | Enable filter | Enables the <u>measured value filter</u> [► 27]. | BOOL | RW | TRUE |
| 8000:03 | Overcurrent Protection Reset | Reset <u>overcurrent protection</u> [► 28]. | BOOL | RW | FALSE |
| 8000:11 | Chopper threshold overvoltage | The Chopper is switched on if the voltage U_p exceeds this value. Unit: mV. | UINT32 | RW | 50000 _{dec} |
| 8000:12 | Chopper threshold undervoltage | If the voltage U_p falls below this value, the bit "Undervoltage" is set in the process data. Unit: mV. | UINT32 | RW | 22000 _{dec} |
| 8000:13 | Chopper hysteresis voltage | Hysteresis voltage for switching off the Chopper. Unit: mV. | UINT32 | RW | 1000 _{dec} |
| 8000:14 | Terminal overtemperature threshold | If the internal temperature exceeds this value, the bit Terminal Overtemperature is set to TRUE. Unit: °C. | UINT8 | RW | 80 _{dec} |
| 8000:15 | Ambient temperature offset | Enter the ambient temperature here. This value is incorporated into the calculation of the <u>temperature of the brake resistor</u> [► 25]. Unit: °C. | UINT8 | RW | 50 _{dec} |
| 8000:18 | I2T warn level | If the internal temperature exceeds this value, the bit "I2T warning " is set to TRUE. Unit: °C. | UINT16 | RW | 100 _{dec} |
| 8000:19 | I2T error level | The chopper is disabled if the internal temperature exceeds this value. The bit "I2T error" is set to TRUE. Unit: °C. | UINT16 | RW | 120 _{dec} |
| 8000:1A | Filter Settings | Measured value filter type: 0: FIR 50 Hz 1: FIR 60 Hz 2: IIR1 3: IIR2 4: IIR3 5: IIR4 6: IIR5 7: IIR6 8: IIR7 9: IIR8 | UINT16 | RW | 0 |

6.2.2 Objects for information and diagnostics

Index 800F: BCT Vendor data

| Index (hex) | Name | Meaning | Data type | Flags | Default |
|-------------|-------------------------|---|-----------|-------|------------------------------|
| 800F:0 | BCT Vendor data | | UINT8 | RO | 0x16 (22 _{dec}) |
| 800F:13 | Resistor current offset | Vendor calibration: Offset value for <u>current</u> measurement [▶ 27]. | INT16 | RW | - |
| 800F:14 | Resistor current gain | Vendor calibration: Gain value for <u>current</u> measurement [▶ 27]. | UINT16 | RW | - |
| 800F:15 | DC link voltage offset | Vendor calibration: Offset value for <u>voltage</u> measurement [▶ 27]. | INT16 | RW | - |
| 800F:16 | DC link voltage gain | Vendor calibration: Offset value for <u>voltage</u> measurement [▶ 27]. | UINT16 | RW | - |

Index A000: BCT Diag data

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|---------------|---|-----------|-------|------------------------------|
| A000:0 | BCT Diag data | | UINT8 | RO | 0x11 (17 _{dec}) |
| A000:11 | Temperature | <u>Internal temperature</u> [▶ 26]. Unit: °C. | UINT8 | RO | - |

6.2.3 Standard objects

Index 1000 Device type

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|-------------|---|-----------|-------|---------------------|
| 1000:0 | Device type | Bit 0...15: Device profile number Bit 16...31: Module profile number (Device profile number 5001: Modular Device Profile MDP) | UINT32 | RO | 5001 _{dec} |

Index 1009 Hardware version

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|------------------|--|-----------|-------|---------|
| 1009:0 | Hardware version | Hardware version [► 7] | STRING | RO | - |

Index 100A Software version

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|------------------|--|-----------|-------|---------|
| 100A:0 | Software version | Firmware version [► 7] | STRING | RO | - |

Index 1011 Restore default parameters

Access rights: read/write

| Index (hex) | Name | Description | Data type | Flags | Default |
|-------------|----------------------------|---|-----------|-------|----------------|
| 1011:0 | Restore default parameters | Restore default settings | UINT8 | RO | 0x01 (1dec) |
| 1011:01 | Subindex 001 | Resets the CoE parameters to the factory settings. To do this, write the value 0x64616F6C in this parameter. | UINT32 | RW | 0 |

Index 1018 Identity

| Index (hex) | Name | Description | Data type | Flags | Value |
|-------------|---------------|--|-----------|-------|---------------------------------------|
| 1018:0 | Identity | Information for identifying the slave | UINT8 | RO | 0x04 (4dec) |
| 1018:01 | Vendor ID | Vendor identifier (2: Beckhoff Automation) | UINT32 | RO | 2 |
| 1018:02 | Product code | Product code | UINT32 | RO | 2568405 2 _{hex} |
| 1018:03 | Revision | Bit 0...15: Index number of the product version Bit 16...31: Revision of the device description (ESI) | UINT32 | RO | Bit 0...15: 1032 _{dec} |
| 1018:04 | Serial number | Reserved | UINT32 | RO | 0 |

Index 10F0: Backup parameter handling

| Index | Name | Meaning | Data type | Flags | Default |
|---------|---------------------------|---|-----------|-------|-----------------------------|
| 10F0:0 | Backup parameter handling | Information for standardized loading and saving of backup entries | UINT8 | RO | 0x01 (1 _{dec}) |
| 10F0:01 | Checksum | Checksum across all backup entries of the EtherCAT slave | UINT32 | RO | 0 |

Index B000: BCT Command

| Index | Name | Meaning | Data type | Flags | Default |
|---------|-------------|---------|---------------------|-------|-----------------------------|
| B000:0 | BCT Command | | UINT8 | RO | 0x03 (3 _{dec}) |
| B000:01 | Request | | OCTET-STRING [2] | RW | {0} |
| B000:02 | Status | | UINT8 | RO | 0 |
| B000:03 | Response | | OCTET-STRING [6] | RO | {0} |

Index F000: Modular Device Profile

| Index | Name | Meaning | Data type | Flags | Default |
|---------|---------------------------|--|-----------|-------|--------------------------------|
| F000:0 | Modular Device Profile | General information for the modular device profile | UINT8 | RO | 0x02 (2 _{dec}) |
| F000:01 | Index distance | Index distance of the objects of the individual channels | UINT16 | RO | 0x0010 (16 _{dec}) |
| F000:02 | Maximum number of modules | Number of channels | UINT16 | RO | 0x0001 (1 _{dec}) |

Index F008: Code word

| Index | Name | Meaning | Data type | Flags | Default |
|--------|-----------|---------|-----------|-------|---------|
| F008:0 | Code word | | UINT32 | RW | 0 |

Index F081: Download revision

| Index | Name | Meaning | Data type | Flags | Default |
|---------|-------------------|---------|-----------|-------|-----------------------------|
| F081:0 | Download revision | | UINT8 | RO | 0x01 (1 _{dec}) |
| F081:01 | Revision number | | UINT32 | RW | 0 |

6.2.4 PDO Mapping and PDO Assignment

Index 1A00: BCT TxPDO-Map Inputs

| Index | Name | Meaning | Data type | Flags | Default |
|---------|----------------------|--|-----------|-------|---------------------------|
| 1A00:0 | BCT TxPDO-Map Inputs | PDO Mapping TxPDO 1 | UINT8 | RO | 0x0C (12 _{dec}) |
| 1A00:01 | SubIndex 001 | 1. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x01 (Terminal Overtemperature)) | UINT32 | RO | 0x6000:01, 1 |
| 1A00:02 | SubIndex 002 | 2. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x02 (I2T error)) | UINT32 | RO | 0x6000:02, 1 |
| 1A00:03 | SubIndex 003 | 3. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x03 (I2T warning)) | UINT32 | RO | 0x6000:03, 1 |
| 1A00:04 | SubIndex 004 | 4. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x04 (Overvoltage)) | UINT32 | RO | 0x6000:04, 1 |
| 1A00:05 | SubIndex 005 | 5. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x05 (Undervoltage)) | UINT32 | RO | 0x6000:05, 1 |
| 1A00:06 | SubIndex 006 | 6. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x06 (Chopper on)) | UINT32 | RO | 0x6000:06, 1 |
| 1A00:07 | SubIndex 007 | 7. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x07 (Overcurrent Protection)) | UINT32 | RO | 0x6000:07, 1 |
| 1A00:08 | SubIndex 008 | 8. PDO Mapping entry (7 bits align) | UINT32 | RO | 0x0000:00, 7 |
| 1A00:09 | SubIndex 009 | 9. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x0F (Input cycle counter)) | UINT32 | RO | 0x6000:0F, 2 |
| 1A00:0A | SubIndex 010 | 10. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x11 (DC link voltage)) | UINT32 | RO | 0x6000:11, 32 |
| 1A00:0B | SubIndex 011 | 11. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x13 (Resistor Current)) | UINT32 | RO | 0x6000:13, 32 |
| 1A00:0C | SubIndex 012 | 12. PDO Mapping entry (object 0x6000 (BCT Inputs), entry 0x14 (Duty Cycle)) | UINT32 | RO | 0x6000:14, 8 |

Index 1A01: BCT TxPDO-Map Load

| Index | Name | Meaning | Data type | Flags | Default |
|---------|--------------------|--|-----------|-------|--------------|
| 1A01:0 | BCT TxPDO-Map Load | PDO Mapping TxPDO 2 | UINT8 | RO | 1 |
| 1A01:01 | SubIndex 001 | 1. PDO Mapping entry (object 0x6001 (BCT Load Factor), entry 0x01 (I2T load factor)) | UINT32 | RO | 0x6001:01, 8 |

Index 1C12: RxPDO assign

| Index | Name | Meaning | Data type | Flags | Default |
|--------|--------------|--------------------|-----------|-------|---------|
| 1C12:0 | RxPDO assign | PDO Assign Outputs | UINT8 | RO | 0 |

Index 1C13: TxPDO assign

| Index | Name | Meaning | Data type | Flags | Default |
|---------|--------------|--|-----------|-------|-------------------------------|
| 1C13:0 | TxPDO assign | PDO Assign Inputs | UINT8 | RW | 1 |
| 1C13:01 | SubIndex 001 | 1. allocated TxPDO (contains the index of the associated TxPDO mapping object) | UINT16 | RW | 0x1A00 (6656 _{dec}) |
| 1C13:02 | SubIndex 002 | 2. allocated TxPDO (contains the index of the associated TxPDO mapping object) | UINT16 | RW | 0 |

Index 6000: BCT Inputs

| Index | Name | Meaning | Data type | Flags | Default |
|---------|--------------------------|---------|-----------|-------|---------------------------|
| 6000:0 | BCT Inputs | | UINT8 | RO | 0x14 (20 _{dec}) |
| 6000:01 | Terminal overtemperature | | BOOL | RO | 0 |
| 6000:02 | I2T error | | BOOL | RO | 0 |
| 6000:03 | I2T warning | | BOOL | RO | 0 |
| 6000:04 | Overvoltage | | BOOL | RO | 0 |
| 6000:05 | Undervoltage | | BOOL | RO | 0 |
| 6000:06 | Chopper on | | BOOL | RO | 0 |
| 6000:07 | Overcurrent Protection | | BOOL | RO | 0 |
| 6000:0F | Input cycle counter | | BIT2 | RO | 0 |
| 6000:11 | DC link voltage | | UINT32 | RO | 0 |
| 6000:13 | Resistor Current | | INT32 | RO | 0 |
| 6000:14 | Duty Cycle | | UINT8 | RO | 0 |

Index 6001: BCT Load Factor

| Index | Name | Meaning | Data type | Flags | Default |
|---------|-----------------|---------|-----------|-------|---------|
| 6001:0 | BCT Load Factor | | UINT8 | RO | 1 |
| 6001:01 | I2T load factor | | UINT8 | RO | 0 |

6.2.5 Sync manager objects

Index 1C00: Sync manager type

| Index | Name | Meaning | Data type | Flags | Default |
|---------|-------------------|---|-----------|-------|-----------------------------|
| 1C00:0 | Sync manager type | Using the Sync Managers | UINT8 | RO | 0x04 (4 _{dec}) |
| 1C00:01 | SubIndex 001 | Sync-Manager Type Channel 1: Mailbox Write | UINT8 | RO | 0x01 (1 _{dec}) |
| 1C00:02 | SubIndex 002 | Sync-Manager Type Channel 2: Mailbox Read | UINT8 | RO | 0x02 (2 _{dec}) |
| 1C00:03 | SubIndex 003 | Sync-Manager Type Channel 3: Process Data Write (Outputs) | UINT8 | RO | 0x03 (3 _{dec}) |
| 1C00:04 | SubIndex 004 | Sync-Manager Type Channel 4: Process Data Read (Inputs) | UINT8 | RO | 0x04 (4 _{dec}) |

Index 1C33: SM input parameter

| Index | Name | Meaning | Data type | Flags | Default |
|---------|-------------------------|--|-----------|-------|---|
| 1C33:0 | SM input parameter | Synchronization parameters for the inputs | UINT8 | RO | 0x20 (32 _{dec}) |
| 1C33:01 | Sync mode | Current synchronization mode: 0: Free Run 1: Synchron with SM 3 Event (no outputs available) 2: DC - Synchron with SYNC0 Event 3: DC - Synchron with SYNC1 Event 34: Synchron with SM 2 Event (outputs available) | UINT16 | RW | 0 |
| 1C33:02 | Cycle time | as 1C32:02 | UINT32 | RW | 0x000F4 240 (100000 0 _{dec}) |
| 1C33:03 | Shift time | Time between SYNC0 event and reading of the inputs (in ns, only DC mode) | UINT32 | RO | 0 |
| 1C33:04 | Sync modes supported | Supported synchronization modes: Bit 0: free run is supported Bit 1: Synchron with SM 2 Event is supported (outputs available) Bit 1: Synchron with SM 3 Event is supported (no outputs available) Bit 2-3 = 01: DC mode is supported Bit 4-5 = 01: Input Shift through local event (outputs available) Bit 4-5 = 10: Input Shift with SYNC1 Event (no outputs available) Bit 14 = 1: dynamic times (measurement through writing of 1C32:08 or 1C33:08) | UINT16 | RO | 1 |
| 1C33:05 | Minimum cycle time | as 1C32:05 | UINT32 | RO | 0x00002 710 (10000 _{dec}) |
| 1C33:06 | Calc and copy time | Time between reading of the inputs and availability of the inputs for the master (in ns, only DC mode) | UINT32 | RO | 0 |
| 1C33:07 | Minimum delay time | | UINT32 | RO | 0 |
| 1C33:08 | Get Cycle Time | as 1C32:08 | UINT16 | RW | 0 |
| 1C33:09 | Maximum delay time | Time between SYNC1 event and reading of the inputs (in ns, only DC mode) | UINT32 | RO | 0 |
| 1C33:0B | SM event missed counter | as 1C32:11 | UINT16 | RO | 0 |
| 1C33:0C | Cycle exceeded counter | as 1C32:12 | UINT16 | RO | 0 |
| 1C33:0D | Shift too short counter | as 1C32:13 | UINT16 | RO | 0 |
| 1C33:20 | Sync error | as 1C32:32 | BOOL | RO | 0 |

7 Appendix

7.1 General operating conditions

Protection rating according to IP code

The degrees of protection are defined and divided into different classes in the IEC 60529 standard (EN 60529). Degrees of protection are designated by the letters "IP" and two numerals: **IPxy**

- Numeral x: Dust protection and contact protection
- Numeral y: Protection against water

| x | Meaning |
|---|---|
| 0 | Not protected |
| 1 | Protected against access to dangerous parts with the back of the hand. Protected against solid foreign objects of 50 mm Ø |
| 2 | Protected against access to dangerous parts with a finger. Protected against solid foreign objects of 12.5 mm Ø |
| 3 | Protected against access to dangerous parts with a tool. Protected against solid foreign objects of 2.5 mm Ø |
| 4 | Protected against access to dangerous parts with a wire. Protected against solid foreign objects of 1 mm Ø |
| 5 | Protection against access to dangerous parts with a wire. Dust-protected. Ingress of dust is not prevented completely, although the quantity of dust able to penetrate is limited to such an extent that the proper function of the device and safety are not impaired |
| 6 | Protection against access to dangerous parts with a wire. Dust-tight. No ingress of dust |

| y | Meaning |
|---|---|
| 0 | Not protected |
| 1 | Protection against vertically falling water drops |
| 2 | Protection against vertically falling water drops when enclosure tilted up to 15° |
| 3 | Protection against spraying water. Water sprayed at an angle of up to 60° on either side of the vertical shall have no harmful effects |
| 4 | Protection against splashing water. Water splashed against the enclosure from any direction shall have no harmful effects |
| 5 | Protection against water jets. |
| 6 | Protection against powerful water jets. |
| 7 | Protected against the effects of temporary immersion in water. Ingress of water in quantities causing harmful effects shall not be possible when the enclosure is immersed in water at a depth of 1 m for 30 minutes |

Chemical resistance

The resistance refers to the housing of the IP67 modules and the metal parts used. In the table below you will find some typical resistances.

| Type | Resistance |
|---|--|
| Water vapor | unstable at temperatures > 100 °C |
| Sodium hydroxide solution (ph value > 12) | stable at room temperature unstable > 40 °C |
| Acetic acid | unstable |
| Argon (technically pure) | stable |

Key

- resistant: Lifetime several months
- non inherently resistant: Lifetime several weeks
- not resistant: Lifetime several hours resp. early decomposition

7.2 Accessories

Protective caps for connectors

| Ordering information | Description |
|----------------------|---|
| ZS5000-0010 | Protective cap for M8 sockets, IP67 (50 pieces) |

Labelling material

| Ordering information | Description |
|----------------------|---|
| ZS5100-0000 | Inscription labels, unprinted, 4 strips of 10 |
| ZS5000-xxxx | Printed inscription labels on enquiry |

Cables

A complete overview of pre-assembled cables for fieldbus components can be found [here](#).

| Ordering information | Description | Link |
|----------------------|---------------------------|-------------------------|
| ZK1090-3xxx-xxxx | EtherCAT cable M8, green | Website |
| ZK1093-3xxx-xxxx | EtherCAT cable M8, yellow | Website |
| ZK203x-xxxx-xxxx | Power cable 7/8", 5-pin | Website |

Tools

| Ordering information | Description |
|----------------------|---|
| ZB8801-0000 | Torque wrench for plugs, 0.4...1.0 Nm |
| ZB8801-0001 | Torque cable key for M8 / wrench size 9 for ZB8801-0000 |



Further accessories

Further accessories can be found in the price list for fieldbus components from Beckhoff and online at <https://www.beckhoff.com>.

7.3 Version identification of EtherCAT devices

7.3.1 General notes on marking

Designation

A Beckhoff EtherCAT device has a 14-digit designation, made up of

- family key
- type
- version
- revision

| Example | Family | Type | Version | Revision |
|------------------|--|---|--------------------------------|----------|
| EL3314-0000-0016 | EL terminal 12 mm, non-pluggable connection level | 3314 4-channel thermocouple terminal | 0000 basic type | 0016 |
| ES3602-0010-0017 | ES terminal 12 mm, pluggable connection level | 3602 2-channel voltage measurement | 0010 high-precision version | 0017 |
| CU2008-0000-0000 | CU device | 2008 8-port fast ethernet switch | 0000 basic type | 0000 |

Notes

- The elements mentioned above result in the **technical designation**. EL3314-0000-0016 is used in the example below.
- EL3314-0000 is the order identifier, in the case of "-0000" usually abbreviated to EL3314. "-0016" is the EtherCAT revision.
- The **order identifier** is made up of
 - family key (EL, EP, CU, ES, KL, CX, etc.)
 - type (3314)
 - version (-0000)
- The **revision** -0016 shows the technical progress, such as the extension of features with regard to the EtherCAT communication, and is managed by Beckhoff.
In principle, a device with a higher revision can replace a device with a lower revision, unless specified otherwise, e.g. in the documentation.
Associated and synonymous with each revision there is usually a description (ESI, EtherCAT Slave Information) in the form of an XML file, which is available for download from the Beckhoff web site.
From 2014/01 the revision is shown on the outside of the IP20 terminals, see Fig. "EL2872 with revision 0022 and serial number 01200815".
- The type, version and revision are read as decimal numbers, even if they are technically saved in hexadecimal.

7.3.2 Version identification of IP67 modules

The serial number/ data code for Beckhoff IO devices is usually the 8-digit number printed on the device or on a sticker. The serial number indicates the configuration in delivery state and therefore refers to a whole production batch, without distinguishing the individual modules of a batch.

Structure of the serial number: **KK YY FF HH**

KK - week of production (CW, calendar week)
 YY - year of production
 FF - firmware version
 HH - hardware version

Example with serial number 12 06 3A 02:

12 - production week 12
 06 - production year 2006
 3A - firmware version 3A
 02 - hardware version 02

Exceptions can occur in the **IP67 area**, where the following syntax can be used (see respective device documentation):

Syntax: D ww yy x y z u

D - prefix designation
 ww - calendar week
 yy - year
 x - firmware version of the bus PCB
 y - hardware version of the bus PCB
 z - firmware version of the I/O PCB
 u - hardware version of the I/O PCB

Example: D.22081501 calendar week 22 of the year 2008 firmware version of bus PCB: 1 hardware version of bus PCB: 5 firmware version of I/O PCB: 0 (no firmware necessary for this PCB) hardware version of I/O PCB: 1




Fig. 9: EP1258-00001 IP67 EtherCAT Box with batch number/DateCode 22090101 and unique serial number 158102

7.3.3 Beckhoff Identification Code (BIC)

The Beckhoff Identification Code (BIC) is increasingly being applied to Beckhoff products to uniquely identify the product. The BIC is represented as a Data Matrix Code (DMC, code scheme ECC200), the content is based on the ANSI standard MH10.8.2-2016.



Fig. 10: BIC as data matrix code (DMC, code scheme ECC200)

The BIC will be introduced step by step across all product groups.

Depending on the product, it can be found in the following places:

- on the packaging unit
- directly on the product (if space suffices)
- on the packaging unit and the product

The BIC is machine-readable and contains information that can also be used by the customer for handling and product management.

Each piece of information can be uniquely identified using the so-called data identifier (ANSI MH10.8.2-2016). The data identifier is followed by a character string. Both together have a maximum length according to the table below. If the information is shorter, spaces are added to it.

Following information is possible, positions 1 to 4 are always present, the other according to need of production:

| Position | Type of information | Explanation | Data identifier | Number of digits incl. data identifier | Example |
|----------|------------------------------------|---|-----------------|--|-------------------------|
| 1 | Beckhoff order number | Beckhoff order number | 1P | 8 | 1P 072222 |
| 2 | Beckhoff Traceability Number (BTN) | Unique serial number, see note below | SBTN | 12 | SBTN k4p562d7 |
| 3 | Article description | Beckhoff article description, e.g. EL1008 | 1K | 32 | 1K EL1809 |
| 4 | Quantity | Quantity in packaging unit, e.g. 1, 10, etc. | Q | 6 | Q1 |
| 5 | Batch number | Optional: Year and week of production | 2P | 14 | 2P 401503180016 |
| 6 | ID/serial number | Optional: Present-day serial number system, e.g. with safety products | 51S | 12 | 51S 678294 |
| 7 | Variant number | Optional: Product variant number on the basis of standard products | 30P | 32 | 30P F971, 2*K183 |
| ... | | | | | |

Further types of information and data identifiers are used by Beckhoff and serve internal processes.

Structure of the BIC

Example of composite information from positions 1 to 4 and with the above given example value on position 6. The data identifiers are highlighted in bold font:

1P072222**SBTN**k4p562d7**1K**EL1809 **Q1** **51S**678294

Accordingly as DMC:



Fig. 11: Example DMC **1P072222SBTNk4p562d71KEL1809 Q1 51S678294**

BTN

An important component of the BIC is the Beckhoff Traceability Number (BTN, position 2). The BTN is a unique serial number consisting of eight characters that will replace all other serial number systems at Beckhoff in the long term (e.g. batch designations on IO components, previous serial number range for safety products, etc.). The BTN will also be introduced step by step, so it may happen that the BTN is not yet coded in the BIC.

| NOTICE |
|--|
| This information has been carefully prepared. However, the procedure described is constantly being further developed. We reserve the right to revise and change procedures and documentation at any time and without prior notice. No claims for changes can be made from the information, illustrations and descriptions in this documentation. |

7.3.4 Electronic access to the BIC (eBIC)

Electronic BIC (eBIC)

The Beckhoff Identification Code (BIC) is applied to the outside of Beckhoff products in a visible place. If possible, it should also be electronically readable.

The interface that the product can be electronically addressed by is crucial for the electronic readout.


EtherCAT devices (IP20, IP67)

All Beckhoff EtherCAT devices have an ESI-EEPROM which contains the EtherCAT identity with the revision number. The EtherCAT slave information, also colloquially known as the ESI/XML configuration file for the EtherCAT master, is stored in it. See the corresponding chapter in the EtherCAT system manual ([Link](#)) for the relationships.

Beckhoff also stores the eBIC in the ESI-EEPROM. The eBIC was introduced into Beckhoff IO production (terminals, box modules) in 2020; as of 2023, implementation is largely complete.

The user can electronically access the eBIC (if present) as follows:

- With all EtherCAT devices, the EtherCAT master (TwinCAT) can read the eBIC from the ESI-EEPROM
 - From TwinCAT 3.1 build 4024.11, the eBIC can be displayed in the online view.
 - To do this, check the "Show Beckhoff Identification Code (BIC)" checkbox under EtherCAT → Advanced Settings → Diagnostics:



- The BTN and its contents are then displayed:

| No | Addr | Name | State | CRC | Fw | Hw | Production Data | ItemNo | BTN | Description | Quantity | BatchNo | SerialNo |
|----|------|-----------------|-------|-----|----|----|-----------------|--------|----------|-------------|----------|---------|----------|
| 1 | 1001 | Term 1 (EK1100) | OP | 0,0 | 0 | 0 | --- | | | | | | |
| 2 | 1002 | Term 2 (EL1018) | OP | 0,0 | 0 | 0 | 2020 KW36 Fr | 072222 | k4p562d7 | EL1809 | 1 | | 678294 |
| 3 | 1003 | Term 3 (EL3204) | OP | 0,0 | 7 | 6 | 2012 KW24 Sa | | | | | | |
| 4 | 1004 | Term 4 (EL2004) | OP | 0,0 | 0 | 0 | --- | 072223 | k4p562d7 | EL2004 | 1 | | 678295 |
| 5 | 1005 | Term 5 (EL1008) | OP | 0,0 | 0 | 0 | --- | | | | | | |
| 6 | 1006 | Term 6 (EL2008) | OP | 0,0 | 0 | 12 | 2014 KW14 Mo | | | | | | |
| 7 | 1007 | Term 7 (EK1110) | OP | 0 | 1 | 8 | 2012 KW25 Mo | | | | | | |

- Note: As shown in the figure, the production data HW version, FW version, and production date, which have been programmed since 2012, can also be displayed with "Show production info".
- Access from the PLC: From TwinCAT 3.1. build 4024.24, the functions *FB_EcReadBIC* and *FB_EcReadBTN* for reading into the PLC are available in the Tc2_EtherCAT library from v3.3.19.0.
- EtherCAT devices with a CoE directory may also have the object 0x10E2:01 to display their own eBIC, which can also be easily accessed by the PLC:

- The device must be in PREOP/SAFEOP/OP for access:

| Index | Name | Flags | Value |
|---------|---|-------|---|
| 1000 | Device type | RO | 0x015E1389 (22942601) |
| 1008 | Device name | RO | ELM3704-0000 |
| 1009 | Hardware version | RO | 00 |
| 100A | Software version | RO | 01 |
| 100B | Bootloader version | RO | J0.1.27.0 |
| 1011:0 | Restore default parameters | RO | > 1 < |
| 1018:0 | Identity | RO | > 4 < |
| 10E2:0 | Manufacturer-specific Identification C... | RO | > 1 < |
| 10E2:01 | SubIndex 001 | RO | 1P158442SBTN0008jckp1KELM3704 Q1 2P482001000016 |
| 10F0:0 | Backup parameter handling | RO | > 1 < |
| 10F3:0 | Diagnosis History | RO | > 21 < |
| 10F8 | Actual Time Stamp | RO | 0x170bfb277e |

- The object 0x10E2 will be preferentially introduced into stock products in the course of necessary firmware revision.
- From TwinCAT 3.1. build 4024.24, the functions *FB_EcCoEReadBIC* and *FB_EcCoEReadBTN* for reading into the PLC are available in the *Tc2_EtherCAT* library from v3.3.19.0
- The following auxiliary functions are available for processing the BIC/BTN data in the PLC in *Tc2_Uilities* as of TwinCAT 3.1 build 4024.24
 - *F_SplitBIC*: The function splits the Beckhoff Identification Code (BIC) *sBICValue* into its components using known identifiers and returns the recognized substrings in the *ST_SplittedBIC* structure as a return value
 - *BIC_TO_BTN*: The function extracts the BTN from the BIC and returns it as a return value
- Note: If there is further electronic processing, the BTN is to be handled as a string(8); the identifier "SBTN" is not part of the BTN.
- Technical background
 The new BIC information is written as an additional category in the ESI-EEPROM during device production. The structure of the ESI content is largely dictated by the ETG specifications, therefore the additional vendor-specific content is stored using a category in accordance with the ETG.2010. ID 03 tells all EtherCAT masters that they may not overwrite these data in the event of an update or restore the data after an ESI update.
 The structure follows the content of the BIC, see here. The EEPROM therefore requires approx. 50..200 bytes of memory.
- Special cases
 - If multiple hierarchically arranged ESCs are installed in a device, only the top-level ESC carries the eBIC information.
 - If multiple non-hierarchically arranged ESCs are installed in a device, all ESCs carry the eBIC information.
 - If the device consists of several sub-devices which each have their own identity, but only the top-level device is accessible via EtherCAT, the eBIC of the top-level device is located in the CoE object directory 0x10E2:01 and the eBICs of the sub-devices follow in 0x10E2:nn.

7.4 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages: www.beckhoff.com

You will also find further documentation for Beckhoff components there.

Support

The Beckhoff Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963 157
e-mail: support@beckhoff.com
web: www.beckhoff.com/support

Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963 460
e-mail: service@beckhoff.com
web: www.beckhoff.com/service

Headquarters Germany

Beckhoff Automation GmbH & Co. KG

Hülshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963 0
e-mail: info@beckhoff.com
web: www.beckhoff.com

More Information:
www.beckhoff.com/ep9576-1032

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

