

Documentation | EN

EK9000

Modbus TCP/UDP Bus Coupler for EtherCAT Terminals




Table of contents

1 Foreword	5
1.1 Notes on the documentation	5
1.2 Guide through documentation	6
1.3 Notes on information security.....	7
1.4 Safety instructions	8
1.5 Documentation issue status	9
1.6 Version identification of EtherCAT devices	10
1.6.1 General notes on marking.....	10
1.6.2 Version identification of EK Couplers.....	11
1.6.3 Beckhoff Identification Code (BIC).....	12
1.6.4 Electronic access to the BIC (eBIC).....	14
2 Product description	16
2.1 EKxxx - System overview	16
2.2 EK9000 - Introduction	17
2.3 Technical data - EK9000	18
2.4 Technical data - Modbus	19
3 Mounting and wiring	20
3.1 Explosion protection	20
3.1.1 ATEX - Special conditions (standard temperature range).....	20
3.1.2 ATEX - Special conditions (extended temperature range).....	21
3.1.3 IECEx - Special conditions.....	22
3.1.4 Continuative documentation for ATEX and IECEx.....	23
3.2 UL notice	24
3.3 Mounting	25
3.3.1 Dimensions	25
3.3.2 Installation on mounting rails – Bus Coupler.....	25
3.4 Wiring	28
3.4.1 Power supply.....	28
3.4.2 Ethernet.....	29
3.5 Note - power supply	33
3.6 Disposal	34
4 Parameterization and commissioning	35
4.1 DIP switch	35
4.2 Further interfaces	36
4.3 IP address	36
5 Configuration	37
5.1 Configuration via the HTML pages of the Bus Coupler.....	37
5.2 EtherCAT configuration	39
5.3 Modbus configuration	42
5.4 EtherCAT mapping in the Modbus process image.....	44
5.5 EK9000 - EtherCAT configurations	45
6 Ethernet	48
6.1 ModbusTCP/UDP	48

6.1.1	ModbusTCP/UDP protocol.....	48
6.1.2	Modbus-Interfaces	49
6.1.3	ModbusTCP slave error answer (BK9000, BX/BC9000, IP/ILxxxx-B/C900, EK9000)	52
6.1.4	Access via a second client.....	52
6.1.5	Modbus functions	54
7	Error handling and diagnosis	63
7.1	LED indicators.....	63
8	Appendix.....	65
8.1	Update Bus Coupler image	65
8.2	FAQ.....	66
8.3	List of Abbreviations.....	67
8.4	Support and Service.....	68

1 Foreword

1.1 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

The qualified personnel is obliged to always use the currently valid documentation.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 Guide through documentation

NOTICE



Further components of documentation

This documentation describes device-specific content. It is part of the modular documentation concept for Beckhoff I/O components. For the use and safe operation of the device / devices described in this documentation, additional cross-product descriptions are required, which can be found in the following table.

Title	Description
EtherCAT System Documentation (PDF)	<ul style="list-style-type: none"> • System overview • EtherCAT basics • Cable redundancy • Hot Connect • EtherCAT devices configuration
Explosion Protection for Terminal Systems (PDF)	Notes on the use of the Beckhoff terminal systems in hazardous areas according to ATEX and IECEx
Infrastructure for EtherCAT/Ethernet (PDF)	Technical recommendations and notes for design, implementation and testing
Software Declarations I/O (PDF)	Open source software declarations for Beckhoff I/O components

The documentations can be viewed at and downloaded from the Beckhoff website (www.beckhoff.com) via:

- the “Documentation and Download” area of the respective product page,
- the [Download finder](#),
- the [Beckhoff Information System](#).

If you have any suggestions or proposals for our documentation, please send us an e-mail stating the documentation title and version number to: documentation@beckhoff.com

1.3 Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <https://www.beckhoff.com/secguide>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <https://www.beckhoff.com/secinfo>.

1.4 Safety instructions

Safety regulations

Please note the following safety instructions and explanations!
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

Personal injury warnings

⚠ DANGER

Hazard with high risk of death or serious injury.

⚠ WARNING

Hazard with medium risk of death or serious injury.

⚠ CAUTION

There is a low-risk hazard that could result in medium or minor injury.

Warning of damage to property or environment

NOTICE

The environment, equipment, or data may be damaged.

Information on handling the product



This information includes, for example:
recommendations for action, assistance or further information on the product.

1.5 Documentation issue status

Version	Comments
2.4.0	<ul style="list-style-type: none">• Update chapter "Configuration"• Update chapter "Technical data"• Structure update
2.3.4	<ul style="list-style-type: none">• Update chapter "Technical data"• Structure update
2.3.3	<ul style="list-style-type: none">• Update chapter "Technical data"• Chapter " Notes on information security " added• Chapter " Note - Power supply " added• Structure update
2.3.2	<ul style="list-style-type: none">• Update chapter "Modbus interface"• Structure update
2.3.1	<ul style="list-style-type: none">• Update chapter "Technical data"• Structure update
2.3.0	<ul style="list-style-type: none">• Update chapter "Technical data"• Structure update
2.2.0	<ul style="list-style-type: none">• Update chapter "UL notes"
2.1.0	<ul style="list-style-type: none">• Update chapter "Modbus interfaces"• Update chapter "Technical data"
2.0.2	<ul style="list-style-type: none">• Update chapter "Updating the image of the Bus Coupler"
2.0.1	<ul style="list-style-type: none">• Chapter "Technical data" updated
2.0.0	<ul style="list-style-type: none">• Migration
1.1.0	<ul style="list-style-type: none">• Description of the HTML configuration updated
1.0.0	<ul style="list-style-type: none">• First release

1.6 Version identification of EtherCAT devices

1.6.1 General notes on marking

Designation

A Beckhoff EtherCAT device has a 14-digit designation, made up of

- family key
- type
- version
- revision

Example	Family	Type	Version	Revision
EL3314-0000-0016	EL terminal 12 mm, non-pluggable connection level	3314 4-channel thermocouple terminal	0000 basic type	0016
ES3602-0010-0017	ES terminal 12 mm, pluggable connection level	3602 2-channel voltage measurement	0010 high-precision version	0017
CU2008-0000-0000	CU device	2008 8-port fast ethernet switch	0000 basic type	0000

Notes

- The elements mentioned above result in the **technical designation**. EL3314-0000-0016 is used in the example below.
- EL3314-0000 is the order identifier, in the case of "-0000" usually abbreviated to EL3314. "-0016" is the EtherCAT revision.
- The **order identifier** is made up of
 - family key (EL, EP, CU, ES, KL, CX, etc.)
 - type (3314)
 - version (-0000)
- The **revision** -0016 shows the technical progress, such as the extension of features with regard to the EtherCAT communication, and is managed by Beckhoff.
In principle, a device with a higher revision can replace a device with a lower revision, unless specified otherwise, e.g. in the documentation.
Associated and synonymous with each revision there is usually a description (ESI, EtherCAT Slave Information) in the form of an XML file, which is available for download from the Beckhoff web site.
From 2014/01 the revision is shown on the outside of the IP20 terminals, see Fig. "EL2872 with revision 0022 and serial number 01200815".
- The type, version and revision are read as decimal numbers, even if they are technically saved in hexadecimal.

1.6.2 Version identification of EK Couplers

The serial number/ data code for Beckhoff IO devices is usually the 8-digit number printed on the device or on a sticker. The serial number indicates the configuration in delivery state and therefore refers to a whole production batch, without distinguishing the individual modules of a batch.

Structure of the serial number: **KK YY FF HH**

KK - week of production (CW, calendar week)

YY - year of production

FF - firmware version

HH - hardware version

Example with serial number 12 06 3A 02:

12 - production week 12

06 - production year 2006

3A - firmware version 3A

02 - hardware version 02



Fig. 1: EK1101 EtherCAT coupler with revision 0815 and serial number 41130206

1.6.3 Beckhoff Identification Code (BIC)

The Beckhoff Identification Code (BIC) is increasingly being applied to Beckhoff products to uniquely identify the product. The BIC is represented as a Data Matrix Code (DMC, code scheme ECC200), the content is based on the ANSI standard MH10.8.2-2016.




Fig. 2: BIC as data matrix code (DMC, code scheme ECC200)

The BIC will be introduced step by step across all product groups.

Depending on the product, it can be found in the following places:

- on the packaging unit
- directly on the product (if space suffices)
- on the packaging unit and the product

The BIC is machine-readable and contains information that can also be used by the customer for handling and product management.

Each piece of information can be uniquely identified using the so-called data identifier (ANSI MH10.8.2-2016). The data identifier is followed by a character string. Both together have a maximum length according to the table below. If the information is shorter, spaces are added to it.

Following information is possible, positions 1 to 4 are always present, the other according to need of production:

Position	Type of information	Explanation	Data identifier	Number of digits incl. data identifier	Example
1	Beckhoff order number	Beckhoff order number	1P	8	1P 072222
2	Beckhoff Traceability Number (BTN)	Unique serial number, see note below	SBTN	12	S BTNk4p562d7
3	Article description	Beckhoff article description, e.g. EL1008	1K	32	1K EL1809
4	Quantity	Quantity in packaging unit, e.g. 1, 10, etc.	Q	6	Q 1
5	Batch number	Optional: Year and week of production	2P	14	2P 401503180016
6	ID/serial number	Optional: Present-day serial number system, e.g. with safety products	51S	12	51S 678294
7	Variant number	Optional: Product variant number on the basis of standard products	30P	32	30P F971, 2*K183
...					

Further types of information and data identifiers are used by Beckhoff and serve internal processes.

Structure of the BIC

Example of composite information from positions 1 to 4 and with the above given example value on position 6. The data identifiers are highlighted in bold font:

1P072222**S**BTNk4p562d7**1K**EL1809 **Q**1 **51S**678294

Accordingly as DMC:



Fig. 3: Example DMC **1P**072222**S**BTNk4p562d7**1K**EL1809 **Q**1 **51S**678294

BTN

An important component of the BIC is the Beckhoff Traceability Number (BTN, position 2). The BTN is a unique serial number consisting of eight characters that will replace all other serial number systems at Beckhoff in the long term (e.g. batch designations on IO components, previous serial number range for safety products, etc.). The BTN will also be introduced step by step, so it may happen that the BTN is not yet coded in the BIC.

NOTICE
This information has been carefully prepared. However, the procedure described is constantly being further developed. We reserve the right to revise and change procedures and documentation at any time and without prior notice. No claims for changes can be made from the information, illustrations and descriptions in this documentation.

1.6.4 Electronic access to the BIC (eBIC)

Electronic BIC (eBIC)

The Beckhoff Identification Code (BIC) is applied to the outside of Beckhoff products in a visible place. If possible, it should also be electronically readable.

The interface that the product can be electronically addressed by is crucial for the electronic readout.

K-bus devices (IP20, IP67)

Currently, no electronic storage or readout is planned for these devices.


EtherCAT devices (IP20, IP67)

All Beckhoff EtherCAT devices have an ESI-EEPROM which contains the EtherCAT identity with the revision number. The EtherCAT slave information, also colloquially known as the ESI/XML configuration file for the EtherCAT master, is stored in it. See the corresponding chapter in the EtherCAT system manual ([Link](#)) for the relationships.

Beckhoff also stores the eBIC in the ESI-EEPROM. The eBIC was introduced into Beckhoff IO production (terminals, box modules) in 2020; as of 2023, implementation is largely complete.

The user can electronically access the eBIC (if present) as follows:

- With all EtherCAT devices, the EtherCAT master (TwinCAT) can read the eBIC from the ESI-EEPROM
 - From TwinCAT 3.1 build 4024.11, the eBIC can be displayed in the online view.
 - To do this, check the "Show Beckhoff Identification Code (BIC)" checkbox under EtherCAT → Advanced Settings → Diagnostics:



- The BTN and its contents are then displayed:

No	Addr	Name	State	CRC	Fw	Hw	Production Data	ItemNo	BTN	Description	Quantity	BatchNo	SerialNo
1	1001	Term 1 (EK1100)	OP	0.0	0	0	---						
2	1002	Term 2 (EL1018)	OP	0.0	0	0	2020 KW36 Fr	072222	k4p562d7	EL1809	1		678294
3	1003	Term 3 (EL3204)	OP	0.0	7	6	2012 KW24 Sa						
4	1004	Term 4 (EL2004)	OP	0.0	0	0	---	072223	k4p562d7	EL2004	1		678295
5	1005	Term 5 (EL1008)	OP	0.0	0	0	---						
6	1006	Term 6 (EL2008)	OP	0.0	0	12	2014 KW14 Mo						
7	1007	Term 7 (EK1110)	OP	0	1	8	2012 KW25 Mo						

- Note: As shown in the figure, the production data HW version, FW version, and production date, which have been programmed since 2012, can also be displayed with "Show production info".
- Access from the PLC: From TwinCAT 3.1. build 4024.24, the functions *FB_EcReadBIC* and *FB_EcReadBTN* for reading into the PLC are available in the *Tc2_EtherCAT* library from v3.3.19.0.
- EtherCAT devices with a CoE directory may also have the object 0x10E2:01 to display their own eBIC, which can also be easily accessed by the PLC:

- The device must be in PREOP/SAFEOP/OP for access:

Index	Name	Flags	Value
1000	Device type	RO	0x015E1389 (22942601)
1008	Device name	RO	ELM3704-0000
1009	Hardware version	RO	00
100A	Software version	RO	01
100B	Bootloader version	RO	J0.1.27.0
1011:0	Restore default parameters	RO	> 1 <
1018:0	Identity	RO	> 4 <
10E2:0	Manufacturer-specific Identification C...	RO	> 1 <
10E2:01	SubIndex 001	RO	1P158442SBTN0008jckp1KELM3704 Q1 2P482001000016
10F0:0	Backup parameter handling	RO	> 1 <
10F3:0	Diagnosis History	RO	> 21 <
10F8	Actual Time Stamp	RO	0x170bfb277e

- The object 0x10E2 will be preferentially introduced into stock products in the course of necessary firmware revision.
- From TwinCAT 3.1. build 4024.24, the functions *FB_EcCoEReadBIC* and *FB_EcCoEReadBTN* for reading into the PLC are available in the *Tc2_EtherCAT* library from v3.3.19.0
- The following auxiliary functions are available for processing the BIC/BTN data in the PLC in *Tc2_Uilities* as of TwinCAT 3.1 build 4024.24
 - *F_SplitBIC*: The function splits the Beckhoff Identification Code (BIC) *sBICValue* into its components using known identifiers and returns the recognized substrings in the *ST_SplittedBIC* structure as a return value
 - *BIC_TO_BTN*: The function extracts the BTN from the BIC and returns it as a return value
- Note: If there is further electronic processing, the BTN is to be handled as a string(8); the identifier "SBTN" is not part of the BTN.
- Technical background
 The new BIC information is written as an additional category in the ESI-EEPROM during device production. The structure of the ESI content is largely dictated by the ETG specifications, therefore the additional vendor-specific content is stored using a category in accordance with the ETG.2010. ID 03 tells all EtherCAT masters that they may not overwrite these data in the event of an update or restore the data after an ESI update.
 The structure follows the content of the BIC, see here. The EEPROM therefore requires approx. 50..200 bytes of memory.
- Special cases
 - If multiple hierarchically arranged ESCs are installed in a device, only the top-level ESC carries the eBIC information.
 - If multiple non-hierarchically arranged ESCs are installed in a device, all ESCs carry the eBIC information.
 - If the device consists of several sub-devices which each have their own identity, but only the top-level device is accessible via EtherCAT, the eBIC of the top-level device is located in the CoE object directory 0x10E2:01 and the eBICs of the sub-devices follow in 0x10E2:nn.

PROFIBUS; PROFINET, and DeviceNet devices

Currently, no electronic storage or readout is planned for these devices.

2 Product description

2.1 EKxxxx - System overview



Fig. 4: EtherCAT Terminals at an EKxxxx series Bus Coupler

The Bus Couplers from the EKxxxx series allow EtherCAT Terminals to be operated on conventional fieldbus systems. The ultra-fast, high-performance EtherCAT Terminals with their large range of signal types are thus also available for other fieldbus and Industrial Ethernet systems.

The EKxxxx Bus Couplers are fieldbus slaves and contain an EtherCAT master for the EtherCAT terminals. They convert the telegrams from the higher-level fieldbus systems into the E-bus signal representation. A station consists of an EKxxxx and a number of EtherCAT Terminals.

The EKxxxx is integrated in exactly the same way as the Bus Couplers from the BKxxxx series via the corresponding fieldbus system configuration tools and the associated configuration files, such as GSD, ESD or GSDML.

EtherCAT makes a very flexible topology configuration possible. Thanks to the Ethernet physics, long distances can also be bridged without the bus speed being affected. When changing to the field level – without a control cabinet – the EtherCAT Box modules (EPxxxx) in protection class IP65 can also be connected to the EK9xxx.

Bus Couplers for various fieldbus systems

The variants from the EKxxxx series differ from one another by the interface for the higher-level fieldbus system.

An overview of the various Beckhoff Bus Couplers covering the most important fieldbus systems can be found on the [Beckhoff Website](#).

Embedded PCs with fieldbus interface and decentralized control

The TwinCAT-programmable variant is the CX80xx Embedded PC series.

The variants from the CX80xx series differ from one another by the interface for the higher-level fieldbus system and the possibility to program it.

An overview of the various Beckhoff Embedded PCs covering the most important fieldbus systems can be found on the [Beckhoff Website](#).

2.2 EK9000 - Introduction




Fig. 5: EK9000

The EK9000 Bus Coupler connects Ethernet networks with the EtherCAT Terminals (ELxxxx) and EtherCAT Box modules (EPxxxx) and converts the telegrams from Ethernet to E-bus signal representation.

One station consists of an EK9000 and any number of EtherCAT Terminals. RJ45 is used for the Ethernet connection. In EtherCAT, the Ethernet coupler has at its disposal a lower-level, powerful and ultra-fast I/O system with a large selection of terminals. The coupler supports the Modbus-TCP protocol and therefore fits seamlessly into Ethernet networks.

Configuration

The EK9000 is configured based on HTML pages provided by the Bus Coupler or via the Modbus interface.

2.3 Technical data - EK9000

Technical data	EK9000
Protocol	ModbusTCP/UDP
Interfaces	2 x Ethernet 100 MBit/s, 1 x USB device (behind the front flap)
Bus interface	2 x RJ 45 (switched)
I/O connection	E-bus (EtherCAT Terminals)
Web-based Management	yes
I/O terminals	E-bus (EL, ES, EP), standard digital signals, standard analog signals No gateway EC terminals, no EC terminals with XFC or DC function, no general EtherCAT devices
Number of EC terminals	max. 255
Max size of process data	max. 1440 bytes input and output data
Power supply	24 V _{DC} (-15 %/+20 %)
Power supply I/O terminals	2 A
Max. power loss	3 W
Dimensions (W x H x D)	64 mm x 100 mm x 73 mm
Operating/storage temperature Horizontal installation position	-25°C ... +60°C/-40°C...+85°C see note! **)
Operating/storage temperature Other installation position	0...+55 °C/-25...+85 °C see note! **)
Relative humidity	95 % without condensation
Protection class/installation position	IP20/any
Marking/Approval*)	CE, EAC, UKCA cULus [▶ 24], ATEX [▶ 21], UKCA [▶ 22]

*) Real applicable approvals/markings see type plate on the side (product marking).

● E-bus for current/installation positions **)

- i** - for -25°C..+60°C only horizontal installation position, E-bus current 1 A max.
- for 0...+55 °C installation position any, E-bus current 2 A max.

Ex markings

Standard	Marking
ATEX	II 3 G Ex nA IIC T4 Gc
IECEX	Ex nA IIC T4 Gc

System data	Modbus (EK9000)
Number of I/O modules	control-dependent
Number of I/O points	control-dependent
Transmission medium	4 x 2 twisted pair copper cables category 5 (100 MBit/s)
Cable length	100 m
Transmission rate	100 Mbit/s
Topology	star-shaped cabling, line topology

2.4 Technical data - Modbus

Technical data Ethernet	EK9000
Number of ports	2
integrated switch	2 x Ethernet 100 Mbit/s, 1 x USB device (behind the front flap)
Bus interface	2 x RJ 45 (switched)
100 Mbit/s	Yes, full duplex
Autocrossing	Yes
Protocol	
ModbusTCP	Yes
ModbusUDP	Yes
Functions/service	
Read Coils 1	Yes
Read Discrete Inputs 2	Yes
Read Holding Register 3	Yes
Read Input Register 4	Yes
Write Single Coil 5	Yes
Diagnostics 8	Yes
Write Single Register 6	Yes
Write Multiple Coils 15	Yes
Write Multiple Register 16	Yes
Read/Write Multiple Register 23	Yes
TCP/IP	Yes
ARP	Yes
Web services	Yes
DHCP	Yes
Diagnosis/Status/Alarm	
RUN LED	Yes, green/red
WD LED	Yes, green/red
ERR LED	Yes, green/red
A station consists of an EKxxxx and a number of EtherCAT Terminals.	Yes
Diagnostic messages	Yes

3 Mounting and wiring

3.1 Explosion protection

3.1.1 ATEX - Special conditions (standard temperature range)

⚠ WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components with standard temperature range in potentially explosive areas (directive 2014/34/EU)!

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60079-15! The environmental conditions during use are thereby to be taken into account!
- For dust (only the fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9): The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to EN 60079-31 for group IIIA or IIIB and IP6X for group IIIC, taking into account the environmental conditions under which the equipment is used!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of 0 to 55°C for the use of Beckhoff fieldbus components standard temperature range in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010
- EN 60079-31:2013 (only for certificate no. KEMA 10ATEX0075 X Issue 9)

Marking

The Beckhoff fieldbus components with standard temperature range certified according to the ATEX directive for potentially explosive areas bear one of the following markings:



II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: 0 ... +55°C

II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: 0 ... +55°C
(only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

or



II 3G KEMA 10ATEX0075 X Ex nA nC IIC T4 Gc Ta: 0 ... +55°C

II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: 0 ... +55°C
(only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

3.1.2 ATEX - Special conditions (extended temperature range)

⚠ WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components with extended temperature range (ET) in potentially explosive areas (directive 2014/34/EU)!

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60079-15! The environmental conditions during use are thereby to be taken into account!
- For dust (only the fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9): The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to EN 60079-31 for group IIIA or IIIB and IP6X for group IIIC, taking into account the environmental conditions under which the equipment is used!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of -25 to 60°C for the use of Beckhoff fieldbus components with extended temperature range (ET) in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010
- EN 60079-31:2013 (only for certificate no. KEMA 10ATEX0075 X Issue 9)

Marking

The Beckhoff fieldbus components with extended temperature range (ET) certified according to the ATEX directive for potentially explosive areas bear the following marking:



II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: -25 ... +60°C
II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: -25 ... +60°C
 (only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

or



II 3G KEMA 10ATEX0075 X Ex nA nC IIC T4 Gc Ta: -25 ... +60°C
II 3D KEMA 10ATEX0075 X Ex tc IIIC T135°C Dc Ta: -25 ... +60°C
 (only for fieldbus components of certificate no. KEMA 10ATEX0075 X Issue 9)

3.1.3 IECEx - Special conditions

WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components in potentially explosive areas!

- For gas: The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to IEC 60079-15, taking into account the environmental conditions under which the equipment is used!
- For dust (only the fieldbus components of certificate no. IECEx DEK 16.0078X Issue 3):
The equipment shall be installed in a suitable enclosure providing a degree of protection of IP54 according to EN 60079-31 for group IIIA or IIIB and IP6X for group IIIC, taking into account the environmental conditions under which the equipment is used!
- The equipment shall only be used in an area of at least pollution degree 2, as defined in IEC 60664-1!
- Provisions shall be made to prevent the rated voltage from being exceeded by transient disturbances of more than 119 V!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range for the use of Beckhoff fieldbus components in potentially explosive areas!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The front hatch of certified units may only be opened if the supply voltage has been switched off or a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2011
- EN 60079-15:2010
- EN 60079-31:2013 (only for certificate no. IECEx DEK 16.0078X Issue 3)

Marking

Beckhoff fieldbus components that are certified in accordance with IECEx for use in areas subject to an explosion hazard bear the following markings:

Marking for fieldbus components of certificate no. IECEx DEK 16.0078X Issue 3:	IECEx DEK 16.0078 X Ex nA IIC T4 Gc Ex tc IIIC T135°C Dc
--	---

Marking for fieldbus components of certificates with later issues:	IECEx DEK 16.0078 X Ex nA IIC T4 Gc
--	--

3.1.4 Continulative documentation for ATEX and IECEx

NOTICE



Continulative documentation about explosion protection according to ATEX and IECEx




Pay also attention to the continuative documentation

Ex. Protection for Terminal Systems

Notes on the use of the Beckhoff terminal systems in hazardous areas according to ATEX and IECEx,


that is available for [download](#) within the download area of your product on the Beckhoff homepage www.beckhoff.com!

3.2 UL notice

⚠ CAUTION	
	<p>Application</p> <p>Beckhoff EtherCAT modules are intended for use with Beckhoff's UL Listed EtherCAT System only.</p>
⚠ CAUTION	
	<p>Examination</p> <p>For cULus examination, the Beckhoff I/O System has only been investigated for risk of fire and electrical shock (in accordance with UL508 and CSA C22.2 No. 142).</p>
⚠ CAUTION	
	<p>For devices with Ethernet connectors</p> <p>Not for connection to telecommunication circuits.</p>

Basic principles

UL certification according to UL508 with limited power consumption. The current consumed by the device is limited to a max. possible current consumption of 4 A. Devices with this kind of certification are marked by this sign:



Application

If terminals certified *with restrictions* are used, then the current consumption at 24 V_{DC} must be limited accordingly by means of supply

- from an isolated source protected by a fuse of max. 4 A (according to UL248) or
- from a voltage supply complying with *NEC class 2*.
A voltage source complying with *NEC class 2* may not be connected in series or parallel with another *NEC class 2* compliant voltage supply!

These requirements apply to the supply of all EtherCAT bus couplers, power adaptor terminals, Bus Terminals and their power contacts.

3.3 Mounting

3.3.1 Dimensions

The following illustrations show the dimensions of the Bus Couplers.

Drawings in DWF and STEP format can be found in the Download section of the Beckhoff website.




Fig. 6: EK9xxx – dimensions taking the EK9300 as an example

3.3.2 Installation on mounting rails – Bus Coupler

Snapping onto the mounting rail

The Bus Coupler can simply be snapped onto the mounting rail. To this end position the block on the mounting rail and push it slightly until it engages on the right-hand side. This is indicated by a distinct click. Use a screwdriver to push up the lock on the left-hand side, thereby turning it and causing it to engage audibly.




Fig. 7: EK9300 - Snapping onto the mounting rail

NOTICE

Avoid damage!

Do not force the module or apply excessive pressure!

Installation positions

The installation position of the Bus Coupler is arbitrary.

NOTICE

Installation position of EtherCAT terminals

Observe the installation position of the EtherCAT terminals used – not all of them have an arbitrary installation position. Pay attention to the respective EtherCAT infrastructure components and installation instructions.




Fig. 8: Recommended distances for standard installation position

NOTICE

Comply with the permitted installation position and minimum distances!

We recommend the installation in the horizontal position for optimum ventilation. Furthermore, it is not necessary with this installation position to check whether there are terminals present that may only be installed horizontally.

Other installation positions are allowed, but not recommended.




Fig. 9: Other installation positions

3.4 Wiring

3.4.1 Power supply

Supply of Bus Couplers and Bus Terminals (Us)

The Bus Coupler requires a supply voltage of 24 V_{DC} (-15 %/+20 %) for operation.

The connection is made via the two upper terminal points labelled **24 V** and **0 V**. This power input supplies the Bus Coupler electronics and, via the E-Bus, the electronics of the EtherCAT Terminals. It is electrically isolated from the peripheral supply (Up) of the power contacts.

In order to guarantee the operation of the Bus Coupler and the terminal segment in all cases, the power supply unit must supply 2 A at 24 V.




Fig. 10: Bus Coupler power supply

Power contacts supply (Up)

The three power contacts (spring contacts) are located on the right-hand lateral surface of the Bus Coupler. The spring contacts are hidden in slots so that they can not be accidentally touched. When a Bus Terminal is added, its blade contacts are connected to the spring contacts of the Bus Coupler. The tongue and groove guides on the top and bottom of the Bus Terminal Controllers and of the Bus Terminals guarantees that the power contacts mate securely.

The lower six terminal points labelled **+**, **-** and **PE** are for supplying power to the peripheral supply (Up). These terminal points are connected in pairs to a power contact. This power input allows voltages of up to 24 V and is electrically isolated from the Bus Coupler supply voltage (Us).

The connection of these terminal points in pairs enables the supply to be forwarded. The current load of the power contacts may not permanently exceed 10 A. The current carrying capacity between two terminal points is identical to the current carrying capacity of the connecting wires.

The spring-loaded terminal points are designed for wires with cross-sections from 0.08 mm² to 2.5 mm².

LED

If the power supply unit is connected correctly and the power supply is switched on, the two upper LEDs in the terminal prism are green. The left-hand LED (Us) indicates the supply for the Bus Coupler electronics. The right-hand LED (Up) indicates the supply for the power contacts. The other LEDs indicate the state of the E-bus. The detailed meanings of the LED displays are described in the chapter *LED displays*.

PE power contacts

NOTICE
<p>Power contact PE</p> <p>The PE power contact must not be used for other potentials.</p>

3.4.2 Ethernet

3.4.2.1 Ethernet connections



Fig. 11: RJ45 interface

Assignment of the RJ45 interface, port (switched)

EK9xxx: X001 / X002

PIN	Signal	Description
1	TD +	Transmit +
2	TD -	Transmit -
3	RD +	Receive +
4	connected	reserved
5		
6	RD -	Receive -
7	connected	reserved
8		

3.4.2.2 Ethernet cable

Transmission standards

10Base5

The transmission medium for 10Base5 consists of a thick coaxial cable ("yellow cable") with a max. transmission speed of 10 Mbit/s arranged in a line topology with branches (drops) each of which is connected to one network device. Because all the devices are in this case connected to a common transmission medium, it is inevitable that collisions occur often in 10Base5.

10Base2

10Base2 (Cheaper net) is a further development of 10Base5, and has the advantage that the coaxial cable is cheaper and, being more flexible, is easier to lay. It is possible for several devices to be connected to one 10Base2 cable. It is frequent for branches from a 10Base5 backbone to be implemented in 10Base2.

10BaseT

Describes a twisted pair cable for 10 Mbit/s. The network here is constructed as a star. It is no longer the case that every device is attached to the same medium. This means that a broken cable no longer results in failure of the entire network. The use of switches as star couplers enables collisions to be reduced. Using full-duplex connections they can even be entirely avoided.

100BaseT

Twisted pair cable for 100 Mbit/s. It is necessary to use a higher cable quality and to employ appropriate hubs or switches in order to achieve the higher data rate.

10BaseF

The 10BaseF standard describes several optical fiber versions.

Short description of the 10BaseT and 100BaseT cable types

Twisted-pair copper cable for star topologies, where the distance between two devices may not exceed 100 meters.

UTP

Unshielded twisted pair

This type of cable belongs to category 3, and is not recommended for use in an industrial environment.

S/UTP

Screened/unshielded twisted pair (screened with copper braid)

Has an overall shield of copper braid to reduce influence of external interference. This cable is recommended for use with Bus Couplers.

FTP

Foiled shielded twisted pair (screened with aluminum foil)

This cable has an overall shield of laminated aluminum and plastic foil.

S/FTP

Screened/foiled-shielded twisted pair (screened with copper braid and aluminum foil)

Has a laminated aluminum screen with a copper braid on top. Such cables can provide up to 70 dB reduction in interference power.

STP

Shielded twisted pair

Describes a cable with an outer screen, without defining the nature of the screen any more closely.

S/STP

Screened/shielded twisted pair (wires are individually screened)

This identification refers to a cable with a shield for each of the two wires as well as an overall shield.

ITP

Industrial Twisted-Pair

The structure is similar to that of S/STP, but, in contrast to S/STP, it has only one pair of conductors.

3.4.2.3 Ethernet topology

EK9000

The construction of the EK9000 can take place in a line, with adherence to the following points:

- Maximum 20 Bus Couplers one behind the other
- No switches should be used in the line




Fig. 12: Ethernet topology

3.5 Note - power supply

⚠ WARNING**Power supply from SELV / PELV power supply unit!**

SELV / PELV circuits (safety extra-low voltage / protective extra-low voltage) according to IEC 61010-2-201 must be used to supply this device.

Notes:

- SELV / PELV circuits may give rise to further requirements from standards such as IEC 60204-1 et al, for example with regard to cable spacing and insulation.
- A SELV supply provides safe electrical isolation and limitation of the voltage without a connection to the protective conductor, a PELV supply also requires a safe connection to the protective conductor.

3.6 Disposal



Products marked with a crossed-out wheeled bin shall not be discarded with the normal waste stream. The device is considered as waste electrical and electronic equipment. The national regulations for the disposal of waste electrical and electronic equipment must be observed.

4 Parameterization and commissioning

4.1 DIP switch

Ten-pole DIP switch S001

The DIP switch has the following meaning for the Ethernet interfaces X001 and X002, which are switched:



Fig. 13: DIP switch S001, left off "0", right on "1"

DIP 9	DIP 10	Function of DIP 1 to DIP 8	Restart behaviour	Behaviour with factory settings
0	0	Last byte of the IP address via DIP switches 1 to 8	<ul style="list-style-type: none"> IP address via DIP switch (byte 4) Bytes 1..3 from the setting (Web page) 	<ul style="list-style-type: none"> IP address via DIP switches 192.168.1.xxx (xxx DIP switch) SNM 255.255.255.0
0	1	DHCP DIP switch 1 to 8 set to OFF	<ul style="list-style-type: none"> IP address via DHCP 	<ul style="list-style-type: none"> IP address via DHCP
1	0	Reserved	-	-
1	1	Reserved	-	-

Two-pole DIP switch

(under the flap between the battery and the SD card slot)

DIP switch (red)	Meaning
1 off and 2 off	normal mode, coupler is started
1 on and 2 off	The EK starts in Config Mode; the internal Flash memory can be accessed via the USB interface (for example for an image update).
1 off and 2 on	Factory setting
1 on and 2 on	No function so far

4.2 Further interfaces

Additional interfaces are located under the flap of the EK9xx0.




Fig. 14: Additional interfaces of the EK9xx0

Battery

No battery is required for the EK9xx0, therefore this option is not included.

Red DIP switch

Default setting is OFF/OFF.

In order, for example, to load new firmware to the EK via USB, the first DIP switch must be set to “1” before switching on. If the RUN LED lights up blue, the EK can be connected to the PC by a USB cable. The PC then finds the internal Flash as the storage medium. The storage medium may not be formatted!

Micro SD card

Alternatively the firmware can also be loaded to an SD card. Booting always takes place from the SD card if there is one in the slot. This can be used, for example, to test a firmware before copying it to the EK’s internal Flash.

USB interface

The USB interface can only be used if the “red” DIP switch has been set accordingly. See “Red DIP switch”.

4.3 IP address

The IP address or the mode (e.g. DHCP) can be set using the [DIP switch \[► 35\]](#). Furthermore, an [HTML page \[► 37\]](#) is available for the configuration.

5 Configuration

5.1 Configuration via the HTML pages of the Bus Coupler

An HTML page is available for the configuration. This can be reached via the IP address/Config (e.g. 192.168.1.3/config). We recommend the use of Chrome or Firefox as browser.

If DHCP is used, enter the name of the Bus Coupler instead of the IP address. The default name of the Bus Coupler starts with the string "EK-", followed by the last 3 bytes of its MAC address (MAC ID). The MAC address can be found on the sticker on the left of the Bus Coupler.

Sample: The MAC address is 00-01-05-02-03-04. The resulting default name is "EK-020304". Now enter "EK-020304/Config" in your browser. The login name is "guest", the default password is "1" (without quotes).

NOTICE

Restarting the coupler after changing the configuration

If the configuration or mapping is changed, the coupler must be restarted in order to recalculate the mapping of the EtherCAT Terminals.

The configuration is based on standard web technology and the browsers therefore work with a cache memory. This can lead to content from the cache memory being displayed and not from the device itself, so it is recommended to delete the cache memory of the browser after restarting the coupler and then call it up again so that old data is not displayed.

The firmware and hardware versions as well as the serial number can be read on the information diagnostic page. The diagnosis history can be read if problems occur. The diagnosis history is not saved and is cleared in the case of a restart.




Fig. 15: Configuration via HTML pages - information diagnostic page

Network-Interface

The network interface enables you to set the IP address. Please note that the DIP switch of the EK9000 takes precedence and its setting applies regardless of what you set in the dialog.




Fig. 16: Configuration via HTML pages - network interface

Sample

DIP switch DIP 1 = on; DIP 2..10 off, setting in the dialog 10.1.2.3 -> genuine IP address = 10.1.2.1 (the DIP switch overwrites the last byte of the IP address).

Set the desired IP address and then click on the checkmark.

Note: the old IP address is displayed again in the dialog field since it is still the valid address.

A software reboot is necessary after changing the IP address. To do this, go onto "Boot Opt." and click on "Reboot...".

With the DIP switch setting

- DIP 1 to DIP 8 = on and
- DIP 9 and DIP 10 = off

the complete 4 bytes of the IP address are accepted from the dialog field.

5.2 EtherCAT configuration

EtherCAT Terminals can be configured and parameterized via the HTML page *Beckhoff Device Manager*.

The screenshot shows the BECKHOFF Device Manager interface. On the left, there are navigation buttons for 'Device', 'EtherCAT', and 'Modbus'. The main content area is divided into several sections:

- EtherCAT Master:** Shows the State Machine with buttons for Init, Pre-Op, Safe-Op, Op (highlighted), and Boot.
- Network Statistics:** A table showing network performance metrics.

Counter	Cyclic	Queued
Send Frames	18464	201
Frames/sec	1000	11
Lost Frames	0	0
Tx/Rx Errors	0	0
- EtherCAT Slaves:** A table listing three slaves with their states and addresses.

Name	State	Addr	Restore State
Slave 1 (EL2002)	Init Pre-Op Safe-Op Op Boot	1001	
Slave 2 (EL3204)	Init Pre-Op Safe-Op Op Boot	1002	EMPTY
Slave 3 (EL3202)	Init Pre-Op Safe-Op Op Boot	1003	EMPTY
- EtherCAT Slave Mappings:** A section for defining mappings between slave names and addresses.
- Configuration Management:** Contains buttons for 'Create Restore File', 'Delete Restore File', 'Backup Restore File', and 'Upload Restore File', each with a brief description of its function.

Fig. 17: Configuration via HTML pages - EtherCAT configuration

EtherCAT Master

The current state of the EtherCAT Master on the EK coupler is displayed here. It should usually be in the OP state.

Network Statistics

The EtherCAT statistics are output here.

EtherCAT Slaves

Display of the EtherCAT slaves and their states. The Restore State indicates whether a Restore File has been created for the terminals.

Restore File

The Restore File is required in order to be able to parameterize EtherCAT Terminals again. If EtherCAT Terminals are exchanged and have been parameterized, this information is usually lost when the EtherCAT Terminal is exchanged. The Restore File loads the parameters to the new terminal when the coupler is started. The Restore File has to be created if you want to change the default mapping of the terminals, or if you have to.

- EMPTY
means there is no Restore File for the terminal
- VALID
a valid Restore File has been created

- MAPPING
The terminal mapping has been changed, but has not yet been stored in a Restore File.

EtherCAT Slaves Mappings

In some EtherCAT Terminals the process image can be changed; it must be stored in the EtherCAT master. The terminals that can be changed are displayed under "EtherCAT Slaves Mapping"; the corresponding mapping must be set and stored in the Restore file. The coupler is then restarted so that it can activate the mapping (attention: the process image is changed as a result)

EtherCAT Slave Mappings	
Name	Mapping
Slave 4 (EL1502)	1a001a01 (After Reboot: 2Ch. Counter)
Slave 6 (EL3002)	Compact
Slave 8 (EL5151)	Standard After Reboot: Standard 16 Bit (MDP 511))
	Compact

Fig. 18: Configuration via HTML pages - EtherCAT slave mappings

Parameterization of the EtherCAT Terminals

To parameterize an EtherCAT Terminal, select the required terminal. Its objects are then displayed and can be edited if necessary. The settings are then stored in the terminal. Note that any modifications are lost if the terminal is replaced. In this case use the restore file, which contains your modifications.

i Restore file overwrites Modbus modifications

If the Restore File is used, the object parameters are always loaded into the terminal on starting the coupler. This will overwrite changes that you have made by Modbus Interface or web page.

BECKHOFF Device Manager

Device
←
→

EtherCAT

Modbus

Master

Slave 1
EL2002

Slave 2
EL3204

Slave 3
EL3202

Slave 4
EL1502

Slave 5
EL3314

Slave 6
EL3002

Slave 7
EL4032

Slave 8
EL5151

Slave 2 EL3204

Name: Slave 2 (EL3204-0000-0018)

Type: EL3204

Address: 1002

Vendor ID: 2

Hardware Version: 09

Software Version: 07

EtherCAT State

State Machine: Init Pre-Op Safe-Op Op Boot

Parameter

Index	Name	Value
8000	RTD Settings Ch.1	> 27 <
8000: 01	Enable user scale	0
8000: 02	Presentation	Signed
8000: 05	Siemens bits	0
8000: 06	Enable filter	0
8000: 07	Enable limit 1	0
8000: 08	Enable limit 2	0
8000: 09	Enable automatic calibration	0
8000: 0A	Enable user calibration	0
8000: 0B	Enable vendor calibration	1
8000: 11	User scale offset	0x0000 (0)
8000: 12	User scale gain	0x00010000 (65536)
8000: 13	Limit 1	0x0000 (0)
8000: 14	Limit 2	0x0000 (0)
8000: 15	Filter settings	5 Hz
8000: 16	Calibration intervall	0x0000 (0)
8000: 17	User calibration offset	0x0000 (0)
8000: 18	User calibration gain	0xFFFF (65535)
8000: 19	RTD element	Resistor 1/16 Ohm resolution (0..4095 Ohm)

Fig. 19: Configuration via HTML pages - parameterizing the EtherCAT Terminals

5.3 Modbus configuration

Modbus configuration settings.

BECKHOFF Device Manager

Modbus Device

MAC Address	00:01:05:21:5D:1E
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway Address	0.0.0.0

Modbus Settings

Watchdog Mode	Telegram
Watchdog Timeout	1000
Writelock	Yes
Fallback Mode	Set to Zero
Enable Modbus/TCP	Yes
Max. TCP connections	3
Enable Modbus/UDP	Yes
TCP/UDP Port	502

Ethernet Statistics

Counter	Frames	Errors
Ethernet Rx Frames	5186944 (336.2/sec)	0
Ethernet Tx Frames	4501343 (307.5/sec)	0

IPStack Statistics

Diagnosis	Value
Ip Frames	Send 4501067/0 Recv 4798235/0
Arp Request	Send 0/0 Recv 24/0
Arp Reply	Send 24/0 Recv 21/0
Echo Request	Send 0/0 Recv 0/0
Echo Reply	Send 0/0 Recv 0/0
Link Status changed	1

Fig. 20: Configuration via HTML pages - Modbus configuration

Modbus Device

All parameters are "read only" and are for the purposes of diagnosis only.

Modbus Settings

Settings can be made here for the Modbus interface.

Watchdog Mode (0x1122)

You can choose between Disabled, Telegram and Write here. The watchdog is activated with the first write telegram to the process data; write access is given to the master that was the first to execute a write access to the process data.

- Disabled
the watchdog is switched off; outputs that are set remain set.
- Telegram
the watchdog is also retriggered by read telegrams to the process data.
- Write
the watchdog is retriggered only by write telegrams to the process data.

The setting is also to be written via the Modbus Interface Offset 0x1122.

Watchdog Timeout (0x1120)

The timeout in [ms] is to be entered here, recommended values 500 ms - 5000 ms; smaller values are not recommended because this can very quickly lead to a watchdog error. The maximum value is one minute.

Writelock (0x1124)

Enables writing from a second master (client) also. Note that only the first master triggers the watchdog when writing from a second master. Furthermore, also pay attention to overlapping write commands. Sample: if a master sets the first digital output to TRUE and the second Modbus client sets the first output to FALSE, the output will be switched on and off continuously.

Fallback Mode (0x1123)

The fallback mode is only active if watchdog mode is also activated. You can choose here between "Freeze" (outputs are retained) and "Set to Zero" (outputs are written to zero).

Enable ModbusTCP

Activate or deactivate the ModbusTCP protocol.

Max. TCP connection

Number of simultaneously used TCP connections. It is recommended not to allow more than 3. The more TCP connections, the worse the performance of the coupler.

Enable ModbusUDP

Activate or deactivate the ModbusUDP protocol.

TCP/UDP-Port

TCP or UDP port number of the Modbus communication.

Ethernet statistics

Displays the statistics for the incoming and transmitted Ethernet frames.

IP Stack statistics

Displays the IP statistics.

Modbus Service statistics

Displays the Modbus statistics ([see also Diagnosis Function 8 \[▶ 57\]](#)).

5.4 EtherCAT mapping in the Modbus process image

The Modbus service page shows in which Modbus process image (offset) the EtherCAT Terminals that are used are located. The page also indicates where the terminals are located in the Modbus process image and which Modbus function can be used to access them.

Information on how to interpret the data of the individual EtherCAT Terminals can be found in the terminal-specific documentation.

Modbus Register Interface

Address	Function	Value
0x0000..0x07FF	Process data interface - Inputs	
0x0800..0x0FFF	Process data interface - Outputs	
0x1000	Coupler Id	EK9000Modbus
0x1010	Holding register area byte size	23
0x1011	Input register area byte size	70
0x1012	Coil area bit size	2
0x1013	Discrete input area bit size	0
0x1020	Watchdog expiration time in ms	997
0x1120	Watchdog Timeout in ms	1000
0x1121	Watchdog Reset (write 1 to reset)	0
0x1122	Watchdog Mode	Telegram
0x1123	Fallback Mode	Set to Zero
0x1124	Use write lock	0

Modbus Mapping - Input Register (Read 4)

Address	Slave	Bit Offset	Data Size
0x0000..0x0007	Slave 2 (EL3204-0000-0018)	0	16 Bytes
0x0008..0x000B	Slave 3 (EL3202-0000-0016)	0	8 Bytes
0x000C..0x0011	Slave 4 (EL1502-0000-0020)	0	12 Bytes
0x0012..0x0019	Slave 5 (EL3314-0000-0017)	0	16 Bytes
0x001A..0x001B	Slave 6 (EL3002-0000-0018)	0	4 Bytes
0x001C..0x0022	Slave 8 (EL5151-0000-0024)	0	14 Bytes

Modbus Mapping - Holding Register (Read 3,23 Write 6,16,23)

Address	Slave	Bit Offset	Data Size
0x0800..0x0805	Slave 4 (EL1502-0000-0020)	0	12 Bytes
0x0806..0x0807	Slave 7 (EL4032-0000-0016)	0	4 Bytes
0x0808..0x080A	Slave 8 (EL5151-0000-0024)	0	6 Bytes
0x080B..0x080B	Slave 1 (EL2002-0000-0017)	0	2 Bits

Modbus Mapping - Input Status (Read 2)

Bit Address	Slave	Data Size

Modbus Mapping - Coils (Read 1 Write 5)

Bit Address	Slave	Data Size
1	Slave 1 (EL2002-0000-0017)	2 Bits

Fig. 21: EtherCAT mapping in the Modbus process image

5.5 EK9000 - EtherCAT configurations

The EK9000 is an EtherCAT master with automatic configuration, i.e. all EtherCAT Terminals must always be present when switching on the system. Since the boot-up of the EK9000 generally takes considerably longer than the start-up of the EtherCAT slave devices, the latter can be operated on the same power supply. With decentralised EtherCAT slaves, care must be taken that they are switched on earlier or at the same time as the supply voltage.

Switching EtherCAT devices on or off during the runtime

If one or more EtherCAT devices should fail during the operating phase, an error response is generated on the Modbus. The input data of all EtherCAT devices are then invalid and the output data are no longer accepted. This also applies to the devices that are still in operation on the EK9000. If you wish to use the option to plug in or unplug devices during the runtime, a further "Sync Unit" must be configured. This is not possible with an EK9000. In this case use a CX8090.

EtherCAT topology

All EtherCAT devices must be entered in the order in which they map themselves on the EK9000 and thus on the EtherCAT master. EtherCAT devices are automatically addressed; with a few exceptions all EtherCAT Bus Terminals are equipped with an EtherCAT ASIC. EtherCAT Terminals without an ASIC are, for example, EL9400, EL9070 and other EL9xxx. You can identify these EtherCAT Terminals using the technical data "Message to E-bus". If there is a "-" here, this terminal need not be taken into account for the mapping.

EtherCAT devices are registered in the direction of the EtherCAT telegram.

Sample configuration with EK1100 EtherCAT coupler




Fig. 22: Sample configuration with EK1100 EtherCAT coupler

Sample configuration with EPxxxx EtherCAT Box




Fig. 23: Sample configuration with EPxxxx EtherCAT Box

Example configuration with EK1122 (2-port EtherCAT junction in protection class IP20)

The counting direction is to be observed when using an EK1122!

If EtherCAT junction 1 on the EK1122 is connected, then the EtherCAT frame is forwarded here first (1); if junction 1 is not connected the frame on junction 2 is sent (2), only after that does the sequence continue with the E-bus on the right-hand side (3).




Fig. 24: Example configuration with EK1122 (2-port EtherCAT junction in protection class IP20)

If neither junction is used, then junctions 1 and 2 are bridged, so to speak, and the EtherCAT frame goes directly to the E-Bus on the right-hand side.

Example configuration with EP1122 (2-port EtherCAT junction in protection class IP65)

The counting direction is to be observed when using an EP1122! It is comparable with the EK1122.

If EtherCAT junction 1 on the EP1122 is connected, then the EtherCAT frame is forwarded here first (1); if junction 1 is not connected the frame on junction 2 is sent (2), only after that does the sequence continue with the EtherCAT connection on the right-hand side (3).




Fig. 25: Example configuration with EP1122 (2-port EtherCAT junction in protection class IP65)

If neither junction is used, then junctions 1 and 2 are bridged, so to speak, and the EtherCAT frame goes directly to the EtherCAT connection on the right-hand side.

● No Hot Swap during operation

i You cannot use EP1122 and EK1122 on an EKxxxx for Hot Swap and also not for connection and disconnection during operation. EP1122 and EK1122 are suitable only for topology extension (star) on an EKxxxx.

6 Ethernet

6.1 ModbusTCP/UDP

6.1.1 ModbusTCP/UDP protocol

The Ethernet protocol is addressed by means of the MAC-ID. The user does not normally need to be concerned about this address. The IP number has a length of 4 bytes, and must be parameterized by the user on the Bus Coupler and in the application. In ModbusTCP, the TCP port is set to 502. The UNIT can be freely selected under ModbusTCP, and does not have to be configured by the user.




Fig. 26: ModbusTCP/UDP protocol stack

ModbusUDP

Modbus UDP can also be used instead of ModbusTCP with some products. The port number usually remains the same. Very little changes for the user.

The advantages of ModbusUDP are that it is in most cases simpler to use and usually somewhat faster than a TCP/IP connection.

The advantages of ModbusTCP are the more secure data transmission with repetitions already built in as well as further typical advantages that a TCP/IP connection features.

TCP port number

The TCP port number for ModbusTCP has been standardised to 502.

Modbus-Unit

The unit is returned by the slave.

ModbusTCP Protocol

Byte	Name	Description
0	Transaction identifier	Is returned by the slave
1	Transaction identifier	Is returned by the slave
2	Protocol identifier	always 0
3	Protocol identifier	always 0
4	Length field	0 (if the message is less than 256 bytes in length)
5	Length field	Number of following bytes
6	UNIT identifier	returned by the slave
7	Modbus	Modbus protocol with the function follows

6.1.2 Modbus-Interfaces

Address		Description	
0x0000 0x00FF		Process data interface Inputs	
0x0800 0x08FF		Process data interface Outputs	
0x1000 0x1006	Read only	Bus Coupler detection	
0x1010		Process image length in bit, analog outputs	
0x1011		Process image length in bit, analogue inputs	
0x1012		Process image length in bit, digital outputs	
0x1013		Process image length in bits, digital inputs	
0x1020		Watchdog, current time in [ms]	
0x1021		Number of triggered fallbacks (watchdog timeout or bus error)	
0x1022		Number of active TCP connections	
0x1030		Hardware version	
0x1031		Software version Main	
0x1032		Software version Sub-Main	
0x1033		Software version Beta	
0x1034		Serial number	
0x1035		Production date Day	
0x1036		Production date Month	
0x1037		Production date Year	
0x1040		E-Bus Status 1 OK, 0 not OK	
0x1120	Read/Write	Watchdog predefined time in [ms] (default: 1000)	
0x1121		Watchdog reset register	
0x1122		Type of watchdog	2 Disable
			1 Telegram watchdog (Default)
			0 Watchdog write telegram
0x1123		Fallback Mode Behaviour in case of a watchdog or E-bus error	2 Stop E-bus, E-bus is stopped, E-bus can be reactivated with 0x1140
			1 Freeze
			0 Set to Zero (Default)
0x1124		Writelock Locks the writing of a 2nd Modbus client	1 Yes (Default)
			0 No
0x1140		Write 0, E-bus is switched to INIT, value > 0 EtherCAT master is switched to OP (attention: the last output values are written again), 5 sec timeout in which no fallback is considered.	

Extended Modbus interface

Address		Description
0x6000	Read only	Bus Coupler detection (9000dec)
0x6001		1st terminals
0x60xx		xxth terminal

Address		Register communication via Modbus interface - Description	
0x1400	Read/Write	READ	WRITE
		STATUS	CONTROL
		0x010x - Error	0x0001 execute
		0x020x - Busy	--
		0x040x - done	-
0x1401		Bit 15 0 - Read/ 1 - Write Bit 0..14 Terminal number (position in the EtherCAT structure), starts with 1	
0x1402		CoE index number	
0x1403		Register bit 0..7 Sub Index, bit 8..15 not used	
0x1404		Length in byte	
0x1405		Error Code: ADS Error Code	
0x1406..14FF		Data[1]...Data[FF]	

Example: Reading the 2nd EtherCAT Terminal (EL3204) Object 0x1008 SubIndex 0x00 (name of the terminal)

(Example: <https://infosys.beckhoff.com/content/1033/ek9000/Resources/10949467915.zip>)

1st step

ModbusRegWrite
 MB.Addr:=0x1400
 MB.Len:= 5 (words or registers)
 0x1400:=0x0001
 0x1401:=0x0002; read bit 15=FALSE, 2nd terminal
 0x1402:=0x1008; Object 0x1008
 0x1403:=0x0000; SubIndex 0
 0x1404:=0x0000; Length (only necessary for writing)

Client:

ModbusT CP	Function Code	Start Addr	Length	Byte Len	Execute	R/W terminal	Object No.	SubIndex	Length Write
7 byte	1 byte	2 byte	2 byte	1 byte	2 byte	2 byte	2 byte	2 byte	2 byte
00 00 00 00 00 11 00	10	14 00	00 05	0A	00 01	00 02	10 08	00 00	00 00

Server:

ModbusTCP	Function Code	Start Addr	Length
7 byte	1 byte	2 byte	2 byte
00 00 00 00 00 06 00	10	14 00	00 05

2nd step

ModbusRegRead
 MB.Addr:=0x1400
 MB.Len:= 12 (words or registers)
 0x1400:=0x0201; SDO communication not yet completed, polling must continue, repeat step 2 until value is 0x0400 (where 0x0500 indicates an error).
 0x1401:=0x0002;2nd terminal
 0x1402:=0x1008;
 0x1403:=0x0000;

Client:

ModbusTCP	Function Code	Start Addr	Modbus Length
7 byte	1 byte	2 byte	2 byte
00 00 00 00 00 06 00	03	14 00	00 14

Server:

ModbusTCP	Function Code	Byte Length	Execute	R/W terminal	Object No.	SubIndex	COE Length	Rest
7 byte	1 byte	1 byte	2 byte	2 byte	2 byte	2 byte		30 byte
00 00 00 00 00 2B 00	03	28	02 01	00 02	10 08	00 00	00 00	Don't use it, because length is 0 byte

3rd step (repeat step 2):

ModbusRegRead

- MB.Addr:=0x1400
- MB.Len:= 12 (words or registers)
- 0x1400:=0x0400; without error data ready
- 0x1401:=0x0002; 2nd terminal
- 0x1402:=0x1008; Object 0x1008
- 0x1403:=0x0000; SubIndex
- 0x1404:=0x000B; Length
- 0x1405:=0x0000; Error Code
- 0x1406:=0x4C45; 'EL'
- 0x1407:=0x3233; '32'
- 0x1408:=0x3430; '02'
- 0x1409:=0x30D2; '-0'
- 0x140A:=0x3030; '00'
- 0x140B:=0x0030; '0'

Client:

ModbusTCP	Function Code	Start Addr	Modbus Length
7 byte	1 byte	2 byte	2 byte
00 00 00 00 00 06 00	03	14 00	00 14

Server:

ModbusTCP	Function Code	Byte Len	Execute	R/W terminal	Object No.	SubIndex	COE Length	Error	Data	Rest
7 byte	1 byte	1 byte	2 byte	2 byte	2 byte	2 byte	2 byte	2 byte	11 byte	17 byte
00 00 00 00 00 2B 00	03	28	04 00	00 02	10 08	00 00	00 0B	00 00	4C 45 32 33 32 30 30 D2 30 30 30	Don't use it, because length is 11 byte

If more data is read than the CoE length returns, this data is to be ignored. Old data may still be in the buffer here, but this is irrelevant for the response; the COE length must be evaluated here.

Example: Writing the 5th EtherCAT Terminal (EL3318) Object 0x8000 SubIndex 0x19, value for 75µV measurement = 102 dec

Example of a write to an EL3318 (5th terminal) where the first channel of the terminal is to be set to the 75µV measurement type.

1st step

Write Multiple Registers (Modbus Function Code 16)

MB.Addr:=0x1400

MB.Len:= 7 (words or registers)

0x1400:=0x0001

0x1401:=0x8005; Write (bit 15 = TRUE), 5. Terminal

0x1402:=0x8000; Object 0x8000

0x1403:=0x0019; SubIndex 0x19

0x1404:=0x0002; Length

0x1405:=0; Error Code

0x1406:=102; Value for 0x8000, SubIdx 0x19

2nd step

Read Multiple Register (Modbus Function Code 3), at least 6 words should be read here. If an error occurs, the error code starts at offset 0x1405.

Query up to bit 10 in offset 0x1400, if this is "done" (0x04xx), the write was successful.

If the response in offset 0x1400 is the value 0x02xx, the write process has not yet been completed. The reading is then to be repeated.

If the response in offset 0x1400 is the value 0x01xx, an error has occurred. The error code can then be found in offset 0x1405, it is a ADS error code.

Modbus UDP

The communication can also optionally be used via Modbus UDP.

6.1.3 ModbusTCP slave error answer (BK9000, BX/BC9000, IP/ILxxxx-B/C900, EK9000)

When the user sends the slave either a request or information that the coupler does not understand, the slave responds with an error report. This answer contains the function and the error code. 0x80 is added to the value returned by the function.

Code	Name	Meaning
1	ILLEGAL FUNCTION	Modbus function not implemented
2	ILLEGAL DATA ADDRESS	Invalid address or length
3	ILLEGAL DATA VALUE	Invalid parameter - Diagnostic functions - Incorrect register
4	SLAVE DEVICE ERROR	Watchdog or K-Bus error EK9000: E-bus error
6	SLAVE DEVICE BUSY	Output data is already been received from another IP device

6.1.4 Access via a second client

The EK9000 can also be addressed via a further client. This can access the coupler for reading. However, a write procedure is rejected and acknowledged with a Modbus error as long as the first client is still triggering the watchdog.

If the first client fails, the second client takes over after half the watchdog time and can write the outputs itself after half the watchdog time. If the watchdog time is set accordingly high, this can take place virtually non-reactively, i.e. the set outputs remain set. If the first client becomes active again, it then receives a Modbus error message when writing.

● **Function**

i The manufacturer of the application is solely responsible for the use and method of this type of communication.

● **When this method doesn't take effect**

i The first client's application is frozen, but Modbus telegrams are still being sent. In this case the second Modbus client would have no chance to take over the EK9000 because Modbus telegrams are still being sent.

6.1.5 Modbus functions

6.1.5.1 ModbusTCP functions

In the Modbus protocol, the functions determine whether data is to be read or written, and what kind of data is involved.

Function	Code	Description
Read coil status [► 54]	1	Read digital outputs
Read input status [► 54]	2	Read digital inputs
Read holding register [► 55]	3	Read analog outputs and inputs / GPR
Read input register [► 55]	4	Reading the inputs / GPR
Force single coil [► 56]	5	Writing a digital output
Preset single register [► 57]	6	Writing an output / GPR
Diagnostics [► 57]	8	Diagnostics
Force multiple coils [► 60]	15	Write a number of digital outputs
Preset multiple register [► 61]	16	Writing several outputs / GPRs
Read / write registers [► 62]	23	Write and read a number of process data outputs / GPRs

GPR (General Preset Register) - register structure of the Modbus interface (see Appendix)

6.1.5.2 Read coil status (Function 1)

The *Read coil status* function can be used to read the digital outputs that have been set.

The first 10 digital outputs are read in this example. The start address is zero. An offset can be entered in the *Start address* field

Query

Byte Name	Sample
Function code	1
Start address high	0
Start address low	0
Count high	0
Count low	10

The fieldbus coupler answers with *byte count 2*, i.e. 2 bytes of data are returned. The query was for 10 bits, and these are now distributed over 2 bytes. The third bit is set in the output process image, and the fieldbus coupler shows the value 4 in the first data byte.

Response

Byte Name	Sample
Function code	1
Byte Count	2
Data bits 0...7	4
Data bits 8..0.18	0

6.1.5.3 Read input status (Function 2)

The *Read input status* function can be used to read the digital input data. The first 10 digital inputs are read in this example. The start address is zero. An offset can be entered in the *Start address* field

Query

Byte Name	Sample
Function code	2
Start address high	0
Start address low	0
Count high	0
Count low	10

The fieldbus coupler answers with *byte count 2*, i.e. two bytes of data are returned. The query was for 10 bits, and these are now distributed over 2 bytes. The third bit is set in the output process image, and the fieldbus coupler shows the value 4 in the first data byte.

Response

Byte Name	Sample
Function code	2
Byte Count	2
Data bits 0..0.7	1
Data bits 8...18	0

6.1.5.4 Read holding register (Function 3)

The *Read holding register* function can be used to read the input and output words and the registers. Inputs from offset 0 - 0xFF and outputs from offset 0x800 - 0x8FF, and for controllers (BC, BX) the flag area from offset 0x4000.

In this example the first two analog outputs (or two output words) are read. The analog outputs (or output words) start at offset 0x800. The length indicates the number of channels (or words) to be read.

Query

Byte Name	Sample
Function code	3
Start address high	8
Start address low	0
Count high	0
Count low	2

The fieldbus coupler answers with byte count 4, i.e. 4 bytes of data are returned. The query was for two analog channels, and these are distributed over two words. In the analog output process image, the first channel has the value 0x3FFF, while the second channel has the value 0x0.

Response

Byte Name	Sample
Function code	3
Byte Count	4
Data 1 high byte	63
Data 1 low byte	255
Data 2 high byte	0
Data 2 low byte	0

6.1.5.5 Read input register (Function 4)

The function *Read input register* reads the inputs on a word basis.

In this example the first two analog inputs (or the first two input words) are read. The analog inputs (or input words) start at an offset of 0x0000. The length indicates the number of words to be read. A KL3002, for example, has two words of input data. Therefore, the length to be entered at *Number low* is two.

Query

Byte Name	Sample
Function code	4
Start address high	0
Start address low	0
Count high	0
Count low	2

The fieldbus coupler answers with byte count 4, i.e. four bytes of data are returned. The query was for two analog channels, and these are now distributed over 2 words. In the analog input process image, the first channel has the value 0x0038, while the second channel has the value 0x3F1B.

Response

Byte Name	Sample
Function code	4
Byte Count	4
Data 1 high byte	0
Data 1 low byte	56
Data 2 high byte	63
Data 2 low byte	11

6.1.5.6 Force single coil (Function 5)

The *Force single coil* function can be used to write a digital output. The third digital output is written in this example. The digital outputs start at address 0x0000. The digital value is located in *Data high*. To switch the output on, *Data high* must contain the value 0xFF, while 0x00 is used to switch the output off again. *Data low* must contain the value 0x00.

Query

Byte Name	Sample
Function code	5
Start address high	0
Start address low	2
Data high	255
Data low	0

The coupler answers with the same telegram.

Response

Byte Name	Sample
Function code	5
Start address high	0
Start address low	2
Data high	255
Data low	0

6.1.5.7 Preset single register (Function 6)

The function *Preset singles register* can be used to access the output or flag process image (only for controllers) and the [Modbus TCP interface](#) [► 49].

Function 6 writes the first output word. The outputs start at an offset of 0x0800. Here again the offset always describes a word. This means offset 0x0803 refers to the fourth word in the output process image.

Query

Byte Name	Sample
Function code	6
Start address high	8
Start address low	0
Data high	63
Data low	255

The Fieldbus Coupler replies with the same telegram and confirmation of the received value.

Response

Byte Name	Sample
Function code	6
Start address high	8
Start address low	0
Data high	63
Data low	255

6.1.5.8 Diagnosis (Function 8)

The diagnosis function provides a series of tests for checking the communication system between the master and the slave and for examining a variety of internal error states within the slave.

The function uses two bytes in the query to specify a sub-function code defining the test that is to be carried out. The slave returns the function code and the sub-function code in the response.

The diagnostic queries use a two-byte data field to send diagnostics data or control information to the slave.

Query

Byte Name	Sample
Function code	8
Sub-function high	0
Sub-function low	0
Data high	2
Data low	3

Response

Byte Name	Sample
Function code	8
Sub-function high	0
Sub-function low	0
Data high	2
Data low	3

Coupler reset (Sub-function 1)

The Bus Coupler is reset with sub-function 1, error counters are reset and the Bus Coupler performs a self-test. No telegrams are either received or sent while the Bus Coupler is being reset. The IP socket is closed.

**Tip or pointer**

Before the Coupler restarts it sends a reply with sub-function 1, after which the IP socket is closed.

Sub-function	Data field (query)	Data field (response)
0x0001	0x0000	0x0000

Delete all counter contents (sub-function 10)

When this sub-function is called the controller clears all error counters.

Sub-function	Data field (query)	Data field (response)
0x000A	0x0000	Echo query data

Read Coils (sub-function 32)

Indicates the number of Read Coils commands.

Sub-function	Data field (query)	Data field (response)
0x0020	0x0000	Counter value

Read Coils Error (sub-function 33)

Indicates the number of Read Coils commands with error.

Sub-function	Data field (query)	Data field (response)
0x0021	0x0000	Counter value

Read Discrete Inputs (sub-function 34)

Indicates the number of Read Discrete Inputs commands.

Sub-function	Data field (query)	Data field (response)
0x0022	0x0000	Counter value

Read Discrete Inputs Error (sub-function 35)

Indicates the number of Read Discrete Inputs commands with error.

Sub-function	Data field (query)	Data field (response)
0x0023	0x0000	Counter value

Read Holding Register (sub-function 36)

Indicates the number of Read Holding Register commands.

Sub-function	Data field (query)	Data field (response)
0x0024	0x0000	Counter value

Read Holding Register Error (sub-function 37)

Indicates the number of Read Holding Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x0025	0x0000	Counter value

Read Input Register (sub-function 38)

Indicates the number of Read Input Register commands.

Sub-function	Data field (query)	Data field (response)
0x0026	0x0000	Counter value

Read Input Register Error (sub-function 39)

Indicates the number of Input Holding Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x0027	0x0000	Counter value

Write Single Coil (sub-function 40)

Indicates the number of Write Single Coil commands.

Sub-function	Data field (query)	Data field (response)
0x0028	0x0000	Counter value

Write Single Coil Error (sub-function 41)

Indicates the number of Write Single Coil commands with error.

Sub-function	Data field (query)	Data field (response)
0x0029	0x0000	Counter value

Write Single Register (sub-function 42)

Indicates the number of Write Single Register commands.

Sub-function	Data field (query)	Data field (response)
0x002A	0x0000	Counter value

Write Single Register Error (sub-function 43)

Indicates the number of Write Single Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x002B	0x0000	Counter value

Diagnostic Register (sub-function 44)

Indicates the number of Diagnostic Register commands.

Sub-function	Data field (query)	Data field (response)
0x002C	0x0000	Counter value

Diagnostic Register Error (sub-function 45)

Indicates the number of Diagnostic Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x002D	0x0000	Counter value

Write Multiple Coils (sub-function 46)

Indicates the number of Write Multiple Coils commands.

Sub-function	Data field (query)	Data field (response)
0x002E	0x0000	Counter value

Write Multiple Coils Error (sub-function 47)

Indicates the number of Write Multiple Coils commands with error.

Sub-function	Data field (query)	Data field (response)
0x002F	0x0000	Counter value

Write Multiple Register (sub-function 48)

Indicates the number of Write Multiple Register commands.

Sub-function	Data field (query)	Data field (response)
0x0030	0x0000	Counter value

Write Multiple Register Error (sub-function 49)

Indicates the number of Write Multiple Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x0031	0x0000	Counter value

R/W Multiple Register (sub-function 50)

Indicates the number of R/W Multiple Register commands.

Sub-function	Data field (query)	Data field (response)
0x0032	0x0000	Counter value

R/W Multiple Register Error (sub-function 51)

Indicates the number of R/W Multiple Register commands with error.

Sub-function	Data field (query)	Data field (response)
0x0033	0x0000	Counter value

6.1.5.9 Force multiple coils (Function 15)

The *Force multiple coils* function can be used to set or reset a number of digital outputs at the same time.

The first 20 digital outputs are written in this example. The digital outputs start at an offset of 0x0000. Here the offset always describes a bit. Offset 0x0003 writes to the fourth bit in the output process image. The length indicates the number of bits, and the *Byte count* is formed from the combination all the bytes that are to be written.

Sample: 20 bits yield a byte count of 3 (rounded up to a byte boundary).

The data bytes contain the values for the individual bits. In this example, bits 0 to 15 are set to TRUE, while bits 16 to 23 are FALSE.

Query

Byte Name	Sample
Function code	15
Start address high	0
Start address low	0
Length high	0
Length low	20
Byte Count	3
Data 1 bit 0..0.7	255
Data 2 bit 8..0.15	255
Data 3 bit 16...23	0

Response

The Bus Coupler answers with the same telegram.

Byte Name	Sample
Function code	15
Start address high	0
Start address low	0
Length high	0
Length low	20

6.1.5.10 Preset single register (Function 16)

The *Preset multiple register* function can be used to write a number of outputs. The first two analog output words are written in this example. The outputs start at an offset of 0x0800. Here the offset always describes a word. Offset 0x0003 writes to the fourth word in the output process image. The length indicates the number of words, and the *Byte count* is formed from the combination of all the bytes that are to be written.

Sample: 4 words – correspond to a byte count of 8

The data bytes contain the values for the analog outputs. In this example, two words are to be written. The first word is to receive the value 0x7FFF, and the second word is to receive the value 0x3FFF.

Query

Byte Name	Sample
Function code	16
Start address high	8
Start address low	0
Length high	0
Length low	2
Byte Count	4
Data 1 byte 1	127
Data 1 byte 2	255
Data 2 byte 1	63
Data 2 byte 2	255

Response

The coupler replies with the start address and the length of the transmitted words.

Byte Name	Sample
Function code	16
Start address high	8
Start address low	0
Length high	0
Length low	2

6.1.5.11 Read / write registers (Function 23)

A number of analog outputs can be written and a number of analog inputs read with one telegram using the *Read / write registers* function. In this example the first two analog output words are written, and the first two analog inputs are read. The analog outputs start at offset 0x0800, while the inputs start at offset 0x0000. Here the offset always describes a word. Offset 0x0003 writes to the fourth word in the output process image. The length indicates the number of words, and the *Byte count* is formed from the combination of all the bytes that are to be written.

Sample: 4 words – correspond to a byte count of 8

The data bytes contain the values for the analog outputs. In this example, two words are to be written. The first word is to receive the value 0x3FFF, and the second word is to receive the value 0x7FFF.

Query

Byte Name	Sample
Function code	23
Read start address high	0
Read start address low	0
Read length high	0
Read length low	2
Write start address high	8
Write start address low	0
Write length high	0
Write length low	2
Byte Count	4
Data 1 high	63
Data 1 low	255
Data 2 high	127
Data 2 low	255

Response

The coupler replies with the start address and the length of the bytes to be transferred in *Byte count*. The data information follows. In this example the first word contains 0x0038 while the second word contains 0x3F0B.

Byte Name	Sample
Function code	23
Byte Count	4
Data 1 high	0
Data 1 low	56
Data 2 high	63
Data 2 low	11

7 Error handling and diagnosis

7.1 LED indicators




Fig. 27: EK9000 LEDs

Ethernet interface X001

Interface X001/X002	Ethernet	Meaning
LED green	on	Link available/activity
LED yellow	is not used	-

LEDs on the coupler

Labelling	Meaning	Colours	Meaning
RUN	Indicates the status of the coupler	red	May only light up during the start-up phase
		green	Coupler is ready
		blue (If red DIP switch 1 is set to on when starting the coupler)	The internal Flash can be reached via USB (firmware update)

LED WD	Modbus Status	Meaning
	green/red/yellow	
EtherCAT bootup	yellow 200 ms flashing	EC master booting up, Modbus communication not yet possible
Parameterization of the terminals	yellow 400 ms flashing	EC master parameterizing the EC Terminals, Modbus communication not yet possible
Run	green on	OK
Watchdog	red 400 ms flashing	Watchdog error

LED ERR	Modbus diagnosis		Meaning
	green	red	
Modbus error	off	briefly lights up	Erroneous Modbus telegram received (see Diag History)
Coupler IP setting	off	flashing 400 ms	Coupler has no IP address (DHCP active)
Device is in IO exchange	off	off	OK
2nd Client	on	off	2 nd client is active, but write telegrams are responded to with an error

LEDs on the power supply terminal




Fig. 28: LEDs on the power supply terminal

Operation with E-bus terminals

Display LED	Description	Meaning
1 Us 24 V (top left, 1 st row)	Coupler supply voltage	connected to -24 V
2 Up 24 V (top right, 1 st row)	Power contacts supply voltage	connected to -24 V
3 L/A (left center, 2 nd row)	EtherCAT LED	flashing green: EtherCAT communication active connected to E-bus / no data traffic not connected to E-bus

8 Appendix

8.1 Update Bus Coupler image

● Loss of data



The data in the internal flash memory are deleted.
Save your data before you update the Bus Coupler image.

The Bus Coupler image can be updated via the USB interface. To this end the Bus Coupler is connected with a host PC via a USB cable. Windows then shows the Bus Coupler as a removable data storage device, and the files can be copied.





The Bus Coupler should only be updated after consultation with the Beckhoff Service. The Beckhoff Service will provide all the required files.

Requirements

- First, check whether the Bus Coupler supports the image.
- The Bus Coupler is connected with the host PC via a USB cable.

Update the image as follows:

1. Switch off the Bus Coupler.
2. Switch the red 2-pin **DIP switch 1** to “on” (to the right) and switch on the Bus Coupler. The Bus Coupler appears as a removable data storage device on the host PC.
3. Select and delete all files. Do not format.

 BklpcDiag	01.01.2006 11:00	Dateiordner	
 Documents and Settings	01.01.2006 11:00	Dateiordner	
 TwinCAT	01.01.2006 11:00	Dateiordner	
 NK.bin	22.05.2017 15:03	BIN-Datei	12.697 KB

4. Remove the USB cable, once all files have been copied, and switch the 2-pin DIP switch to “off” (to the left).
 5. Restart the Bus Coupler.
- ⇒ The image has been updated successfully. After the update, the Bus Coupler may take a little longer to start up.

8.2 FAQ

How can I leave the outputs in the current state in case of a Modbus error?

Set the watchdog module to disable [Web page] or the Modbus interface 0x1122 to "2".

How can I change the mapping of an EtherCAT Terminal?

Use the Web configuration for this and generate a Restore File.

How do I know what the MAC address of the Bus Coupler is?

The MAC address is printed on the label on the side of the Bus Coupler.

What is the USB interface for and what can I do with it?

The USB interface is to be used at present only for firmware updates.

What is the purpose of the DIP switch behind the flap?

It is necessary, for example, for the use of the firmware update (see chapter entitled "DIP switch").

Can I also operate K-bus terminals?

No, only EtherCAT terminals or EtherCAT boxes can be connected. You can use the BK9050 or BK9100 for K-bus terminals. The use of EtherCAT couplers for K-bus such as the BK1120 or BK1250 is not possible.

I have an EtherCAT slave from a third-party vendor, can I also connect it?

No, devices from other vendors can only be used with a CX (see CX8090 or similar products).

I would like to operate the drive terminals/drives on the EK9000. Is that possible?

No, use a CX with a suitable performance for this, e.g. CX9020 or higher.

I would like to operate TwinSAFE terminals on the EK9000. Is that possible?

No, the TwinSAFE terminals require a TwinCAT system for configuration; use the CX8090 for this.

How do I see that there is an EtherCAT error?

In this case the ERR LED lights up red and Modbus telegrams are responded to with error code 4.

8.3 List of Abbreviations

ADS

Automation Device Specification (disclosed protocol for the communication of all Beckhoff controllers)

DAP

Device Access Point

E/A

Inputs and outputs

E-Bus

This means EtherCAT in the terminal group (ELxxxx, ESxxxx, or EMxxxx terminals)

EtherCAT

EtherCAT (Ethernet for Control Automation Technology) is the Ethernet solution for industrial automation, characterized by outstanding performance and particularly simple handling.

Fast Ethernet

This is taken to mean the data rate 100 Mbits/s to be used according to the standard 100 Base-T.

IP20

Protection class of the Bus Terminals, EtherCAT Terminals

IPC

Industrial PC

K-Bus

Terminal bus (KLxxxx, KMxxxx or KSxxxx terminals)

KS2000

Configuration software for Bus Terminals, Bus Couplers, Bus Terminal Controllers, fieldbus box modules, etc.

ModbusTCP

Modbus telegram based on TCP/IP.

ModbusRTU

Modbus telegram based on RS232/422/485.

ModbusUDP

Modbus telegram based on UDP/IP.

PE

The PE power contact can be used as a protective earth.

TwinCAT

The Windows Control and Automation Technology, programmer and configuration tool from the Beckhoff company.

8.4 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for local support and service on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages: www.beckhoff.com

You will also find further documentation for Beckhoff components there.

Support

The Beckhoff Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963 157
e-mail: support@beckhoff.com
web: www.beckhoff.com/support

Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963 460
e-mail: service@beckhoff.com
web: www.beckhoff.com/service

Headquarters Germany

Beckhoff Automation GmbH & Co. KG

Hülshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963 0
e-mail: info@beckhoff.com
web: www.beckhoff.com

More Information:
www.beckhoff.com/EK9000

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

