**BECKHOFF** New Automation Technology

Manual | EN CX7000 Embedded PC



2025-03-11 | Version: 1.5

# Table of contents

1	Note	s on the o	documentation	7
	1.1	Represe	ntation and structure of warnings	8
	1.2	Docume	ntation issue status	9
2	For y	our safet	ty	10
	2.1	Intended	- l use	10
	2.2	Staff qua	alification	10
	2.3	Safety in	istructions	10
	2.4	Notes or	n information security	11
3	Tran	sport and	I storage	12
4	Prod	uct overv	/iew	13
	4.1	Structure	9	14
	4.2	Name pl	ate	15
	4.3	Ethernet	interface (X001)	16
	4.4	USB inte	erface (X002)	18
	4.5	MicroSD	card	18
5	Com	missioniı	าต	20
-	5.1	Mountine	J	20
		5.1.1	Note the permissible installation positions	20
		5.1.2	Fastening to the DIN rail	22
		5.1.3	Changing the MicroSD card	23
		5.1.4	Installing passive EtherCAT Terminals	24
	5.2	Power s	upply	25
		5.2.1	Connect Embedded PC	26
		5.2.2	UL requirements	27
6	Multi	function	I/Os	28
	6.1	Digital in	puts	30
	6.2	Digital o	utputs	31
	6.3	Counter	mode	33
		6.3.1	Select operation mode	35
		6.3.2	Switching outputs	36
		6.3.3	Set counter value	37
		6.3.4	Setting the limit value for counters	38
	6.4	Increme	ntal encoder mode	39
		6.4.1	Switching outputs	41
		6.4.2	Latching the counter value	42
		6.4.3	Setting the limit value for counters	43
	6.5	Analog s	ignal mode	44
	6.6	PWM sig	gnal mode	45
		6.6.1	Setting the PWM clock frequency and duty cycle	47
		6.6.2	Setting the channel synchronization	48
7	Conf	iguration		49
	7.1	Starting	the Beckhoff Device Manager	49
	7.2	Persiste	nt data	50

	7.3	NOVRA	М	. 51
		7.3.1	Creating a Retain Handler	. 52
		7.3.2	Creating and linking variables	. 54
		7.3.3	Deleting variables under the Retain Handler	. 57
	7.4	Software	e configuration	. 58
		7.4.1	User name and password	. 58
		7.4.2	Setting the IP address	. 59
		7.4.3	Configure virtual local area network (VLAN)	. 60
		7.4.4	Update image	. 60
		7.4.5	Updating the firmware for multifunction I/Os	. 62
		7.4.6	Updating the ESI device description	. 63
8	Twin	САТ		. 64
	8.1	First Ste	ps	64
		8.1.1	Connect to the CX70x0	. 64
		8.1.2	Scan multifunction I/Os	. 66
		8.1.3	Establishing ADS communication	. 68
		8.1.4	Creating a PLC project	. 70
		8.1.5	Linking variables	. 72
		8.1.6	Load configuration to CX	. 73
	8.2	Reading	the IP and MAC addresses	. 76
	8.3	Virtual E	thernet interface	. 76
	8.4	CoE acc	ess to multi-function I/Os	. 77
	8.5	Power s	upply terminal	. 79
	8.6	Cycle ar	d processing times	. 81
		8.6.1	Measuring processing time in the PLC program	. 81
		8.6.2	Real-Time Clock (RTC)	. 81
		8.6.3	I/O Idle Task:	. 82
		8.6.4	Use NTP provider	. 82
		8.6.5	Cycle time of 250 µs	. 84
	8.7	Function	Blocks	. 90
		8.7.1	FB_CX7000_LED_ERR	. 90
		8.7.2	FB_CX7000_LED_WD	. 91
		8.7.3	FB_CX70xx_RW_EEPROM	. 92
		8.7.4	FB_CX70xx_ResetOnBoardIO	. 93
	8.8	Importar	it attribute pragmas	. 94
		8.8.1	Attribute 'Tc2GvIVarNames'	. 94
		8.8.2	Attribute 'pack_mode'	. 94
		8.8.3	Attribute 'TcCallAfterOutputUpdate'	. 95
9	Error	handling	g and diagnostics	. 99
	9.1	Diagnos	tic LEDs	. 99
		9.1.1	K-bus	100
		9.1.2	E-bus	103
	9.2	Diagnos	is of the multi-function I/Os	104
	9.3	Memory	usage	105
	9.4	Real-tim	e and CPU load	107

10 Technical data	
11 Appendix	111
11.1 Third-Party components	111
11.2 Accessories	111
11.3 Certifications	111
List of tables	112
List of figures	113

## **1** Notes on the documentation

This description is intended exclusively for trained specialists in control and automation technology who are familiar with the applicable national standards.

The documentation and the following notes and explanations must be complied with when installing and commissioning the components.

The trained specialists must always use the current valid documentation.

The trained specialists must ensure that the application and use of the products described is in line with all safety requirements, including all relevant laws, regulations, guidelines, and standards.

#### Disclaimer

The documentation has been compiled with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without notice. Claims to modify products that have already been supplied may not be made on the basis of the data, diagrams, and descriptions in this documentation.

#### Trademarks

Beckhoff<sup>®</sup>, TwinCAT<sup>®</sup>, TwinCAT/BSD<sup>®</sup>, TC/BSD<sup>®</sup>, EtherCAT<sup>®</sup>, EtherCAT G<sup>®</sup>, EtherCAT G10<sup>®</sup>, EtherCAT P<sup>®</sup>, Safety over EtherCAT<sup>®</sup>, TwinSAFE<sup>®</sup>, XFC<sup>®</sup>, XTS<sup>®</sup>, and XPlanar<sup>®</sup> are registered and licensed trademarks of Beckhoff Automation GmbH.

If third parties make use of the designations or trademarks contained in this publication for their own purposes, this could infringe upon the rights of the owners of the said designations.

# Ether**CAT**.

EtherCAT<sup>®</sup> is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

#### Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The distribution and reproduction of this document, as well as the use and communication of its contents without express authorization, are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event that a patent, utility model, or design are registered.

#### Third-party trademarks

Trademarks of third parties may be used in this documentation. You can find the trademark notices here: <u>https://www.beckhoff.com/trademarks</u>.

## **1.1** Representation and structure of warnings

The following warnings are used in the documentation. Read and follow the warnings.

#### Warnings relating to personal injury:

Hazard with high risk of death or serious injury.
Hazard with medium risk of death or serious injury.
There is a low-risk hazard that can result in minor injury.

#### Warnings relating to damage to property or the environment:

NOTICE

There is a potential hazard to the environment and equipment.

#### Notes showing further information or tips:



This notice provides important information that will be of assistance in dealing with the product or software. There is no immediate danger to product, people or environment.

## **1.2** Documentation issue status

Version	Comment
1.0	First version.
1.1	UL notes added.
	Chapter "Function blocks" for LEDs added.
	Composition of the hostname revised.
	Chapter "TwinCAT" revised
1.2	Technical data adapted for counter and encoder mode.
1.3	Connection cross-section adapted for multi-function I/ Os. Chapters "CoE access to multi-function I/Os" and "Diagnosis of multi-function I/Os" revised.
1.4	New firmware with TF6701 TwinCAT 3 IoT Communication (MQTT), and TF6730 TwinCAT 3 IoT Communicator.
1.5	Description of VLAN, NTP provider, and I/O Idle Task added.

# 2 For your safety

Read the chapter on safety and follow the instructions in order to protect from personal injury and damage to equipment.

#### Limitation of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Unauthorized modifications and changes to the hardware or software configuration, which go beyond the documented options, are prohibited and nullify the liability of Beckhoff Automation GmbH & Co. KG.

In addition, the following actions are excluded from the liability of Beckhoff Automation GmbH & Co. KG:

- Failure to comply with this documentation.
- Improper use.
- Use of untrained personnel.
- Use of unauthorized replacement parts.

### 2.1 Intended use

The embedded PC is a control system for use in machine and system engineering for automation, visualization and communication. The embedded PC is designed for installation in a control cabinet or terminal box and is used together with Bus or EtherCAT Terminals to receive digital and analog signals from sensors and output them to actuators or forward them to higher-level controllers.

The Embedded PC is designed for a working environment that meets the requirements of protection class IP20. This involves finger protection and protection against solid foreign objects up to 12.5 mm, but not protection against water. Operation of the devices in wet and dusty environments is not permitted, unless specified otherwise. The specified limits for electrical and technical data must be adhered to.

#### Improper use

The Embedded PC is not suitable for operation in the following areas:

- Potentially explosive atmospheres.
- · Areas with an aggressive environment, e.g. aggressive gases or chemicals.
- Living areas. If the devices are to be used in living areas, the relevant standards and guidelines for interference emissions must be adhered to, and the devices must be installed in housings or control boxes with suitable shielding.

### 2.2 Staff qualification

All operations involving Beckhoff software and hardware may only be carried out by qualified personnel with knowledge of control and automation engineering. The qualified personnel must have knowledge of the administration of the Industrial PC and the associated network.

All interventions must be carried out with knowledge of control programming, and the qualified personnel must be familiar with the current standards and guidelines for the automation environment.

### 2.3 Safety instructions

The following safety instructions must be followed during installation and working with networks and the software.

#### Mounting

• Never work on live equipment. Always switch off the power supply for the device before installation, troubleshooting or maintenance. Protect the device against unintentional switching on.

- Observe the relevant accident prevention regulations for your machine (e.g. the BGV A 3, electrical systems and equipment).
- Ensure standard-compliant connection and avoid risks to personnel. Ensure that data and supply cables are laid in a standard-compliant manner and ensure correct connection.
- Observe the relevant EMC guidelines for your application.
- Avoid polarity reversal of the data and supply cables, as this may cause damage to the equipment.
- The devices contain electronic components, which may be destroyed by electrostatic discharge when touched. Observe the safety precautions against electrostatic discharge according to DIN EN 61340-5-1/-3.

#### Working with networks

- Restrict access to all devices to an authorized circle of persons.
- Change the default passwords to reduce the risk of unauthorized access.
- Protect the devices with a firewall.
- Apply the IT security precautions according to IEC 62443, in order to limit access to and control of devices and networks.

### 2.4 Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <u>https://www.beckhoff.com/secguide</u>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <u>https://www.beckhoff.com/secinfo</u>.

# 3 Transport and storage

#### Transport

#### NOTICE

#### Short circuit due to moisture

Moisture can form during transport in cold weather or in the event of large temperature fluctuations.

Avoid moisture formation (condensation) in the embedded PC, and leave it to adjust to room temperature slowly. If condensation has occurred, wait at least 12 hours before switching on the embedded PC.

Despite the robust design of the unit, the components are sensitive to strong vibrations and impacts. Transporting a control cabinet with a built-in embedded PC can result in excessive impact on the embedded PC.

- During transport, the device must therefore be protected from excessive mechanical stress.
- Appropriate packaging of the industrial PC, in particular the original packaging, can improve vibration resistance during transport.
- Send the embedded PC in the original packaging and additional outer packaging.

Table 1: Dimensions and weight.

	CX7000	
Dimensions (W x H x D)	49 mm x 100 mm x 73 mm	
Weight	approx. 142 g	

#### Storage

• Store the Embedded PC in the original packaging.

## 4 Product overview

The CX7000 embedded PC has an Arm® Cortex®-M7 single-core processor running at 480 MHz and the following basic configuration:

- a microSD card slot with integrated 512 MB microSD card,
- an Ethernet interface (10/100 Mbit/s, RJ45),
- a USB interface (max. 12 Mbit/s, max. 100 mA),
- integrated multi-function I/Os.

The CX7000 is programmed with TwinCAT 3 via the Ethernet interface. In addition, the Beckhoff Device Manger is available as a web interface for configuring the CX7000.

#### Multi-function I/Os

Special features of the CX7000 series are the eight integrated multifunction inputs and four integrated multifunction outputs.

- 8 digital inputs, 24 V DC, filter 3 ms, type 3, 1-wire technique
- 4 digital outputs, 24 V DC, 0.5 A, 1-wire technique

The integrated multifunction I/Os of the CX7000 can be configured via TwinCAT 3 for other operation modes in order to enable fast counting or the processing of analog values:

- Counter mode: 1 x digital counter input 100 kHz, 1 x digital input for up/down counter 20 kHz, 2 x digital counter outputs
- Incremental encoder mode: 2 x digital inputs for 250 kHz encoder signal (A/B input), 2 x digital encoder output
- Analog signal mode: 2 x digital inputs configured as analog inputs 0 to 10 V, 12-bit resolution with 16bit representation
- PWM signal mode: 2 x digital outputs configured for PWM signal, 15 Hz...100 kHz

#### Power supply terminal

EtherCAT Terminals (E-bus) or bus terminals (K-bus) can optionally be connected directly on the right-hand side; the CX7000 automatically recognizes which system is connected during the start-up phase. If further electrical signals are to be processed, the CX7000 can be extended as required and extremely flexibly by EtherCAT Terminals or bus terminals in addition to the integrated I/Os.

#### Firmware

The real-time operating system TwinCAT/RTOS, which is based on FreeRTOS, is used as the operating system or firmware. Note that TwinCAT/RTOS is a closed system and you cannot install your own software. This provides a certain level of security, as third-party software such as viruses or similar cannot be installed and the CX7000 can be connected to a network. The CX7000 can be used from TwinCAT 3.1 Build 4024.12. The following TwinCAT functions are included and licensed:

- TC1000 TC3 ADS
- TC1100 TC3 IO
- TC1200 TC3 PLC
- TF4100 TC3 Controller Toolbox
- TF4110 TC3 Temperature Controller
- TF6255 TC3 Modbus-RTU
- TF6340 TC3 Serial Communication
- TF6701 | TwinCAT 3 IoT Communication (MQTT)\*)
- TF6730 | TwinCAT 3 IoT Communicator<sup>\*</sup>)

<sup>1)</sup> Image version 114606 and TwinCAT 3 XAE 4024.47 or higher required.

The open source licenses are available as a ZIP file on the microSD card.

## 4.1 Structure



Fig. 1: Sample configuration of a CX7000 Embedded PC.

Table 2: Legend for th	e configuration of the	basic CPU module
------------------------	------------------------	------------------

No.	Component	Description
1	MicroSD card slot (under the cover).	Slot for industrial MicroSD cards. Memory space for firmware and TwinCAT 3 projects.
2	Ethernet interface (X001)	For the connection to local networks. Serves as a programming interface.
3 USB interface (X002) Interface for additional USB data storage device.		Interface for additional USB data storage device.
4 I/O Status LEDs		Diagnosis of the power supply for the Embedded PC and the terminal bus. Status of the E-bus or K-bus communication and multifunction I/Os.
5	Diagnostic LEDs	1 x TwinCAT Status, 1 x Flash access, 1 x Error LED.
6	Spring-loaded terminals, +24 V and 0 V	Power supply (Us) for Embedded PC.
7	Spring-loaded terminals, +24 V and 0 V	Power supply (Up) for integrated multifunction I/Os and Bus Terminals via the power contacts.

## 4.2 Name plate



Fig. 2: Name plate example.

Table 3: Information on the name plate.

No.	Description	
1	Power supply 24 V DC.	
2	MAC addresses of the built-in Ethernet interface.	
3	Hardware version and date of manufacture.	
4	Product designation for identification of the embedded PC.	
5	Serial number/Beckhoff Traceability Number (BTN) for clear identification of the product. The host name is formed from BTN and the serial number/Beckhoff Traceability Number (BTN). Example: the BTN 00004xrr results in the host name <b>BTN-00004xrr</b> .	
6	CE marking	
7	EAC marking	
8	Machine-readable information in the form of a Data Matrix Code (DMC, code scheme ECC200) that can be used for better identification and management.	
9	Marking for garbage disposal. Do not dispose of this product with household waste.	
10	UL marking with prescribed information on power supply, fuse, temperature, and cable cross-sections.	
11	UKCA marking	

## 4.3 Ethernet interface (X001)

You can program and commission the CX7000 Embedded PC via the X001 Ethernet interface. The Ethernet interface achieves speeds of 10 / 100 Mbit/s.



Fig. 3: Ethernet interface X001.

The LEDs on the left of the interface indicate the connection status. The upper LED (LINK/ACT) indicates whether the interface is connected to a network. If this is the case, the LED lights up green. The LED flashes when data transfer on the interface is in progress.

The lower LED (SPEED) indicates the connection speed. The LED is not lit if the speed is 10 Mbit/s. At 100 Mbit/s the LED lights up orange.

Table 4: Ethernet interface X001, pin assignment.

PIN	Signal	Description
1	TD +	Transmit +
2	TD -	Transmit -
3	RD +	Receive +
4	connected	reserved
5		
6	RD -	Receive -
7	connected	reserved
8		

#### Transmission standards

#### 10Base5

The transmission medium for 10Base5 consists of a thick coaxial cable ("yellow cable") with a max. data transfer rate of 10 Mbaud arranged in a line topology with branches (drops) each of which is connected to one network device. Because all the devices are in this case connected to a common transmission medium, it is inevitable that collisions occur often in 10Base5.

#### 10Base2

10Base2 (Cheaper net) is a further development of 10Base5, and has the advantage that the coaxial cable is cheaper and, being more flexible, is easier to lay. It is possible for several devices to be connected to one 10Base2 cable. It is frequent for branches from a 10Base5 backbone to be implemented in 10Base2.

#### 10BaseT

Describes a twisted pair cable for 10 Mbaud. The network here is constructed as a star. It is no longer the case that every device is attached to the same medium. This means that a broken cable no longer results in failure of the entire network. The use of switches as star couplers enables collisions to be reduced. Using full-duplex connections they can even be entirely avoided.

#### 100BaseT

Twisted pair cable for 100 Mbaud. It is necessary to use a higher cable quality and to employ appropriate hubs or switches in order to achieve the higher data rate.

#### 10BaseF

The 10BaseF standard describes several optical fiber versions.

#### Short description of the 10BaseT and 100BaseT cable types

Twisted-pair copper cable for star topologies, where the distance between two devices may not exceed 100 meters.

#### UTP

Unshielded twisted-pair This type of cable belongs to category 3, and is not recommended for use in an industrial environment.

#### S/UTP

Screened/unshielded twisted-pair (shielded with copper braid) Has an overall shield of copper braid to reduce influence of external interference. This cable is recommended for use with Bus Couplers.

#### FTP

Foiled shielded twisted-pair (shielded with aluminum foil) This cable has an outer shield of laminated aluminum and plastic foil.

#### S/FTP

Screened/foiled shielded twisted-pair (shielded with copper braid and aluminum foil) Has a laminated aluminum shield with a copper braid on top. Such cables can provide up to 70 dB reduction in interference power.

#### STP

Shielded twisted-pair Describes a cable with overall shielding without further specification of the type of shielding.

#### S/STP

Screened/shielded twisted-pair (wires are individually shielded) This identification refers to a cable with a shield for each of the two wires as well as an outer shield.

#### ITP

Industrial Twisted-Pair The structure is similar to that of S/STP, but, in contrast to S/STP, it has only two pairs of conductors.

## 4.4 USB interface (X002)

A USB flash drive can be connected to the USB interface and used as an additional memory. The USB interface supports transfer speeds of up to 12 Mbit/s and no more than 100 mA. The file is accessed from TwinCAT or the PLC program with the help of the associated function blocks. No other devices can be connected to the USB interface and used.

The same functional mode can be used for accessing files on the MicroSD card. Use *C*:\ as the drive letter for accessing the MicroSD card and *D*:\ for accessing the USB flash drive.

#### Function blocks for data access

The function blocks can be used to process files from the PLC locally on the PC. The TwinCAT target system is identified by the AMS network address. This mechanism makes it possible, amongst other things, to store or to edit files on other TwinCAT systems in the network. Access to files consists of three sequential phases:

- 1. Opening the file.
- 2. Read or write access to the opened file.
- 3. Closing the file.

Opening the file has the purpose of establishing a temporary connection between the external file, whose name is all that initially is known, and the running program. Closing the file has the purpose of indicating the end of the processing and placing it in a defined output state for processing by other programs.

Name	Description
FB_EOF	Check the end of file
FB_FileOpen	Open a file
FB_FileClose	Close a file
FB_FileGets	Get string from a file
FB_FilePuts	Put string to a file
FB_FileRead	Read from a file
FB_FileWrite	Write to a file
FB_FileSeek	Move the file pointer
FB_FileTell	Get the file pointer position
FB_FileDelete	Delete a file
FB_FileRename	Rename a file
FB_CreateDir	Create new directory
FB_RemoveDir	Remove directory

#### Requirements

Development environment	Target system type	PLC libraries to include (Cate- gory group)
TwinCAT v3.1.0	PC or CX (x86, x64, ARM)	Tc2_System (System)

### 4.5 MicroSD card

The basic equipment of the CX7000 includes a 512 MB microSD card. You can optionally order the embedded PC with a larger 16 GB microSD card.

The cards employed are SLC memory with extended temperature range for industrial applications. Use exclusively microSD cards approved by Beckhoff.

Order identifier	Capacity	Description
CX1900-0131	16 GB	microSD card (SLC memory) with extended temperature range for industrial applications instead of the 512 MB card (ordering option)

Order identifier	Capacity	Description
CX1900-0122	512 MB	microSD card (SLC memory) with
CX1900-0132	16 GB	extended temperature range for industrial applications as spare part.

# 5 Commissioning

## 5.1 Mounting



Fig. 4: CX70xx Embedded PC, dimensions.

### 5.1.1 Note the permissible installation positions

#### NOTICE

#### Overheating

The Embedded PC may overheat if the installation position is incorrect or the minimum distances are not adhered to. Adhere to the maximum ambient temperature of 60°C and the mounting instructions.

Install the Embedded PC horizontally in the control cabinet on a DIN rail, in order to ensure optimum heat dissipation.

Note the following specifications for the control cabinet:

- The Embedded PC should only be operated at ambient temperatures between -25 °C and 60 °C. Measure the temperature below the Embedded PC at a distance of 30 mm to the cooling fins, in order to determine the ambient temperature correctly.
- Adhere to the minimum distances of 30 mm above and below the Embedded PC.
- Additional electrical equipment affects the heat generation in the control cabinet. Select a suitable control cabinet enclosure depending on the application, or ensure that excess heat is dissipated from the control cabinet.

The Embedded PC must be mounted horizontally on the DIN rail. Ventilation openings are located at the top and bottom of the housing. This ensures an optimum airflow through the Embedded PC in vertical direction. In addition, a minimum clearance of 30 mm above and below the Embedded PC is required, in order to ensure adequate ventilation.



Fig. 5: CX70xx Embedded PC, permissible installation position.

If vibrations and impact occur in the same direction as the DIN rail, the Embedded PC must be secured with an additional bracket, in order to prevent it slipping.

#### Installation positions with reduced temperature range up to 45 °C

You can also mount the Embedded PC vertically or horizontally on the mounting rail. Note that you can then only operate the Embedded PC up to an ambient temperature of 45 °C.

Ensure that Bus Terminals that are connected to the Embedded PC are designed for operation in vertical or horizontal position.

#### **Restrictions for E-bus/K-bus current**

The maximum E-bus/K-bus current varies depending on the selected installation position and the ambient temperature.

Table 5: Maximum E-bus/K-bus current depending on the selected installation position and the ambient temperature.

E-bus/K-bus current	Installation position	Ambient temperature
max. 1.5 A	variable	-2545 °C
max. 1.3 A	horizontal	-2555 °C
max. 1 A	variable	-2555 °C
max. 1 A	horizontal	-2560 °C

### 5.1.2 Fastening to the DIN rail

The housing is designed such that the Embedded PC can be pushed against the DIN rail and latched onto it.

Requirements:

• DIN rail of the type TS35/7.5 or TS35/15 according to EN 60715.

#### Fasten the Embedded PC to the DIN rail as follows:

1. Place the Embedded PC on the DIN rail. Slightly press the Embedded PC onto the DIN rail until a soft click can be heard and the Embedded PC has latched.



- 2. Subsequently, lock the catch on the left side of the Embedded PC.
- 3. Turn the latch counter clockwise until the latch quietly clicks and engages.



⇒ You have installed the Embedded PC successfully. Check again that the mounting is correct and that the Embedded PC is engaged on the DIN rail.

### 5.1.3 Changing the MicroSD card

#### Loss of data

MicroSD cards are subjected to heavy load during operation and have to withstand many write
cycles and extreme ambient conditions. MicroSD cards from other manufacturer may fail, resulting in data loss.

Only use industrial MicroSD cards provided by Beckhoff.

The MicroSD card slot is intended for an industrially compatible MicroSD card. The firmware of the Embedded PC is stored on the MicroSD card. If necessary, the MicroSD card can be written to from TwinCAT 3, allowing user-defined data to be stored.

The eject mechanism is based on the push/push principle. Below, we show you how to change the MicroSD card.

Requirements:

• The Embedded PC must be switched off. The MicroSD card may only be installed or removed in switched-off state.

#### Changing the MicroSD card

1. Push the black cover upwards.



- 2. Gently push the MicroSD card.
- 3. The card is unlatched with a quiet click and raised about 2 3 mm out of the housing.



- 4. Push the new MicroSD card into the card slot with the contacts at the front. The contacts face to the right.
- 5. A soft click can be heard when the MicroSD card engages.
- $\Rightarrow$  The card is seated correctly when it is about 1 mm deeper than the front side of the housing.

### 5.1.4 Installing passive EtherCAT Terminals

#### Incorrectly installed passive EtherCAT Terminals

The E-bus signal between an Embedded PC and the EtherCAT Terminals can be impaired due to incorrectly installed passive EtherCAT Terminals.

Passive EtherCAT Terminals should not be installed directly on the power supply unit.

EtherCAT Terminals that do not take part in active data exchange are referred to as passive terminals. Passive EtherCAT Terminals have no process image and do not require current from the terminal bus (E-bus).

Passive EtherCAT Terminals (e.g. EL9195) can be detected in TwinCAT. In the tree structure the EtherCAT Terminal is displayed without process image, and the value in column "E-bus (mA)" does not change, compared to the preceding EtherCAT Terminal.



Fig. 6: Identifying a passive EtherCAT Terminal in TwinCAT.

The entry "Current consumption via E-Bus" in the technical data of an EtherCAT Terminal indicates whether a particular EtherCAT Terminal requires power from the terminal bus (E-bus).

The following diagram shows the permissible installation of a passive EtherCAT Terminal. The passive EtherCAT Terminal was not directly attached to the power supply unit.



Fig. 7: Passive EtherCAT Terminals, permissible installation.

### 5.2 Power supply

#### NOTICE

#### Damage to the Embedded PCs

The Embedded PCs may be damaged during wiring. The cables for the power supply should only be connected in de-energized state.

The power supply terminal requires an external voltage source which provides 24 V DC (-15 % / +20 %).

The cabling of the Embedded PC in the control cabinet must be done in accordance with the standard EN 60204-1:2006 (PELV = Protective Extra Low Voltage):

- The "PE" and "0 V" conductors of the voltage source for a basic CPU module must be on the same potential (connected in the control cabinet).
- Standard EN 60204-1:2006, section 6.4.1:b stipulates that one side of the circuit, or one point of the energy source for this circuit must be connected to the protective earth conductor system.

#### Connections



Fig. 8: Connections for system voltage (Us) and power contacts (Up).

Table 6: Key for the connection example.

No.	Description
1	The upper spring-loaded terminals labeled "24 V Us" and "0 V Us" supply the basic CPU module and the terminal bus (data transfer via K- or E-bus) with voltage.
2	The spring-loaded terminals labeled "+24 V Up" and "0 V Up" supply the multi-functional I/Os, the bus terminals, and EtherCAT Terminals with voltage via the power contacts.

#### Fuse

- When dimensioning the fuse for the system voltage (Us), take the maximum power consumption of the embedded PC into account (see: <u>Technical data [▶ 109]</u>)
- Protect the power contacts (Up) with a fuse with a max. rating of 10 A (slow-blow).

#### Interrupting/switching off the power supply

To switch off the embedded PC, do not disconnect the ground (0 V), because otherwise current may continue to flow via the shielding, depending on the device, and damage the embedded PC or peripheral devices.

Always disconnect the 24 V line. Devices connected to the embedded PC which have their own power supply (e.g. a panel) must have the same potential for "PE" and "0 V" as the embedded PC has (no potential difference).

### 5.2.1 Connect Embedded PC

The cables of an external voltage source are connected to spring-loaded terminals on the power supply terminal. Observe the required conductor cross-sections and strip lengths.

Table	7:	Reauir	ed wire	cross-sections	and	strip	lenaths.
1 0.010	•••	1.0090.00		0.000 0000.0000	01110	00. IP	

Conductor cross-section	e*: 0.08 1.5 mm <sup>2</sup>	e*: AWG 28 16
	f*: 0.25 1.5 mm <sup>2</sup>	f*: AWG 22 16
	a*: 0.14 0.75 mm²	a*: AWG 26 19
Strip length	8 9 mm	0.33 inch

\*e: single-wire, solid wire; f: stranded wire; a: with wire end sleeve



Fig. 9: Connection example with a CX7000.

#### Connect the Embedded PC as follows:

1. Open a spring-loaded terminal by slightly pushing with a screwdriver or a rod into the square opening above the terminal.



- 2. The wire can now be inserted into the round terminal opening without any force.
- 3. The terminal closes automatically when the pressure is released, holding the wire safely and permanently.
- ⇒ You have successfully connected the voltage source to the power supply terminal when the two upper LEDs of the power supply terminal light up green.

The left LED (Us 24V) indicates the supply of the basic CPU module and terminal bus. The red LED (Up 24V) indicates the Bus Terminal supply via the power contacts.

### 5.2.2 UL requirements

The CX7000 Embedded PCs are UL-certified. The corresponding UL label can be found on the name plate.



Fig. 10: UL label on CX7000.

The CX7000 Embedded PCs can thus be used in areas where special UL requirements have to be met. These requirements apply to the system voltage (Us) and the power contacts (Up). Applications without special UL requirements are not affected by UL regulations.

UL requirements:

- The Embedded PCs must not be connected to unlimited voltage sources.
- Embedded PCs may only be supplied from a 24 V DC voltage source. The voltage source must be insulated and protected with a fuse of maximum 4 A (corresponding to UL248).
- Or the power supply must originate from a voltage source that corresponds to NEC class 2. An NEC class 2 voltage source must not be connected in series or parallel with another NEC class 2 voltage source.



Fig. 11: Connection example for areas with special UL requirements.

# 6 Multifunction I/Os

A total of four adjustable slots are available for configuring the operation modes. A slot is a certain number of inputs and outputs. For each slot a maximum of one module (DI, DIO, ENC, CNT or PWM) can be assigned, which in turn determines the operation mode for the respective slot. A module is therefore a function that these inputs and outputs can assume. The current module configuration is listed in TwinCAT under the CX7028 interface. Note that the CX7028 interface for controlling the multifunction I/Os has its own CPU and the CX7028 interface is not displayed or does not work under TwinCAT if the power supply (Up) is not connected.



Fig. 12: CX7028 interface, slot and module configuration under TwinCAT.

Modules can be assigned to a specific slot with the button < or removed again with  $\mathbf{x}$ . There is a choice of different modules depending on the slot used. The module used by each slot is listed in the following.

#### Cycle time for multifunction I/Os

Communication to the multifunction I/Os is monitored with a fixed watchdog of 100 ms. This means that the cycle time for the multifunction I/O must be faster than 100 ms.

#### Slot 1:

When using slot 1, inputs 1, 2 and (\*3) as well as outputs 1 and 2 are configured.

Slot		Module	ModuleIdent		Module	ModuleIdent	Description	
	InOut[12]	ENC	0x00601B74	<	ENC	0x00601B74	Encoder	
	InOut[34]	PWM_DI_2x	0x00501B74		CNT	0x00701B74	Counter	
	In[56]	DI_2x	0x00101B74	X	DIO_2x	0x00301B74	Digital, 2xDI 2xDO	
	In[78]	AI_2x	0x00401B74		- 15 DA 1223			
<			>		<			

Fig. 13: Supported modules when using slot 1.

- ENC (incremental encoder mode). 2 x digital input for 250 kHz encoder signal, 2 x encoder digital output.
- CNT (counter mode). 1 x counter digital input 100 kHz, 1 x digital input as up/down counter 20 kHz, 2 x counter digital output.
- DIO\_2x (digital inputs and outputs). 2 x digital input, 24 V DC, filter 3 ms, type 3, 2 x digital output, 24 V DC, 0.5 A, 1-wire technique.

\*) Input 3 is only available in incremental encoder mode. If the level is high, the value of the incremental encoder can be latched or the counter reset.

#### Slot 2:

When using slot 2, inputs 3 and 4 as well as outputs 3 and 4 are configured.

Slot	InOut[12] InOut[34] In[56] In[78]	Module ENC PWM_DI_2x DI_2x AI_2x	ModuleIdent 0x00601B74 0x00501B74 0x00101B74 0x00101B74	< X	Module DIO_2x PWM_DI_2x	ModuleIdent 0x00001B74 0x00501B74	Description Digital, 2xDI 2xDO PWM 2x, Digital, 2xDI	
<			>		<			3

Fig. 14: Supported modules when using slot 2.

- DIO\_2x (digital inputs and outputs). 2 x digital input, 24 V DC, filter 3 ms, type 3, 2 x digital output, 24 V DC, 0.5 A, 1-wire technique.
- PWM\_DI\_2x (PWM signal mode). 2 x digital input, 24 V DC, filter 3 ms, 2 x digital output configured for PWM signal.

#### Slot 3:

When using slot 3, inputs 5 and 6 are configured.

Slot	InOut[12] InOut[34] In[56] In[78]	Module ENC PWM_DI_2x DI_2x AI_2x	ModuleIdent 0x00601B74 0x00501B74 0x00101B74 0x00401B74	< X	Module ModuleIdent Description	
<		_	>		٢	1

Fig. 15: Supported modules when using slot 3.

Slot 3 contains only one module and therefore cannot be configured differently. The module supports 2 x digital input, 24 V DC, filter 3 ms, type 3.

#### Slot 4:

When using slot 4, inputs 7 and 8 are configured.

Slot	InOut[12] InOut[34] In[56] In[78]	Module ENC PWM_DI_2x DI_2x AI_2x	ModuleIdent 0x00601B74 0x00501B74 0x00101B74 0x00101B74	×	Module ModuleIden AI_2x 0x00401B7 DI_2x 0x00201B7	t Description 4 Analog, 2xAI, 010V 4 Digital, 2xDI	
<			>		<		

Fig. 16: Supported modules when using slot 4.

- Al\_2x (analog signal mode). 2 x digital input configured as analog input 0 to 10 V, 12 bits
- DI\_2x (digital input). 2 x digital input, 24 V DC, filter 3 ms, type 3

## 6.1 Digital inputs

The digital inputs acquire binary control signals from the process level. Typically, these are mechanical contacts such as normally closed contacts or normally open contacts, electronic sensors such as inductive proximity switches, optical sensors or other methods in order to generate a low/high signal in the sense of control technology. Thanks to integrated multi-function I/Os, the CX70xx has a total of 8 digital inputs, 24 V DC, filter 3 ms, type 3.



Fig. 17: Configurable digital inputs.

The digital inputs have a 3 ms input filter. The signal status of each individual input is displayed by an LED. For digital inputs 3, 4, 5 and 6, additional filter settings can be made in the appropriate CoE objects and, for example, the resolution and filter time can be set.

Table 8: Technical data, multi-function I/Os as digital inputs.

Technical data	CX7000
Connection technology	1-wire
Number of inputs	8
Nominal voltage	24 V DC (-15 %/+20 %)
Specification	EN 61131-2, type 3
Signal voltage "0"	-3+5 V
Signal voltage "1"	1130 V
Input filter	Configurable, default: 3 ms, min.: 10 μs
Connection cross-section	e*: 0.08…1.5 mm², f*: 0.25…1.5 mm², a*: 0.14…0.75 mm²
Connection cross section AWG	e*: AWG 2816, f*: AWG 2216, a*: AWG 2619
Strip length	8 9 mm

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

### 6.2 Digital outputs

NOTICE

#### Feedback at the 24 V outputs

A voltage of 24 V at the outputs can destroy the device if the power supply (Up) is not connected (feedback). Connect the power supply (Up) so that 24 V can be applied to the outputs.

The digital outputs forward binary 24 V DC control signals, electrically isolated, to actuators at the process level. The high level of the positive switching logic corresponds to the supply voltage.

Outputs 3 and 4 have a PWM output stage. If the two digital outputs are used as normal digital outputs, the internal wiring will cause a leakage current of less than 100  $\mu$ A, which will cause a voltage of about 5 V. If you want to reach nearly 0 V at the low level of the output, you have to connect a 47 k $\Omega$  resistance to ground.

Another possibility is to operate the two outputs in PWM mode and to write the variable PWM output of the PWM signal for FALSE with 0x0000 and for TRUE with 0xFFFF. This activates the PWM output stage, which does not generate any leakage current.



Fig. 18: Configurable digital outputs.

The CX7000 contains a total of four outputs, which indicate their signal state by means of light emitting diodes. The outputs can be used to switch standard actuators such as contactors and valves.

Technical data	CX7000				
Connection technology	1-wire				
Number of outputs	4				
Nominal voltage	24 V DC (-15 %/+20 %)				
Load type	ohmic, inductive, lamp load				
Max. output current	24 V/0.5 A (short-circuit proof)				
Changeover times	T <sub>oN</sub> : 20 μs typ., T <sub>oFF</sub> : 10 μs typ.				
Short circuit current	< 2 A typ.				
Max. breaking energy (ind.)	< 150 mJ/channel				
Connection cross-section	e*: 0.08…1.5 mm², f*: 0.25…1.5 mm², a*: 0.14…0.75 mm²				

Technical data	CX7000
Connection cross section AWG	e*: AWG 28…16,
	f*: AWG 2216,
	a*: AWG 2619
Strip length	8 9 mm

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

## 6.3 Counter mode

The CX7000 Embedded PC can be configured as an up/down counter that enables the counting of a pulse. The embedded PC is suitable for fast counting tasks with a cut-off frequency of up to 100 kHz, whereby the CX7000 can be operated in 1-counter mode.



Fig. 19: Configurable inputs and outputs in counter mode.

The CX7000 supports three operation modes in counter mode:

- Up/down counter
- Up counter
- Down counter

In addition, output 1 can be switched depending on the counter value. Output 2 can be switched from the PLC. This allows fast control signals for field devices to be used and switched.

The operation modes are set in TwinCAT via CoE objects.

#### Up/down counter

In the up/down counter operation mode, the pulse to be counted is detected by digital input 1. The counting direction is specified by digital input 2.

If there is a high level at input 1 and at the same time at input 2, the counter counts upwards. If there is a high level at input 1 and a low level at input 2, the counter counts downwards.

#### Up counter

In this operation mode, the signal is detected at digital input 1.

#### Down counter

In this operation mode, the signal is detected at digital input 1.



Table 10: Technical data, multi-function I/Os in counter mode.

Technical data	CX7000					
Number of counters	1 x up/down counter, 1 x up or down counter					
Nominal voltage	24 V DC (-15 %/+20 %)					
Specification	EN 61131-2, type 3					
Signal voltage "0"	-3+5 V					
Signal voltage "1"	1130 V					
Cut-off frequency	Up/down counter: 20 kHz <sup>1)</sup> , counting in one direction only: 100 kHz					
Counter depth	32-bit					
Max. output current	24 V/0.5 A (short-circuit proof)					
Special features	Set counter, switch outputs, reset counter					
Connection cross-section	e*: 0.081.5 mm², f*: 0.251.5 mm², a*: 0.140.75 mm²					
Connection cross section AWG	e*: AWG 2816, f*: AWG 2216, a*: AWG 2619					
Strip length	8 9 mm					

<sup>1)</sup> The up/down counter can also count up to 100 kHz, only with a direction reversal the counting frequency must be <= 20 kHz, otherwise pulses will be lost.

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

### 6.3.1 Select operation mode

The CX7000 supports three operation modes in counter mode: The operation mode is set in TwinCAT via CoE objects. You can choose between the three operating modes up/down counter, up counter and down counter.

#### Proceed as follows:

- 1. Click the CX7028 device on the left in the structure tree.
- 2. Click the **CoE-Online** tab.

Solution Explorer 🛛 🝷 🕂 🗙	CX7000 ⇒ ×						-
© ⊃ 🟠 🛗 -   ™ - 🗃   🔑 🗕	General Process	Data Slots Startup CoE	Online Online	ADS			
Search Solution Explorer (Ctrl+;)	Undate Lis	t 🗌 Arata Hadata					
Solution 'CX7000' (1 project)			Set Value Dialo	og	×		
🔺 📊 CX7000	Advanced				01		
SYSTEM	Add to Start	Jp Online Data	Dec:	1	UK		
A MOTION			Hex:	0x01	Cancel		
PLC PLC	Index	Name	Enum	Count up	~	^	
SAFETY	6060	Input	2110111	Extern count direction			
96. C++	6070	Input		Count up			
ANALYTICS	÷ 7000:0	CNT Outputs	Bool:	Count down	E dit		
▲ 🔀 I/O		CNT Outputs_2	Distant	01	1		
	7010	Output	Dinary.				
Device 2 (CX/000)	/020	Output	Bit Size:	○1 ●8 ○16 ○32	○64 ○?	_	
image	/030	Output CNT Settinge	PO	> 24 -			
P 🛄 Inputs	8000.0	Enable reload	RW	FALSE			
Outputs	8000:09	Operating mode	RW	Count up (1)			
Term 1 (CV7029)	8000:0F	Reversion of rotation	RW	FALSE			
DEV Inputs Device	8000:22	Counter reload value	RW	0x00000100 (256)			
Module 1 (CNT)		DIO Settings Ch.1	RO	>1<		~	
Module 3 (DIO 2x)	<					>	
Module 5 (DI 2x)							
Module 7 (DI 2x)	Name	Online	Туре	Size >Addr In/O	ut User ID Linked to		$\sim$
Mappings	🔁 Diag	0	BIT	0.1 11.4 Input	t 0		
	🔁 TxPDO State	0	BIT	0.1 11.5 Input	t 0		× .
Solution Explorer Team Explorer	<						>

3. Double-click the CoE object 8000:09 Operating mode.

4. Under the **Enum** option, select the required operation mode.

⇒ The operation mode is applied. Note that you can only use one operation mode at a time with the CX7000 and mode mixing is not possible.

### 6.3.2 Switching outputs

With the CX7000, it is possible to switch output 1 automatically as soon as a certain counter value is reached. This enables fast processing without the PLC. A second output, output 2, can be switched via the PLC irrespective of the counter value.

Output 1 is switched or switched off respectively by the variables **Switch on threshold value** and **Switch off threshold value**:

- If the value set under Switch on threshold value is reached, the output is switched.
- If the value set under Switch off threshold value is reached, the output is switched off.

When counting downwards, the corresponding switching instruction is executed in reverse. If the value falls below the value set in **Switch on threshold value**, output 1 is switched off.

Proceed as follows:



- 1. Use the variable **Switch on threshold value** to specify a counter value at which the output should be switched.
- 2. Use the variable **Switch off threshold value** to specify a counter value at which the output should be switched off.
- 3. Then set the variable **Enable output functions** to **True** so that the settings are applied.
- ⇒ Only when the variable Enable output functions is set to True the function is enabled and the output is switched.

If the parameterized counter value from **Switch on/off threshold** is reached or exceeded, but the variable **Enable output functions** is not set, the switching order is not executed. The output is switched as soon as **Enable output functions** is set. Likewise, a subsequently activated counter value **Switch on/off threshold** affects the output immediately when the switching condition is fulfilled.
### 6.3.3 Set counter value

This step shows you how to set the counter value to a specific value. The variable **Set counter value is** used to specify a value and the variable **Set counter** is used to set the counter value. Both variables can be controlled from the PLC.

CX7000 - TcXaeShell		7 8	Quick Launch (Ctrl+Q)	₽ = ¤ ×
File Edit View Project Build Debug TwinCAT Twi	nSAFE PLC Team	Scope Tools	Window Help	
	Debug - Twin	CAT OS (ARMT2)	- 🕨 Attach	- 🎜 🚆
Build 🕮 💷 (Loaded) 🕒 = 👬 🧱 🖉 🖉 🔨 🛞	CX7000	- CX-	-57E102 -	- 8 -
Solution Explorer - T ×	CX7000 ⊕ × MAIN			-
◎ ◎ 🏠 🛱 - '₀ - 🗗 🏓 🗕	Variable Flags Onlin	e		
Search Solution Explorer (Ctrl+;)				
👂 🛄 Outputs 🔺	Value: 1			
InfoData	New Value: Fo	rce R	lelease	Write
Term 1 (CX7028)	Comment:			
DEV Inputs Device				
Module I (CNI)				
CNT Outputs				
A Outputs				
Set counter				
Set output				1
Enable output functions				
Set Counter Value				
Switch off threshold value				
Output 2				
Module 3 (DIO_2x)				
Module 5 (DI_2x)				
Mannings				
Untitled1 Instance - Device 2 (CX7000)				
Solution Explorer Team Explorer				
□ Ready	- 		î	Add to Source Control 🔺 🔡

- 1. Use the variable **Set counter value** to specify a value to set as a counter value.
- 2. Then set the variable **Set counter** to **True** to apply the settings.
- ⇒ Only when the variable Set counter is set to True, the value set under Set counter value is applied for the counter value.

## 6.3.4 Setting the limit value for counters

This step shows you how to set a limit value in TwinCAT from which the counter value is automatically reset to zero. When counting upwards, the counter value is reset to zero when the limit value is reached. When counting downwards, the counter value is reset to the set limit value when zero is reached.

The counter value is a UDINT variable. The counter counts only in the positive range from 0 to 0xFFFF\_FFFF (4294967295). If the value falls below zero, the counter is set to the maximum positive value. If it exceeds 4294967295, the counter is set to zero. The two variables **Counter underflow** or **Counter overflow** respectively indicate the overflow and are reset either on reaching 0x4000 in the positive direction or on reaching 0xFFFFC000 in a negative direction or if the corresponding other overflow has been reached.

- 1. Click the CX7028 device on the left in the structure tree.
- 2. Click the **CoE-Online** tab.



- 3. Double-click the CoE object 8000:22 Counter reload value and set the limit value.
- 4. Then double-click the CoE object 8000:03 Enable reload and set the value to True.
- ⇒ Only when the CoE object 8000:03 Enable reload is set to True are the function and the defined limit value active.

## 6.4 Incremental encoder mode

In incremental encoder mode, the CX7000 can be configured as an interface for direct connection of 24 V incremental encoders. A quadruple evaluation is used and both high level and low level are detected at input 1 and input 2.



Fig. 20: Configurable inputs and outputs in incremental encoder mode.

The range of functions in encoder mode corresponds to the range of functions in counter mode. In addition, the counter value at input 3 can be latched, i.e. the value is entered in the process data on a high level at input 3. Alternatively, the counter can be reset on a high level at input 3.

In addition, output 1 can be switched depending on the counter value. Output 2 can be switched from the PLC. This allows fast control signals for field devices to be used and switched.



Technical data	CX7000
Technology	Incremental encoder interface
Nominal voltage	24 V DC (-15 %/+20 %)
Specification	EN 61131-2, type 3
Encoder connection	1 x A, B: 24 V, single-ended
Additional inputs	Latch input, 24 V DC
Cut-off frequency	250,000 increments/s (with 4-fold evaluation), corresponds to 62.5 kHz
Counter depth	32-bit
Quadrature decoder	4-fold evaluation
Max. output current	24 V/0.5 A (short-circuit proof)
Special features	Latch function, software gate, set counter, switch outputs, reset counters
Connection cross-section	e*: 0.081.5 mm², f*: 0.251.5 mm², a*: 0.140.75 mm²
Connection cross section AWG	e*: AWG 2816, f*: AWG 2216, a*: AWG 2619
Strip length	8 9 mm

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

### 6.4.1 Switching outputs

With the CX7000, it is possible to switch output 1 automatically as soon as a certain counter value is reached. This enables fast processing without the PLC. A second output, output 2, can be switched via the PLC irrespective of the counter value.

Output 1 is switched or switched off respectively by the variables **Switch on threshold value** and **Switch off threshold value**:

- If the value set under Switch on threshold value is reached, the output is switched.
- If the value set under Switch off threshold value is reached, the output is switched off.

#### Proceed as follows:



- 1. Use the variable **Switch on threshold value** to specify a counter value at which the output should be switched.
- 2. Use the variable **Switch off threshold value** to specify a counter value at which the output should be switched off.
- 3. Then set the variable Enable output functions so that the settings are applied.
- ⇒ Only when the variable Enable output functions is set to True is the function enabled and the settings applied.

If the parameterized counter value from **Switch on/off threshold** is reached or exceeded, but the variable **Enable output functions** is not set, the switching order is not executed. The output is switched as soon as **Enable output functions** is set. Likewise, a subsequently activated counter value **Switch on/off threshold** affects the output immediately when the switching condition is fulfilled.

### 6.4.2 Latching the counter value

In incremental encoder mode, the counter value can be latched and thus the current value can be entered in the process data. Input 3 is used as a latch input.

To enable the function, the variable **Enable latch extern on positive edge** must be set to **True**. On a high level at input 3, the current counter value is entered into the variable **Latch Value**. You can monitor the validity of the variable. As soon as the latch value is entered, the variable **Latch extern valid** is also set to **True**.

CX7000 - TcXaeShell	V P Quick Launch (Ctrl+Q)
File Edit View Project Build Debug TwinCAT TwinSAFE	PLC Team Scope Tools Window Help
- 『 O - O   證 - ':: - ':: III 🔐 💾 🔏 🗇 台   ツ - ペ -   Debug	<ul> <li>TwinCAT OS (ARMT2)</li> <li>Attach</li> </ul>
Build (Loaded) 🔹 🚽 🔛 🧧 🖉 🔨 🎯 🍖 🐔 💋	CX7000 • CX-57E102 • = ;;
Solution Explorer 🔷 🗸 🗶	CX7000 ≄ ×
○ ○ 🏠 🕂 -   ]⊙ - @   🏓 💻	Variable Flags Online
Search Solution Explorer (Ctrl+;)	Value: 125
🔺 🦉 Term 1 (CX7028)	
DEV Inputs Device	New Value: Force Release Write
Module 1 (ENC)	Comment:
A Deputs	
2 Latch extern valid	
👻 Set counter done	
🔁 Counter underflow	v
2 Counter overflow	
Status of input A	125-
Countervalue	
2 Latch value	
🖌 🌮 Status	
👻 Status of output	
Status of output 2	
Status of extern latch	
Enable latch extern on positive edge	
🖙 Set counter 👻	
Solution Explorer Team Explorer	<
C Ready	🚰 🔶 🛉 Add to Source Control 🔺

- 1. Set the variable Enable latch extern on positive edge to True to enable the latch function.
- 2. Monitor the status of the latch input with the variable Status of extern latch.
- 3. On a high level at input 3, the current counter value is entered into the variable Latch Value.
- 4. Monitor the validity of the latch value via the variable **Latch extern valid**. Once the latch value has been written, the variable is also set to **True**.
- ⇒ To execute a latch again, the variable **Enable latch extern on positive edge** must receive a high level again.

## 6.4.3 Setting the limit value for counters

This step shows how you can set a limit value in TwinCAT from which the counter value is automatically reset to zero. When counting upwards, the counter value is reset to zero when the limit value is reached. When counting downwards, the counter value is reset to the set limit value when zero is reached.

- 1. Click the CX7028 device on the left in the structure tree.
- 2. Click the CoE-Online tab.



- 3. Double-click the CoE object 8000:12 Counter reload value and set the limit value.
- 4. Then double-click the CoE object 8000:09 Enable reload and set the value to True.
- The function is only active when Enable reload is set. Alternatively, the latch input can be used and the counter value can thus be reset externally. To do this, the latch function must be disabled and the CoE object Enable extern reset set to True. With this setting, the current counter value is set to zero on a high level at input 3.

Index	Name	Flags	Value	Unit
7020	Output	RO P	FALSE	
7030	Output	RO P	FALSE	
8000:0	ENC Settings	RO	> 18 <	
8000:02	Enable extern reset	RW	TRUE	
8000:04	Gate polarity	RW	Enable pos. gate (1)	
8000:09	Enable reload	RW	TRUE	
8000:0E	Reversion of rotation	RW	FALSE	
8000:12	Counter reload value	RW	0x00000100 (256)	
+ 8020:0	DIO Settings Ch.1	RO	>1<	

# 6.5 Analog signal mode

The single-ended inputs 7 and 8 acquire signals in the range of 0 to 10 V.



Fig. 21: Configurable analog inputs.

The voltage is digitized with a resolution of 12 bits. LEDs are used to indicate the signal state.

Table	12:	Technical	data,	multi-function	I/Os	in	analog	mode.
-------	-----	-----------	-------	----------------	------	----	--------	-------

Technical data	CX7000
Technology	single ended
Number of inputs	2
Signal voltage	010 V
Internal resistance	500 kΩ
Input filter cut-off frequency	2 kHz
Resolution	12-bit (16-bit representation)
Measuring error	< ±0.3 % (relative to full scale value)
Connection cross-section	e*: 0.081.5 mm², f*: 0.251.5 mm², a*: 0.140.75 mm²
Connection cross section AWG	e*: AWG 2816, f*: AWG 2216, a*: AWG 2619
Strip length	8 9 mm

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

## 6.6 **PWM** signal mode

NOTICE

### Feedback at the 24 V outputs

A voltage of 24 V at outputs 3 and 4 can destroy the device (feedback). No voltage may be applied to the outputs in PWM mode.

The PWM signal mode enables a pulse width modulated binary signal to be output at outputs 3 and 4.



Fig. 22: Configurable inputs and outputs in PWM signal mode

This signal is separated into duty cycle (0... 100 %) and PWM clock frequency (15 Hz... 100 kHz). The LEDs are clocked with the outputs, and show the duty cycle by their brightness. The signal values are transferred in 16-bit values.



Table 13: Technic	al data, mu	Ilti-function I/	Os in l	PWM mode.
-------------------	-------------	------------------	---------	-----------

Technical data	Digital inputs
Connection technology	PWM output
Number of outputs	2
Nominal voltage	24 V DC (-15 %/+20 %)
Load type	ohmic, inductive, lamp load
Max. output current	24 V/0.5 A (short-circuit proof)
PWM clock frequency	15 Hz100 kHz
Duty cycle	0…100 % (T <sub>on</sub> > 20 ns, T <sub>off</sub> > 200 ns)
Short circuit current	< 2 A typ.
Special features	separate frequency can be set for each channel

Technical data	Digital inputs
Connection cross-section	e*: 0.081.5 mm², f*: 0.251.5 mm², a*: 0.140.75 mm²
Connection cross section AWG	e*: AWG 2816, f*: AWG 2216, a*: AWG 2619
Strip length	8 9 mm

\*e: single-wire, solid wire; f: stranded wire; a: with ferrule

### 6.6.1 Setting the PWM clock frequency and duty cycle

The signals at outputs 3 and 4 are output with pulse width modulation, the signals being separated into duty cycle and PWM clock frequency. Separate values for duty cycle and PWM clock frequency can be defined for both outputs.

|--|

Value	Decimal	Hexadecimal
0 %	0	0x0000
25 %	16383	0x3FFF
50 %	32767	0x7FFF
100 %	65.535	0xFFFF

Table 15: PWM period (PWM clock frequency), representation of the PWM signal in the delivery state.

Value	Decimal	Hexadecimal	Frequency
0.010 ms	010	0x0000-0x000A	100 kHz
0.011 ms	11	0x000B	90.909 kHz
0.100 ms	100	0x0064	10 kHz
1.000 ms	1000	0x03E8	1 kHz
16.38 ms	16383	0x3FFF	61.04 Hz
65.53 ms	65535	0xFFFF	15.26 Hz

The variable **PWM output** correspond to the duty cycle and **PWM period** to the PWM clock frequency at which the signal is output.

CX7000 - TcXaeShell File Edit View Project Build Debug TwinCAT Twin O - O 1 12 - C - Build (Loaded) - Euclided (Loaded) - Build (Loaded) - CX7000 - TcXaeShell Build Debug TwinCAT Twin CX7000 - Build Debug TwinCAT Twin CX7000 - CX7000 - CX700 - CX7000 - CX7000 - CX7000 - CX7000 - CX7000 - CX7000 - CX7000 - CX7000 - CX7000 - CX700 - CX70	NSAFE PLC Team Scope Tools Debug  TwinCAT OS (ARMT2) CX7000 CX-5	Quick Launch (Ctrl+Q)     P     Image: Ctrl+Q       Window     Help       Image: Point Ctrl+Q     Image: Ctrl+Q       Image: Po
Solution Explorer       4 ×         Search Solution Explorer (Ctrl+;) <ul> <li>Image</li> <li>Inputs</li> <li>Outputs</li> <li>InfoData</li> <li>If Term 1 (CX7028)</li> <li>DEV Inputs Device</li> <li>Module 3 (PWM_DI_2x)</li> <li>P PWM_DI_2x Inputs Channel 1</li> <li>P PWM DI 2x Outputs Channel 2</li> <li>PWM DI 2x Outputs Channel 1</li> <li>PWM DI 2x Outputs Channel 2</li> <li>PWM DI 2x Input Channel 1</li> <li>D 12x Input Channel 2</li> <li>Mappings</li> </ul>	CX7000 + × General Module Name: Module 3 (PWM_D)_2x) Object Id: 0x03090003 Type: Comment: Comment: Disabled	Create symbols
Ready		↑ Add to Source Control ▲

- 1. On the left in the structure tree, select an output for which you wish to set the duty cycle and PWM clock frequency.
- 2. Link the variables **PWM output** and **PWM period** with the appropriate variables from your PLC project.
- 3. In the variables, set the values for duty cycle and PWM clock frequency according to the above tables.

## 6.6.2 Setting the channel synchronization

The channel synchronization option makes the output of output 2 dependent on output 1. The following values are available in the CoE objects:

- No: no dependency
- Ch2 = Ch1: Duty cycle and PWM clock frequency of output 1 are also applied to output 2. The phase position is 0, i.e. the rising and falling edges of output 1 and output 2 are synchronized.
- Ch2 = Ch1 inverted: Duty cycle and PWM clock frequency of output 1 are also applied to output 2. However, the PWM clock frequency is inverted. The phase position is 0, i.e. a rising edge at output 1 triggers a falling edge at output 2 at the same time.

- 1. Click the CX7028 device on the left in the structure tree.
- 2. Click the CoE-Online tab.



- 3. Double-click the CoEobject 8020:09 Channel synchronization.
- 4. Under the option **Enum**, select the type of synchronization required.

# 7 Configuration

## 7.1 Starting the Beckhoff Device Manager

Using the Beckhoff Device Manager, an Industrial PC can be configured by remote access with the aid of a web browser. The access takes place via the HTTP protocol and Port 80 (TCP).

Requirements:

- Host PC and Embedded PC must be located in the same network. The network firewall must allow access via port 80 (HTTP).
- IP address or host name of the Embedded PC.

Table 16: Access data for the Beckhoff Device Manager on delivery.

User name	Password				
Administrator	1				

#### Start the Beckhoff Device Manager as follows:

- 1. Open a web browser on the host PC.
- 2. Enter the IP address or the host name of the Industrial PC in the web browser to start the Beckhoff Device Manager.
  - Example with IP address: <u>http://169.254.136.237/config</u>
  - Example with host name: http://BTN-000f89fa/config
- 3. Enter the user name and password. The start page appears:

	🖵 BECKHOFF I	Device N	Manager				
l		284	Î~	Device			×
		<b>1</b> 0	System	Name	BTN-000f89fa	]	
	Device		-	Date Time	31.01.2022 14:22:00		
			62	Operating System	TC/RTOS 0.9		
			Connectivity	Image Version	CX7000 Loader 0.9.41133-	c0a85bc06a047b9f+Rel31	
			i 12	Hardware Version	CX7080 v01.2 2021-06-01		
	Hardware		Boot	Serial number of IPC	000f89fa		
				Device Manager Version	2.0.3.26		
				Workload			
	Software			Ö	7%		
		<u> </u>		CPU	Max: 100%		
		5.JD			00%		
	TwinCAT			Memory	29% Max: 100%		
		도입					
	Security						

⇒ Navigate forward in the menu and configure the Industrial PC. Note that modifications only become active once they have been confirmed. It may be necessary to restart the Industrial PC.

## 7.2 Persistent data

### NOTICE

### Application example

In the following example, changes to the loads, the power supply or even just aging components can lead to the application no longer fulfilling the desired function. Beckhoff takes no responsibility for the implementation of the example in an application.

Normally, persistent data are only stored during the TwinCAT stop or by a function block. This chapter shows you how to store persistent data on a CX7000 without a UPS.

In the case of an Embedded PC with UPS, the function block is usually linked to the UPS. The function block becomes active as soon as a power failure is detected, writes the persistent data and then shuts down the Embedded PC. With a 1-second UPS, the Embedded PC is not shut down because there is too little time left for this.

In the case of a small controller such as the CX7000 which is delivered without a 1-second UPS, you can still use this function. All that is needed is to use a power supply unit that has enough residual energy to supply power to the CX7000 with this residual energy for a certain period of time. A small test can show you if this is possible with your power supply unit:

### Testing a power supply unit

When the CX7000 is running, turn off the AC voltage of your power supply unit and measure how long the CX7000 continues to run. If it is more than three seconds, you may be able to use the power supply unit as a replacement for a 1-second UPS. Note that power supply units also age and lose capacity. You should therefore include a safety factor, such as a factor of three, so that you have enough reserve to be able to operate the power supply unit for a longer period of time as a replacement for a 1-second UPS.

Now determine how long the power supply unit maintains the supply of power. You need an EL1722 for this, which you connect to the AC side of the power supply unit. Then write a small program:

```
VAR
    bPower230V AT %I* : BOOL; (*link to the EL1722*)
END_VAR
VAR RETAIN
    Counter : INT;
END_VAR
Program:
IF NOT bPower230V THEN (*bPower230V is linked to the EL1722*)
    Counter:=counter+1; (*the counter is a retain value*)
END_IF
```

Create a boot project and turn off the AC voltage of the power supply unit. As soon as the EL1722 no longer displays a value, the counter is incremented and the data are copied to the internal NOVRAM. Turn the AC voltage back on and log in. You must now multiply the counter value by the task time. Repeat this a few times to be sure that the power supply unit always behaves in the same way. Next, you have to insert the function block FB\_WritePersistentData. This is contained in the Tc2\_Utilities library (in the "TwinCAT PLC" folder).

Then determine how long it takes to store the persistent data. Repeat this process a few times too, so that you obtain a constant value and can determine a maximum value in case of fluctuations. You can determine the time required via the Busy flag. The function block is being processed as long as the Busy flag is set. Multiply the value determined by two to incorporate a further safety factor.

### Example:

Your measurement shows that the power supply unit maintains the supply of power for three seconds and that the persistent data is written in about 400 ms. With the recommended safety factors, the power supply is maintained for one second and the persistent data is written in about 800 ms.

The power supply is therefore maintained for a longer period of time than is needed to store the persistent data. Therefore you can use the example power supply unit as a replacement for the 1-second UPS.

## 7.3 NOVRAM

The NOVRAM can be used to reliably save important variable values, such as production data or counter values, in the event of a power failure. The memory size of the NOVRAM is limited and only suitable for smaller data quantities up to 4 kB.

In this chapter, we show you how the NOVRAM is used in TwinCAT 3.

### **Operating principle**

The NOVRAM (Non-Volatile Random Access Memory) is a special memory component that is used to reliably save important data. The NOVRAM consists of two sections, a volatile memory and a non-volatile memory.

TwinCAT only writes to the volatile section of the NOVRAM. In the event of a power failure, the data are automatically copied from the volatile memory into the non-volatile memory. The energy required for this process is supplied by a capacitor. As soon as the power supply is restored, the data are automatically copied back into the volatile memory so that TwinCAT can continue to use them.



Fig. 23: Controller behavior with and without NOVRAM.

### Memory size

The NOVRAM has a capacity of 4 kB. The data are saved cyclically and alternately based on the dual buffer principle, in order to avoid the risk of data inconsistency.

### Requirements

Development Environ- ment	Target platforms	Hardware	PLC libraries to include
TwinCAT 3.1 Build: 4020	PC or CX (x86, x64, Arm <sup>®</sup> )	CX70xx, CX9020, CX20x0, CX20x2, CX20x3	Tc2_loFunctions

## 7.3.1 Creating a Retain Handler

Under TwinCAT 3 (from Build 4020) a delta algorithm is used to save data in the NOVRAM. The algorithm does not save all the variables in the NOVRAM. Instead, it searches for changes (delta function) compared to the previous cycle and only saves variables that have changed.

To use the delta algorithm, a Retain Handler must be created in TwinCAT 3, and the relevant variables must be declared in the PLC with the keyword VAR\_RETAIN.

A new feature of this method is that no function blocks have to be used. The Retain Handler saves data in the NOVRAM in the event of a power failure and makes them available again once the power has been restored.

This chapter describes how to create a Retain Handler in TwinCAT 3. The Retain Handler saves data in the NOVRAM and makes them available again. In other words, important variable values such as production data or counter values are retained during a restart or power failure.

Requirements for this step:

- TwinCAT 3.1 Build: 4020.
- A target device selected in TwinCAT.

### Create the Retain Handler as follows:

1. Right-click on **Devices** in the tree view on the left-hand side.

2. In the context menu click on **Scan**.



3. Select Device (NOV-DP-RAM) and confirm with OK.



4. Click on **Yes** to search for boxes.



5. Click on **Device (NOV-DP-RAM)** in the tree view on the left-hand side and then on the tab **Generic NOV-DP-RAM Device**.

Solution Explorer 🔹 🔻 🗙	Retain Example 🗙		
<ul> <li>Solution 'Retain Example' (1 project)</li> <li>Retain Example</li> <li>SYSTEM</li> <li>MOTION</li> <li>PLC</li> <li>SAFETY</li> <li>C++</li> <li>I/O</li> <li>Devices</li> <li>Image</li> <li>Inputs</li> <li>Outputs</li> </ul>	Genera Generic NOV- PCI Vendor ID (hex): Device ID (hex): BaseAddr (0-5):	DP-RAM Device DPRAM (Online)	Search
	Bus/Slot (Addr): © RAM (e.g. ISA) Address Size:	0xF0100000	
i viappings	Export/Import Data	utputs	Export

- 6. Click the option **RAM**.
- 7. Right-click on Device (NOV-DP-RAM) in the tree view and then on Add New Item.

🐌 Device 4 (NO	V-DP-	RAM)
🛟 Image		Add New Item
Inputs Outputs Mannings	×	Add Existing Item Remove
		Change NetId

8. Select the Retain Handler and click on OK.

isert Box		
Туре:	Beckhoff Automation GmbH	Ok
		Cancel

⇒ You have successfully created a Retain Handler in TwinCAT.



In the next step you can create retain variables in the PLC and link them with the Retain Handler.

## 7.3.2 Creating and linking variables

Once you have created a Retain Handler in TwinCAT, you can declare variables in the PLC and link them to the Retain Handler. The variables have to be identified in the PLC with the keyword VAR RETAIN.

If self-defined data types (DUTs) are used as retain data, the data types must be available in the TwinCAT type system. To do this, the structures must be created directly as STRUCT RETAIN, with all occurrences of the structure then handled by the Retain Handler.



Fig. 24: Labeling with keyword STRUCT RETAIN for self-defined Data Unit Types (DUTs)

Retain data cannot be used for POUs (function blocks) as a whole. However, individual elements of a POU can be used.

Prerequisite for this step:

• A PLC project created in TwinCAT.

#### Create variables as follows:

1. Create the variables in your PLC project in a VAR RETAIN area.

1	PROGRAM MAIN
2	
з	VAR RETAIN
4	x :UINT;
5	y :UINT;
6	z :UINT;
7	END VAR
8	
9	VAR
10	
11	datain AT%I*: REAL;
12	dataout AT%Q*: BYTE;
13	
14	END_VAR

2. For self-defined Data Unit Types (DUTs), use the keyword STRUCT RETAIN.

- BECKHOFF
- 3. Click on Build in the toolbar at the top, then on Build Solution



4. Click on your PLC Instance in the tree view on the left and then on the tab Data Area.

<b>a</b>				-		1			_		
Solution 'Retain Example' (1 project)	bje	at Co	ontext Parameter (In	it) Data A	Area						
Retain Example		Ar	Name	Туре	S.,	CS	Ele	Retain Hdl		0w	Co
	+	0 (0)	PIcTask Inputs	Input	5	$\overline{}$	1 Sy				2
	+	1 (0)	PIcTask Outputs	Outp	5	~	4 Sy				
RetainPLC	+	3 (0)	PlcTask Internal	Inter	5	•	12 S				
RetainPLC Project	-	4 (0)	PIcTask Retains	Retai	5	~	3 Sy	00000000	-		- 1
External Types			MAIN.x	UINT	2						
References			MAIN.v	UINT	2						
DUIS			MAIN.7	UINT	2		-				
POUs											10 m
MAIN (PRG)											
VISUs											
PlcTask (PlcTask)											
RetainPLC.tmc											
RetainPLC Instance											
PlcTask Inputs											
PlcTask Outputs											
PlcTask Retains											
a 📑 MAIN.											

5. Under Retain Hdl, select the Retain Handler that you have created.

je	ct C	ontext Parameter (In	iit) Data A	lrea						
	Ar	Name	Туре	S	CS	Ele	Retain Hdl	0w	Co	
+	0 (0)	PlcTask Inputs	Input	5	~	1 Sy				
+	1 (0)	PIcTask Outputs	Outp	5	~	4 Sy				
+	3 (0)	PlcTask Internal	Inter	5	~	12 S				
-	4 (0)	PlcTask Retains	Retai	5	~	3 Sy	03020001 'Box 1	1 (Retain Handler)		
		MAIN.x	UINT	2			0000000			
		MAIN.y	UINT	2			03020001 'Box 1	(Retain H	landler)	
		MAIN.z	UINT	2						

After selecting a Retain Handler as the target, the symbols are linked in the tree view and a mapping is created.

In the tree view, the PLC variables are created under the Retain Handler and linked to the PLC instance

variables.



An existing link is indicated by an arrow icon.

## 7.3.3 Deleting variables under the Retain Handler

If variables are deleted from the PLC, the link with the Retain Handler is cancelled. However, the variables continue to be shown under the Retain Handler and are not deleted automatically.

Under TwinCAT 3 the variables have to be deleted manually.

Prerequisites for this step:

• Variables declared with VAR\_RATAIN were deleted from the PLC.

Delete the variables under the Retain Handler as follows:

1. The variable GVL\_Retain.iNt under the Retain Handler is to be deleted.



- 2. Right-click on the Retain Handler in the tree view on the left.
- 3. In the context menu click on Optimize Retain Variables.



⇒ The variable under the Retain Handler is deleted.

## 7.4 Software configuration

### 7.4.1 User name and password

In the delivery state, the CX7000 has a preset user name with password, which is necessary for logging in to TwinCAT or the Beckhoff Device Manager.

- User name: Administrator
- Password: 1

The user name is fixed and cannot be changed. It is also not possible to add another user name. The preset password can be changed via the Beckhoff Device Manager (see: Starting the Beckhoff Device Manager). The password can contain a maximum of 32 characters. Numbers, letters and special characters are allowed and a distinction is also made between upper and lower case letters.

BECKHOFF D	Device N	Manager				
	<u>,</u> ,	сĭ	Login			
	帚	Wizard	Change User Passwords			✓ ×
Device		A	Username	Administrator	]	
the second se		©″	Password	•		
		Access	New Password	•••••		
Hardwara			New Password (confirm)	•••••		
natuwale	_					
	L.CA					
Software						
	دائ					
	5. S					
TwinCAT						
	~					
	도법					
Security						
Security						

Fig. 25: Changing the password in the Beckhoff Device Manager.

You can restore the delivery state and preset password by removing the MicroSD card, accessing the MicroSD card with a card reader and deleting the device.conf file in the /etc folder. The password cannot be reset without physical access to the CX7000 and thus to the MicroSD card.

### 7.4.2 Setting the IP address

DHCP is enabled by default for the CX7000. Without a DHCP server, the CX7000 uses a local IP address in the address range 169.254.x.x

In the case of the CX7000 Embedded PC, there are several ways to set the IP address. One way is to call the Beckhoff Device Manager and set the IP address for the CX7000 in the browser (see: Starting the Beckhoff Device Manager).

Another way to set the IP address is offered by the boot.conf file, which is created on the MicroSD card after the first start. This step shows you how to set the IP address in the boot.conf file.

Requirements:

• MicroSD card reader

#### Proceed as follows:

- 1. Switch the Embedded PC off and remove the MicroSD card from the Embedded PC.
- 2. Open the Boot.conf file under \etc



#### 3. Set the DhcpEnabled entry to false.

- 4. Assign an IP address under **IPv4**.
- 5. Make the settings for subnet mask, gateway and DNS server.
- ⇒ Save the changes and install the MicroSD card in the Embedded PC again. The settings are effective after startup.

## 7.4.3 Configure virtual local area network (VLAN)

From image version 140501, a virtual local area network (VLAN) can be configured on the Ethernet interface (X001). The VLAN forms a logical network segment and its own broadcast domain. This means that the network is subdivided regardless of the physical network topology on-site. The data traffic of a VLAN's associated devices is isolated from other VLANs.

The configuration takes place in the file /etc/boot.conf on the microSD card. Update the image first if you are using an older image version on the embedded PC (see: <u>Update image [ $\blacktriangleright$  60]</u>).

Requirements:

• card reader for microSD cards

#### Proceed as follows:

- 1. Switch the embedded PC off and take the microSD card out of the embedded PC.
- 2. Insert the microSD card into an external card reader and open the microSD card's folder tree.
- 3. Open the boot.conf file under \etc and navigate to the entries for the VLAN.

```
; VLanEnabled on Interface 0 can be true or false (default). If true, VLAN Tagging is supported.
0:VLanEnabled = false
; VLanID on Interface 0 can be set from 0 to 4094. When VLAN is enabled, it defines the
operating VLAN.
0:VLanID = 1
; VLanPriority on Interface 0 can be set from 0 to 7. When VLAN is enabled, it defines the
priority of the packets, sent with a VLAN Tag. 0 has a higher priority than 7.
0:VLanPriority = 0
```

- 4. Edit the parameters VLanEnabled, VLanID und VLanPriority according to your requirements.
- ⇒ Save the changes and reinstall the microSD card in the embedded PC. The settings will take effect after the device is started.

### 7.4.4 Update image

NOTICE

### Failure of the power supply

The bootloader may be corrupted if the update is interrupted. The CX70x0 thus becomes unusable and must be sent in for repair. Ensure a stable power supply during initial start-up and do not interrupt the update.

The new image will be copied directly to the MicroSD card in order to update the image of the Embedded PC. The new image is made available by Beckhoff Service. Perform the update only after consulting with Beckhoff Service.

Requirements:

• Card reader for MicroSD cards.

### Update the image as follows:

- 1. Switch the Embedded PC off and remove the MicroSD card from the Embedded PC.
- 2. Insert the MicroSD card into an external card reader and open the MicroSD card's folder tree.
- 3. Delete all files and folders on the MicroSD card.

- BECKHOFF
- 4. Copy all files and folders of the new image to the empty MicroSD card.



- 5. Re-install the MicroSD card in the Embedded PC and start the Embedded PC.
- ⇒ The Embedded PC is started and saves the current hardware configuration. New folders are created, such as Hard Disk or TwinCAT. The image has now been successfully updated.



## 7.4.5 Updating the firmware for multifunction I/Os

This step shows you how to update the firmware of the multifunction I/Os. The firmware is provided by Beckhoff Service and the update is carried out in TwinCAT.

Requirements:

• EtherCAT firmware file (\*.efw)

### Proceed as follows:

- 1. Start TwinCAT in configuration mode (config mode).
- 2. On the left in the structure tree, click the CX7028 device and then click the Online tab.

Solution Explorer 👻	Ψ×	CX7000 🗢 🗙 MAIN						Ŧ
○ ○ 🏠 📇 - Ìo - ā   🗡 💻		General Process Data	Slots Startup	CoE - Online Online	ADS			
Search Solution Explorer (Ctrl+;)	P-9	State Machine						
Solution 'CX7000' (1 project)         CX7000         System         MOTION         PLC         SAFETY         C++         ANALYTICS         Image         Povices         Image         Outputs         Outputs         InfoData         Image         Image <td></td> <td>State Machine         Init         Pre-Op         Op         DLL Status         Port A:         Port B:         Port C:         Port D:         File Access over Ether         Download</td> <td>Bootstrap Safe-Op Clear Error erCAT Upload</td> <td>Current State: Requested State:</td> <td>BOOT</td> <td></td> <td></td> <td></td>		State Machine         Init         Pre-Op         Op         DLL Status         Port A:         Port B:         Port C:         Port D:         File Access over Ether         Download	Bootstrap Safe-Op Clear Error erCAT Upload	Current State: Requested State:	BOOT			
Module 1 (CNT)								
Module 3 (DIO_2x)		Name	Online	Туре	Size	>Addr	In/Out	^
Module 5 (DI_2x)	-	🔁 Diag	0	BIT	0.1	11.4	Input	<b>v</b>
Solution Explorer Team Explorer		<					>	

- 3. Click the **Bootstrap** button to switch the multifunction I/Os to the bootstrap state.
- 4. Click the **Download** button and select a current efw file.



⇒ The update takes about 3 to 4 minutes. A progress bar indicates the progress of the update. Do not switch the CX7000 off during this time.

When the update is complete, return to the Operational (Op) state by clicking the **Op** button.

### 7.4.6 Updating the ESI device description

The TwinCAT System Manager and the TwinCAT EtherCAT Master require the device description files of all EtherCAT devices for configuration in online and offline mode. These device descriptions are the so-called ESI files (EtherCAT Slave Information) in XML format. These files can be requested from the respective vendor and are made available for download. An \*.xml file may contain several device descriptions.

ESI files for Beckhoff EtherCAT devices are provided at <u>https://www.beckhoff.com</u>.

Requirements:

- ESI file for the CX7000 in XML format.
- If necessary, the associated \*.xsd file, which describes the structure of the XML file.

#### Proceed as follows:

- 1. Copy the ESI file into the TwinCAT installation directory: \TwinCAT\3.1\Config\lo\Onboardlo.
- 2. Create the folder manually if it doesn't exist.
- 3. Open TwinCAT and click in the menu under TwinCAT > EtherCAT Devices on Reload Device Description.

CX7000 - TcXaeShell		V 🗗 Quick Launch (Ctrl+Q)
File       Edit       View       Project       Build       Debug         Image: Control of the state of the sta	TwinCAT         TwinSAFE         PLC         Team         Scope         Tools           Windows	Window         Help           ▶         ▶         Attach ▼         □
Solution Explorer • 4 × CX7000 + > CX7000 + < CX700 + < CX700 + < CX700 + < CX700 + < CX	Restart TwinCAT System           Restart TwinCAT (Config Mode)           Restart TwinCAT (Config Mode)           Restart TwinCAT (Config Mode)	-
Search Solution 'CX7000' (1 project) Solution 'CX7000' (1 project) Configured Allocated /	n 🔆 Scan S 💿 Toggle Free Run State Nov Show Online Data	)] 64KB ~
	Show Sub Items       Image: Weight of the state of the st	pet Set on target
Image: Second secon	Access Bus Coupler/IP Link Register Update Firmware/EEPROM Show Realtime Ethernet Compatible Devices	(none)
Q PLC     Object     SAFETY     Object     C++     I/O Idle T	File Handling Selected Item EtherCAT Devices	E Time (ms) Cycle Ticks Priority Update Device Descriptions (via ETG Website)
Maly IICS     PIcTask     PIcAuxTa	TcProjectCompare Target Browser Bode Plot	Reload Device Descriptions         Manage User Defined Whitelist         Manage User Defined Blacklist
Solution Explorer Team Explorer	Filter Designer About TwinCAT	·
🗇 Ready		↑ Add to Source Control 🔺 💡

⇒ The ESI file is re-read into TwinCAT. An error is returned if there is a faulty ESI file. Check whether the structure of the \*.xml corresponds to the associated \*.xsd file or whether the files match the CX7000.

# 8 TwinCAT

# 8.1 First Steps

### 8.1.1 Connect to the CX70x0

Before you can configure the CX7000 in TwinCAT, you must establish a connection between your engineering computer and the CX7000 (target system). The engineering computer and the Embedded PC must be in the same network and subnet or alternatively connected directly via an Ethernet cable (peer-to-peer).

The IP address or host name of the CX7000 is required for the connection.

Requirements:

- TwinCAT must be in Config mode.
- IP address or host name of the Embedded PC.

### Establish a connection as follows:

- 1. In the menu at the top click on **File > New > Project** and create a new TwinCAT XAE project.
- 2. In the tree view on the left click on **SYSTEM**, and then **Choose Target**.



3. Click on Search (Ethernet).

⊕- <mark>.22</mark> <locab (10.0.2.15.1.1)<="" th=""><th>OK Cancel</th></locab>	OK Cancel
	Search (Ethernet)
	Search (Heidbuds)

4. Click Broadcast Search and search for available devices on the network.

Enter Host Name / IP:	[			Re	efresh Status		Broadcast Search
Host Name Connected	Address	AMS NetId	TwinCAT	OS Version	Fingerprint	Commer	nt
Route Name (Target):				Route	Name (Remot	e): [[	DESKTOP-RUCO4K9
Route Name (Target): AmsNetId:				Route Target	Name (Remot Route	e): [[	DESKTOP-RUC04K9 Remote Route
Route Name (Target): AmsNetId: /irtual AmsNetId (NAT):				Route   Target O Pri	Name (Remot Route oject	e): [[	DESKTOP-RUCO4K9 Remote Route O None / Server
Route Name (Target): AmsNetId: /irtual AmsNetId (NAT): Transport Type:	TCP_IP			Route I ⊖ Target ○ Pr ● St ○ Te	Name (Remot Route oject atic mporary	e): [[	DESKTOP-RUCO4K9 Remote Route O None / Server Static O Temporary
Route Name (Target): AmsNetId: /irtual AmsNetId (NAT): Fransport Type: Address Info:				Route Target OPn OSt OTe	Name (Remot Route oject atic mporary	e): [[	DESKTOP-RUCO4K9 Remote Route None / Server © Static O Temporary
Route Name (Target): AmsNetId: Virtual AmsNetId (NAT): Transport Type: Address Info: O Host Name	TCP_IP			Route I Target O Pr I St O Te Adva	Name (Remot Route oject atic emporary anced Setting:	e): [[ s [	DESKTOP-RUCO4K9 Remote Route None / Server Static Temporary Unidirectional
Route Name (Target): AmsNetId: Virtual AmsNetId (NAT): Transport Type: Address Info: O Host Name O IP / Connection Timeout (s):	TCP_IP			Route I Target O Pr I St O Te	Name (Remot Route oject atic emporary anced Setting:	e): [ 	DESKTOP-RUCO4K9 Remote Route None / Server Static Temporary Unidirectional

5. Mark the appropriate CX7000 and click **Add Route**. The host name and IP address facilitate identification.

	laiog					
Enter Host Nam	ne / IP:			Be	efresh Status	Broadcast Search
Host Name (	Connected	Address	AMS NetId	TwinCAT	OS Version	Fingerprint
BTN-000f89fa		192.168.178.30	5.95.143.108.1.1	3.1.4025	TC/RTOS (0.9)	0DA75F7C2C42FE738AB
<						
<						
< loute Name (Targ	get):	BTN-000f89fa		Route	Name (Remote):	DESKTOP-RUC04K9
< loute Name (Targ msNetId:	get):	BTN-000f89fa 5.95.143.108.1.1		Route I	Name (Remote): : Route	DESKTOP-RUC04K9 Remote Route
< loute Name (Targ msNetId: irtual AmsNetId (I	get): NAT):	BTN-000f89fa 5.95.143.108.1.1		Route Target O Pro	Name (Remote): : Route oject	DESKTOP-RUC04K9 Remote Route O None / Server
< loute Name (Targ msNetId: irtual AmsNetId (I	get): NAT):	BTN-000/89fa 5.95.143.108.1.1		Route   Target O Pri © Sta	Name (Remote): Route oject atic	DESKTOP-RUC04K9 Remote Route O None / Server
<ul> <li>Loute Name (Targ msNetId: intual AmsNetId (I ransport Type:</li> </ul>	get): NAT):	BTN-000/89fa 5.95.143.108.1.1 TCP_IP		Route Target O Pr O St O Te	Name (Remote): . Route oject atic :mporary	DESKTOP-RUC04K9 Remote Route None / Server Static Temporary
< loute Name (Targ .msNetId: 'irtual AmsNetId (I ransport Type: .ddress Info:	get): NAT):	BTN-000/89fa 5.95.143.108.1.1 TCP_IP 192.168.178.30		Route Target OPr St OTe	Name (Remote): . Route oject atic :mporary	DESKTOP-RUC04K9 Remote Route None / Server Static Temporary
<ul> <li>voute Name (Targ msNetId: intual AmsNetId (I ransport Type: ddress Info: O Host Name</li> </ul>	get): NAT): IP A	BTN-000/89fa 5.95.143.108.1.1 TCP_IP 192.168.178.30 ddress		Route I Target O Pro St. Te Adva	Name (Remote): Route oject atic emporary anced Settings	DESKTOP-RUC04K9 Remote Route None / Server Static Temporary
<ul> <li>coute Name (Targ msNetId: intual AmsNetId (I ransport Type: .ddress Info: O Host Name</li> <li>connection Timeo</li> </ul>	get): NAT): IP Ar put (s):	BTN-000/89fa 5.95.143.108.1.1 TCP_IP 192.168.178.30 ddress 5	  	Route I Target O Pr O St O Te	Name (Remote): Route oject atic mporary anced Settings	DESKTOP-RUC04K9 Remote Route None / Server Static Temporary
Route Name (Targ     AmsNetId:     /intual AmsNetId (I     ransport Type:     Address Info:         O Host Name     Connection Timeco	get): NAT): ● IP Ar put (s): o (IP de)	BTN-000/89fa 5.95.143.108.1.1 TCP_IP 192.168.178.30 ddress 5	→	Route I Target Pr St Te Adva	Name (Remote): Route oject atic mporary anced Settings	DESKTOP-RUC04K3 Remote Route None / Server Static Temporary Unidirectional

6. Enter the user name and password in the User and Password fields respectively and click OK. User name: Administrator Password: 1

☑ Secure ADS (Tw	inCAT 3.1 >= 4024)		
Self Signed Certif	icate		
Check Fingerprint:	5D0B1AC29E014C07F4457	65E17E09CE6C7525EE9AF5582624E3FE8F90	1335277B
Compare with:			
O Shared Certificate	e Authority (CA)	🗌 Ignore Commo	on Name
O Preshared Key (P	SK)		
Remote User Credentia	ls		
Jser:	Administrator	Password:	
			- 210

7. The new device is displayed in the Choose Target System window.

8. Select the device you want to specify as target system and click **OK**.



⇒ You have successfully established a connection between your engineering computer and the CX7000 (target system) in TwinCAT. The new target system and the host name are displayed in the menu bar.



Using this procedure you can search for all available devices and also switch between the target systems at any time.

### 8.1.2 Scan multifunction I/Os

Special features of the CX7000 series are the eight integrated multifunction inputs and four integrated multifunction outputs. This chapter shows how to scan and create the multifunction I/Os in TwinCAT.

Note that the CX7028 interface for controlling the multifunction I/Os has its own CPU and the CX7028 interface is not displayed or does not work under TwinCAT if the power supply(Up) is not connected.

1. On the left side of the tree view, right-click **Devices** and then click **Scan**.



available I/O devices are displayed.

- 2. Select the appropriate I/O devices. For this example, at least the CX7028 interface, i.e. the CX7000 device, must be selected. If you still want to operate Bus or EtherCAT Terminals on the CX7000, then you must also select EtherCAT as a device.
- 3. A total of four slots are created. For each slot a maximum of one module (DI, DIO, ENC, CNT or PWM) can be assigned, which in turn determines the operation mode for the respective slot.

CX7000 - TcXaeShell	V 🗗 Quick La	aunch (Ctrl+Q)
File Edit View Project Build Debug	TwinCAT TwinSAFE PLC Team Scope Tools	Window Help
🖁 G • O   🔁 • 🖆 • 🚔 🔛 💾 👗 🗗	🗇 🦻 🗸 🖓 🗣 Release 🕞 TwinCAT OS (ARMT2)	→ Attach → <sup>11</sup> / <sub>2</sub>
Build 🕮 🗤 (Loaded) 🔹 🚽 🔛 🤷	🤹 📉 🎯 🍡 🔏 🛛 CX7000 🔹 🖻	BTN-000f89fa 🚽 🚽 🛱
Solution Explorer 🔹 म 🗙	CX7000 -₽ ×	-
G O 🟠 🛗 - 🐻 - 🗗 🏓 💻	General Process Data Slots Startup CoE - Online Onlin	ne ADS
Search Solution Explorer (Ctrl+;)	Slot Module ModuleIdent Mod	dule ModuleIdent Description
▲ 🔄 I/O	InOut[12] DIO_2x 0x00301B74	ENC 0x00601B74 Encoder CNT 0x00701B74 Counter
<ul> <li>Devices</li> <li>BEOK Device 3 (CX7000)</li> </ul>	■ noa(j4) Dio_2x 0x00001074	DIO_2x 0x00301B74 Digital, 2xDI 2xDC
🛟 Image	In[78] DI_2x 0x00201874	
Inputs		
↓ InfoData		
🔺 📜 Term 1 (CX7028)		
DEV Inputs Device		
Module 1 (DIO_2x)		
Module 5 (DIO_2X)		
Module 7 (DI_2x)		
📸 Mappings		, i i i i i i i i i i i i i i i i i i i
Solution Explorer Team Explorer		>
Ready		🛧 Add to Source Control 🔺 🔡

- 4. Modules can be assigned to a specific slot with the button < or removed again with x.
- ⇒ Define the required modules according to their requirements. There is a choice of different modules depending on the slot used. Which modules are supported by which slot is listed in the chapter <u>Multifunction I/Os [▶ 28]</u>.

## 8.1.3 Establishing ADS communication

This chapter shows you how to connect a CX7000 to another CX70x0 or any TwinCAT controller. The ADS protocol provides the simplest way to connect two TwinCAT systems to each other. With the ADS protocol, data can be both read and written. ADS function blocks are normally used for communication; these are included in the Tc2\_System library. In the following example, data are to be written to and read from a memory area.

In order to set up an ADS connection, an ADS route is created first. Communication then takes place via Ethernet and data exchange via the TCP/IP protocol. The ADS route is then the interface between the ADS and TCP/IP connection. The ADS route indicates which AmsNetId is assigned to which TCP/IP address. As a result, the ADS function blocks no longer use the TCP/IP address, but the AmsNetId.

Requirements:

- Two CX70x0 Embedded PCs.
- Both CX70x0s are in the same network and accessible via ADS.

### Proceed as follows:

- 1. Start TwinCAT and connect to the first CX70x0 (see: Connect to the CX70x0 [ 64]).
- 2. On the left in the tree view, click Routes, select the Static Routes tab, and click the Add button.

Solution Explorer 🔹 👎 🗙	CX7000 ⊅ ×						•
◎ ◎ 🏠 🕂 - 💿 - 🗗 🎤 💻	Current Routes Static	Routes Project	Routes NetId Man	agement			^
Search Solution Explorer (Ctrl+ü)		A		-		<u> </u>	
Image: Solution 'CX7000' (1 project)         Image: System         Image: System         Image: System         Image: Solution 'CX7000' (1 project)         Image: System         Image: Solution 'CX7000'         Image: System         Image: Solution 'CX7000'         Image: Solution 'CX7000'	House DESKTOP-RUC	AmsNetId 10.0.2.15.1.1	Address 172.17.40.29	TCP_IP	Max Fragment	Comment	
MOTION	<					>	
PLC	Add	Remove					
SAFETY	MQTT Broker		Name	Торіс	User	Security	~

3. Under **Remote Route**, select the **Static** option so that the ADS route remains in the project, and then click the **Broadcast Search** button.

Enter Host Name / IP:				Refresh Stat	us	Broa	dcast Search	
Host Name	Connected	Address	AMS NetId	TwinCAT	OS Version		Fingerprint	.,
CX-315394		172.17.40.52	5.49.83.148.1.1	3.1.4022	Windows 7			
CX-35D5DA		172.17.42.34	5.53.213.218.1.1	3.1.4024	Windows 10	1809	3C8B9B1B4I	
CX-3D3A1B		172.17.42.23	5.61.58.27.1.1	2.11.2301	Win CE (6.0	0		
CX-52D1BA		172.17.42.47	5.85.240.128.1.1	3.1.4024	Windows 10	1809	D08A9839D	
CX-5F0F80		172.17.42.27	5.95.15.128.1.1	3.1.4025	TC/RTOS (	0.9)	5AC4C9ECE	
CX-5F8F6A		172.17.42.28	5.95.143.106.1.1	3.1.4025	TC/RTOS (	0.9)	983E7D7F3ŧ	
CX-5F8F6C		172.17.40.64	5.95.143.108.1.1	3.1.4025	TC/RTOS (	0.9)	9E63837915	
CX7000-TwinSAFE		172.17.42.21	5.75.184.87.1.1	3.1.4025	TC/RTOS (	0.9)	8B0EBA629I	2
<							>	
Route Name (Target):	CX-5F8F6	iC	Rou	ute Name (Re	mote): C	X-57E1	02	
AmsNetId:	5.95.143.	108.1.1	 	raet Boute		Bemote	Boute	
				) Project		O Nor	ne / Server	
/irtual AmsNetId (NAT):				Chatio		@ \$Ha	tion of the second s	
Fransport Type:	TCP_IP	~		) Temporary			nporary	
Address Info:	172.17.40	).64	]					
◯ Host Name	Address			dvanced Sett	ings 🗌	Unidin	ectional	
Connection Timeout (s):	5	+						
ulau Eragmont Cigo (kButo):	0		]				Class	ł

4. Select the second CX70x0 as the destination of the ADS route. The ADS route is entered for both Embedded PCs. The AmsNetId of the second CX70x0 is displayed and can be used in the program for ADS function blocks.

Solution Explorer 🛛 👻 🕂 🗙	CX7000 ⇔ ×					
◎ ● 🏠 🗄 - 💿 - 🗃 🏓 💻	Current Routes Stat	ic Routes Project R	loutes NetId Mar	nagement		
Search Solution Explorer (Ctrl+ü) Solution 'CX7000' (1 project) CX7000 CX7000	Route DESKTOP-RUC CX-5F8F6C	AmsNetId 10.0.2.15.1.1 5.95.143.108.1.1	Address 172.17.40.29 172.17.40.64	Type TCP IP TCP_IP	Max Fragment	Comment
Iccense       ▷ <ul> <li>Real-Time</li> <li> </li> <li></li></ul>						
Type System	< Add	Remove				>
SAFETY C++ ANALYTICS	MQTT Broker	N	lame	Topic	User	Security

5. Now connect to the second CX70x0, which has been set as the destination of the ADS route, and write a small program. Define an array and increment a value of the array.

```
VAR
MarksTest AT %MB0 : ARRAY[0..9] of INT;
END_VAR
Program:
```

MarksTest[0]:=MarksTest[0]+1;

- 6. Activate the configuration and switch the CX70x0 to Run mode.
- 7. For the first CX70x0, write a program that reads the incremented value of the array.

```
VAR
    ADSREAD : ADSREAD:
    NetID : STRING:='5.81.38.23.1.1'; (* AMSNetId of the target*)
    Value : INT; (* value of target MarksTest[0]*)
    Error : INT;
    NoError : INT;
END VAR
Program:
    ADSREAD (
        NETID:=NetID ,
PORT:=851 , (* plc port of the target*)
        IDXGRP:=16#4020 , (* Marks %MB*)
        IDXOFFS:=0 , (* Marks offset in byte*)
LEN:=2 , (* length of data in byte*)
        DESTADDR:=ADR(Value) , (* pointer to the data in which the value is to be stored *)
        READ:=TRUE ,
        TMOUT:= ,
        BUSY=> ,
        ERR=> ,
        ERRID=> );
    IF NOT ADSREAD.BUSY THEN
        IF NOT ADSREAD.ERR THEN
            NoError:=NoError+1;
        ELSE
            Error:=Error+1;
        END IF
    ADSREAD (Read:=FALSE);
    END IF
```

- 8. The incremented value is read out and transmitted to the first CX70x0.
- You should see on the first CX70x0 how the value of the Value variable is incremented. The writing of the data works in the same way. Data can be written with the ADSWRITE function block. Make sure that you set the offset (IDXOFFSET) to 10 in this sample setup so that the array [4... 9] is written. Limit the length to 10 bytes, as an array of 0... 9 of type INT was created and the memory thus uses %MB0... MB19 (10 \* 2 bytes) (The elements 0...4 for reading the array and the elements 5...9 for writing it).

Use one ADS command at a time. Wait until the ADS service is finished, i.e. the BUSY output of the

function block is switched to FALSE, and only then use the next ADS function block. To optimize the access timing, you can also use an ADSREADWRITE function block that reads and writes the data at the same time.

### 8.1.4 Creating a PLC project

The next steps describe how to create a PLC project in TwinCAT and add it in the tree view.

Prerequisites for this step:

• A newly created TwinCAT XAE project.

### Create a PLC project as follows:

- 1. Right-click on **PLC** in the tree view.
- 2. In the context menu click on Add New Item and select the Standard PLC Project.



3. In the tree view click on the newly created PLC project, then double-click on MAIN (PRG) under POUs.



4. Write a small program, as shown in the diagram below.



5. In the tree view right-click on the PLC project, then click on **Build** in the context menu.



⇒ You have successfully created a PLC project and added the project in TwinCAT. A PLC instance with the variables for the inputs and outputs is created from the PLC project.



In the next step you can link the variables with the hardware.

## 8.1.5 Linking variables

Once the PLC project was successfully added in the System Manager, you can link the newly created input and output variables from the PLC project with the inputs and outputs of your hardware.

Prerequisites for this step:

• A PLC program attached in TwinCAT.

#### Link the variables as follows:

 Double-click on the input or output variables in the tree view under PLC. The Attach Variable window appears and shows which inputs or outputs can be linked with the variables from the PLC project.



2. Double-click on the inputs or outputs of the hardware in the **Attach Variable** window. Link the input variables with the inputs and the output variables with the outputs of the hardware.



Variables that are already linked are indicated with a small arrow icon in TwinCAT.

3. In the toolbar click on Activate Configuration.



- 4. Confirm the request whether TwinCAT is to start in Free Run mode with Yes.
- ⇒ You have successfully linked variables with the hardware. Use Activate Configuration to save and activate the current configuration.

The configuration can now be loaded on the CX, in order to automatically start TwinCAT in Run mode, followed by the PLC project.
## 8.1.6 Load configuration to CX

Once variables are linked, the configuration can be saved and loaded on the CX. This has the advantage that the PLC project is loaded and started automatically when the CX is switched on. The start of the previously created PLC project can thus be automated.

Prerequisites for this step:

- A completed PLC project, added in the System Manager.
- Variables from the PLC project, linked with the hardware in the System Manager.
- A CX selected as target system.

#### Load the configuration from the System Manager to the CX as follows:

- 1. In the tree view on the left click on SYSTEM.
- 2. Click on the Settings tab.

Solution Explorer 🛛 🝷 👎	X TwinCAT Project1 + X
◎ ◎ ☆   '@ - # 副   # -	Version (Local) Version (Target Settings Data Types Interfaces Functions
Search Solution Explorer (Ctrl+ü)	Boot Settings (Target)     Auto Boot:      Config Mode     Auto Logon
<ul> <li>PLC</li> <li>SAFETY</li> <li>C++</li> </ul>	User Name Administrator Password

3. Under Boot Settings select the option Run Mode (Enable) and tick the Auto Logon checkbox.

Version (Local)	Version (Target)	Settings	Data Types	Interfaces	Functions	
Boot Settings	(Target)		_		A	vlga
Auto Boot:	Run Mo	de (Enable	e)			
	Config M	Mode				
Auto Logon						
User Nar	me Administrat	or				
Passwor	d .					

- 4. Enter the user name and password for the CX in the User Name and Password fields.
- 5. Click on Apply.
- 6. In the tree view on the left right-click on the PLC project under PLC.

7. In the context menu click on **Autostart Boot Project**. The setting is selected

Solution Explorer 🔹 🗸	<b>д х</b>		
Search Solution Explorer (Ctrl+ū)	p.		
<ul> <li>Solution 'TwinCAT Project1' (1 p</li> <li>TwinCAT Project1</li> <li>SYSTEM</li> <li>MOTION</li> <li>PLC</li> <li>Example</li> </ul>	projec	t Activate Boot Project	
Example Instance	1	Autostart Boot Project	
SAFETY		Change ADS Port	
		Install Project Libraries	
	×	Remove Rename	Del

- 8. Right-click on the project folder in the tree view.
- 9. In the context menu click on **Auto Save to Target as Archive**. The setting is selected.



⇒ You have successfully loaded the CX configuration. From now on, TwinCAT will start in Run mode and the PLC project will start automatically.

Next, the master can be added in a new project in the System Manager and can then be used to find slaves that have already been set up.

## 8.2 Reading the IP and MAC addresses

This sample shows you how to read the IP and MAC addresses. The function block FB\_MDP\_NIC\_Read can be used to retrieve information from the network adapter.

#### Sample

```
Var
    FB MDP NIC Read
                       : FB MDP NIC Read;
END_VAR
PROGRAM:
FB MDP NIC Read(
   bExecute:=TRUE ,
    tTimeout:= ,
    iModIdx:= ,
    sAmsNetId:= ,
    bBusy=> ,
   bError=> ,
    nErrID=> ,
    iErrPos=>
    stMDP ModuleHeader=> ,
    stMDP ModuleContent=> );
```

The output stMDP\_ModuleHeader displays the header information. The output stMDP\_ModuleContent displays, among other things, the information about the IP and MAC addresses.

stMDP_ModuleHeader	ST_MDP_ModuleHea	
🖗 iLen	UINT	4
🖗 nAddr	DWORD	131072
🕸 sType	T_MaxString	'Nic'
🗇 sName	T_MaxString	'st'
nDevType	DWORD	141072
🖃 🍫 stMDP_ModuleContent	ST_MDP_NIC_Prope	
🛊 iLen	UINT	8
sMACAddress	T_MaxString	'00:01:05:5f:0f:7a'
😻 sIPAddress	T_MaxString	'169.254.123.15'
😻 sSubnetMask	T_MaxString	'255.255.0.0'
bdhcp	BOOL	TRUE
iReserved	BYTE	0

Fig. 26: Content of the MDP module with IP and MAC address.

## 8.3 Virtual Ethernet interface

The virtual Ethernet interface integrates network adapters into the TwinCAT system. This makes it possible to establish a virtual Ethernet communication via ADS, TCP or UDP to a BK9xx0. Do not use more than two BK9xx0 and a cycle time > 50 ms.



Fig. 27: Virtual Ethernet communication via ADS, TCP or UDP.

#### Proceed as follows:

1. In the tree view on the left, right-click on Devices.



- 2. Click on Add New Item and select the Virtual Ethernet Interface.
- The Virtual Ethernet Interface is created in the tree view on the left. The ADS port number can be read out under the ADS tab. The Enable ADS Communication option must be active so that ADS communication to the BK9xx0 is possible.

Solution Explorer 🔹 👎 🗙	CX7000 ↔ ×					•
○ ○ 습 🛱 - Ĭo - @ 🗡 🗕	General ADS					
Search Solution Explorer (Ctrl+;)         P +           Solution 'CX7000' (1 project)            Image: CX7000         CX7000           Image: System         Image: CX7000	Enable ADS	Communication	<b>Port:</b> Max Timeout:	28673 (0x7001) 0 \$	Change S	
<ul> <li>✓ (V)</li> <li>✓ Devices</li> <li>✓ Device 2 (CX7000)</li> <li>✓ Device 1 (Virtual-Ethernet)</li> <li>✓ Image</li> <li>✓ Inputs</li> <li>✓ Box 2 (BK9000)</li> <li>✓ Inputs</li> <li>✓ Outputs</li> <li>✓ Inputs</li> <li>✓ Outputs</li> <li>✓ Term 2 (KL1104)</li> <li>✓ Term 3 (KL2809)</li> </ul>						
End Term (KL9010)	Number	Box Name Box 2 (BK9000)	Address 0.0.0.0	s Type BK9000	In Size 8.0	Out Size 2.0
Solution Explorer Team Explorer						

## 8.4 CoE access to multi-function I/Os

The FB\_EcCoeSdoReadEx function block allows data to be read from an object directory of an EtherCAT slave via SDO data (Service Data Object). The nSubIndex and nIndex parameters allow the object that is to be read to be selected. Via bCompleteAccess := TRUE the parameter can be read with subelements.

Sample: Read the firmware version of the multi-function I/Os.

```
VAR
AMSNetID AT %I*:T_AmsNetIdArr;
Port AT %I*:T_AmsPort;
FB_EcCoESdoReadEx: FB_EcCoESdoReadEx;
FirmwareVersion: STRING;
END_VAR
```

The AmsNetId and port number are required for communication with the CX7028 interface. The inputs of the function block FB\_EcCoeSdoReadEx can be linked with the input variables netId and port under TwinCAT, so that the function block is permanently connected to the CX7028 interface.





Fig. 28: CoE access to multi-function I/Os, input variables "netId" and "port" under TwinCAT.

The input sNetId of the function block corresponds to the input netId under TwinCAT. The function block requests a string and the link returns a byte array. You can convert the byte array to a string using the F CreateAmsNetId function. The input nSlaveAddr corresponds to the input port under TwinCAT.

```
FB_EcCoESdoReadEx(
sNetId:=F_CreateAmsNetId(nIds:=AMSNetID), (* AmsNetId of the CX7028 Interface *)
nSlaveAddr:=Port, (* Port Number(nSlaveAddr): 0x1000 *)
nSubIndex:=,
nIndex:=16#100A, (* Index Number *)
pDstBuf:=ADR(FirmwareVersion),
cbBufLen:=SIZEOF(FirmwareVersion),
bExecute:=TRUE,
tTimeout:=,
bCompleteAccess:=,
bBusy=>,
bError=>,
nErrId=>);
```

The index number for the CoE object **Software version** is located under the CoE Online tab.

CX7000 - TcXaeShell File Edit View Project Build Debug TwinCAT Tw	inSAFE PLC	V 🗗 Qui Team Scope Tools Window	ck Launch (Ctrl- / Help	+Q) P	- = ×
8 · · · · · · · · · · · · · · · · · · ·	Debug	TwinCAT OS (ARMT2)	Attach +		- 🏓 🚆
Build (Loaded) 🝷 🚽 🔛 🧧 🖉 🔨 🍥 🙋	🐾 🔏 🛛 CX7000	) - BTN-000f8	9fa 🔹 :	Untitled1	• ÷
Solution Explorer 👻 🕂 🗙	CX7000 ↔ ×				Ŧ
◎ ● 🔂 📇 -   To - @   🔑 💻	General Proce	ss Data Slots Startup CoE - Online	Online ADS		
Search Solution Explorer (Ctrl+;)					
Solution 'CX7000' (1 project)	Update	e List 🔄 Auto Update 🗹 S	iingle Update	Show Offline Data	
A 📑 CX7000	Advand	ced			
SYSTEM	Add to St	artup Online Data	Module OD (A	DE Port): 0	]
MOTION	100 March 100 Ma			1222281	-
	Index	Name	Flags	Value	^
C SAFETY	1000	Device type	RO	0x00001389 (5001)	
1964 C++	1008	Device name	RO	CX7028	
ANALYTICS	1009	Hardware version	RO	00	
▲ 🔀 I/O	100A	Software version	RO	02 <beta 11=""></beta>	
▲ The Devices	100B	Bootloader version	RO	M0.1.29.0	
Device 2 (CX7000)		Restore default parameters	RO	>1<	
📲 Image	± 1018:0	Identity	RO	>4<	
Inputs	± 10F0:0	Backup parameter handling	RO	>1<	
Outputs	± 10F3:0	Diagnosis History	RO	>21 <	
InfoData	101-8	Timestamp Object	RO	0x125ad01e40	
🔺 📙 Term 1 (CX7028)	± 1600:0	DIO_2x RxPDO-Map Outputs Ch.1	RO	>11<	_
DEV Inputs Device	+ 1610:0	DIO_2x RxPDO-Map Outputs Ch.2	RO		
Module 3 (PWM_DI_2x)	± 1620:0	PWM_DI_2x RxPDO-Map Ch.1	RO	>2<	*
PWM_DI_2x Inputs Channel 1	<				>
PWM_DI_2x Inputs Channel 2					
Solution Explorer Team Explorer	Name	Online Tvn	e Size	>Addr In/O	ut User II
C Ready				↑ Add to Source (	Control 🔺 🔡

Fig. 29: CoE communication, listing of CoE objects with matching index number.

With the FB\_EcCoeSdoWriteEx function block an object from the object directory of an EtherCAT slave can be written by SDO-Download. Pay attention to whether the object can be accessed for reading; this is displayed in the Flags column. The nSubIndex and nIndex parameters allow the object that is to be written to be selected. Via bCompleteAccess := TRUE the parameter can be written with subelements.

## 8.5 **Power supply terminal**

EtherCAT Terminals (E-bus) or Bus Terminals (K-bus) can optionally be connected directly on the right-hand side; the CX7000 automatically recognizes which system is connected during the start-up phase.

#### K-bus interface

The CX7000 reads out the terminal types during scanning and creates them in the System Manager under a Bus Coupler.

CX7000 - TcXaeShell File Edit View Project Build Debug Twi ○ - ○   韓 - 曾 - 曾 ■ ■ ↓ 日 合	✓     ✓     Quick Launch (Ctrl+Q)     ✓       inCAT     TwinSAFE     PLC     Team     Scope     Tools     Window     Help       ♡     -       Release     •     TwinCAT OS (ARMT2)     •     ▶     Attach • "	×
Build (Loaded) - Review of the second	Image: CX7000       BTN-000f89fa         Image: Device 1 (CX-BK)       Id: 1         iject Id:       0x03010010         pe:       CX Terminal Device         mment:       Image: CX Terminal Device         Image: Disabled       Create symbols Image: Create symbols	
Figure 4 (KL2012)	Add to Source	Control

Fig. 30: K-bus interface of a CX7000 in the TwinCAT System Manager.

For K-bus diagnostics there is a status variable in TwinCAT under the Bus Coupler, which can be used for diagnostic purposes and indicates the status of the K-bus communication. For more information, refer to the chapter "Error handling and diagnostics" at <u>K-bus [▶ 100]</u>.

#### E-bus interface

#### Distributed clocks

The Embedded PCs of the CX7000 series are not suitable for the use of EtherCAT slaves that use distributed clocks or require them.

The operation of EtherCAT Terminals and EtherCAT devices is also possible at CX7000. The CX7000 also recognizes these terminals automatically during scanning, reads out the terminal types and creates them in the System Manager under an EtherCAT Coupler.

CX7000 - TcXaeShell File Edit View Project Build Debug	TwinCAT TwinSAF	E PLC Team Scope lease TwinCAT OS ( S CX7000	Quick Launch (Ctrl+Q)	- • ×
Solution Explorer	CX7000 + × General Adapter Eth Network Adapter Description: Device Name:	erCAT Online CoE - Online	DPRAM	^
<ul> <li>Image</li> <li>Image-Info</li> <li>SyncUnits</li> <li>Inputs</li> <li>Outputs</li> <li>InfoData</li> <li>Iferm 1 (EK1200)</li> <li>Image-Info</li> </ul>	Address: MAC Address: IP Address:	0x20000000 00 01 05 5f 8f 6d 0.0.0.0 (0.0.0) Promiscuous Mode (use with Virtual Device Names	Search Compatible Devices th Wireshark only)	
Ferm 4 (EL1008)     Ferm 5 (EL1008)     Ferm 5 (EL2008)     Solution Explorer     Team Explorer     Ready	Adapter Referen	ce	✓ Add to Sou	rce Control 🔺 🔐

Fig. 31: E-bus interface of a CX7000 in the TwinCAT System Manager.

For more information on diagnostics, refer to the chapter "Error handling and diagnostics" at E-bus [> 103].

## 8.6 Cycle and processing times

### 8.6.1 Measuring processing time in the PLC program

This sample shows you how to determine the processing time of a program code with the help of a small PLC program. This allows you to measure, for example, how long the PLC needs for a mathematical function, a loop or a specific program part. The resolution is 1 ns per digit.

#### Sample

```
VAR
MeasureStart : T_DCTIME64;
MeasureResult : T_DCTIME64;
END_VAR
```

PROGRAM:

```
MeasureStart:=F_GetActualDcTime64(); (*Insert your program code to measure the processing time*)
MeasureResult:=F_GetActualDcTime64()-MeasureStart;
```

#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT v3.1.0	PC or CX (x86, x64, ARM)	Tc2_EtherCAT

### 8.6.2 Real-Time Clock (RTC)

The CX7000 has an internal, capacitor-buffered real-time clock (RTC) for time and date, which continues to run in the switched-off state. The capacitance of the capacitor is sufficient for at least 30 days and, unlike a battery-backed solution, is maintenance-free. The time is lost and must be reset if the CX7000 is turned off for more than 30 days

The following settings are possible in the boot.conf file:

- SNTP Server
- Update time (default = 1 hour)
- · Change UTC Offset
- DHCP server

#### Sample

The sample below shows you how to read the time. In the sample, the time is output as UTC time and one hour is added to get the CET time.

```
VAR
                        : FB_LocalSystemTime;
: DATE_AND_TIME;
    FB LocalSvstemTime
    DATEANDTIME
    DATEANDTIME_Add1h : DATE_AND_TIME;
END VAR
PROGRAM:
FB LocalSystemTime(
       sNetID:= ,
       bEnable:=TRUE ,
       dwCycle:= ,
        dwOpt:= ,
        tTimeout:= ,
        bValid=> ,
        systemTime=> ,
        tzID=> );
DATEANDTIME:=SYSTEMTIME TO DT(TIMESTR:=FB LocalSystemTime.systemTime); (*UTC Time*)
DATEANDTIME_Add1h:=DATEANDTIME+T#1H; (*UTC Time + 1h*)
```

#### Requirements

Development environment	Target platform	PLC libraries to be integrated (category group)
TwinCAT v3.1.0	PC or CX (WES7/Win7/Win10: TC RT x86/x64, WEC6/7: TC RT x86, WEC7: TC CE7 ARMV7, TC/BSD: TC RT x64, TC OS ARMT2)	Tc2_Utilities (System)

### 8.6.3 I/O Idle Task:

The I/O Idle Task executes the asynchronous mappings and is also responsible for acyclic communication with the EtherCAT devices (e.g. writing parameters).

#### Recommended setting for the I/O Idle Task

By default, the I/O Idle Task is set to 1 ms for TwinCAT controllers. This standard setting has no effect on high-performance control systems and can be ignored. In a small controller such as the CX70xx, however, the default setting of 1 ms leads to a higher basic load. Therefore, proceed as follows:

- first set the I/O Idle Task to 10 ms
- the I/O Idle Task is always placed at the end of the priority list.

ettings	Online	Priorities	C++ Debugger		
Priority	Cycle	Core	Task	Comment	^
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
iii 12	10.0		PlcTask		
13					
14					
15	10.0	0	I/O Idle Task		
16					
17					
18					
19					¥

Fig. 32: Setting for the I/O Idle Task in TwinCAT 3 Engineering.

#### Cycle timeout of the I/O Idle Task

A cycle timeout of the I/O Idle Task can also be neglected unless the I/O Idle Task continuously counts up. In this case, attempts should be made to slow down acyclic communication, query less data, and reduce the number of acyclic communications.

### 8.6.4 Use NTP provider

An NTP provider is available on the CX70xx from image version 140501 or higher.

The NTP provider can be used on different CX70xx Embedded PCs to provide approximately the same time. There is typically a deviation of ±5 ms between two CX70xxs.

Further information on how to insert the NTP provider into TwinCAT as a TcCOM module and put it into operation can be found here: <u>https://infosys.beckhoff.com/english.php?content=../content/1033/</u>tc3\_grundlagen/6326712203.html&id=

#### Example program for using the NTP provider

https://infosys.beckhoff.com/content/1033/CX7000/Resources/16683737611.zip

#### Variable declaration in the ST editor

```
PROGRAM TimeSync
VAR
(*
Time format:
                                     begin 1.1.1601
FileTime64
                   8 Byte len
                                                        Bit/100ns
DCTime64
                   8 Byte len
                                     begin 1.1.2000
                                                        Bit/100ns
*)
    Test FileTime64:T FILETIME64;
                                     (* not used only to see where
                                        this time begin to see the different *)
    Test DCTime64:T DCTIME64;
                                       (* not used only to see where
                                        this time begin to see the different *)
    nLocalTime : T_FILETIME64;
nPLC_DC_TASKTime : T_FILETIME64;
                                                  // Filetime 64 - Local RTOS Time
(* Filetime 64 - Local DC Time | Local DC Time =
                                                   System Time see DiffSysTimeToPLCDCTime *)
    nSysTime AT %I*
                            : T FILETIME64;
                                                  // Filetime 64 - Sytem Time
    nExtTime AT %I* : T_FILETIME64;
nSysToExtTimeOffset AT %I* :LINT,
nSysToExtTimeDeviation
                                                  // Filetime 64 - TCNet Ext NTP Time
                                     :LINT;
                                                  // Offset this is the offset from ExtTime to SysTime
    nSysToExtTimeDeviation AT %I*
                                        :LINT;
                                                   (* Only for Info: Diff from NTP to the NPT Filter
                                                   time is it < 1ms then is bIsSynchronized = TRUE *)
    blsConnected AT %I*:BOOL;
                                           // Connection to the NTP Server
    bIsSynchronized AT %I*:BOOL;
                                          // see nSysToExtTimeDeviation
    FB LocalSystemTime: FB LocalSystemTime;
                                                      // Functionblock for read the local RTOS Time
                                  // Time & data - local RTOS Time
    dt LocalTime: DT;
    dt PLC DC TASKTime: DT;
                                 (* Time & data - This is the time from the TaskInfo Array, this
                                   is the same time as the Sytem Time from the NTP Object *)
    dt nSysTime: DT;
                                  // Time & data - Sytem Time from the NTP Object
                                  // Time & data - NTP Object Ext NTP Time
    dt_nExtTime: DT;
    PlcTaskSystemInfo
                                       : PlcTaskSystemInfo; // Task Info
    DiffSysTimeToPLCDCTime: LINT;
                                               // Local DC Time = System Time
    DiffLocalTimeToExtTime: LINT;
                                                (* local Time - ExtTime = same time like
                                                the nSysToExtTimeOffset Time *)
                                               // FB to get Sec/min/Hour... from a DCTime64
// Format DCTime64 from nExtTime
    FB EcDcTimeCtrl64 1:FB EcDcTimeCtrl64;
    nExtTime64: ULINT;
    sec_1: WORD;
                                                // nExtTime Sec
    Min 1: WORD;
                                                // nExtTime Min
   msec_1: WORD;
                                               // nExtTime mSec
    nLocalTimeDC64: ULINT;
                                               // DCtime64 - from local filetime64
    MaxPLCTime: UDINT;
                                        // Offest Time in LREAL [ms]
    lrTimeoffset: LREAL;
    lrTimeDeviation: LREAL;
                                        (* Deviation Time [ms] this time show you the diff to the
                                         NTP filter time, if its <1ms the is bIsSynchronized = TRUE *)
    FB CX7000 LED WD: FB CX7000 LED WD;
                                            // NPT Status via WD LED from CX7000
```

END\_VAR

#### Program in the ST editor

MaxPLCTime:=MAX(PlcTaskSystemInfo.LastExecTime,MaxPLCTime);

lrTimeoffset:=LINT\_TO\_LREAL(nSysToExtTimeOffset)/1000/10; // Read NTP Offset Time and convert it to
Real in [ms]

```
lrTimeDeviation:=LINT TO LREAL(nSysToExtTimeDeviation)/1000/10; // Read NTP Offset Time and convert
it to Real in [ms]
// Read the local time from RTOS
FB LocalSystemTime(
    sNetID:= ,
    bEnable:=TRUE ,
    dwCycle:= ,
    dwOpt:= ,
    tTimeout:= ,
    bValid=>
    systemTime=> ,
    tzID=> );
dt LocalTime:=SystemTime TO DT(FB LocalSystemTime.systemTime);
nLocalTime:=SystemTime TO Filetime64(FB LocalSystemTime.systemTime);
dt nSysTime:=Filetime64 TO DT(nSysTime);
                                              // Convert nSysTime to date & time
dt nExtTime:=Filetime64 TO DT(nExtTime);
                                              // Convert nExtTime to date & time
DiffSysTimeToPLCDCTime:=ULINT TO LINT(nPLC DC TASKTime-nSysTime);
                                                                            // Must be 0 because
SysTime = Local DC Time
DiffLocalTimeToExtTime:=ULINT TO LINT(nExtTime-nPLC DC TASKTime);
                                                                            // Same diff like
nSysToExtTimeOffset
// Ext NTP object as trigger for Outputs
nExtTime64:=FILETIME64 TO DCTIME64(nExtTime);
FB_EcDcTimeCtrl64_1.A_GetMilli (in:=nExtTime64,get=>msec_1);
FB_EcDcTimeCtrl64_1.A_GetSecond (in:=nExtTime64,get=>sec_1);
FB_EcDcTimeCtrl64_1.A_GetMinute (in:=nExtTime64,get=>Min_1);
// Toggle Outpt every Sec
IF (sec 1 MOD 2) =0 THEN
    gvl.bCX7028_Out_4:=TRUE;
ELSE
    gvl.bCX7028 Out 4:=FALSE;
END IF
// Set DO NTP Status
gvl.bCX7028 Out 1:=bIsConnected;
gvl.bCX7028 Out 2:=bIsSynchronized;
// WD LED from CX7000
// Red - no connection
// Green flashing - it is connected to NTP Server but it is not sync (that means that the filter is
active and the synchonsation to the NTP Server is running - not with TC!)
// Green on - connection and synchonsation is running
FB CX7000 LED WD(
   bEnable:=TRUE
    eLED:=
    tFlashingTimeP1:= ,
    tFlashingTimeP2:= ,
    bError=> ,
    nErrorID=> );
IF blsConnected AND NOT blsSynchronized THEN
    FB CX7000 LED WD.eLED :=Tc2 SystemCX.E CX7000 LED.LED flashing GREEN OFF;
ELSIF bisConnected AND bisSynchronized THEN
   FB_CX7000_LED_WD.eLED :=Tc2_SystemCX.E_CX7000_LED.LED_GREEN ;
ELSE
    FB_CX7000_LED_WD.eLED :=Tc2_SystemCX.E_CX7000_LED.LED_RED ;
END IF
```

## 8.6.5 Cycle time of 250 µs

Note that a cycle time of 250  $\mu$ s on a CX7000 represents an extreme optimum and all boundary conditions must be right. Furthermore, a cycle time of 250  $\mu$ s only makes sense if the inputs and outputs are correspondingly fast.

The CX7000 has different interfaces, including, for example, the K-bus. The K-bus can achieve perhaps 1 ms under optimal conditions and is therefore unsuitable for cycle times of 250  $\mu$ s. The E-bus (EtherCAT) is much faster, but the structure of an EtherCAT frame and the merging of the data into an EtherCAT frame is much more complex, so that only 1 ms is possible here as well.

Of course, EtherCAT can be operated with other Industrial PCs under 100 µs. However, these are usually equipped with more powerful CPUs and may use a DMA controller for EtherCAT processing. That is not the case with the CX7000, however, so the CPU power and the interfaces to EtherCAT are the limiting factors. Of course, the CX7000 as a small controller was not developed for high-speed applications and, due to its cost-efficiency, should not be compared to more powerful Industrial PCs.

#### Setting a cycle time of 250 µs

A cycle time of 250  $\mu$ s is possible on a CX7000 if the boundary conditions are right. The CX7000 is helped by the multifunction I/Os, which are connected to the CPU via a fast IO connection. The connection is kept very lean and has a correspondingly good data throughput. It is possible to reach the 250  $\mu$ s with the help of the multifunction I/Os. Of course, the PLC program may contain only very little code and the core limit must be set to 90%, which in turn results in the described disadvantages (see: <u>Real-time and CPU load [ $\blacktriangleright$  107]).</u>

COLE						
Core	RT-	Core	Base Time	Core Limit		Latency Warning
Availa Share	able Cores d / Isolated:	1 🔹 0	Read f	rom Target	Set on Target	
Route Config Alloca	er Memory gured Size [MB]: ated / Available:	4 9 / 8	Global T Maximal	ask Config Stack Size [KB]	64KB ~	
	Offine Thomas	s C++ Debugger				

In addition, you should set the priority of the task so that the 250  $\mu s$  task has the highest priority in the system.



If you now allow a digital output of the CX7028 interface to toggle, for example with  $Out_01:=not Out_01$  in the 250 µs task, the task is output at a frequency of 2 kHz. In order for the output to be optimally fast, this output should have a load. Only wire the output with a digital input; as a result, the load is very small and the switch-off behavior of the driver is relatively slow. Slow here means in relation to the 250 µs task time. It makes a difference whether the output requires 50 µs or 100 µs to switch off. If you now wish to measure the response time, i.e. the time it takes for the CX7000 to react to an input, the following background is important:

From a cycle time of 1 ms or greater, an optimal cycle is operated, i.e. the inputs of the CX7028 interface are read by the processor of the CX7028 interface about 20% before the new task cycle. If the task time is faster than 1 ms, the time is not sufficient for the optimized response time. In this case the inputs are read with the task cycle. As a result, a task time of 500  $\mu$ s achieves the same response time as a task time of 1 ms. With a task time of less than 1 ms, the update needs four task cycles for a cycle. With 1 ms or slower it needs two task cycles. This should make you aware that it is not always the shortening of the cycle time that shortens the reaction time, but also the internal process, which plays a decisive role in the reading of the data.

Here is a sample, so that you can reproduce this behavior yourself and see and measure the differences:

- 1. Connect the +24 V Up and 0 V Up power supply to power the multifunction I/Os.
- 2. Connect output 1 to input 1 to toggle the output as described.
- 3. Connect output 2 to input 2.
- 4. Set the core limit to 90%, the base time to 250 μs, the priority of the fast task to the highest priority, and the idle task to 10 ms.

The inputs have only a minimal filter time and are therefore well suited for the measurement. A load on the output is not necessary in this case. For the following samples, we always leave the base time at 250 µs and only increase the number of cycle ticks in order to set the corresponding task time.

Name:	PlcTask		Port:	350
Auto start			Object Id:	0x02010030
Auto Priori	ty Management	t	Options	
Priority:	8	-	Disable	
Cycle ticks:	4 🜩	1.000 ms	Create s	symbols
Start tick (	(modulo):	0 ≑		ude external symbols
Separa	ate input update	e		
Pre	e ticks:	0 ‡		
Warning b	y exceeding			
Messa	ge box			and an and the set
Watehdag Cu	olog:	0		point exceptions
watchuog cy	CIES.	•	Watchd	log stack

#### Sample program

```
PROGRAM MAIN
VAR
   bOut 1 AT %Q*:BOOL; (*toggle Output link to digital Output pin 7*)
   bOut 2 AT %Q*:BOOL; (*reaction time link to digital Output pin 14*)
    bIn 1 AT %I*: BOOL; (*toggle Output link to digital Input pin 2*)
   bIn 2 AT %I*: BOOL; (*reaction time link to digital Input pin 10*)
   fbTimer : TON;
    fbflanke1 : R TRIG;
   fbflanke2 : R TRIG;
   cnt1: INT; (*toggle Output*)
   cnt1 M: INT; (*toggle Output*)
   cnt2: INT; (*reaction time*)
   cnt2_M: INT; (*reaction time*)
END VAR
PROGRAM MAIN
bOut_1:= NOT bOut_1; (*toggle Output*)
bOut 2:= NOT bIn 2; (*reaction time*)
fbflanke1(CLK:=bIn_1);
IF fbflanke1.Q THEN
   cnt1:=cnt1+1; (*toggle Output*)
END IF
fbflanke2(CLK:=bIn 2);
IF fbflanke2.Q THEN
   cnt2:=cnt2+1; (*reaction time*)
END IF
fbTimer(PT:=T#1S,in:=NOT fbTimer.Q);
IF fbTimer.Q THEN
   cnt2_M:=cnt2; (*reaction time*)
    cnt1_M:=cnt1; (*toggle Output*)
    cnt1:=0;
    cnt2:=0;
END IF
```

The toggling of the output results in a frequency of 2 kHz – 250  $\mu$ s On, 250  $\mu$ s Off – i.e. a period duration of 500  $\mu$ s. When measuring the positive edge, this is 2000 edge changes in one second.



bOut_1	BOOL	TRUE
bOut_2	BOOL	TRUE
< bIn_1	BOOL	FALSE
< bIn_2	BOOL	FALSE
🛙 < fbTimer	TON	
🛙 < fbflanke1	R_TRIG	
🛙 < fbflanke2	R_TRIG	
cnt1	INT	1014
cnt1_M	INT	2000
cnt2	INT	253
cnt2_M	INT	500

Fig. 33: Measurement at a task time of 250  $\mu$ s.

In the case of the response time, it is 500 changes in one second, as the optimized access to the inputs does not apply here.

	bOut_1	BOOL	TRUE
	bOut_2	BOOL	TRUE
	<pre> bIn_1 </pre>	BOOL	TRUE
	bIn_2	BOOL	FALSE
Ŧ	fbTimer	TON	
Ð	ø fbflanke1	R_TRIG	
Ŧ	fbflanke2	R_TRIG	
	cnt1	INT	68
	<pre> cnt1_M </pre>	INT	1001
	cnt2	INT	17
	cnt2_M	INT	250

Fig. 34: Measurement at a task time of 500  $\mu$ s.

As expected, the values are only half as large with a task time that is twice as long.

	\$	bOut_1	BOOL	FALSE
	\$	bOut_2	BOOL	TRUE
	\$	bIn_1	BOOL	FALSE
	ø	bIn_2	BOOL	FALSE
E	ø	fbTimer	TON	
E	ø	fbflanke1	R_TRIG	
$\blacksquare$	ø	fbflanke2	R_TRIG	
	\$	cnt1	INT	169
	\$	cnt1_M	INT	501
	ø	cnt2	INT	84
	ø	cnt2_M	INT	251

Fig. 35: Measurement at a task time of 1 ms.

With a task time of 1 ms, you can clearly see that the optimized mode actually helps to reduce the response time. While the toggle change has halved again, i.e. it is now still 500 Hz with a task time of 1 ms, the value for the response time has remained the same.

### 8.6.5.1 Cycle time ≥1 ms

Fig. 36: CX7000 CPU and PLC.

Yellow and red: Mapping and update of the IOs. Light grey: Time remaining until the task begins again (OS). Dark grey: PLC cycle.



Fig. 37: CPU of the CX7028 interface.

Red: Output update.

Grey: CPU processing of the multifunction IOs.

**Yellow:** Input update (from a cycle time of 1 ms there is a waiting period of up to approx. 80% of the cycle time before the update of the input signals so that the inputs are read as late as possible, i.e. before the next cycle).



#### 8.6.5.2 Cycle time < 1 ms

From a cycle time of < 1 ms, the update of the input signals is carried out immediately and is therefore only available with the next cycle. The input signals are therefore always one cycle old.



With this background knowledge, you should be able to make the right settings on the CX7000 for your application.

## 8.7 Function Blocks

### 8.7.1 FB\_CX7000\_LED\_ERR

FB_CX7000_LE	D_ERR	
 eLED E_CX7000_LED	BOOL bError	_
 tFlashingTimeP1 TIME	DINT nErrorID	_
 tFlashingTimeP2 TIME		

The function block allows the use of the ERR LED on the CX7000. The function block is immediately active when it is called and controls the ERR LED via the mode.

The ERR LED of the CX7000 can be used to make the states of the PLC program, communication or other indications externally visible.

The ERR LED has two colors, red and green. If both colors are switched on, the LED lights up yellow. You can either turn the LED on or make it flash.



User-specific function of the LEDs

Due to the user-specific usability of the LEDs, Beckhoff Support cannot know the meaning of a flashing code and cannot support the customer.

• Document the function of the LEDs for your customers.

#### 🐔 Inputs

VAR	INPUT			
	bEnable	: BOOL;	//	set TRUE to enable LED handling; Reset in order to re
set	error			
	eLED	: E CX7000 LED;	11	LED flashing mode
	tFlashingTimeP1	: TIME:=T#250MS;	11	Flashing Time >=200ms first pulse
	tFlashingTimeP2	: TIME:=T#250MS;	11	Flashing Time >=200ms second pulse
END	VAR			

Name	ТҮРЕ	Description
bEnable	BOOL	The function block controls the LED as soon as and as long as the input is TRUE.
eLED	E_CX7000_LED	LED mode
tFlashingTimeP1	TIME	Time for the first pulse (>= 200 ms)
tFlashingTimeP2	TIME	Time for the second pulse (>= 200 ms)

#### Outputs

```
VAR_OUTPUT
bError : BOOL; // error flag
nErrorID : UDINT; (* ADS Error ID. If nErrorID=DEVICE_SRVNOTSUPP probably the image
version need to be updated to support this feature. *)
END_VAR
```

Name	Туре	Description
bError	BOOL	The function block has an error.
nErrorID	UDINT	ADS Error Code Example:
		DEVICE_SRVNOTSUPP: the image version of the CX7000 does not support this feature. An update (>=35695) is necessary.

#### Sample:

```
VAR
BK9000_BoxState AT %I* : WORD;
fbErrorLED : FB_CX7000_LED_ERR;
END VAR
```

```
BECKHOFF
```

```
IF BK9000_BoxState=0 THEN
fbErrorLED.eLED :=E_CX7000_LED.LED_flashing_GREEN_OFF;
ELSE
fbErrorLED.eLED :=E_CX7000_LED.LED_flashing_RED_OFF;
END_IF
fbErrorLED(
    bEnable := TRUE,
    tFlashingTimeP1 := ,
    tFlashingTimeP2 := ,
    bError => ,
    nErrorID => );
```

#### NOTICE

#### Function block can only be used for CX7000

The function block can and must only be used for the CX7000.

### 8.7.2 FB\_CX7000\_LED\_WD

	FE	3_CX7000_I	LED_WD	
	eLED	1ED	BOOL bError	_
	tFlashingTimeP1	TIME	DINT nErrorID	_
_	tFlashingTimeP2	TIME		

The function block allows the use of the WD LED on the CX7000. The function block is immediately active with the call and controls the WD LED via the mode.

You can use the WD LED of the CX7000 to make the states of the PLC program, communication or other indications externally visible. The WD LED has two colors, red and green. If both colors are switched on, the LED lights up yellow. You can turn on the LED and/or make it flash.



#### User-specific function of the LEDs

Due to the user-specific usability of the LEDs, Beckhoff Support cannot know the meaning of a flashing code and cannot support the customer.

• Document the function of the LEDs for your customers.

*	Inputs		
VAR_	_INPUT bEnable	: BOOL;	<pre>// set TRUE to enable LED handling; Reset in order to re</pre>
set	error eLED tFlashingTimeP1 tFlashingTimeP2	: E_CX7000_LED; : TIME:=T#250MS; : TIME:=T#250MS;	// LED flashing mode // Flashing Time >=200ms first pulse // Flashing Time >=200ms second pulse
END_	VAR		

Name	Туре	Description
bEnable	BOOL	The function block controls the LED as soon as and as long as the input is TRUE.
eLED	E_CX7000_LED	LED mode
tFlashingTimeP1	TIME	Time for the first pulse (>= 200 ms)
tFlashingTimeP2	TIME	Time for the second pulse (>= 200 ms)

#### Outputs

VAR\_OUTPUT bError : BOOL; // error flag nErrorID : UDINT; (\* ADS Error ID. If nErrorID=DEVICE\_SRVNOTSUPP probably the image v ersion need to be updated to support this feature. \*) END\_VAR

Name	Туре	Description
bError	BOOL	The function block has an error.

Name	Туре	Description
nErrorID	UDINT	ADS Error Code Example:
		DEVICE_SRVNOTSUPP: the image version of the CX7000 does not support this feature. An update (>=35695) is necessary.

NOTICE

#### Function block can only be used for CX7000

The function block can and must only be used for the CX7000.

### 8.7.3 FB\_CX70xx\_RW\_EEPROM

	FB_CX70xx_RW_EE	PROM
_	bExecute BOOL	BOOL bBusy -
_	eMode E_CX70xx_EEPROM_Mode	BOOL bError
_	pSrcBuf PVOID	UDINT nErrorID
_	cbSrcBufSize UINT	UINT nDataSizeEEPROM
_	pDstBuf PVOID	UINT nWritesCycles
_	cbDstBufSize UINT	

The function block allows a maximum of 120 bytes to be written to the EEPROM (hardware) of the CX70xx. The EEPROM may be written to a maximum of 200 times. The memory is intended for one-time writing.

This function block can be used to personalize the CX70xx. That means, in the simplest case you write your company ID into the EEPROM. When starting the CX70xx program, read the contents of the memory. For example, if it is empty, you cannot continue to run the program because it is no longer your original CX70xx that you programmed.

If you want to exchange a CX70xx for a new device, the EEPROM must be written again by you.

*	Inputs	
VAR_	INPUT	
	bExecute	: BOOL; // rising edge triggers process with selected mode
	eMode	: E_CX70xx_EEPROM_Mode; // select RW mode
	pSrcBuf	: PVOID; // pointer to WRITE EEPROM data buffer
	cbSrcBufSize	: UINT; // size of WRITE EEPROM data buffer (max.120 Bytes)
	pDstBuf	: PVOID; // pointer to READ EEPROM data buffer
	cbDstBufSize	: UINT; // max.size of READ EEPROM data buffer (max.120 Bytes)
END_	VAR	

Name	Туре	Description
bExecute	BOOL	A positive edge starts the function block.
eMode	E_CX70xx_ EEPROM_M ode	ReadOnly: EEPROM read WriteOnly: EEPROM write WriteAndRead: EEPROM write and read
pSrcBuf	PVOID	Pointer to the data buffer to be written.
cbSrcBufLen	UINT	Length of data to be written (max. 120 bytes)
pDstBuf	PVOID	Pointer to the data buffer into which the contents of the EEPROM are to be copied.
cbDstBufLen	UINT	Length of data to be read. (maximum 120 bytes) When reading, the length information must be greater than or equal to the data contained in the EEPROM.



VAR	OUTPUT				
	bBusy	:	BOOL;	11	FB is working
	bError	:	BOOL;	11	FB has an Error
	nErrorID	:	UDINT;	(*	Error Code

- If nErrorID=DEVICE INVALIDACCESS the EEPROM write cycles reached max. value.
- If nErrorID=DEVICE\_INVALIDPARM the given pointer parameter is invalid/null.
- If nErrorID=DEVICE\_INVALIDSIZE the given buffer size is too small or too big.
- If nErrorID=DEVICE\_SRVNOTSUPP probably the image version need to be updated to support this feat ure. \*)
- nDataSizeEEPROM : UINT; nWritesCycles : UINT; 0)
- // current size of (read) EEPROM data in bytes (max.120 Bytes)
  // already performed EEPROM write cycles (maximum possible = 20

0) END\_VAR

Name	Туре	Description
bBusy	BOOL	The function block is active and working.
bError	BOOL	The function block has an error.
nErrorID	UDINT	ADS Error Code Examples:
		DEVICE_INVALIDACCESS: the EEPROM write cycles have reached the maximum value. The EEPROM cannot be rewritten.
		DEVICE_INVALIDPARM: the allocated pointers are invalid/NULL.
		DEVICE_INVALIDSIZE: the allocated buffer size is too small or too large.
		DEVICE_SRVNOTSUPP: the image version of the CX70xx does not support this feature. An update (>=35695) is necessary.
nDataSizeEEPROM	UINT	Current size in bytes of the read EEPROM data
nWritesCycles	UINT	Number of write operations still available

## 8.7.4 FB\_CX70xx\_ResetOnBoardIO

	FB_CX70xx_	ResetOnBoardIO	
_	bExecute BOOL	BOOL bBusy	-
_	sNetId T_AmsNetID	BOOL bError	┝
_	tTimeout TIME	UDINT nErrorID	┝

The function block allows to execute a reset from the OnBoard I/O of the CX70xx Embedded PC.

Typical use case is after an error in the communication to the OnBoard I/Os (CX7028). Such an error occurs when the power supply (Up) of the OnBoard I/Os is interrupted.

#### NOTICE

#### State of the I/Os

Outputs that are still set in the process image are switched on again immediately after a reset.

Further details on the OnBoard I/O can be found in the documentation of the CX70xx Embedded PC.

*	Inputs	
VAR_	_INPUT bExecute sNetId tTimeout	: BOOL; // rising edge triggers process : T_AmsNetID; // AMS Net ID of the OnBoard IOs : TIME := DEFAULT_ADS_TIMEOUT; // maximum time allowed for execution of this ADS c
omma END_	and _VAR	

Name	Туре	Description
bExecute	BOOL	A positive edge starts the function block.
sNetId	T_AmsNetID	AMS Net ID of the OnBoard I/Os
tTimeout	TIME	States the length of the timeout that may not be exceeded by execution of the ADS command.

### Outputs

```
VAR_OUTPUT
bBusy : BOOL; // FB is working
bError : BOOL; // FB has an Error
nErrorID : UDINT; (* Error Code. If nErrorID=DEVICE_SRVNOTSUPP probably the image versio
n need to be updated to support this feature. *)
END_VAR
```

Name	Туре	Description
bBusy	BOOL	The function block is active and working.
bError	BOOL	The function block has an error.
nErrorID	UDINT	ADS Error Code Examples:
		DEVICE_SRVNOTSUPP: the image version of the CX70xx does not support this feature. An update (>=47912) is necessary.

#### Sample:

```
FUNCTION BLOCK FB Test ResetOnboardIO
VAR
    AMSNetTD
                : T AmsNetIdArr;
                                      // link to the AMS Net ID of the OnBoard IOs
               : WORD; // link
: BOOL; // if R
: FB_CX70xx_ResetOnBoardIO;
    State
                                      // link to the State of the OnBoard IOs
                                      // if Ready to Reset you can reset the OnBoard IOs
    bReset
    fbReset
END VAR
IF State<>8 AND NOT State.8 AND State.4 THEN // if OnBoard IO device signals an error and is not OP
but present
    bReset := TRUE;
ELSE
    bReset := FALSE;
END IF
IF NOT fbReset.bBusy AND bReset THEN
    fbReset(bExecute:=TRUE, sNetId:=F CreateAmsNetId(AMSNetID));
ELSE
    fbReset(bExecute:=FALSE);
END IF
```

## 8.8 Important attribute pragmas

Attribute pragmas are used to influence compilation and pre-compilation. TwinCAT supports a number of predefined attribute pragmas. Attributes are defined in the declaration part.

### 8.8.1 Attribute 'Tc2GvIVarNames'

The pragma has the effect that symbols, which are declared in a GVL, are addressed via ADS just like in TwinCAT 2 (without the use of the GVL name as namespace).

Syntax: {attribute 'Tc2GvIVarNames'}

#### Sample:

```
{attribute 'Tc2GvlVarNames'}
VAR_GLOBAL
Test : INT;
END_VAR
GVL.Test:=GVL.Test+1; (*without attribute*)
Test:=Test+1; (*with attribute*)
```

## 8.8.2 Attribute 'pack\_mode'

This attribute pragma specifies how a data structure is packaged during allocation. The attribute must be inserted above the data structure and affects the packing of the whole structure.

Syntax: {attribute 'pack\_mode' := '<Value>'}

### Sample

In this sample, the pack mode has been set to 0. If you determine the size of the structure in the sample with SIZEOF, you get the value 8.

1 byte + 4 bytes (DINT) + 1 byte + 2 bytes (INT) = 8 bytes

If you set the pack mode to 2 (WordAlignment), you get the value 10 because a padding byte is inserted after each byte. If you set the pack mode to 4 (DWordAlignment), then you get the value 12, because this time three padding bytes are inserted after each byte. A pack mode of 8 (LWordAlignment) does not change anything, because the sample does not use variables that require 8 bytes.

The CX7000 works with the DWordAlignment (pack mode 4) if you do not use the attribute.

For more information about the pack\_mode attribute, see: Attribute 'pack\_mode'

## 8.8.3 Attribute 'TcCallAfterOutputUpdate'

The attribute pragma  ${\tt TcCallAfterOutputUpdate}$  causes the IO update to take place before the PLC cycle and not after the PLC program as is set by default.



Fig. 38: Default calling of a PLC task.



Fig. 39: Calling a PLC task with the attribute tcCallAfterOutputUpdate.

This function can be used for projects with strongly fluctuating cycle times. In projects with strongly fluctuating cycle times, the outputs, since they are written after the PLC cycle, are sometimes written earlier (short PLC cycle time) and sometimes later (long PLC cycle time). These fluctuations cause jitter in the outputs. The disadvantage is that the attribute cannot react quite as quickly and a cycle is always lost. You have to decide whether you want to react quickly to an input (default setting) or whether you prefer to have a deterministic behavior of the outputs (setting of the attribute).

Syntax: {attribute 'TcCallAfterOutputUpdate'}

Insertion location: This attribute must be added to all program POUs, which are to be called after the output update.

#### Sample:

To illustrate the behavior, you need a digital output terminal such as an EL2008 and an oscilloscope.

Write a small PLC program and link the variable bOut with a digital output:

bOut:=not bOut;

The PLC program is very simple and does not cause any fluctuations. The pulse is displayed on the oscilloscope as follows:



Fig. 40: Pulse of a digital output without load.

Now extend the PLC program with a For loop to create a program load. The mathematical function used does not matter and is intended only to generate a load:

Whenever the output is set to TRUE, the loop is run through and a load is generated. As a result, more time is needed to run the PLC and the output is written later than usual. During the next cycle, the output is set back to FALSE, the loop is not run through and the output is set to FALSE faster, because the PLC program is finished faster without a For loop. The result is that the pulse is very much shorter.



Fig. 41: Shortened pulse of a digital output with load.

If the For loop is called upon FALSE instead of TRUE, the result is inverted.

bOut:=not bOut;

```
IF not bOut THEN

For loop:=1 to 2000 do

lrTest:=SIN(INT_TO_LREAL(loop)*3.14);

END_FOR

END_IF

5ns 0.0000s
```



Fig. 42: Inverted representation of a digital output.

With the attribute pragma <code>TcCallAfterOutputUpdate</code>, the pulse is constant and is independent of how long the For loop takes or whether it is called. The whole thing only works if the PLC task is not exceeded. Therefore, when reproducing the sample, pay attention to the exceed counters of the task.

CH1

#### Detecting a PLC program with different runtimes

The PLC program must be supplemented in order to detect PLC programs with different runtimes. Different runtimes are not recognizable in the online view, since an average value is always formed over several cycles. Therefore, outliers can only be detected if they lie above the task time. If the outliers are still within the task time, they are not easily visible.

For this we then use the system variable: PlcTaskSystemInfo

```
VAR
    bOut : BOOL;
    PlcTaskSystemInfo : PlcTaskSystemInfo;
    udiValue : ARRAY[0..19] of UDINT;
    Cnt : INT;
END_VAR
Program:
bOut:=not bOut;
IF bOut THEN
   For loop:=1 to 2000 do
        lrTest:=SIN(INT TO LREAL(loop)*3.14);
    END_FOR
END IF
PlcTaskSystemInfo:=_TaskInfo[1];
udiValue[Cnt]:= PlcTaskSystemInfo.LastExecTime;
cnt:=cnt+1;
IF Cnt >19 THEN
        Cnt:=0;
END IF
```

With this program extension you can see that the PLC program with a For loop requires 7.7 ms and without a For loop 1.1 ms. The specification is 100 ns per digit.

🖃 < 🕸 udiValue	ARRAY [0 19] OF U.	
udiValue[0]	UDINT	77728
udiValue[1]	UDINT	10713
udiValue[2]	UDINT	71049
udiValue[3]	UDINT	11065
<pre>udiValue[4]</pre>	UDINT	69882
udiValue[5]	UDINT	11027
udiValue[6]	UDINT	77084
udiValue[7]	UDINT	11939
udiValue[8]	UDINT	77494
udiValue[9]	UDINT	18527
udiValue[10]	UDINT	76724
udiValue[11]	UDINT	11043
udiValue[12]	UDINT	71519
udiValue[13]	UDINT	11406
udiValue[14]	UDINT	79004
udiValue[15]	UDINT	11118
udiValue[16]	UDINT	70745
🖗 udiValue[17]	UDINT	12007
muliValua[18]	UDINE	77761

Fig. 43: Determination of different running times in the PLC program.

The measurement coincides with the displays on the oscilloscope, on which it can be seen that a pulse is sometimes 6.5 ms longer or 6.5 ms shorter. You can measure the processing time of the For loop (<u>Measuring processing time in the PLC program [ $\triangleright$  81]). The result of this measurement will coincide with the observed values through the program extension, with a certain inaccuracy and jitter.</u>

# 9 Error handling and diagnostics

## 9.1 Diagnostic LEDs

Display	LED	Meaning
т	тс	TwinCAT status LED:
wD		TwinCAT is in Run mode (green). TwinCAT is in Stop mode (red).
ERR		TwinCAT is in Config mode (blue).
•		Error or crash of the PLC (yellow).
		Displays errors at system startup by error code and error argument. The red LED flashes with two different frequencies.
SD	WD	No function. Reserved
	ERR	If only the ERR LED (red) lights up when starting the CX70xx, then the bootloader is damaged and the device must be sent in for repair.

The TC-LED flashes at a specified frequency and in a specified order, thus indicating the error code and argument.

#### Table 17: TC LED, order and meaning.

Sequence	Meaning	
Fast flashing	Starting the sequence	
First slow sequence	Error code	
No display	Pause, the LED is off	
Second slow sequence	Error argument	

Count how many times the red TC LED flashes in order to determine the error code and argument.

Table 18: TC LED, error description and remedy.

Error code	Error argument	Description Remedy		
1	1	microSD card not recognized	Check the microSD card.	
	2	Card init failed - preloader Image is defective. Install a new		
	3	No partition found - preloader	the microSD card.	
	4	Filesystem mount failed - preloader		
	5	Card init failed - loader		
	6	No partition found - loader		
	7	Filesystem mount failed - loader		
2 1		Loader not found		
	2	Loader file invalid (checksum, size, read error)		
	3	TC dll not found		
	4	TC dll checksum error		
	5	EEPROM file missing or invalid		
	6	TcOsSys.dll version not compatible with loader		
3	1	Rbf not found		
	2 CCAT 1 init failed			
	3	CCAT 2 init failed	]	
	4	CCAT EEPROM writing failed		

Error code	Error argument	Description	Remedy
	5	CCAT 1 EEPROM reloaded failed	
	6	CCAT 2 EEPROM reloaded failed	
4	1	Peripheral not working	Hardware defective, replace the CX
	2	Voltage Vo not reached	
	3	Low speed external oscillator not running	
	4	High speed external oscillator not running	
	5	Flash failed	
	6	Device overclocked (old Hardware)	
5	5	RAM error detected	

### 9.1.1 K-bus

The power supply unit checks the connected Bus Terminals for errors. The red LED "K-bus ERR" is off if no error is present. The red LED "K-bus ERR" flashes if Bus Terminal errors are present.

Table	19:	Diagnostic	LEDs in	K-Bus	mode.
-------	-----	------------	---------	-------	-------

Display	LED	Meaning
	Us 24 V	Power supply for basic CPU module. The LED lights green if the power supply is correct.
Cnt / DI1 DI3	Up 24V	Power supply for terminal bus. The LED lights green if the power supply is correct.
DI5 DI6 AI1 / DI7 DI8 / AI2 D01 D02 PWM1 / D03 DI D04 / PWM2	K-BUS RUN	Diagnostic K-bus. The green LED lights up in order to indicate error-free operation. "Error-free" means that the communication with the fieldbus system is also running.
	K-BUS ERR	Diagnostic K-bus. The red LED flashes to indicate an error. The red LED flashes with two different frequencies.

The frequency and number of the flashes can be used to determine the error code and the error argument. An error is indicated by the "K-bus ERR" LED in a particular order.

Table 20: K-bus ERR LED, fault indication sequence through the LED.

Order	Meaning	
Fast flashing	Starting the sequence	
First slow sequence	Error code	
No display	Pause, the LED is off	
Second slow sequence	Error code argument	

Count how often the red LED K-bus ERR flashes, in order to determine the error code and the error argument. In the error argument the number of pulses shows the position of the last Bus Terminal before the error. Passive Bus Terminals, such as a power feed terminal, are not included in the count.

Error code	Error code argu- ment	Description	Remedy
Persistent, continuous flashing		EMC problems.	<ul><li>Check power supply for undervoltage or overvoltage peaks.</li><li>Implement EMC measures.</li></ul>

Error code	Error code argu- ment	Description	Remedy
			• If a K-bus error is present, it can be localized by a restart of the power supply unit (by switching it off and then on again).
3 pulses	0	K-bus command error.	No Bus Terminal inserted.
			<ul> <li>One of the Bus Terminals is defective; halve the number of Bus Terminals attached and check whether the error is still present with the remaining Bus Terminals. Repeat this procedure until the faulty Bus Terminal has been found.</li> </ul>
4 pulses	0	K-bus data error, break behind the power supply unit.	Check whether the Bus End Terminal 9010 is connected.
	n	Break behind Bus Terminal n.	Check whether Bus Terminal n+1 after the power supply unit is connected correctly; replace if necessary.
5 pulses	n	K-bus error in register communication with Bus Terminal n.	Replace Bus Terminal at location n.
6 pulses	0	Error at initialization.	Replace Embedded PC.
	1	Internal data error.	Hardware reset of the Embedded PC (switch off and back on again).
	8	Internal data error.	Hardware reset of the Embedded PC (switch off and back on again).
7 pulses	0	Process data lengths of the set and actual configurations do not correspond.	Check the configuration and the Bus Terminals for consistency.

For some error the LED "K-BUS ERR" does not go out, even if the error was rectified. Switch the power supply for the power supply unit off and back on again to switch off the LED after the error has been rectified.

#### State variable

In TwinCAT there is a State variable under the Bus Coupler for K-bus diagnostics.

CExample - Microsoft Visual Studio	T. SAFE DI	C Task Same I	MC-d 11-1-	
		telease - Twin	CAT RT (x86)	- 100 <u>"</u>
: 🔝 💶 💋 🌮 🔨 🎯 🔍 🖂 🛛 CX-16C2B8	• • •	Unbenannt1	·   -] > =	●◎□雪層で
Solution Explorer 🛛 👻 부 🗙	Example ×			÷
Solution 'Example' (1 project)	Variable Flags	Online		
🖌 📊 Example	Name:	State		
SYSTEM MOTION	Туре:	UINT		
PLC	Group:	Inputs	Size:	2.0
SAFETY	Address:	0 (0x0)	User ID:	0
▲ 🔽 I/O	Linked to			
<ul> <li>Devices</li> <li>Devices</li> <li>Trage</li> <li>Box 1 (CX-BK)</li> <li>Inputs</li> <li>State</li> <li>Outputs</li> <li>Term 2 (KL2012)</li> </ul>	Comment:	Bit 0 = K-Bus Err Bit 1 = Terminal State Bit 2 = Process Data L Bit 8 = No valid Inputs Bit 9 = K-Bus Input Up Bit 10 = K-Bus Output Bit 11 = Watchdog Err Bit 15 = Acyc. Function	Err Length Err date busy Update busy n atcive (e.g. K-Bus Re	set)
<ul> <li>Term 3 (KL4032)</li> <li>Term 4 (KL3102)</li> <li>End Term (KL9010)</li> </ul>	ADS Info:	Port: 300, IGrp: 0x900	3, IOffs: 0x0, Len: 2	
<ul> <li>◄ -œ Device 4 (USB)</li> <li>▲ Image</li> <li>➡ Inputs</li> </ul>	Full Name:	TIID^Device 3 (CX-BK	0^Box 1 (CX-BK)^Input	s^State
<ul> <li>Outputs</li> <li>Box 1 (CX2100 Power Supply)</li> <li>DIS Inputs</li> <li>BoxInfo</li> <li>Pevice 5 (NOV-DP-RAM)</li> <li>Mappings</li> </ul>	4			
Ready.				

Fig. 44: Status variable for error handling and diagnostics under TwinCAT.

If the value is "0", the K-bus operates synchronous and without error. If the value is <> "0" there may be a fault, or it may only be an indication that the K-bus cycle is longer than the task. In which case it would no longer be synchronous with the task. The task time should be faster than 100 ms. We recommend a task time of less than 50 ms. The K-bus update time typically lies between one and five ms.

Table 22: Description of the State variable values.

Bit	Description	
Bit 0	K-bus error.	
Bit 1	Terminal configuration has changed since the start.	
Bit 2	Process image lengths do not match.	
Bit 8	(still) no valid inputs.	
Bit 9	K-bus input update not yet complete.	
Bit 10	K-bus output update not yet complete.	
Bit 11	Watchdog.	
Bit 15	Acyclic K-bus function active (e.g. K-bus reset).	

If there is a K-bus error, this can be reset via the IOF\_DeviceReset function block (in the TcIoFunctions.lib).

## 9.1.2 E-bus

The power supply unit checks the connected EtherCAT Terminals. In E-bus mode the "Link/Act IO" LED is lit. When data are transferred, the "Link/Act IO" LED flashes.

Table 23: Diagnostic LEDs in K-Bus mode.
--

Display	LED		Meaning
	Us		Power supply for basic CPU module. The LED lights green if the power supply is correct.
Cnt / Dl1 Cnt Dl2 / Cnt Dl3 Cl4	Up		Power supply for terminal bus. The LED lights green if the power supply is correct.
DI5 DI6	Link/Act	off	E-bus not connected.
	IO	on	E-bus connected / no data traffic.
PWM1 / D03 D04 / PWM2		flashes	E-bus connected / data traffic on the E-bus.

# 9.2 Diagnosis of the multi-function I/Os

This chapter describes the diagnostic options for multi-function I/O communication. This is important, for example, if the 24 V power supply for the multi-function I/Os fails or the circuit breaker has triggered.

#### Status variable

The status variable state can be used for diagnostic purposes. In the normal state, the status variable takes the value 0x = 8 (OP, Operational) and thus indicates that everything is error-free.



Fig. 45: Multi-function I/O status variable.

The following table shows which values the variables can assume:

Value	Meaning
0x1	Slave in 'INIT' state
0x2	Slave in 'PREOP' state
0x3	Slave in 'BOOT' state
0x4	Slave in 'SAFEOP' state
0x8	Slave in 'OP' state
0x001_	Slave signals error
0x002_	Invalid vendorld, productCode read
0x004_	Initialization error occurred
0x010_	Slave not present

If there is a power supply failure, the multi-function I/Os do not automatically go back into data exchange. To do this, the multi-function I/Os must be reset. A function block that can be used to reset the multi-function I/Os is the <u>FB\_CX70xx\_ResetOnBoardIO</u> [ $\blacktriangleright$  93] function block.

*Notice* : If outputs are still set in the PLC, the outputs of the multi-function I/Os are immediately reactivated as soon as the multi-function I/Os are reset with the function block.

#### Other diagnostic variables

The diagnostic variables Diag and TxPDO State are currently not in use and are reserved for future use. The variable Input cycle counter, on the other hand, increments with each cycle and indicates the number of I/O cycles exchanged with the multi-function I/Os. As soon as the variable is no longer incremented, no more I/O cycles are exchanged with the multi-function I/Os.



Fig. 46: Further diagnostic variables for multi-function I/Os

Variable	Meaning
Diag	Reserved, currently not used.
TxPDO State	Reserved, currently not used.
Input cycle counter	Incremented by 1 with each cycle. If this counter stops, then no more I/O cycles are exchanged with the multi-function I/Os.

## 9.3 Memory usage

The CX7000 has 32 MB of main memory that is used by the firmware (TwinCAT/RTOS) and TwinCAT (TwinCAT memory). The TwinCAT memory is further divided into the router memory and the PLC memory. The router memory is used for ADS communication and the PLC memory for the actual PLC program including TcConfiguration, mapping and data.

19.1 MB of TwinCAT memory are available to the CX7000. Because the size of the memory is limited, it is important to check the memory usage and to adapt your PLC project if it is exceeded.

#### Router memory

On the one hand, you can adjust the size of the router memory in TwinCAT and set a smaller router memory depending on the ADS communication actually used.

Solution Explorer 💿 🔻 🕂 🗸	CX7000 → × MAIN
ⓒ ◯  ☵ ▾ ఀ⊙ ▾ ฮ "	Settings Online Priorities C++ Debugger
Search Solution Explorer (Ct P - Solution 'CX7000' (1 project) CX7000 CX7000	Router Memory     Global Task Config       Configured Size [MB]:     4       Allocated / Available:     2 / 1
License ▲  A license ■ Real-Time I /O Idle Task ■ Tasks	Available cores (Shared/Isolated):     1     0     Read from Target     Set on target       Core     RT-Core     Ba     Core Limit     Latency Warning
译。Routes 译。Type System 译 TcCOM Objects 函 MOTION	0
DI PLC     SAFETY     SAFETY     SAFETY	Object     RT-Core     Base Time (     Cycle Time (     Cycle Ticks     Priority       VO bits Table     Default (0)     T     1 area     10     11
ANALYTICS	PicTask     Default (0)     1 ms     10 ms     10     11       PicAuxTask     Default (0)     1 ms     10 ms     10     20
Solution Explorer Team Explorer	<

Fig. 47: Settings for router memory in the TwinCAT System Manager.

By default, a value of 32 MB is entered in TwinCAT, which in turn is limited to 9 MB for the CX7000 because of the small main memory in the CX7000. A router memory of 9 MB is usually far too large for a small controller. A router memory of 4 MB is recommended for the CX7000 and can be even smaller if little to no ADS communication is used. However, a router memory of at least 1 MB should be adhered to and should not be less. How much router memory is used can be determined with the function block FB\_GetRouterStatusInfo or alternatively with the Beckhoff Device Manager.

Note that the router memory is only re-created with a power off/on of the CX7000. A TwinCAT restart is not sufficient. As a rule of thumb, the smaller the router memory for ADS communication is set, the larger the application can be, i.e. the PLC program, TcConfiguration, mapping and data.

#### Determining the memory usage

With the function block FB\_GetRouterStatusInfo, or alternatively with the Beckhoff Device Manager, it is possible to determine how large the memory requirement of the router memory is.

BECKHOFF Device Manager				
	<b>.</b>	284	Status	
	帚	Status	TwinCAT Status	Run
Device		Ģ	Version	
-		52	Major	3
		Connectivity	Minor	1
Manduran			Build	4025
Haroware			Revision	3
Software	ГQ		Router Memory	20.5КВ <sub>Мах: 4.0МВ</sub>
TwinCAT			TCOS Memory	<b>7.1MB</b> Max: 19.1MB
Security	La 🖸			

Fig. 48: Usage of the router and TwinCAT memory.

The **Router** display can be used to determine the memory requirements of the router memory. In this example, 20.5 kB of a maximum of 4 MB are used. The **TcOs** display shows the total memory usage of the TwinCAT memory including router memory and PLC program. In this example, a total of 7.1 MB is used.

With the help of this display, the size of the PLC program can also be calculated, as the router memory is fixed at 4 MB and is part of the TwinCAT memory. If you subtract the 4 MB from 7.1 MB, the PLC program occupies 3.1 MB.

#### Memory reserve

Since 7.1 MB of the 19.1 MB TwinCAT memory are used in this example, a reserve of 12 MB remains for the PLC program. Note that more memory is needed for a short time for an Online Change in TwinCAT. If you want to use the Online Change function, it is advisable to always have a certain reserve. In the most extreme case, twice the currently consumed PLC program may be required to execute an Online Change. An error message is displayed in TwinCAT if there is not enough memory available for the Online Change.

## 9.4 Real-time and CPU load

For the proper functioning of the CX7000, it is important to keep an eye on CPU load and real-time compliance. Otherwise, the CX7000 will no longer work reliably in the event of an overload. Note that in the event of an overload, the load indicator is also affected and no longer provides current values. For example, a load of 40% can be incorrectly displayed, but the PLCs are no longer working in real time and the system is overloaded. You should therefore gradually approach the load limit with a small controller.

What is meant by real-time in this context? By default, the PLC works in synchronization with the cycle, which means that a task time is always defined and called at a fixed time. The PLC works in synchronization with the cycle if the task time is not exceeded. For example, if you define a task time of 10 ms and the PLC only needs 2 ms for processing, the selected task time is fine and the PLCs work in synchronization with the cycle.

Even if you do not need the real-time, it is recommended to adhere to the real-time, because otherwise negative effects can occur. These could be connection problems or problems with subsystems such as K-bus or EtherCAT. You can perform the following steps to check whether the CX7000 is optimally set or rather overloaded:

- Observe the exceed counter.
- Check the CPU load.

#### Observe the exceed counter

The exceed counter is incremented as soon as the PLC no longer works in synchronization with the cycle and the defined task time is exceeded. Ideally, the counter value should be zero.



Fig. 49: Display of the exceed counter in TwinCAT.

It is possible for the exceed counter to be incremented at the start of the PLC, for example, because the PLC is called for the first time or certain components are initialized. Observe the exceed counter over a period of several hours. One can only speak of a stable state when the exceed counter is no longer incremented over a longer period of time.

#### Check the CPU load

In TwinCAT, the CPU load is displayed under Realtime and on the Online tab. Check the value to determine whether you can run additional program code or reduce the task time.

Solution Explorer 🔹 🖣 🗙	CX7000 + ×
○ ○ 🏠 🕂 · ] T <u>o</u> • 司   🔑 🗕	Settings Online Priorities C++ Debugger
Search Solution Explorer (Ctrl+;)	Real Time Usage:
	100 % CPU 0 16 %
<ul> <li>Intitled Project</li> <li>External Types</li> <li>References</li> <li>DUTs</li> <li>GVLs</li> <li>POULS</li> </ul>	0 %. System Latency: 100 μs 24 μs
Solution Explorer Team Explorer	

Fig. 50: Display of the CPU load in TwinCAT.

The light green line indicates the preset CPU limit. If the load is  $\geq$  65%, the CX7000 is already very busy and no more code should be executed or the task time shortened. You should not go to the limit and use the CX7000 to full capacity.

#### Measures in the event of overload

If an overload is detected with the help of the steps shown, the load can be reduced by improving the programming or increasing the task time. To find places in the program code with long processing times, the sample in <u>Measuring processing time in the PLC program [ $\blacktriangleright$  81] can be used.</u>

The selected terminal system also has an influence on the real-time. Depending on the number of terminals, the K-bus, for example, can also take several milliseconds and must be taken into account when choosing the task time. It may well be that, with a set task time of 10 ms, the PLC program only needs 5 ms, but the exceed counter still increments. This is due to the fact that the K-bus requires more than 5 ms for processing and the task time of 10 ms including PLC program and K-bus is exceeded. This problem can be solved by reducing the number of terminals or increasing the task time.

By default, the real-time is set to 80%. This is already the maximum value and an increase to 90% is equivalent to an increase to 100%.

Solution Explorer 🛛 👻 🕂 🗙	CX7000 + ×	
○ ○ 습 씁 - ] ⊙ - @ / ፆ -	Settings Online Priorities C++ Debugger	
Search Solution Explorer (Ctrl+;)	Router Memory Global Task Config	-15
Solution 'CX7000' (1 project)	Configured Size [MB]: Allocated / Available: 2/1 Maximal Stack Size [KB] 64KB	
👂 🍓 Real-Time	Available cores (Shared/Isolated): 1 🗘 0 🜩 Read from Target Set on target	
▶ 🛅 Tasks		
E Routes	Core RT-Core Base Ti Core Limit Latency Warning	
Type System	0 🔽 Default 1 ms 💌 80 % 💽 (none)	
TcCOM Objects		

Fig. 51: Setting the real-time load in TwinCAT.

TwinCAT would then consume all the CPU power, and services that the operating system serves would no longer work or would not work adequately. If you increase the real-time load to 90%, you should be aware of the potential consequences for the operating system.
### 10 Technical data

Table 24: Technical data, dimensions and weights.

	CX7000
Dimensions (W x H x D)	49 mm x 100 mm x 73 mm
Weight	142 g

Table	25:	Technical	data,	general	data
-------	-----	-----------	-------	---------	------

Technical data	CX7000
Processor	Arm® Cortex®-M7, 480 MHz
Number of cores	1
Flash memory	512 MB MicroSD (optional 16 GB)
Main memory	32 MB SDR (internal, not expandable)
Number of inputs	8 multifunction inputs (24 V DC)
Number of outputs	4 multifunction outputs (24 V DC, 0.5 A, 1-wire technique)
NOVRAM	4 kB
Interfaces	1 x RJ45 10/100 Mbit/s, 1x USB (max 12 Mbit/s, max 100 mA)
Cooling	passive
Bus interface	-
Data transfer rate	-
Diagnostic LED	1 x TC Status, 1 x WD LED, 1 x ERR LED
Clock	internal, capacitor-buffered real-time clock for time and date (memory > 21 days)
Operating system	TwinCAT/RTOS
Control software	TwinCAT 3 Runtime (XAR)
Power supply	24 V <sub>DC</sub> (-15 %/+20 %)
Max. power consumption	< 2 W (max. 12 W with E-bus/K-bus)
Max. power consumption E-bus/K- bus	7.5 W
TwinCAT 3 functions included	TC1000 TwinCAT 3 ADS, TC1100 TwinCAT 3 I/O, TC1200 TwinCAT 3 PLC, TF4100 TwinCAT 3 Controller Toolbox, TF4110 TwinCAT 3 Temperature Controller, TF6255 TwinCAT 3 Modbus RTU, TF6340 TwinCAT 3 Serial Communication, TF6701 TwinCAT 3 IoT Communication (MQTT), TF6730 TwinCAT 3 IoT Communicator
Approvals	CE, UL

<sup>\*)</sup> Image version 114606 and TwinCAT 3 XAE 4024.47 or higher required.

Table 26: Technical data, I/O terminals.

Technical data	CX7000
I/O connection	via power supply terminal (E-bus or K-bus, automatic recognition)
Power supply for I/O terminals	max. 1.5 A (installation position any, temp2545 °C) max. 1.3 A (installation position horizontal, temp2555 °C) max. 1 A (installation position any, temp2555 °C) max. 1 A (installation position horizontal, temp2560 °C)
Power contacts current load	max. 10 A
Process data on the K-bus	max. 512 bytes In and 512 bytes Out
max. number of terminals (K-bus)	64 (255 with K-bus extension)
E-bus process data	max. 4 kB In and 4 kB Out
max. number of terminals (E-bus)	up to 65534 terminals.

Table 27: Technical data	, environmental conditions.
--------------------------	-----------------------------

Technical data	CX7000
Ambient temperature during operation	-25° C +60 °C
Ambient temperature during	-40° C +85° C
storage	see notes under: <u>Transport and storage [▶ 12]</u>
Relative humidity	95 % no condensation
Vibration resistance	conforms to EN 60068-2-6
Shock resistance	conforms to EN 60068-2-27
EMC immunity	conforms to EN 61000-6-2
EMC emission	conforms to EN 61000-6-4
Protection rating	IP20

Table 28: Technical data, Ethernet interface X001.

Technical data	CX7000
Data transfer medium	4 x 2 twisted pair copper cables category 5 (100 Mbit/s)
Cable length	100 m from switch to CX7000
Data transfer rate	10/100 Mbit/s
Тороlоду	star wiring
Protocols	all non-real-time-capable protocols that are based on TCP or UDP and do not require a real-time extension

## 11 Appendix

### 11.1 Third-Party components

This device contains Beckhoff software and third-party software. Please refer to the license file on the storage medium.

### 11.2 Accessories

Table 29: microSD cards.

Order number	Description
CX1900-0122	512 MB microSD card
CX1900-0132	16 GB microSD card

Table 30: Further spare parts.

Order number	Description
ZB8701	Slotted screwdriver 2.0 x 40 mm, HD terminals

### 11.3 Certifications

#### FCC Approvals for the United States of America

#### FCC: Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### FCC Approval for Canada

#### **FCC: Canadian Notice**

This equipment does not exceed the Class A limits for radiated emissions as described in the Radio Interference Regulations of the Canadian Department of Communications.

## List of tables

Table 1	Dimensions and weight	12
Table 2	Legend for the configuration of the basic CPU module	14
Table 3	Information on the name plate	15
Table 4	Ethernet interface X001, pin assignment.	16
Table 5	Maximum E-bus/K-bus current depending on the selected installation position and the ambi- ent temperature	21
Table 6	Key for the connection example	25
Table 7	Required wire cross-sections and strip lengths	26
Table 8	Technical data, multi-function I/Os as digital inputs	30
Table 9	Technical data, multi-function I/Os as digital outputs	31
Table 10	Technical data, multi-function I/Os in counter mode	34
Table 11	Technical data, multi-function I/Os in encoder mode	40
Table 12	Technical data, multi-function I/Os in analog mode.	44
Table 13	Technical data, multi-function I/Os in PWM mode.	45
Table 14	PWM output (duty cycle), representation of the PWM signal in the delivery state	47
Table 15	PWM period (PWM clock frequency), representation of the PWM signal in the delivery state	47
Table 16	Access data for the Beckhoff Device Manager on delivery	49
Table 17	TC LED, order and meaning.	99
Table 18	TC LED, error description and remedy.	99
Table 19	Diagnostic LEDs in K-Bus mode	100
Table 20	K-bus ERR LED, fault indication sequence through the LED.	100
Table 21	K-BUS ERR LED, fault description and troubleshooting	100
Table 22	Description of the State variable values	102
Table 23	Diagnostic LEDs in K-Bus mode	103
Table 24	Technical data, dimensions and weights.	109
Table 25	Technical data, general data	109
Table 26	Technical data, I/O terminals	109
Table 27	Technical data, environmental conditions	110
Table 28	Technical data, Ethernet interface X001	110
Table 29	microSD cards	111
Table 30	Further spare parts	111

# List of figures

Fig. 1	Sample configuration of a CX7000 Embedded PC	14
Fig. 2	Name plate example	15
Fig. 3	Ethernet interface X001.	16
Fig. 4	CX70xx Embedded PC, dimensions.	20
Fig. 5	CX70xx Embedded PC, permissible installation position	21
Fig. 6	Identifying a passive EtherCAT Terminal in TwinCAT.	24
Fig. 7	Passive EtherCAT Terminals, permissible installation	24
Fig. 8	Connections for system voltage (Us) and power contacts (Up)	25
Fig. 9	Connection example with a CX7000	26
Fig. 10	UL label on CX7000	27
Fig. 11	Connection example for areas with special UL requirements	27
Fig. 12	CX7028 interface, slot and module configuration under TwinCAT.	28
Fig. 13	Supported modules when using slot 1	28
Fig. 14	Supported modules when using slot 2.	29
Fig. 15	Supported modules when using slot 3.	29
Fig. 16	Supported modules when using slot 4.	29
Fig. 17	Configurable digital inputs	30
Fig. 18	Configurable digital outputs	31
Fig. 19	Configurable inputs and outputs in counter mode	33
Fig. 20	Configurable inputs and outputs in incremental encoder mode	39
Fig. 21	Configurable analog inputs.	44
Fig. 22	Configurable inputs and outputs in PWM signal mode	45
Fig. 23	Controller behavior with and without NOVRAM.	51
Fig. 24	Labeling with keyword STRUCT RETAIN for self-defined Data Unit Types (DUTs)	54
Fig. 25	Changing the password in the Beckhoff Device Manager.	58
Fig. 26	Content of the MDP module with IP and MAC address.	76
Fig. 27	Virtual Ethernet communication via ADS, TCP or UDP.	76
Fig. 28	CoE access to multi-function I/Os, input variables "netId" and "port" under TwinCAT	78
Fig. 29	CoE communication, listing of CoE objects with matching index number	78
Fig. 30	K-bus interface of a CX7000 in the TwinCAT System Manager.	79
Fig. 31	E-bus interface of a CX7000 in the TwinCAT System Manager.	80
Fig. 32	Setting for the I/O Idle Task in TwinCAT 3 Engineering	82
Fig. 33	Measurement at a task time of 250 µs	88
Fig. 34	Measurement at a task time of 500 µs	88
Fig. 35	Measurement at a task time of 1 ms.	88
Fig. 36	CX7000 CPU and PLC	89
Fig. 37	CPU of the CX7028 interface	89
Fig. 38	Default calling of a PLC task	95
Fig. 39	Calling a PLC task with the attribute tcCallAfterOutputUpdate.	95
Fig. 40	Pulse of a digital output without load	96
Fig. 41	Shortened pulse of a digital output with load.	96
Fig. 42	Inverted representation of a digital output	97
Fig. 43	Determination of different running times in the PLC program.	98
Fig. 44	Status variable for error handling and diagnostics under TwinCAT	102

## BECKHOFF

Multi-function I/O status variable	104
Further diagnostic variables for multi-function I/Os	104
Settings for router memory in the TwinCAT System Manager	105
Usage of the router and TwinCAT memory	106
Display of the exceed counter in TwinCAT.	107
Display of the CPU load in TwinCAT.	108
Setting the real-time load in TwinCAT	108
	Multi-function I/O status variable. Further diagnostic variables for multi-function I/Os. Settings for router memory in the TwinCAT System Manager. Usage of the router and TwinCAT memory. Display of the exceed counter in TwinCAT. Display of the CPU load in TwinCAT. Setting the real-time load in TwinCAT.

#### **Trademark statements**

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

#### Third-party trademark statements

Arm, Arm9 and Cortex are trademarks or registered trademarks of Arm Limited (or its subsidiaries or affiliates) in the US and/or elsewhere.

More Information: www.beckhoff.com/CX7000

Beckhoff Automation GmbH & Co. KG Hülshorstweg 20 33415 Verl Germany Phone: +49 5246 9630 info@beckhoff.com www.beckhoff.com

