



Functional description | EN

## TF5200 | TwinCAT 3 CNC

Insert stop command





# Table of contents

|                                                                                                |           |
|------------------------------------------------------------------------------------------------|-----------|
| Notes on the documentation.....                                                                | 6         |
| General and safety instructions .....                                                          | 7         |
| <b>1 Overview .....</b>                                                                        | <b>8</b>  |
| <b>2 Description .....</b>                                                                     | <b>9</b>  |
| 2.1 Properties .....                                                                           | 10        |
| 2.1.1 DISTANCE mode .....                                                                      | 11        |
| 2.1.2 POSITION mode .....                                                                      | 13        |
| 2.1.3 Combination of functions “Insert motion stops during processing” and real-time loops...  | 17        |
| 2.2 Applications .....                                                                         | 19        |
| 2.2.1 POSITION mode application .....                                                          | 19        |
| 2.2.2 DISTANCE mode application .....                                                          | 20        |
| 2.3 Combination of functions “Insert motion stops during processing” and real-time loops ..... | 20        |
| <b>3 PLC interface .....</b>                                                                   | <b>23</b> |
| 3.1 Control unit – Insert stop marks (insert command) .....                                    | 23        |
| 3.2 User data .....                                                                            | 23        |
| <b>4 Programming .....</b>                                                                     | <b>25</b> |
| <b>5 Parameter .....</b>                                                                       | <b>26</b> |
| <b>6 Support and Service .....</b>                                                             | <b>28</b> |
| Index .....                                                                                    | 29        |



## List of figures

|         |                                                                                      |    |
|---------|--------------------------------------------------------------------------------------|----|
| Fig. 1  | Stop mark command at standstill .....                                                | 12 |
| Fig. 2  | Stop mark command on motion .....                                                    | 12 |
| Fig. 3  | Stop mark command at standstill: .....                                               | 14 |
| Fig. 4  | STOP mark command at standstill with axis position reached multiple times .....      | 14 |
| Fig. 5  | STOP mark command with relative position specified for a modulo axis.....            | 15 |
| Fig. 6  | STOP mark command with absolute position specified for a modulo axis.....            | 15 |
| Fig. 7  | STOP mark command with relative iterative position specified for a modulo axis ..... | 16 |
| Fig. 8  | Absolute commanded stop.....                                                         | 17 |
| Fig. 9  | Relative commanded stop.....                                                         | 17 |
| Fig. 10 | Premature exit from real-time loop .....                                             | 18 |
| Fig. 11 | POSITION mode application.....                                                       | 19 |
| Fig. 12 | DISTANCE mode application.....                                                       | 20 |
| Fig. 13 | Absolute commanded stop.....                                                         | 21 |
| Fig. 14 | Relative commanded stop.....                                                         | 21 |
| Fig. 15 | Premature exit from real-time loop .....                                             | 22 |

# Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

## Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

## Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

## Patent Pending

The EtherCAT technology is patent protected, in particular by the following applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702

with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

## Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

# General and safety instructions

## Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

## Icons in explanatory text

1. Indicates an action.

⇒ Indicates an action statement.

### **DANGER**

#### **Acute danger to life!**

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.

### **CAUTION**

#### **Personal injury and damage to machines!**

If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.

### **NOTICE**

#### **Restriction or error**

This icon describes restrictions or warns of errors.

#### **Tips and other notes**

 This icon indicates information to assist in general understanding or to provide additional information.

## General example

Example that clarifies the text.

## NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.

#### **Specific version information**

 Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

# 1 Overview

## Task

The function "Insert motion stops during processing" permits the insertion of CNC stop marks in the future processing of an NC program while it is being processed.

## Effectiveness / possible applications

- The function can be used for processes where a stop point is not yet known before program start.
- Another application is for alternating stop points while a program is being processed.



**This function is available as of CNC Build V3.1.3105.01**

## Parameterisation

P-STUP-00033 [► 26] must be parameterised in order to use the function.

## ***Mandatory note on references to other documents***

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons, these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.



## 2 Description

The function " Insert motion stops during processing" permits the insertion of CNC stop marks for the future processing of the program while a program is running. This can be used, for example, for process-controlled machining operations executed in parallel where the positions for these operations are not yet known before program start.

Stop marks are usually inserted via the PLC with the Control unit – Insert stop marks (insert command) [► 23]. Alternatively, stop marks can also be inserted via the NC program, see Programming [► 25]..

The STOP position is specified depending on the mode used. The following modes are available:

- Mode = POSITION – STOP position dependent on an axis position
- Mode = DISTANCE – STOP dependent on distance from program start ("dist\_prog\_start" control unit [► 26])

$STOP = f(\text{axis position} \mid \text{dist\_prog\_start})$

Stop marks are represented by optional M functions. The program is continued after the M function is acknowledged in the PLC.

## 2.1 Properties

### General properties:

- The user can insert a new stop mark while the program is running during motion or at standstill.
- The position of the STOP in the program can be preset depending on the mode used.
- A STOP is represented by a programmed/selectable stop (M00/M01) or a user-defined M function acknowledged in any way.
- A M00/M01 transfers the channel to the stop state and is exited by "Continue movement". With a user-defined, arbitrary M function, the channel does not revert to stop state but waits for the default acknowledgement from the PLC.
- If the new STOP is specified during the motion, the channel is stopped briefly, the STOP is inserted and the channel continues to the newly set STOP. If the new STOP is commanded during standstill, the new STOP is set immediately.
- A STOP can also be commanded before program start. A STOP after program end is set to the end of the program.
- Cross-program STOPs are not possible.
- STOPs can be set with a preset absolute or relative position. If STOPs have a relative preset, they can be commanded once or can be automatically commanded iteratively.
- An already specified STOP can be cleared by the value 0 if a relative dimension is specified, provided the STOP is not reached. When a new STOP is specified, the current STOP is cleared and the new STOP is set.
- When a STOP inserted by the PLC is reached, it is additionally signalled by a special stop condition (stop\_condition\_r). They can be read as follows:
  - by the [HLI](#) [► 26]
  - by the associated [CNC object](#) [► 27]
- The function can also be used in the backward direction.

## 2.1.1 DISTANCE mode

- In DISTANCE mode, the location of the STOP is specified by the "dist\_prog\_start" control unit [► 26].
- "dist\_prog\_start" is the absolute path travelled from program start and is monotonically increasing. This means that each program position can be uniquely identified.
- The "dist\_prog\_start" value can be reset with the NC command #DISTANCE PROG START CLEAR.
- Return values from the CNC to the PLC (display data) are the axis positions of the first three axes and the "dist\_prog\_start" at the next/current STOP.
- A STOP that is set absolute or a one-off relative STOP is cleared during forward/reverse rotation. Relative iterative STOPs are retained.

The table below shows the possible combinations of the parameter "dist\_or\_pos" and the parameter "rel\_abs\_mode" and the resulting behaviour of the CNC for DISTANCE mode ('axis\_nr' = 0):

| Specified dimension<br>(rel_abs_mode) | Distance (dist_or_pos) | CNC behaviour                                                                                                                         |
|---------------------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| relative iterative (0)                | =0                     | a possibly set STOP that is not yet reached is cleared                                                                                |
|                                       | <0                     | immediate one-off STOP at current distance                                                                                            |
|                                       | >0                     | (possibly interrupt) new STOP relative to the current distance, automatic new relative STOPs after continuation of the previous STOP. |
| absolute (1)                          | =< current distance    | immediate STOP at current distance                                                                                                    |
|                                       | > current distance     | STOP at commanded distance                                                                                                            |
| relative one-off (2)                  | =< 0                   | immediate STOP at current distance                                                                                                    |
|                                       | > 0                    | (possibly interrupt) and insert a STOP relative to current distance                                                                   |

## Examples




Fig. 1: Stop mark command at standstill




Fig. 2: Stop mark command on motion

## 2.1.2 POSITION mode

- In POSITION mode, any axis position can be specified. When this axis position is reached for the first time, the system stops. This means that if the same axis position is passed again, it is not stopped again.
- Modulo axes are handled as follows.
  - Absolute position: The specified axis position is shifted to the modulo range. A maximum of one revolution can be moved as a result.
  - Relative position: The commanded axis position describes the path to be traversed to the next stop point. Therefore, more than one revolution can be moved to the next STOP.
- Return values from the CNC to the PLC (display data) are the axis positions of the commanded axes and the "dist\_prog\_start" at the next/current STOP..
- A STOP that is set is cleared with forward/backward rotation by a PLC command (backward\_motion control unit). This means that a STOP in backward direction must only be commanded after the revolution.

The table below shows the possible combinations of the parameter "dist\_or\_pos" and the parameter "rel\_abs\_mode" and the resulting behaviour of the CNC for POSITION mode ('axis\_nr' > 0):

| Specified dimension (rel_abs_mode) | Distance (dist_or_pos)   | CNC behaviour                                                                                                       |
|------------------------------------|--------------------------|---------------------------------------------------------------------------------------------------------------------|
| relative iterative (0)             | = 0                      | a possibly set STOP that is not yet reached is cleared                                                              |
|                                    | <> 0                     | STOP relative to the current axis position (or interrupt point), automatic new relative STOPs when STOP is reached. |
| absolute (1)                       | = current axis position  | STOP at current axis position                                                                                       |
|                                    | <> current axis position | STOP the next time the axis position is reached                                                                     |
| relative one-off (2)               | = 0                      | STOP at current axis position (or interrupt point)                                                                  |
|                                    | <> 0                     | One-off STOP relative to current axis position (or interrupt point)                                                 |

## Examples




Fig. 3: Stop mark command at standstill:




Fig. 4: STOP mark command at standstill with axis position reached multiple times




Fig. 5: STOP mark command with relative position specified for a modulo axis




Fig. 6: STOP mark command with absolute position specified for a modulo axis




Fig. 7: STOP mark command with relative iterative position specified for a modulo axis



### 2.1.3 Combination of functions “Insert motion stops during processing” and real-time loops

When combining the "Insert motion stops during machining" function with "Distance" mode and the real-time loops function when using the "MODULO" option, the following special features must be considered:

- An absolute commanded stop is only possible within the current loop or after exiting the loop.
- A relative one-time stop in a future loop that is not reached by a premature exit is rejected.

#### Absolute commanded stop




Fig. 8: Absolute commanded stop

#### Relative one-time/iterative commanded stop




Fig. 9: Relative commanded stop


**Difference in case of premature exit from real-time loop**

Fig. 10: Premature exit from real-time loop

## 2.2 Applications

### 2.2.1 POSITION mode application

The "Insert stop marks" function in POSITION mode can be used for machining with continuously fed material with a local offset technology process.

For example, in tube or wire machining, the workpiece length is defined by cutting at the start and end of the NC program. If a technology process is also applied, e.g. the tube is insulated by laser, this insulation process takes place at a local offset position.

In the laser insulation process, the CNC must be at a standstill. This can be achieved by inserting a STOP with the "Insert stop marks" function.

Since laser processing is locally displaced from the actual programming point, laser processing in the following program may require a STOP in the current program. This relationship is shown in the figure below. The position axis shown is intended to represent the position of the tube feed axis across programs. The position traversed then corresponds to the length of the tube produced at the end.




Fig. 11: POSITION mode application

If the program sequence is not defined in advance, the STOP position in the program is only known during the program run. The STOP can therefore not be implemented by NC programming.

The "Insert stop marks" function can be used to insert a STOP online during program processing as soon as the next programme is known.

### 2.2.2 DISTANCE mode application

In multichannel machining, where the resulting geometry is created by superimposing individual channels, it may be necessary to stop one channel while the other channel(s) continue machining.

An example of this is a machining operation with two channels working in planes perpendicular to each other.

The figure below shows the movement of the first channel superimposed by an orbiting movement about the Z axis of the second channel.




Fig. 12: DISTANCE mode application

Process-controlled, the same geometry is traversed several times with different process settings. Each process setting requires STOPS in the first channel (discs in the figure), while the second channel continues orbiting until a sufficient quality is reached.

The "Insert stop marks" function offers the option to set the discs for the current process setting at the start of each process setting marking the start of the program. Due to the 2D motion of the channel, equidistant discs can be inserted in the program using the distance traversed.

## 2.3 Combination of functions "Insert motion stops during processing" and real-time loops

When combining the "Insert motion stops during machining" function with "Distance" mode and the real-time loops function when using the "MODULO" option, the following special features must be considered:

- An absolute commanded stop is only possible within the current loop or after exiting the loop.
- A relative one-time stop in a future loop that is not reached by a premature exit is rejected.

### Absolute commanded stop




Fig. 13: Absolute commanded stop

### Relative one-time/iterative commanded stop




Fig. 14: Relative commanded stop


**Difference in case of premature exit from real-time loop**

Fig. 15: Premature exit from real-time loop

## 3 PLC interface

### 3.1 Control unit – Insert stop marks (insert command)

| Insert stop marks               |                                                                                                                                                                                                                                                                                                                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                     | <p>During runtime, the PLC can use this control unit to set stop points in the future NC program. The control unit must then be enabled by <code>enable_w = TRUE</code>.</p> <p>The PLC signals a new assignment of <code>command_2</code> by setting <b><code>command_semaphore_rw</code></b> to TRUE.</p> <p>The CNC sets the <code>command_semaphore_rw</code> to FALSE after the <code>command_w</code> data is read.</p> |
| Data type                       | MC_CONTROL_INSERT_CMD_UNIT                                                                                                                                                                                                                                                                                                                                                                                                    |
| ST path                         | gpCh[channel_idx]^..bahn_mc_control.insert_cmd                                                                                                                                                                                                                                                                                                                                                                                |
| Command data                    |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| ST element                      | <b>.command_w</b>                                                                                                                                                                                                                                                                                                                                                                                                             |
| Data type                       | HLI_INSERT_CMD_COMMAND [► 23]                                                                                                                                                                                                                                                                                                                                                                                                 |
| Access                          | PLC writes <code>command_w</code>                                                                                                                                                                                                                                                                                                                                                                                             |
| Return values                   |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| ST element                      | <b>.state_r</b>                                                                                                                                                                                                                                                                                                                                                                                                               |
| Data type                       | HLI_INSERT_CMD_STATE [► 24]                                                                                                                                                                                                                                                                                                                                                                                                   |
| Access                          | PLC reads                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Activation                      |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| ST element                      | <b>.enable_w</b>                                                                                                                                                                                                                                                                                                                                                                                                              |
| Data type                       | BOOL                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Access                          | PLC writes                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Value range                     | [TRUE/FALSE] ; TRUE: CU enabled in PLC                                                                                                                                                                                                                                                                                                                                                                                        |
| Flow control of commanded value |                                                                                                                                                                                                                                                                                                                                                                                                                               |
| ST element                      | <b>.semaphor_rw</b>                                                                                                                                                                                                                                                                                                                                                                                                           |
| Data type                       | BOOL                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Value range                     | [TRUE, FALSE]                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Special features                | <b>Consumption data item</b>                                                                                                                                                                                                                                                                                                                                                                                                  |
| Access                          | <p>TRUE : PLC triggers on new request</p> <p>FALSE : CNC has read new request</p>                                                                                                                                                                                                                                                                                                                                             |

### 3.2 User data

| Command data – Insert command    |                                                                                                                                                                                                           |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                      | Control data for inserted STOP command                                                                                                                                                                    |
| ST path                          | gpCh[channel_idx]^..bahn_mc_control.insert_cmd.command_w                                                                                                                                                  |
| ST name                          | HLI_INSERT_CMD_COMMAND                                                                                                                                                                                    |
|                                  |                                                                                                                                                                                                           |
| ST element                       | <b>.dist_or_pos</b>                                                                                                                                                                                       |
| Data type                        | LREAL                                                                                                                                                                                                     |
| Description/<br>special features | <p>Relative/absolute distance or axis position at which the stop is to be inserted. [0.1 µm]</p> <p>The default setting is DISTANCE mode, the POSITION mode is active at a value of “.axis_nr“ &gt; 0</p> |
|                                  |                                                                                                                                                                                                           |
| ST element                       | <b>.rel_abs_mode</b>                                                                                                                                                                                      |
| Data type                        | UINT                                                                                                                                                                                                      |

|                                  |                                                                                                                                                                                                                                                                                         |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description/<br>special features | Value = 0 for relative distance with automatic insertion of a new stop when the current stop is reached<br>Value = 1 for one-off insertion at the absolute distance<br>Value = 2 for one-off insertion at the relative distance                                                         |
| ST element                       | <b>.axis_nr</b>                                                                                                                                                                                                                                                                         |
| Data type                        | UINT                                                                                                                                                                                                                                                                                    |
| Description/<br>special features | Value = 0 for DISTANCE mode<br>Value > 0 for POSITION mode: Stop is inserted at the commanded axis position of the axis with the logical axis number = ".axis_nr".                                                                                                                      |
| ST element                       | <b>.m_function_nr</b>                                                                                                                                                                                                                                                                   |
| Data type                        | UINT                                                                                                                                                                                                                                                                                    |
| Description/<br>special features | Number of the inserted M function <ul style="list-style-type: none"> <li>Value = 0 for M00 programmed stop</li> <li>Value = 1 for M01 optional stop (enabled/disabled with m01_stop_enable CU)</li> <li>Value &gt; 1 for M&lt;m_function_nr&gt; with MVS_SVS synchronisation</li> </ul> |
| ST element                       | <b>.add_nr</b>                                                                                                                                                                                                                                                                          |
| Data type                        | DINT                                                                                                                                                                                                                                                                                    |
| Description/<br>special features | Optional additional value of the M function; it is specified as a negative or positive integer.                                                                                                                                                                                         |

| Status data – Insert command |                                                                                                                                                                                                                                                                                                                                                                     |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                  | Status data of the insert command control unit                                                                                                                                                                                                                                                                                                                      |
| ST path                      | gpCh[channel_idx]^bahn_mc_control.insert_cmd.state_r                                                                                                                                                                                                                                                                                                                |
| ST name                      | HLI_INSERT_CMD_STATE                                                                                                                                                                                                                                                                                                                                                |
| ST element                   | <b>.distance_of_next_stop</b>                                                                                                                                                                                                                                                                                                                                       |
| Data type                    | LREAL                                                                                                                                                                                                                                                                                                                                                               |
| Description                  | Absolute distance (dist_prog_start) of the feed axes (#FGROUP) at the next stop [0.1 µm]<br>Value >= 0 : Stop found, axis positions correct<br>Value = -1 : Stop still not found in the NC program                                                                                                                                                                  |
| ST element                   | <b>.position_at_next_stop[idx]</b>                                                                                                                                                                                                                                                                                                                                  |
| Data type                    | ARRAY[0..HLI_CS_AXIS_MAXIDX] OF DINT                                                                                                                                                                                                                                                                                                                                |
| Description                  | When <ul style="list-style-type: none"> <li>command_w.axis_nr = 0, the axis positions X, Y, Z are assigned accordingly at the next stop in the PCS [0.1 µm]</li> <li>command_w.axis_nr &gt; 0; .position_at_next_stop[0] contains the axis position of the commanded axis at the next stop<br/>position_at_next_stop[1]=0 and position_at_next_stop[2]=0</li> </ul> |
| ST element                   | <b>.state</b>                                                                                                                                                                                                                                                                                                                                                       |
| Data type                    | DINT                                                                                                                                                                                                                                                                                                                                                                |
| Description                  | Status if the current command_w. <ul style="list-style-type: none"> <li>Value =0: no stop commanded</li> <li>Value=1: Stop commanded but not yet reached</li> </ul>                                                                                                                                                                                                 |



## 4 Programming

The NC command #INSERT CMD can be used to specify stop marks via the NC program.

The "AXNR" parameter is used to set the mode.

- AXNR = 0 – DISTANCE mode (default)
- AXNR !=0 – POSITION mode

Syntax:

**#INSERT CMD [ON | OFF] [AXNR=.. MNR=.. ADDR=.. DIST=.. [ABS | REL | REL\_ONCE] ]**

|                 |                                                                                                                                                                                                                                                                                                         |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ON</b>       | Insert stop marks is enabled                                                                                                                                                                                                                                                                            |
| <b>OFF</b>      | Insert stop marks is disabled. This results in a stop at the program position.                                                                                                                                                                                                                          |
| <b>AXNR=..</b>  | Logical axis number<br>Stop is inserted at the commanded axis position of the axis with this logical axis number.<br><b>Note: Mode is defined by specifying the logical axis number.</b><br>AXNR = 0 – DISTANCE mode is used<br>AXNR !=0 – POSITION mode is used<br>Default value = 0                   |
| <b>MNR=..</b>   | Number of the inserted M function <ul style="list-style-type: none"> <li>• Value = 0 for M00 programmed stop (default)</li> <li>• Value = 1 for M01 optional stop (enabled/disabled with m01_stop_enable CU)</li> <li>• Value &gt; 1 for M&lt;m_function_nr&gt; with MVS_SVS synchronisation</li> </ul> |
| <b>ADDR=..</b>  | Optional additional value of the M function; it is specified as a negative or positive integer.                                                                                                                                                                                                         |
| <b>DIST=..</b>  | Relative/absolute distance or axis position in [0.1µm] at which the stop is to be inserted.<br>Dependent on the mode used                                                                                                                                                                               |
| <b>ABS</b>      | One-off insertion at the absolute distance                                                                                                                                                                                                                                                              |
| <b>REL</b>      | for relative distance with automatic insertion of a new stop when the current stop is reached.                                                                                                                                                                                                          |
| <b>REL_ONCE</b> | One-off insertion at the relative distance.                                                                                                                                                                                                                                                             |



### The distance specification ABS/REL or REL\_ONCE are mutually exclusive.

When you use simultaneous programming within an #INSERT CMD instruction, the error is output with ID 22130.

The default assignment of the NC command is:

**#INSERT CMD [MNR=0 DIST=0 REL AX=0]**

If M function < 2 is specified, the command for continuing machining must be given by the "Continue motion" control unit after the STOP is reached.

If M function is specified >= 2, the default acknowledgement of the M function is sufficient.

The bit in the [stop conditions](#) [► 26] is displayed on the HLI when an inserted stop is reached.

The combination of the parameters DIST=0 and REL=1 clears the previously set STOP irrespective of the parameters MNR and AXNR,

The current distance can be reset with #DISTANCE PROG START CLEAR.

## 5 Parameter

### Start-up parameters

| <b>P-STUP-00033 Memory size for backward motion</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                                         | This parameter defines the memory size in bytes used for backward motion on the path. During start-up, the NC checks whether the required minimum size is available. If this is not the case, a warning is output and the memory size is set to the required minimum value. If the size is set to 0, the “forward/ backward motion on the path” function is not available. The maximum size is only limited by the resources available on the PC. |
| Parameter                                           | fb_storage_size[i] where i = 0 to 11<br>(maximum number of channels: 12, application-specific)                                                                                                                                                                                                                                                                                                                                                    |
| Data type                                           | UNS32                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Data range                                          | 0 ... MAX(UNS32)                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Dimension                                           | ----                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Default value                                       | 0                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Remarks                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

### Other PLC parameters

| <b>Currently covered path in the NC program (PCS)</b> |                                                                                                                                                                                                              |
|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                                           | Reads the current distance covered in the NC program since program start or since the last # DISTANCE PROG START CLEAR NC command. The calculation is based on the current position in the current NC block. |
| Signal flow                                           | CNC → PLC                                                                                                                                                                                                    |
| ST path                                               | gpCh[channel_idx]^bahn_state.dist_prog_start                                                                                                                                                                 |
| Data type                                             | UDINT (* LREAL)                                                                                                                                                                                              |
| Unit                                                  | 0.1 µm                                                                                                                                                                                                       |
| Access                                                | PLC is reading                                                                                                                                                                                               |
| Special features                                      | * As of CNC Build V3.1.3104.01 the data element is provided in LREAL forma.                                                                                                                                  |

| <b>Stop condition</b> |                                                                              |
|-----------------------|------------------------------------------------------------------------------|
| Description           | Displays the condition why the current motion was stopped.                   |
| Signal flow           | CNC → PLC                                                                    |
| ST path               | gpCh[channel_idx]^bahn_state.stop_conditions_r                               |
| Data type             | DINT                                                                         |
| Value range           | See <a href="#">Value range of stop conditions [► 26]</a> with explanations. |
| Access                | PLC is reading                                                               |

### Value range of stop conditions

| Constant in PLC        | Value  | Explanation                                                                                                                                                                  |
|------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| HLI_SC_FEEDHOLD        | 0x0001 | Path feed stop                                                                                                                                                               |
| HLI_SC_VFG             | 0x0002 | No axis-specific feed enable.                                                                                                                                                |
| HLI_SC_SINGLE_BLOCK    | 0x0004 | Single step mode active.                                                                                                                                                     |
| HLI_SC_M00_OR_M01      | 0x0010 | M00 (programmed stop), M01 (optional stop) is active.                                                                                                                        |
| HLI_SC_PLC_ACKNOWLEDGE | 0x0020 | Stop occurs due to waiting for an acknowledgement from the SPS. This may occur as a result of the output of M or H technology functions but is not restricted to them alone. |
| HLI_SC_OVERRIDE_ZERO   | 0x0040 | Override = 0.                                                                                                                                                                |

|                             |            |                                                                      |
|-----------------------------|------------|----------------------------------------------------------------------|
| HLI_SC_OVERRIDE_RAPID_ZERO  | 0x0080     | Override = 0 with rapid traverse blocks                              |
| HLI_SC_DELAY_TIME           | 0x0200     | Dwell time.                                                          |
| HLI_SC_CHANNEL_SYNC         | 0x0800     | Channel synchronisation is active.                                   |
| HLI_SC_IPO_INPUT_EMPTY      | 0x1000     | Input FIFO of the interpolation is empty.                            |
| HLI_SC_IPO_INPUT_DISABLED   | 0x2000     | Input of function blocks (e.g. motion blocks etc.) disabled.         |
| HLI_SC_WAIT_FOR_AXES        | 0x8000     | Stop occurs due to waiting until a commanded axis swap is completed. |
| HLI_SC_CHANNEL_ERROR        | 0x00010000 | An error occurred in the channel.                                    |
| HLI_SC_WAIT_TECHNO_ACK      | 0x00020000 | Waiting for acknowledgement of M/H/ST technology functions.          |
| HLI_SC_W_C_AFTER_COLLISION  | 0x00040000 | After a detected collision, waiting for motion resumption.           |
| HLI_SC_SLOPE_SUPPLY_PROBLEM | 0x00080000 | Block supply problem (only occurs in conjunction with HSC slope).    |

|                            |            |                                                                                                                                            |
|----------------------------|------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| HLI_SC_BACK_INTERPOLATION  | 0x00100000 | Back interpolation after tracking mode is active.                                                                                          |
| HLI_SC_STOP_REVERSIBLE     | 0x00200000 | Stop since M00 (programmed stop) is active. However, the NC program can be processed backwards despite M00 (available as of V3.1.3039.01). |
| HLI_SC_BREAKPOINT_STOP     | 0x00400000 | Stop after a breakpoint (stop point) is reached; available as of V3.1.3039.01.                                                             |
| HLI_SC_M0_STOP             | 0x02000000 | Stop after an M00 function is reached                                                                                                      |
| HLI_SC_M1_STOP             | 0x04000000 | Stop after an M01 function is reached                                                                                                      |
| HLI_SC_INSERT_STOP_AT_DIST | 0x08000000 | Stop after an M function inserted by the Control Unit "Inserting stop marks" is reached.                                                   |
| HLI_SC_DEC_SYN_CHAN_EMPTY  | 0x10000000 | Decoder is waiting for synchronisation. NC channel has no jobs.                                                                            |

### CNC objects

|                    |                                                                                                                             |                     |      |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------|---------------------|------|
| <b>Name</b>        | bahn_state.stop_conditions_r                                                                                                |                     |      |
| <b>Description</b> | Displays the condition why the current motion was stopped. The value read can be seen in the <a href="#">table [► 26]</a> . |                     |      |
| <b>Task</b>        | GEO (Port 551)                                                                                                              |                     |      |
| <b>Index group</b> | 0x12330<C <sub>ID</sub> >                                                                                                   | <b>Index offset</b> | 0x30 |
| <b>Data type</b>   | UNS32                                                                                                                       | <b>Length</b>       | 4    |
| <b>Attributes</b>  | read                                                                                                                        | <b>Unit</b>         | [-]  |
| <b>Remarks</b>     | Alternatively, the stop condition can also be read by the <a href="#">HLI [► 26]</a> .                                      |                     |      |

## 6 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

### Download finder

Our [download finder](#) contains all the files that we offer you for downloading. You will find application reports, technical documentation, technical drawings, configuration files and much more.

The downloads are available in various formats.

### Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for [local support and service](#) on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on our internet page: [www.beckhoff.com](http://www.beckhoff.com)

You will also find further documentation for Beckhoff components there.

### Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963-157  
e-mail: [support@beckhoff.com](mailto:support@beckhoff.com)

### Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963-460  
e-mail: [service@beckhoff.com](mailto:service@beckhoff.com)

### Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20  
33415 Verl  
Germany

Phone: +49 5246 963-0  
e-mail: [info@beckhoff.com](mailto:info@beckhoff.com)  
web: [www.beckhoff.com](http://www.beckhoff.com)

# Index

## C

|                    |    |
|--------------------|----|
| covered path       |    |
| current:NC program | 26 |

## E

|                        |    |
|------------------------|----|
| Echtzeitstopp          | 23 |
| Echtzeitstopps command | 23 |

## I

|                |    |
|----------------|----|
| Insert Command | 23 |
| command        | 23 |

## N

|                      |    |
|----------------------|----|
| NC program           |    |
| covered path:current | 26 |

## P

|                             |    |
|-----------------------------|----|
| Path                        |    |
| Stop:reason                 | 26 |
| PCS                         |    |
| covered path:NC block:to go | 26 |
| P-STUP-00033                | 26 |

## S

|                            |    |
|----------------------------|----|
| State Insert Command       | 24 |
| Statusdaten Echtzeitstopps | 24 |
| Stop                       |    |
| Path condition             | 26 |
| Path:reason                | 26 |



More Information:  
[www.beckhoff.com/TF5200](http://www.beckhoff.com/TF5200)

Beckhoff Automation GmbH & Co. KG  
Hülshorstweg 20  
33415 Verl  
Germany  
Phone: +49 5246 9630  
[info@beckhoff.com](mailto:info@beckhoff.com)  
[www.beckhoff.com](http://www.beckhoff.com)

