



Functional description | EN

TF5200 | TwinCAT 3 CNC

Manual mode offset limits



Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT technology is patent protected, in particular by the following applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702

with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

General and safety instructions

Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

Icons in explanatory text

1. Indicates an action.

⇒ Indicates an action statement.

DANGER

Acute danger to life!

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.

CAUTION

Personal injury and damage to machines!

If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.

NOTICE

Restriction or error

This icon describes restrictions or warns of errors.

Tips and other notes

This icon indicates information to assist in general understanding or to provide additional information.

General example

Example that clarifies the text.

NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.

Specific version information

Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

Table of contents

Notes on the documentation.....	3
General and safety instructions	4
1 Overview	8
2 Description	9
2.1 Relative offset limits	9
2.2 Absolute offset limits	12
3 Programming relative offset limits	14
4 Parameter	16
4.1 Overview of parameters	16
4.2 Axis parameters	16
4.3 Channel parameters	17
4.4 Manual mode parameters	17
4.5 CNC objects	18
4.6 ISG parameters	21
4.6.1 HLI parameters up to CNC Build V2.20xx	21
5 Support and Service	23
Index	24

List of figures

Fig. 1 Definition ranges of relative offset limits..... 9

Fig. 2 Definition range of absolute offset limits 12

Fig. 3 Access to absolute offset limits in the ISG object browser..... 20

1 Overview

Task

Manual mode Manual mode (HB) permits the control of individual axes using manual operation elements (handwheel, inching keys, joystick). The operator can move axes in manual mode either

- in a user-defined operating mode (i.e. exclusive) or
- during a running NC program

i.e. apply additional command values.

The motion range of axes is limited by 'Offset limits in manual mode' (referred to below as: offset limits).

Properties

Offset limits can be monitored in manual modes with parallel interpolation (G201) and without parallel interpolation (G200). This is applicable to all axis types.

Parameterisation

Offset limit values can be configured for each axis.

- relative offset limits P-AXIS-00137 and P-AXIS-00138)
- absolute offset limits (P-AXIS-00492 and P-AXIS-00493)

Programming

Relative offset limits can also be set by #MANUAL LIMITS[...].

Mandatory note on references to other documents

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons, these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.

2 Description

Task

Monitor offset limits and limit the possible motion paths for:

- all axis types and
- every axis direction

Command values are added to their motion direction while manual mode G200 or G201 is active and up to the point of deselection as programmed by G202.

Offset limit types

A distinction is made between:

- relative and
- absolute offset limits

They apply to G200 and G201. With G200, relative offset limits only act if P-CHAN-00114 is configured accordingly.

If both relative and absolute offset limits are active, the innermost limits are always active.

2.1 Relative offset limits

Definition

After HB is selected, offset limits act relative to the current axis position (start position) and are defined by:

- P-AXIS-00137 and P-AXIS-00138 or
- #MANUAL LIMITS[...]




Fig. 1: Definition ranges of relative offset limits

Activate the monitor

To activate the relative offset limit monitor, at least one of the limits P-AXIS-00137 or P-AXIS-00138 must be configured with the value $\neq 0$.

1. The monitor is activated.



If both limits = 0, the monitor is not active.

Warnings, errors and reactions

- Warning P-ERR-50720: When the monitor is active, the relative offset limits are reached. The warning is output only if P-MANU-00014 is configured accordingly.
2. Interpolation is stopped.
 - ⇒ Move back within the valid range.
 - Warning P-ERR-150008: When the monitor is active, the relative offset limits are exceeded in jog mode by additional command values.
 1. The additional command values are deleted.
 - ⇒ Move back within the valid range.
 - Error message P-ERR-50041 or P-ERR-50042: With G201, software limits switches are exceeded.
 1. Interpolation is stopped.
 - ⇒ Reset the controller.
 - ⇒ Move back within the valid range. The valid range is defined by the software limit switches.

Modulo axis

For modulo axes, relative offset limits can include several modulo revolutions. The specified relative offset limits refer to the axis position that was valid when it was activated by G200 or G201.

This reference position can be determined by the CNC object with (index group 0x21301 and index offset 0x2000C) or directly on the HLI.

For example, the second axis in the first channel can be read via the GEO port with index group 0x21301 and offset 0x20007.

Change reference position

If the reference position is changed, a path motion and re-activation of the manual mode axis are required.

Offset limits with modulo axes

Initial situation	Rel. neg.	Abs. neg.	Rel. pos.	Abs. pos.	
1. Offset limits lie within one modulo revolution	-60 °	120 °	-40 °	220 °	Offset limits 120° 220° 0° 180° 360° Actual position
2. Offset limits comprise several modulo revolutions	-850 °	-670 °	380 °	560 °	-670° offset limits 560° 0° 180° 360° actual position
3.1 Offset limits lie within another modulo range		800 °		920 °	Based on the current position of 100°, offset limits should be within the range of 800° to 920°. Actual position 100° Offset limits 800° 920° 0° 360°
3.2 Motion path about +740°	-40 °	800 °	80 °	920 °	Based on the above state, a path motion and a reactivation of the HB axis are required. Offset limits 800° 920° 0° 360° 840° Actual position

Legend:

- Rel. neg.: Relative negative offset limit
- Abs. neg.: Absolute negative offset limit
- Rel. pos.: Relative positive offset limit
- Abs. pos.: Absolute positive offset limit

2.2 Absolute offset limits

Definition

Absolute offset limits are defined by P-AXIS-00492 and P-AXIS-00493.

1. The monitor is activated.

The adjustable minimum/maximum values are limited by software limit switches.




Fig. 2: Definition range of absolute offset limits

Activate the monitor

To activate the relative offset limit monitor, at least one of the limits P-AXIS-00492 or P-AXIS-00493 must be configured with a value $\neq 0$.

2. The monitor is activated.



If both limits = 0, the monitor is not active.

Warnings, errors and reactions

- Warning P-ERR-50721: When the monitor is active, the absolute offset limits are reached. The warning is output only if P-MANU-00014 is configured accordingly.
3. Interpolation is stopped.
 - ⇒ Move back within the valid range.
 - Warning P-ERR-110570 or P-ERR-110571: The positive or negative absolute offset limits configured are located outside the software limit switches.
 1. Incorrectly configured absolute offset limits are set automatically to the software limits switches.
 - Error message P-ERR-50041 or P-ERR-50042: With G201, software limits switches are exceeded.
 2. Interpolation is stopped.
 - ⇒ Reset the controller.
 - ⇒ Move back within the valid range. The valid range is defined by the software limit switches.
 - The current axis position is outside the absolute offset limits (analogous to warning P-ERR-50721).
 1. Interpolation is not stopped.
 - ⇒ Move back within the valid range.

3 Programming relative offset limits



As of Build V2.11.2010.02, the command #MANUAL LIMITS [...] replaces the command #SET OFFSET [...]. For compatibility reasons, this command is still available but it is recommended not to use it in new NC programs.

Syntax:

#MANUAL LIMITS [AX=<axis_name> | AXNR=.. NEGATIVE=.. POSITIVE=..]

AX=<axis_name>	Name of axis for which the offset limits are valid.
AXNR=..	Logical number of axis for which the offset limit is to be valid, Positive integer
NEGATIVE=..	Negative relative offset value. Must be programmed as <0 in [mm, inch]
POSITIVE=..	Positive relative offset value. Must be programmed as <0 in [mm, inch]

This command defines the positive and negative limits for the permissible relative path motion in G201/G202 manual mode for each path axis. The relative negative and positive offset limits refer here to the starting point when manual mode was selected. Offset limits are also considered in G200 by setting the parameter P-CHAN-00114.



Relative offset limits can be overwritten at any time in the NC program. A sign check is made. Relative offset limits apply to each axis in the programming coordinate system (PCS).

Program relative offset limits

```
%100
N010 G74 Y1
N015 G01 X10 Y10 F1000

N020 #MANUAL LIMITS[AX=X NEGATIVE=-200 POSITIVE=250]
N030 #MANUAL LIMITS[AX=Y NEGATIVE=-300 POSITIVE=350]

N015 G90 G01 X10 Y10 Z0 F1000
N050 G201 X1 Y1

N060 P1 = 1
N070 $WHILE P1 < 10000

N075 Z[P1/1000]

N080 $IF P1 == 100
N090 #MANUAL LIMITS[AX=X NEGATIVE=-14 POSITIVE=14]
N100 $ENDIF
N080 $IF P1 == 600
N050 G202 X1 Y1
N050 G201 X1 Y1
N100 $ENDIF
N080 $IF P1 == 500
N100 $ENDIF

N110 P1 = P1 + 1
N120 #FLUSH WAIT
N120 $ENDWHILE

N1800 M30
```

4 Parameter

4.1 Overview of parameters

ID	Description
P-AXIS-00137	Relative negative offset limit in manual mode
P-AXIS-00138	Relative positive offset limit in manual mode
P-AXIS-00492	Absolute negative ACS movement limit in manual mode
P-AXIS-00493	Absolute positive ACS movement limit in manual mode
P-CHAN-00114	Offset limits also apply to G200
P-MANU-00014	Output a message at offset limit

4.2 Axis parameters

P-AXIS-00137	Relative negative offset limit in manual mode	
Description	This parameter defines the relative negative offset limit. The relative positive offset limit is defined in P-AXIS-00138.	
Parameter	handbetrieb.offsetgrenze_neg	
Data type	SGN32	
Data range	$\text{MIN}(\text{SGN32}) \leq \text{offsetgrenze_neg} \leq 0$	
Axis types	T, R	
Dimension	T: 0.1µm	R: 0.0001 °
Default value	-1000000	
Drive types	----	
Remarks	If the two relative offset limits • P-AXIS-00137 (offsetgrenze_neg) and • P-AXIS-00138 (offsetgrenze_pos) are assigned the value 0, offset monitoring is disabled.	

P-AXIS-00138	Relative positive offset limit in manual mode	
Description	This parameter defines the relative positive offset limit. The relative negative offset limit is defined in P-AXIS-00137 [► 16] .	
Parameter	handbetrieb.offsetgrenze_pos	
Data type	SGN32	
Data range	$0 \leq \text{offsetgrenze_pos} \leq \text{MAX}(\text{SGN32})$	
Axis types	T, R	
Dimension	T: 0.1µm	R: 0.0001 °
Default value	1000000	
Drive types	----	
Remarks	If the two relative offset limits • P-AXIS-00137 [► 16] (offsetgrenze_neg) + • P-AXIS-00138 (offsetgrenze_pos) are assigned the value 0, offset monitoring is disabled.	

P-AXIS-00492	Absolute negative ACS movement limit in manual mode	
Description	The parameter defines the absolute negative ACS movement limit.	
Parameter	handbetrieb.acs_limit_neg	
Data type	SGN32	

Data range	$P\text{-}AXIS\text{-}00177 \leq \text{acs_limit_neg} \leq P\text{-}AXIS\text{-}00178$	
Axis types	T, R	
Dimension	T: 0.1µm	R: 0.0001 °
Default value	0	
drive types.	----	
Remarks	If both parameters <code>acs_limit_neg</code> and <code>acs_limit_pos</code> are set to 0, the offset monitoring is inactive!	

P-AXIS-00493	Absolute positive ACS movement limit in manual mode	
Description	The parameter defines the absolute positive ACS movement limit.	
Parameter	<code>handbetrieb.acs_limit_pos</code>	
Data type	SGN32	
Data range	$P\text{-}AXIS\text{-}00177 \leq \text{acs_limit_pos} \leq P\text{-}AXIS\text{-}00178$	
Axis types	T, R	
Dimension	T: 0.1µm	R: 0.0001 °
Default value	0	
drive types.	----	
Remarks	If both parameters <code>acs_limit_neg</code> and <code>acs_limit_pos</code> are set to 0, the offset monitoring is inactive!	

4.3 Channel parameters

P-CHAN-00114	Relative manual mode offset limits with G200	
Description	With active G200, travel limitation is controlled by predefined software limit switches if homing was done before. Set this parameter to control whether the relative offset limits (<code>#MANUAL LIMITS</code> , <code>P-AXIS-00137</code> , <code>P-AXIS-00138</code>) should also be considered.	
Parameter	<code>rel_offset_limits_std_manual_mode</code>	
Data type	BOOLEAN	
Data range	0: No consideration of relative offset limits with manual mode G200. 1: Consideration of relative offset limits with manual mode G200.	
Dimension	----	
Default value	0	
Remarks		

4.4 Manual mode parameters

P-MANU-00014	Output a message at offset limit	
Description	If this parameter is set to TRUE, the CNC generates a warning if a manual movement stops at a relative offset limit (<code>P-AXIS-00137</code> , <code>P-AXIS-00138</code>) or at an absolute offset limit (<code>P-AXIS-00492</code> , <code>P-AXIS-00493</code>).	
Parameter	<code>move_limit_warning</code>	
Data type	BOOLEAN	
Data range	0/1	
Dimension	----	
Default value	0	
Remarks	This parameter is available as of CNC Build 2.11.2804.12	

4.5 CNC objects

Notes on addressing

For further information on addressing CNC objects, see [FCT-C13//Description].

Name	manual act.abs.limit-		
Description	Read lower absolute manual mode offset limit.		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >001D
Data type	SGN32	Length/byte	4
Attributes	read	Unit	[0.1 μm or 0.0001°]
Remarks			

Name	manual act.abs.limit+		
Description	Read upper absolute manual mode offset limit.		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >001E
Data type	SGN32	Length/byte	4
Attributes	read	Unit	[0.1 μm or 0.0001°]
Remarks			

Name	manual cmd.abs.limit-		
Description	Define lower absolute manual mode offset limit.		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >0019
Data type	SGN32	Length/byte	4
Attributes	read/ write	Unit	[0.1 μm or 0.0001°]
Remarks			

Name	manual cmd.abs.limit+		
Description	Read upper absolute manual mode offset limit.		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >001A
Data type	SGN32	Length/byte	4
Attributes	read/ write	Unit	[0.1 μm or 0.0001°]
Remarks			

Name	manual additive offset		
Description	Offsets moved by handwheel		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >001B
Data type	SGN32	Length/byte	4
Attributes	read	Unit	[0.1 μm or 0.0001°]
Remarks			

Name	manual active position		
Description	Current axis position including manual offset (without modulo calculation)		
Task	GEO (Port 551)		
Index group	0x12130<C _{ID} >	Index offset	0x<A _{ID} >001C

Data type	SGN32	Length/byte	4
Attributes	read	Unit	[0.1 μm or 0.0001°]
Remarks			

Read the manual mode offset limits

The active absolute manual mode offset limits are read by CNC objects.

Read the absolute manual mode offset limits.

The following applies to the negative offset limits of the 2nd axis in Channel 1:

- Task GEO (Port 551)
- Index group 0x12301
- Index offset 0x2001D

The following applies to the positive offset limits of the 2nd axis in Channel 1:

- Task GEO (Port 551)
- Index group 0x12301
- Index offset 0x2001E

Write the manual mode offset limits

The absolute manual mode offsets limits are read by CNC objects.

Define the offset limits in manual mode

The following applies to the negative offset limits of the 2nd axis in Channel 1:

- Task GEO (Port 551)
- Index group 0x12301
- Index offset 0x2001D

The following applies to the positive offset limits of the 2nd axis in Channel 1:

- Task GEO (Port 551)
- Index group 0x12301
- Index offset 0x2001E

Verify absolute offset limits via the ISG object browser




Fig. 3: Access to absolute offset limits in the ISG object browser

4.6 ISG parameters

Command position (ACS)	
Description	Command position of current cycle in the axis coordinate system
Signal flow	CNC → PLC
ST path	gpAx[axis_idx]^lr_state.active_position_acs_r
Data type	DINT
Unit	0.1 µm
Access	PLC is reading

Move back manual mode offset	
Description	If manual mode is active in the channel and if the commanded axis fails to move, the axis is moved by this command so that afterwards manual mode offset is 0.
Data type	MC_CONTROL_BOOL_UNIT, see description of Control unit
Special features	A rising edge (FALSE → TRUE) at command_w initiates the process. The signal is ignored if a manual mode motion is still active or manual mode offset is already 0.
Access	PLC reads request_r + state_r and writes command_w + enable_w
ST path	gpAx[axis_idx]^ipo_mc_control.manual_mv_back_to_start
Commanded, requested and return values	
ST element	.command_w .request_r .state_r
Data type	BOOL
Value range	rising edge (FALSE → TRUE) triggers backward motion
Redirection	
ST element	.enable_w

4.6.1 HLI parameters up to CNC Build V2.20xx

Command position (ACS)	
Description	Command position of current cycle in the axis coordinate system
Signal flow	CNC → PLC
Unit	0,1 µm
ST path	pAC[axis_idx]^addr^.StateLR_Data.D_ActivePositionACS
Data type	DINT
Access	PLC reads

Stop the motion “Move back manual mode offset”	
Description	The motion that was started by the control unit command “Move back manual mode offset” is stopped by the control unit with this command.
Data type	MCControlBoolUnit, see description of Control Unit
Characteristics	A rising edge (FALSE → TRUE) initiates the command. Up to final axis standstill, the datum Axis-specific interpolator shows that the stop process is active by the HLI_AX_MAN_MV_BACK_WAIT_STOP bit.
Access	PLC reads Request + State and writes Command + Enable
ST Path	pAC[axis_idx]^addr^.McControlIpo_Data.MCControlBoolUnit_ManualMvBackStop
Commanded, requested and return values	

ST Element	.X_Command .X_Request .X_State
Data type	BOOL
Valuation	[TRUE = rising edge stops the motion, FALSE]
Redirection	
ST Element	.X_Enable

5 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Download finder

Our [download finder](#) contains all the files that we offer you for downloading. You will find application reports, technical documentation, technical drawings, configuration files and much more.

The downloads are available in various formats.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for [local support and service](#) on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on our internet page: www.beckhoff.com

You will also find further documentation for Beckhoff components there.

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963-157
e-mail: support@beckhoff.com

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963-460
e-mail: service@beckhoff.com

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963-0
e-mail: info@beckhoff.com
web: www.beckhoff.com

Index

A

ACS	
Position:Command	21
Position:Soll	21

C

Command position	
ACS	21

H

Handbetrieb	8
Offset:zurück fahren:Anhalten	21

M

manual mode	
offset:move back	21

O

Offset	
Handbetrieb:zurück fahren:Stopp	21
manual mode:move back	21

P

P-AXIS-00137	16
P-AXIS-00138	16
P-AXIS-00492	16
P-AXIS-00493	17
P-CHAN-00114	17
P-MANU-00014	17
Position	
Command:ACS	21
Soll:ACS	21

S

Sollposition	
ACS	21
Stopp	
Handbetriebsoffset:zurück fahren	21

More Information:
www.beckhoff.com/TF5200

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

