


Functional description | EN

TF5200 | TwinCAT 3 CNC

Vibration Guard



Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT technology is patent protected, in particular by the following applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702

with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

General and safety instructions

Icons used and their meanings

This documentation uses the following icons next to the safety instruction and the associated text. Please read the (safety) instructions carefully and comply with them at all times.

Icons in explanatory text

1. Indicates an action.

⇒ Indicates an action statement.

DANGER

Acute danger to life!

If you fail to comply with the safety instruction next to this icon, there is immediate danger to human life and health.

CAUTION

Personal injury and damage to machines!


If you fail to comply with the safety instruction next to this icon, it may result in personal injury or damage to machines.

NOTICE

Restriction or error

This icon describes restrictions or warns of errors.

Tips and other notes

 This icon indicates information to assist in general understanding or to provide additional information.

General example

Example that clarifies the text.

NC programming example

Programming example (complete NC program or program sequence) of the described function or NC command.

Specific version information


 Optional or restricted function. The availability of this function depends on the configuration and the scope of the version.

Table of contents

Notes on the documentation.....	3
General and safety instructions	4
1 Overview	8
2 Description	9
2.1 Operating principle	9
2.2 Vibration Guard mode	10
2.3 Contour deviation	13
2.3.1 Tolerance monitoring	13
3 Activating the Vibration Guard	14
4 Limitations, special features	15
5 Programming	16
6 Parameters	19
6.1 Overview	19
6.2 Description	20
7 Support and Service	22
Index	23

List of figures

Fig. 1	Setpoint signal smoothing (red - with Vibration Guard; blue - without Vibration Guard).....	9
Fig. 2	Sensitivity ranges for a residual vibration of 5% at damping=0.1	10
Fig. 3	Comparison of Vibration Guard modes at corner contour (10 Hz and damping=0.1).....	11
Fig. 4	2D contour programming example (green - with VGuard and tolerance monitoring; red - only with VGuard; blue - w/o VGuard)	18

1 Overview



This function is an additional option requiring a license.

Task

Vibrations in a machine tool can have a negative impact on machining results. A particularly critical factor is the natural frequency of the machine or frequencies caused by the machining program which may lead to an excitation of the machine.

The Vibration Guard function permits the following:

- the specific smoothing of setpoint curves at axis level to minimise or prevent critical excitation
- specifying a maximum permitted tolerance to limit contour deviations caused by setpoint smoothing



This function is available as of CNC Build V3.1.3075.02

Programming and parametrisation

Parameter settings and function activation can take place

- either in axis lists or
- by using the programming command #VIB GUARD in the NC program.

Mandatory note on references to other documents

For the sake of clarity, links to other documents and parameters are abbreviated, e.g. [PROG] for the Programming Manual or P-AXIS-00001 for an axis parameter.

For technical reasons, these links only function in the Online Help (HTML5, CHM) but not in pdf files since pdfs do not support cross-linking.

2 Description

In many cases, it is impossible to avoid exciting the machine to vibrate during machining work. The intensity of these vibration excitations may vary considerably from machine to machine.

The Vibration Guard function can specifically prevent or minimise vibrations in the machine by specifying a natural frequency and damping factor.

2.1 Operating principle

The Vibration Guard function acts on the axis setpoint signal of each axis. Vibration Guard smooths the signal so that the setpoint signal only excites the machine slightly within the specified frequency range or not at all. An example of setpoint signal smoothing is depicted in the graphic below using a spring-mass damper system.

The signal curve or smoothing has a different characteristic depending on the Vibration Guard mode used. Smoothing also causes a deviation from the original setpoint curve. Therefore, the use of Vibration Guard entails a certain amount of error or distortion in each axis. This error may result in contour deviations at corners or curvatures in a programmed contour.

A tolerance monitoring function is provided to limit axis errors and is described in the subsection Tolerance monitoring.




Fig. 1: Setpoint signal smoothing (red - with Vibration Guard; blue - without Vibration Guard)



The use of Vibration Guard causes axis errors compared to the setpoint signal if Vibration Guard is not activated.

This results in a contour deviation which can be limited by tolerance monitoring.

2.2 Vibration Guard mode

The smoothing curve and therefore the vibration-preventing effect are dependent on parameters and the Vibration Guard mode selected. Each mode has its own characteristic curve and effect.

The following modes are available when using Vibration Guard:

Modes 1 - 3

- Asymmetrical modes (contours may have different forward and backward motions).
- The higher the mode (1- 3), the more sensitive vibration attenuation is compared to deviations to the set frequency (compared to the actual natural frequency of the machine). The [Figure - Sensitivity ranges \[► 10\]](#) depicts the ranges within which the normalised frequency may lie in order to remain below 5% residual vibration (at damping = 0.1).
- The higher the mode (1- 3), the greater the axis error (or contour deviation) – see [Figure - Comparison of Vibration Guard modes \[► 11\]](#)

Mode 4:

- Symmetrical mode (contours are identical in forward and backward motion).




Fig. 2: Sensitivity ranges for a residual vibration of 5% at damping=0.1

The figure above results in the following standard values for each of the modes regarding acceptable percentage deviations to obtain residual vibrations of below 5%:

Table of standard values for sensitivity

Permitted deviations for max. 5% residual vibration (at damping=0.1)	max. negative deviation	max. positive deviation
Mode 1:	-3%	+3%
Mode 2:	-13%	+19%
Mode 3:	-20%	+33%
Mode 4:	-10%	+13%

Standard values for permitted percentage deviations between the frequency setting and the real frequency to obtain a residual vibration of below 5% (at damping= 0.1).




Fig. 3: Comparison of Vibration Guard modes at corner contour (10 Hz and damping=0.1)

Selecting the right Vibration Mode for an axis

Basic procedure:

1. Measurements of machine frequencies at three points
 2. Calculation of percentage deviations
 3. Assessment of calculation results based on the above [Table of standard value for sensitivity \[► 11\]](#)
- Measurements of machine frequencies at three points:
 - At minimum position of Z axis (6.9 Hz)
 - At centre of workspace of Z axis (6 Hz)
 - At maximum position of Z axis (5.4 Hz)
 - Calculation of percentage deviations:
 - minimum Z position at centre of workspace
6.9/6.0 results in 1.15, i.e. +15% deviation.
 - maximum Z position at centre of workspace
5.4/6.0 results in 0.9, i.e. -10% deviation.

Evaluation of results:

The deviations exceed the permitted range of Mode 1 (+/-3%) but are within of the permitted range of Mode 2 (-13%, +19%). The positive deviation for Mode 4 of +15% is greater than the permitted +13%.

So, in this example, Vibration Guard Mode 2 should be set to a frequency of 6 Hz.

A suitable programming command would then be: #VIB GUARD [FREQ=6 MODE=2]

2.3 Contour deviation

A contour deviation is determined by axis errors. Provided the same Vibration Guard Mode was selected for each axis in the axis group, an axis error is dependent on the following factors:

- Cycle time (longer cycle time = greater error)
- Natural frequency (lower natural frequency = greater error)
- Feed rate (greater feed rate = greater error)

The following options are available to influence an axis error or contour deviation:

- Adapt the influencing factor described above (cycle time, natural frequency, feed rate).
- Assign the same Vibration Guard parameters to all axes in an axis group (if they have different settings).
- Activate automatic tolerance monitoring.

2.3.1 Tolerance monitoring

Tolerance monitoring provides a simple and reliable method for handling the Vibration Guard.

The automatic monitoring of axis errors only intervenes if the Vibration Guard function causes axis errors that are too large.

The user must specify the maximum permitted tolerance in the NC program (see Section [Programming](#) [► 16]).

The operating principle of the tolerance monitor is described in more detail in [FCT-C37, Section "Tolerance monitoring"].

3 Activating the Vibration Guard

The Vibration Guard can be parameterised and/or activated in 2 ways:

1. Permanently and for a specific axis in the axis lists.
2. For a specific program and at the same time for all axes in the #VIB GUARD command in the NC program.

No preconfiguration is required in the axes in order to configure and activate the Vibration Guard.

i If the axes in an axis group are configured with different settings, this will lead to asynchronous axis behaviour. It is therefore recommended to always configure the same settings within an axis group.

However, a mixed form is possible: For example, settings can be preconfigured for specific axes in the axis lists and the Vibration Guard can then be flexibly activated or deactivated by the NC command in the NC program.

Configuration or activation in the NC program has priority over configuration or activation in the axis lists.

The Vibration Guards can also be globally and flexibly activated/deactivated or reparameterised in the NC program for all axes during machining work (between motion blocks) (see [Programming example](#) [▶ 17]).

4 Limitations, special features

The FIR filters and the [Vibration Guard \[▶ 9\]](#) are different independent functions with similar objectives. Both functions smooth the axis setpoint signal to avoid exciting the machine to vibrations. FIR filters achieve this in the broadband. On the other hand, the Vibration Guard filters specific critical frequencies selectively.

NOTICE

It is only possible to use FIR filters and the Vibration Guard simultaneously under certain conditions.

The following combinations are **not** possible and will result in the output of an error message:

- Configuring an FIR filter in one axis and at the same time activating the Vibration Guard in the same axis.
- It is **not possible within an NC program** to program both `#FILTER` and `#VIB GUARD [▶ 16]` commands (Error ID 22060).
- If `#FILTER` commands are used, the Vibration Guard may not be activated in the axis lists.
- If `#VIB GUARD [▶ 16]` commands are used, no filter types may be configured in the axes.

It is permitted to use:

- **an FIR filter in one axis and the Vibration Guard in another axis** but only if activation takes place exclusively in the axis lists. In this case, neither `#FILTER` nor `#VIB GUARD` commands can be used.

Axis exchange commands

Axis exchange commands deactivate the Vibration Guard.

Axis exchange commands deactivate a Vibration Guard if it was activated at that time. If the Vibration Guard is to remain activated after an axis exchange, it must be re-activated by a corresponding `#VIB GUARD [▶ 16]` command. If the Vibration Guard was only activated in the axis lists (P-AXIS-00588), the Vibration Guard will remain activated automatically after an axis exchange.

5 Programming

#VIB GUARD [ON | OFF] [MODE=.. FREQ=.. DAMPING=.. AX_DEV=.. ACC_FACT=..] modal

ON	Activate Vibration Guard.
OFF	Deactivate Vibration Guard.
MODE=..	Specify Vibration Guard mode. (see P-AXIS-00571) default value = 1
FREQ=..	Natural frequency of the machine [Hz] (see P-AXIS-00589) default value = 30
DAMPING=..	Damping factor for machine natural frequency (see P-AXIS-00568) Value range: 0 to 1.0 default value = 0.1
AX_DEV=..	Specify the tolerance for tolerance monitoring in [mm, inch *] default value = 0 (no tolerance monitoring). *with active P-CHAN-00439
ACC_FACT=..	Increase the path velocity at block transitions with the Vibration Guard activated. The greater the value setting, the less the velocity is reduced at the block transition. The condition here is the correct setting of P-AXIS-00013 (a_trans_weight) of the axes: Value range: 1.0 to 10.0 Default value: 1.0



Tolerance monitoring can only be activated in the NC program.

Tolerance monitoring is programmed with the parameter AX_DEV which ensures that contour deviations for each axis remain within the tolerance specified in AX_DEV. Tolerance monitoring can only be configured and activated in the NC program. This takes place by specifying the AX_DEV parameter.

If the AX_DEV parameter is not specified in the NC command, tolerance monitoring is again deactivated. Tolerance monitoring is only activated if a corresponding tolerance was specified.

Tolerance monitoring always monitors all axes and therefore only global control is possible in the NC program.

Program 90° corners – with and without tolerance monitoring

Programming example with simple square contour. Feed rate used=4000mm/min, slope type=TRAPEZ (non-linear) and tolerance (AX_DEV)=0.01mm.

The contour is traversed 3 times:

1. with Vibration Guard and tolerance monitoring.
2. with only Vibration Guard and
3. finally without Vibration Guard activated as reference.

```
N010 G00 G90 X0 Y0 Z0

N020 #SLOPE[TYPE=TRAPEZ]
N030 #VIB GUARD ON [MODE=2 FREQ=40 AX_DEV=0.01]

N040 G01 X0 Y1 F4000
N050 G01 X1 Y1
N060 G01 X1 Y0
N070 G01 X0 Y0

N080 #VIB GUARD ON

N090 G01 X0 Y1 F4000
N100 G01 X1 Y1
N110 G01 X1 Y0
N120 G01 X0 Y0

N130 #VIB GUARD OFF

N140 G01 X0 Y1 F4000
N150 G01 X1 Y1
N160 G01 X1 Y0
N170 G01 X0 Y0

N180 M30
```




Fig. 4: 2D contour programming example (green - with VGuard and tolerance monitoring; red - only with VGuard; blue - w/o VGuard)


6 Parameters

6.1 Overview

ID	Parameter	Description
P-AXIS-00568	damping	Damping factor of natural frequency
P-AXIS-00571	mode	Vibration Guard mode
P-AXIS-00588	active	Activating the Vibration Guard
P-AXIS-00589	freq	Natural frequency of machine

Description	Axis parameters	Programming parameter
Activation	vib_guard.active	ON
Deactivation	-	OFF
Mode	vib_guard.mode	MODE
Natural frequency of machine	vib_guard.freq	FREQ
Damping factor of natural frequency	vib_guard.damping	DAMPING
Tolerance monitoring limit [mm]	-	AX_DEV
Path velocity at block transitions	-	ACC_FACT

6.2 Description

P-AXIS-00568	Damping factor of natural frequency
Description	<p>Besides the natural frequency itself, this parameter can also specify the damping factor of the natural frequency which is defined as follows:</p> $DAMPING = \frac{1}{\sqrt{1 + \left(\frac{2\pi}{\delta}\right)^2}}, \quad \delta = \ln(A_1/A_2)$ 
Parameter	vib_guard.damping
Data type	REAL64
Data range	0 ≤ damping ≤ 1
Axis types	T, R, S
Dimension	T: ---- R,S: ----
Default value	0.1
Drive types	----
Remarks	The parameter is available as of V3.1.3075.00

P-AXIS-00571	Vibration Guard mode
Description	<p>This parameter defines Modes 1 - 4 of the <u>Vibration Guard</u> [► 8] function.</p> <p>Modes 1– 3:</p> <ul style="list-style-type: none"> • Asymmetrical modes (contours may have different forward and backward motions). • The higher the mode (1-3), the less sensitive to deviations from the actual natural frequency • The higher the mode (1-3), the larger the axis error (or contour deviation) <p>Mode 4:</p> <ul style="list-style-type: none"> • Symmetrical mode (contours are identical in forward and backward motion).
Parameter	vib_guard.mode
Data type	UNS32
Data range	1 ≤ mode ≤ 4

Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	1	
Drive types	----	
Remarks	See Table of sensitivity to natural frequency: [► 11] The parameter is available as of V3.1.3075.00	

P-AXIS-00588	Activating the Vibration Guard	
Description	This parameter can permanently activate or deactivate the Vibration Guard [► 8] function at program start.	
Parameter	vib_guard.active	
Data type	BOOLEAN	
Data range	0/1	
Axis types	T, R, S	
Dimension	T: ----	R,S: ----
Default value	0	
Drive types	----	
Remarks	Alternatively, the Vibration Guard can also be activated or deactivated by the NC command #VIB GUARD / OFF [► 16] . The parameter is available as of V3.1.3075.00	

P-AXIS-00589	Machine natural frequency	
Description	This parameter specifies the machine's natural frequency which the Vibration Guard [► 8] function is to suppress.	
Parameter	vib_guard.freq	
Data type	REAL64	
Data range	1 ≤ freq	
Axis types	T, R, S	
Dimension	T: Hz	R,S: Hz
Default value	30	
Drive types	----	
Remarks	The parameter is available as of V3.1.3075.00	

7 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Download finder

Our [download finder](#) contains all the files that we offer you for downloading. You will find application reports, technical documentation, technical drawings, configuration files and much more.

The downloads are available in various formats.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for [local support and service](#) on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on our internet page: www.beckhoff.com

You will also find further documentation for Beckhoff components there.

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

Hotline: +49 5246 963-157
e-mail: support@beckhoff.com

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: +49 5246 963-460
e-mail: service@beckhoff.com

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963-0
e-mail: info@beckhoff.com
web: www.beckhoff.com

Index

P

P-AXIS-00568	20
P-AXIS-00571	20
P-AXIS-00588	21
P-AXIS-00589	21

More Information:
www.beckhoff.com/TF5200

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

