
BECKHOFF New Automation Technology

# Manual | EN

TF5420

# TwinCAT 3 | Motion Pick-and-Place



# Table of contents

1	Fore	word	. 5				
	1.1	Notes on the documentation	5				
	1.2	For your safety	5				
	1.3	Notes on information security	. 7				
2	Intro	duction	8				
3	Over	view of the new functions	9				
4	Grou	p State Diagram	11				
5	MC G	Group (TF5420 TwinCAT 3 Motion Pick-and-Place)	13				
	5.1	Configure an MC Group	13				
5.2 MC Group Coordinated Motion							
	5.3	MC Group with Pick-and-Place	20				
6	Spati	ial Configuration	22				
	6.1	Coordinate Frame Object	22				
	6.2	Conveyor Tracking Object	22				
	6.3	Conveyor Tracking Behavior	22				
	6.4	Node Connector Object	23				
	6.5	Configuring a Node Connector	23				
	6.6	Configure for MC_TrackConveyorBelt	28				
	6.7	Background Information	35				
7	PLC	Libraries	38				
	7.1	Tc3_McCoordinatedMotion	38				
		7.1.1 Function Blocks	40				
		7.1.2 Datatypes	76				
	7.2	Tc3_Mc3Definitions	86				
		7.2.1 Datatypes	86				
8	Samp	ples	95				
9	Appe	endix	96				
	9.1	Cyclic Group Interface	96				
		9.1.1 NcToPlc	96				
		9.1.2 PlcToNc	97				
	9.2	Index Offset Specification for MC Group Parameters	97				
	9.3	Differences between MC2 and MC3	97				
	9.4						

## BECKHOFF

## 1 Foreword

### **1.1** Notes on the documentation

This description is intended exclusively for trained specialists in control and automation technology who are familiar with the applicable national standards.

The documentation and the following notes and explanations must be complied with when installing and commissioning the components.

The trained specialists must always use the current valid documentation.

The trained specialists must ensure that the application and use of the products described is in line with all safety requirements, including all relevant laws, regulations, guidelines, and standards.

#### Disclaimer

The documentation has been compiled with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without notice. Claims to modify products that have already been supplied may not be made on the basis of the data, diagrams, and descriptions in this documentation.

#### Trademarks

Beckhoff<sup>®</sup>, ATRO<sup>®</sup>, EtherCAT<sup>®</sup>, EtherCAT G<sup>®</sup>, EtherCAT G10<sup>®</sup>, EtherCAT P<sup>®</sup>, MX-System<sup>®</sup>, Safety over EtherCAT<sup>®</sup>, TC/BSD<sup>®</sup>, TwinCAT<sup>®</sup>, TwinCAT/BSD<sup>®</sup>, TwinSAFE<sup>®</sup>, XFC<sup>®</sup>, XPlanar<sup>®</sup>, and XTS<sup>®</sup> are registered and licensed trademarks of Beckhoff Automation GmbH.

If third parties make use of the designations or trademarks contained in this publication for their own purposes, this could infringe upon the rights of the owners of the said designations.

# Ether**CAT.**

EtherCAT<sup>®</sup> is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

#### Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The distribution and reproduction of this document, as well as the use and communication of its contents without express authorization, are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event that a patent, utility model, or design are registered.

#### Third-party trademarks

Trademarks of third parties may be used in this documentation. You can find the trademark notices here: <u>https://www.beckhoff.com/trademarks</u>.

### **1.2** For your safety

#### Safety regulations

Read the following explanations for your safety.

Always observe and follow product-specific safety instructions, which you may find at the appropriate places in this document.

#### Exclusion of liability

All the components are supplied in particular hardware and software configurations which are appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

#### **Personnel qualification**

This description is only intended for trained specialists in control, automation, and drive technology who are familiar with the applicable national standards.

#### Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

#### Personal injury warnings

Hazard with high risk of death or serious injury.

**WARNING** 

Hazard with medium risk of death or serious injury.

There is a low-risk hazard that could result in medium or minor injury.

#### Warning of damage to property or environment

NOTICE

The environment, equipment, or data may be damaged.

#### Information on handling the product

This information includes, for example: recommendations for action, assistance or further information on the product.

## **1.3** Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <u>https://www.beckhoff.com/secguide</u>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <u>https://www.beckhoff.com/secinfo</u>.

# 2 Introduction

The TF5420 TwinCAT 3 Motion Pick-and-Place software package is installed together with the TF5400 software package.

#### Target system

Windows 10

#### **TwinCAT 3 Motion Pick-and-Place**

TF5420 TwinCAT 3 Motion Pick-and-Place executes multi-dimensional motions. It was specially developed for the requirements of pick-and-place applications. It should be applied to motions where the precise path dynamics in segment transitions are not so important, but where the user wishes to get from one point to another as quickly as possible. The *Tc3\_McCoordinatedMotion* library contains all the associated function blocks.

#### Additional licensing requirements

TF5420 TwinCAT 3 Motion Pick-and-Place requires the TC1260 license.

## 3 Overview of the new functions

As of TF5400 V3.3.72

New: In the GroupDisabled state, PTP commands of the Tc2\_MC2 library (e.g. MC\_MoveAbsolute) are
permitted on axes of the group.

As of TF5400 V3.3.19

- MC-Group Pick-and-Place no longer available.
- New: function block <u>MC\_SetCoordinateTransformPreparation</u> [▶ <u>54</u>] for the MC-Group Coordinated Motion
- · Requires TwinCAT V3.1.4024.40 or higher

As of TF5400 V3.2.27 for the MC Group Coordinated Motion:

- New: Introduction of additional dynamic constraints for path and auxiliary axes.
- New: Optionally, the override also affects the synchronization phase for the MC\_TrackConveyorBelt.
- Optimizations to the MC\_TrackConveyorBelt that prevent SAF cycle misalignment between conveyor (master) and slave axis.
- Optimizations of the error reaction for the MC\_TrackConveyorBelt. In the event of a runtime error of the conveyor belt (master), an active MC\_MovePath is not aborted and an error reaction is to be triggered via the PLC.
- Requires an x64 platform

As of TF5400 V3.1.10.64:

- New: In a CM group with Geo Blending, a blocker that is triggered early enough before it becomes active will be blended over and passed on without interruption.
- Requires TwinCAT V3.1.4024.24 or higher

#### **As of** TF5400 V3.1.10.1:

- New group type MC Group Coordinated Motion is available.
- Cyclic interface is extended for MC Group Coordinated Motion.
- New function blocks for MC Group Coordinated Motion:
  - MC\_BlockerPreparation
  - MC\_ReleaseBlocker
  - MC\_GroupReadBlockerStatus
  - MC\_DwellTimePreparation
- MC\_GroupHalt is implemented for MC Group Coordinated Motion.
- mcTransModeCornerDistance, mcCircPathchoiceShortSegment and mcCircPathchoiceLongSegment are implemented for MC Group Coordinated Motion.
- Requires TwinCAT V3.1.4024.7 or higher

#### As of TF5400 V3.1.6.27:

- The remaining time and distance of the current segment can be read via ADSREAD.
- · Requires TwinCAT V3.1.4022.0 or higher

#### As of TF5400 V3.1.6.3:

• New function blocks for spatial transformations, i.e. for changing the reference system (MC SetCoordinateTransform) and for conveyor tracking (MC TrackConveyorBelt).

#### As of TF5400 V3.1.4.4:


• New: From software version 3.1.4.4 MC\_MAXIMUM is supported as input value. For more detailed information please refer to the documentation for the respective function block.

As of TF5400 V3.1.2.47:

New function block MC\_MoveCircularAbsolutePreparation.

# 4 Group State Diagram

The state diagram describes the state of a Coordinated Motion group. The states described here can be read from the PLC using the function block MC\_GroupReadStatus.





Note	Description
1	Applicable for all non-administrative (movement) function blocks.
2	In the GroupStopping state, many function blocks can be called, but they
	are not executed. Exceptions are <u>MC GroupDisable [) 43]</u> and
	MC_UngroupAllAxes [ 58], which cancel the stop and create the transition to the GroupDisabled state.
3	MC_GroupStop [ ] 62].DONE
4	The number of axes in the group (added via <u>MC AddAxisToGroup [&gt; 40]</u> ) must be equal to the number of axes in the spatial axis convention plus the Additional Axes Count.
5	-
6	MC_GroupDisable can be called in all states and changes the state to

GroupDisabled. When MC\_GroupDisable is called in an error state, the state changes to GroupErrorDisabled.



- 7 The state change to GroupErrorEnabled occurs in the axis/group error case from any state in which the group is enabled.
- 8 The state change occurs when "blsControlLoopClosed" is TRUE for all axes. bPositiveDirection"/"bNegativeDirection" do not have to be enabled.

9

10 <u>MC\_GroupReset</u> [▶<u>48]</u> has no effect if the state is different from GroupErrorStop. MC\_GroupReset must be called to exit the GroupErrorStop state.

# 5 MC Group (TF5420 TwinCAT 3 Motion Pick-and-Place)

### 5.1 Configure an MC Group


Basically, the configuration described here is valid for all Motion Objects in the Advanced Motion Pack.

1. Add new "NC/PTP NCI Configuration" in the Motion section.

Þ	SYSTEM			
		°	Add New Item	Ins
	🙆 SAFETY 🎦		Add Existing Item	Shift+Alt+A
	‰, C++	â	Paste	Ctrl+V
V	Þ <mark>∑</mark> I/O		Paste with Links	
		<u>6</u>	Hide MOTION Configuration	

Insert Motion Configuration										
Туре:	CNC Configuration	Ok Cancel								
Name:	NC-Task 1									

2. Add all axes to the NC-Configuration.



Insert NC Axis									
Name:	Axis 1 Multiple: 4 🔿 OK								
Туре:	Continuous Axis  Cancel								
Parameter:	(default)								
Comment:									

3. Add the appropriate Group to the entry "Objects" in the NC-Configuration: For Coordinated Motion, multi-dimensional movements: <u>MC Group Coordinated Motion</u> [▶ 18] or <u>MC</u> Group with Pick-and-Place [▶ 20].

<ul> <li>MOTION</li> <li>MOTION</li> <li>MC-Task 1 SAF</li> <li>NC-Task 1</li> <li>MC-Task 1</li> <li>Image</li> <li>Tables</li> </ul>			
Dipects ▷ ﷺ Axes PLC SAFETY	° to	Add New Item Add Existing Item Add New Folder	<mark>Ins</mark> Shift+Alt+A
‰. C++ ▷ <mark>2</mark> I/O	â	Reload System TMC Files Paste Paste with Links	Ctrl+V

## BECKHOFF

#### Insert TcCom Object

Search:	Name: Group1 (MC Group Coordinated Motion)	OK
Туре:	Beckhoff Automation GmbH     Motion Control     Spatial Configuration     Kinematic Transformations     XTS configurations     MC Group with Pick-And-Place [Configuration]     MC Group Coordinated Motion [Module]     CA Group [Module]	Cancel Multiple: 1
File:	C:\TwinCAT\3.1\Config\Modules\TcNc3.tmc	

- MOTION
- NC-Task 1 SAF
   NC-Task 1 SVB
   Image
   Tables
   Objects
   Group 1 (MC Group Coordinated Motion)
   Group Outputs
   Group Inputs
- Check the Tasks in the Group. Context ID 0 has to be set to "NC-Task 1 SAF". Context ID 1 has to be set to "NC-Task 1 SVB".

vinCAT Project1 🥲 🗙									
Object	Context	Parameter (Init)	Data Area						
Context:				0		$\sim$			
Depen	d On:			Parent Object ~					
Ne	ed Call Fro	m Sync Mapping							
Data A	veas:		Ir	terfaces:					
☐ 1 'Group Outputs' ☐ 2 'Group Inputs'									
Data P	ointer:		  r	terface Pointer:					
Result	Result:								
ID	Ta	ask		Name	Priority	Cycle Time (µs)	Task Port	Symbol Port	
0	05	5000010	-	NC-Task 1 SAF	4	2000	501	501	
1	05	5000020	-	NC-Task 1 SVB	8	10000	511	511	

- 5. Configure the group parameters according to the desired application. For more explanations referring to the group parameters see the following sections.
- To address the group from the PLC a cyclic interface has to be declared and linked to the IO of the group (see PLC Library <u>Tc3\_McCoordinatedMotion [▶ 18]</u>). To address and enable the axes the library "Tc2\_Mc2" has to be added to the project.
- ⇒ A new "NC/PTP NCI Configuration" has been established.

```
VAR
stGroupRef : AXES_GROUP_REF;
END VAR
```

<ul> <li>Solution 'TwinCAT Project2' (1 project)</li> <li>TwinCAT Project2</li> <li>SYSTEM</li> <li>MOTION</li> <li>MOTION</li> <li>MC-Task 1 SAF</li> <li>NC-Task 1 SVB</li> <li>Image</li> <li>Tables</li> <li>Objects</li> <li>Scoup1 (MC Group Coordinated Motion)</li> <li>Group Outputs</li> </ul>
ToPLC
<ul> <li>Group Inputs</li> <li>Axes</li> <li>PLC</li> <li>Untitled1</li> <li>External Types</li> <li>External Types</li> <li>References <ul> <li>Tc2_MC2</li> <li>Tc2_Standard</li> <li>Tc3_Mc3Definitions</li> <li>Tc3_McCoordinatedMotion</li> <li>Tc3_Module</li> <li>DUTs</li> <li>GVLs</li> <li>POUs</li> <li>MAIN (PRG)</li> <li>VISUs</li> <li>PlcTask (PlcTask)</li> <li>Untitled1 Instance</li> </ul> </li> </ul>
SAFETY

# BECKHOFF

Attach Variable ToPLC (Output)							
Search: PLC Untitled1 MAIN.stGroupRef.NcToPlc > IB 385272.0, MC.NC3TOPLC_GROU CA > IB 385272.0, MC.NC3TOPLC_CAGROUP_REF [192.0] Dxd > IB 385272.0, MC.NC3TOPLC_DXDGROUP_REF [192.0] CM > IB 385272.0, MC.NC3TOPLC_CMGROUP_REF [192.0]	Show Variables Only Unused Exclude disabled Exclude other Devices Exclude same Image Show Tooltips Sort by Address Show Variable Groups Collapse last Level Show Variable Types Matching Type Matching Size All Types Array Mode						
	Offsets Continuous Ignore Gaps Show Dialog Variable Name / Comment						
	/ Hand over						
< >>	Cancel OK						

### 5.2 MC Group Coordinated Motion

Object Context Parameter (Init) Data Area

Name	Value	CS	5	Unit	Туре	PTCID	Comment
Spatial Axes Convention	mcAxesConv4DCartesianXYZC				MC.MC_AXES_CONVENTION	0x05030200	
Additional Axes Count	0				UDINT	0x05030201	Number of axes without a spatial interpretatio
Blending Strategy	mcBlendingGeo	<b>_</b>			MC.MC_BLENDING_STRATEGY	0x05030202	
Time-Override Ramp Time	2.0		5	s	LREAL	0x050300A6	Time it takes to transition the time-override fa
Tracking Override Behavior	Disable				MC.OverrideBehavior	0x050300E3	Defines whether the tracking movement is aff
Blending Path Type	mcBlendingPathTypePoly5				MC.MC_BLENDING_PATH_TYPE	0x05030203	

#### Parameter (Init)

#### **Spatial Axes Conventions**

Three axes conventions can be set.

The axes conventions define how the axes are interpreted in the axis group. In combination with "Additional Axes Count", they define the dimension of the axis group and thus the number of axes that need to be added, as well as the way in which each of the added axes is interpreted.

Parameter	Value	Туре	Description
Spatial	mcAxesConv2DCartesianXY	MC.MC_AXES_CONVENTI	A 2D group consisting of X, Y. The
Axes		ON	order of the translatory axes in the
Convention			configuration determines the order of
			translation.

Parameter	Value	Туре	Description
Spatial Axes Convention	mcAxesConv3DCartesianXY Z	MC.MC_AXES_CONVENTI ON	A 3D group consisting of X, Y, Z. The order of the translatory axes in the configuration determines the order of translation.
Spatial Axes Convention	mcAxesConv4DCartesianXY ZC	MC.MC_AXES_CONVENTI ON	A 4D group consisting of $X, Y, Z$ and a rotary axis around $Z$ (C). The order of the translatory and rotary axes in the configuration determines the order of translation and rotation.

#### Additional Axes Count

Number of axes in the axis group that have no geometric interpretation. Between 0 and 8 axes of this type can be inserted.

#### Blending Strategy

Sets the blending strategy.

Parameter	Value	Туре	Description
Blending Strategy	mcBlendingGeo	TEGY – –	The blending path is defined geometrically and then executed with the dynamics allowed for the path.
Blending Strategy	mcBlendingSuperpos		The blending path results dynamically from the superposition of two segments in the blending area.

#### Time Override Ramp Time

Ramp time for override modification from 0 % to 100 %. The time override is superimposed on the actual profile. This can result in higher dynamics in total during the override changes than were parameterized at the group.

#### Tracking Override Behavior

Defines whether the portion of the movement for accurate synchronization is subject to override or not.

Available from TF5400 3.2.27.

Parameter	Value	Туре	Description
Tracking Override Behavior	Disable		The group override has no effect on the portion of movement for accurate synchronization.
Tracking Override Behavior	Enable	MC.OverrideBehavior	The group override also affects the portion of movement for accurate synchronization.

#### GeoBlending-specific parameters

#### Blending Path Type


Defines the geometry used for the blending path.

Parameter	Value	Туре	Description
Blending Path Type	mcBlendingPathTypeIgnore	MC.MC_BLENDING_PATH _TYPE	No blending.
Blending Path Type	mcBlendingPathTypePoly5		The blending path uses a fifth degree polynomial.

## 5.3 MC Group with Pick-and-Place

The MC Group connects axes in order to execute a multi-dimensional motion.

For new projects, the use of the "MC Group Coordinated Motion" is recommended. As of TF5400 3.2.27, no new projects can be created with the MC Group Pick-and-Place.



#### Axes conventions

Tab: Parameter (Init). Three axes conventions can be set.

The axes conventions define how the axes are interpreted in the axis group. They define the dimension of the axis group and thus the number of axes that need to be added, as well as the way in which each of the added axes is interpreted.

Parameter	Value	Туре	Description
Axes Convention	mcAxesConv2DCartesianXY	MC.MC_AXES_CONVENTI ON	A 2D group consisting of $x, y$ . The order of the translatory axes in the configuration determines the order of translation.
Axes Convention		MC.MC_AXES_CONVENTI ON	A 3D group consisting of $x, y, z$ . The order of the translatory axes in the configuration determines the order of translation.
Axes Convention	mcAxesConv4DCartesianXY ZC	MC.MC_AXES_CONVENTI ON	A 4D group consisting of $x, y, z$ and a rotary axis around $z$ (C). The order of the translatory and rotary axes in the configuration determines the order of translation and rotation.

#### Axis group parameters of the pick-and-place kernel

Solution Explorer 👻 🕂 🗙	PnpSimp	leSample → ×						
	Object	Context Parameter (Init)						
Search Solution Explorer (Ctrl+ü)				1	1	1	1	
Jolution 'PnpSimpleSample' (2 projects)		Name	Value	CS	Unit	Туре	PTCID	Comment
PnpSimpleSample		NET Cycle Time Divisor	1			UINT	0x050300A5	improves accuracy caused
SYSTEM		Time-Override ramp time	3.0		s	LREAL	0x050300A6	Ramp time for override cha
MOTION								
NC-Task 1 SAF								
💼 NC-Task 1 SVB								
<b>≜</b> ₽ Image								
Tables								
Objects								
MC Group_Obj1 (MC Group)								
Group Outputs								
Group Inputs								
Pick-And-Place Kernel_Obj1 (Pick-And-Place Kernel)								

Tab: Parameter (Init).

Parameter	Unit	Туре	Description
NET Cycle Time Divisor			Improves accuracy on the basis of temporal discretization.
Time Override Ramp Time	S		Ramp time for override modification from 0 % to 100 %.

The pick-and-place setpoint generator was specially developed for the requirements of pick-and-place applications. It is intended for motions where the precise path dynamics are not so important, but where the user wishes to get from one point to another as quickly as possible. It is therefore permissible for the algorithm to violate restrictions in the path dynamics within the tolerance sphere. Axis restrictions are never violated.

# 6 Spatial Configuration

The Spatial Configuration describes geometrical relationships between reference frames. Those relationships are of translation and rotation type.

## 6.1 Coordinate Frame Object

Coordinate Frame Objects can be used to hierarchically build up geometrical translation and rotation relationships. For straight interpretation the x-direction of the final element within the hierarchy should point into the conveying direction.

Parameter	Description	Unit
Rotation Convention	Convention used for the calculation of rotations. Default is DIN9300 Z"Y'X where Rotation 3 is the parameter for Z", Rotation 2 is the parameter for Y' and Rotation 1 is the parameter for X.	
Definition Direction	Indicates the direction in which the displacement is programmed (from the point of view of the reference system or the MCS).	
Translation x	Translation in the x-axis direction.	mm
Translation Y	Translation in the y-axis direction.	mm
Translation z	Translation in the z-axis direction.	mm
Rotation 1	Rotation axis is defined by the Rotation Convention.	0
Rotation 2	Rotation axis is defined by the Rotation Convention.	0
Rotation 3	Rotation axis is defined by the Rotation Convention.	0

### 6.2 Conveyor Tracking Object

A Conveyor Tracking object can be used to synchronize an axes group with a conveyor belt. It is added as a child object to a Coordinate Frame object. While the Coordinate Frame describes the static transformation (translation and/or rotation) to the conveyor belt system, the Conveyor Tracking object handles the dynamic part of the tracking.

The Conveyor Tracking parameters are listed in the following table. The dynamics parameters are default values that are used when MC\_DEFAULT is chosen for the corresponding parameter in the MC\_TrackConveyorBelt function block instance.

Parameter	Description	Unit
Velocity	Default velocity for synchronization.	mm s⁻¹
Acceleration	Default acceleration for synchronization.	mm s <sup>-2</sup>
Deceleration	Default deceleration for synchronization.	mm s <sup>-2</sup>
Jerk	Default jerk for synchronization.	mm s <sup>-3</sup>
Default Tracking Behavior	Conveyor tracking behavior after InSync has been reached.	
Synchronization Tolerance Distance	Distance to tracking target in which the tracking is considered synchronized (InSync = TRUE). Usage of this parameter might be useful if the master signal is noisy. This parameter only has influence if MC Group Coordinated Motion is in use.	mm

## 6.3 Conveyor Tracking Behavior

The Default Tracking Behavior defines the kind of default disturbance rejection during tracking. A disturbance may be an unexpected impulse or a conveyor indexing movement.

#### mcTrackingBehaviorDynLimited

 $\label{eq:Velocity} Velocity \ synchronization \ to \ the \ {\tt ConveyorBelt} \ is \ maintained \ using \ the \ given \ {\tt Acceleration},$ 

Deceleration **and** Jerk.

Relevant when disturbances are not known precisely or disturbance dynamics are significant.

Dynamic limits are input to the MC\_TrackConveyorBelt function block. The values from the Conveyor Tracking Object will be used when MC\_Default is input to the function block. When the conveyor indexes, the response will be limited by the dynamic parameters.

When the DynLimited setting is used, the response is compensated with the jerk limit. The function block output MC TrackConveyorBelt.InSync indicates when there is synchronization.



#### InSync

Using the mcTrackingBehaviorDynLimited operation mode the InSync = TRUE output may disappear when the synchronized position has been lost. Staying within the parameterized dynamics the algorithm tries to return to the synchronized position on its own. When the synchronized position has been reached the InSync = TRUE output appears, again.

#### mcTrackingBehaviorStayInSync

Velocity synchronization to the ConveyorBelt is maintained with non-limited Acceleration, Deceleration and Jerk.

When the conveyor indexes, the tracking response will not be limited. Rather, the tracking response intends to remain synchronized and follow the conveyor unconditionally. The function block output MC TrackConveyorBelt.InSync indicates when there is synchronization.

#### lnSync

Using the mcTrackingBehaviorStayInSync operation mode when the InSync signal has once become TRUE, it stays TRUE as long as the command is active.

### 6.4 Node Connector Object

A Node Connector is an administrative Object, that establishes a transformation from one reference frame (node) to another.

Parameter	Description
Start node	Object ID of the starting point for the coordinate transformation. The default ID value is 0 and stands for the $WCS$ , the World Coordinate System.
End node	Object ID of the end point of the coordinate transformation, e.g. a point on the Conveyor Belt.

### 6.5 Configuring a Node Connector

Configuring for  $MC\_SetCoordinateTransform$  is illustrated at the example of a pallet located relative to the WCS or MCS coordinate system.

#### Node connector objects

Node connector objects are used by MC\_SetCoordinateTransform and MC\_TrackConveyorBelt. Instead of coordinate frames, node connector objects are addressed by the PLC as representatives.

#### Example

To introduce a coordinate transform using MC\_SetCoordinateTransform:

1. Insert an MC Group.

<ul> <li>MOTION</li> <li>MC-Task 1 SAF</li> <li>NC-Task 1 SVE</li> <li>Image</li> <li>Tables</li> </ul>	3		
🖀 Objects 👘			
🚉 Axes	Add New Ite	m I	ns

#### Insert TcCom Object

Search:	Name: Group1 (MC Group Coordinated Motion)	ОК
Туре:	Beckhoff Automation GmbH Motion Control Spatial Configuration Kinematic Transformations XTS configurations MC Group with Pick-And-Place [Configuration] MC Group Coordinated Motion [Module] CA Group [Module]	Cancel Multiple: 1
File:	C:\TwinCAT\3.1\Config\Modules\TcNc3.tmc	]

2. Insert a Node Connector.

D E Obie	cts			
ਤ੍ਰੈਂਬ Axes	° 🗆	Add New Item	Ins	

# BECKHOFF

#### Insert TcCom Object

Search:	Name: PALLET (Node Connector)	OK
<u>Type:</u>	Beckhoff Automation GmbH Motion Control Spatial Configuration Node Connector [Module] Corveyor Tracking [Module] Conveyor Tracking [Module] Conveyor Tracking [Module] MC Group with Pick-And-Place [Configuration] MC Group Coordinated Motion [Module] CA Group [Module]	Cancel Multiple: 1
File:	C:\TwinCAT\3.1\Config\Modules\TcNcKin.tmc	

#### 3. Insert a Coordinate Frame.

Insert TcCom Object							
Search: Name: PALLET (Coordinate Frame)	ОК						
Type: Beckhoff Automation GmbH Motion Control Spatial Configuration Node Connector [Module] Coordinate Frame [Module] Conveyor Tracking [Module] Conveyor Tracking [Module] Configurations MC Group with Pick-And-Place [Configuration] MC Group Coordinated Motion [Module] CA Group [Module]	Cancel Multiple: 1						
File: C:\TwinCAT\3.1\Config\Modules\TcNcKin.tmc							

4. Enter relevant Node Connector Parameters - in this example the end node refers to the pallet object identification.

Name	Comment
Configuration	
Start node	First spatial node.
	Coordinates are interpreted in respect to this reference node.
	0x0 represents the world coordinate system (WCS).
End node	Last spatial node.
	This node is moved in respect to the start node.
	0x0 represents the world coordinate system (WCS).

	Name	Value	CS	Unit	Туре
-	Configuration				
	Start node	00000000 💌			OTCID
	End node	01010040 💌		PALLET (Coordinate Frame)	OTCID

5. Enter relevant Coordinate Frame Parameters.


	Name	Value	CS	Unit	Туре
-	Configuration				
	Rotation convention	Rotation_Z3Y2X1_DIN9300 💌	$\Box$		MC.CoordInterpretation_SO3
	Definition direction	toReference 💌	$\Box$		MC.ReferenceDefDir
-	Kinematic				
	Translation X	0.0		mm	LREAL
	Translation Y	150.0		mm	LREAL
	Translation Z	0.0		mm	LREAL
	Rotation 1	0.0		•	LREAL
	Rotation 2	0.0		•	LREAL
	Rotation 3	0.0		•	LREAL

6. Link the inserted Node Connector to the  ${\tt PLC}$  .

PLC	TY Add New Item
0)	Standard PLC Project Plc Templates
म म म	References Tc3_McCoordinatedMotion Tc3_Module Tc3_Standard Tc3_System
GVL +⊐	×
1 2 3 4	<pre>{attribute 'qualified_only'} VAR_GLOBAL</pre>

t Context Parameter (Init)	Data Area	Symbol Initialization	
Name	Value	Unit	Туре
GVL.oidEndNode_PALLET	01010030 💌	PALLET (Node Connector)	Tc3_McCoordinatedMotion.MC_COORD_REF

⇒ Finally, you can insert the MC SetCoordinateTransform function block.




The axis group AxisGroup is linked with the Pick-and-Place function blocks.

For axis movements a move command has to be programmed, e.g. MovePath.

## 6.6 Configure for MC\_TrackConveyorBelt

To track a conveyor belt using MC\_TrackConveyorBelt:

1. Insert an MC Group.



#### Spatial Configuration

# **BECKHOFF**

#### Insert TcCom Object

Search:	Name: Group1 (MC Group Coordinated Motion)	OK
Туре:	Beckhoff Automation GmbH Motion Control Spatial Configuration Kinematic Transformations XTS configurations MC Group with Pick-And-Place [Configuration] MC Group Coordinated Motion [Module] CA Group [Module]	Cancel Multiple: 1
File:	C:\TwinCAT\3.1\Config\Modules\TcNc3.tmc	

2. Insert a Node Connector.

# BECKHOFF

#### Insert TcCom Object

Search:	Name:         CB (Node Connector)	OK
<u>I</u> ype:	Beckhoff Automation GmbH Motion Control Spatial Configuration Coordinate Frame [Module] Conveyor Tracking [Module] Conveyor Tracking [Module] Conveyor Tracking [Module] Conveyor Tracking [Module] MC Group with Pick-And-Place [Configuration] MC Group Coordinated Motion [Module] CA Group [Module]	Cancel <u>Multiple:</u> Insert Instance Reload
File:	C:\TwinCAT\3.1\Config\Modules\TcNcKin.tmc	

#### 3. Insert a Coordinate Frame.

Insert TcCo	m Object			
Search:		Name:	CB (Coordinate Frame)	ОК
Type:		rol Configuration le Connector <mark>rdinate Frame</mark> veyor Tracki ic Transforma nfigurations	[Module] e [Module] ng [Module]	Cancel Multiple: 1 💽 Insert Instance Reload
File:	C:\TwinCAT\3.1\Config\	Modules\Tcl	NcKin.tmc	

4. Insert Conveyor Tracking. Firstly, a Coordinate Frame has been created. Secondly, the Conveyor Tracking Object has to be added as a child element to the Coordinate Frame created previously.

	Insert TcCo	om Object			
	Search:		Name:	CB (Conveyor Tracking)	OK
	Type:	Environmentation Environment	hation GmbH trol Configuration de Connector ordinate Frame iveyor Tracki iveyor Tracki nigurations up with Pick- up Coordinate	[Module] s [Module] ng [Module]	UK Cancel Multiple: 1 + Insert Instance Reload
	File:	C:\TwinCAT\3.1\Config	Modules\Tcl	NcKin.tmc	
4		C-Task 1 SAF NC-Task 1 SVB Image	ector) Frame)	ated Motion)	
	PLC     PLC     N     ■     N	* Axes ciSimpleSample NciSimpleSample Pi NciSimpleSample In DicTask Inputs PIcTask Outputs	-		

5. Enter relevant Node Connector Parameters - the end node refers to the conveyor tracking object identification.

Name	Comment		
Configuration			
Start node	First spatial node.		
	Coordinates are interpreted in respect to this reference node.		
	0x0 represents the world coordinate system (WCS).		
End node	Last spatial node.		
	This node is moved in respect to the start node.		
	0x0 represents the world coordinate system (WCS).		

	Name	Value	CS	Unit	Туре	PTCID
-	Configuration					
	Start node	00000000 💌	$\Box$		OTCID	0x05010108
	End node	01010050 💌	$\Box$	CB (Conveyor Tracking)	OTCID	0x05010107

6. Enter relevant Coordinate Frame Parameters.

**BECKHOFF** 

Name	Comment		
Configuration			
Rotation convention	Set the interpretation of the rotation angles.		
Definition direction	Set the definition direction.		
Kinematic			
Translation X	Translation in x-direction		
Translation Y	Translation in y-direction		
Translation Z	Translation in z-direction		
Rotation 1	Rotation angle 1, interpretation set by rotation convention		
Rotation 2	Rotation angle 2, interpretation set by rotation convention		
Rotation 3	Rotation angle 3, interpretation set by rotation convention		


	Name	Value	CS	Unit	Туре
-	Configuration				
	Rotation convention	Rotation_Z3Y2X1_DIN9300			MC.CoordInterpretation_SO3
	Definition direction	toReference 💌			MC.ReferenceDefDir
-	Kinematic				
	Translation X	0.0		mm	LREAL
	Translation Y	150.0		mm	LREAL
	Translation Z	0.0		mm	LREAL
	Rotation 1	0.0		۰	LREAL
	Rotation 2	0.0		•	LREAL
	Rotation 3	0.0		۰	LREAL

7. Enter relevant Conveyor Tracking Parameters.

Name	Value	CS	Unit	Туре
Velocity	2000.0			LREAL
Acceleration	1500.0			LREAL
Deceleration	1500.0			LREAL
Jerk	25000.0			LREAL
Default Tracking Behavior	mcTrackingBehaviorDynLimited 💌			MC.MC_DEFAULT_TRACKING_BEHAVIOR
Synchronization Tolerance Distance	0.0		mm	LREAL

The Default Tracking Behavior specifies whether, after InSync has been reached for the first time, the tracking movement is still limited by the specified dynamic limits (InSync may be lost again) or synchronization is forced (even if the dynamic limits need to be violated in order to do so).

8. Link the Node Connector to the  ${\tt PLC}$  .



Object Context Parameter (Init) Data Area			Init) Data Area	Symbol Initialization	
	Name Value		Unit	Туре	
	-	GVL.oidConveyorBelt	01010030 💌	CB (Node Connector)	Tc3_McCoordinatedMotion.MC_COORD_REF

## BECKHOFF

⇒ Finally, you can insert the MC\_TrackConveyorBelt function block.

```
1
     PROGRAM MAIN
 2
     VAR
 3
          AxisGroup : AXES_GROUP_REF;
 4
          ConveyorBelt : AXIS_REF;
          MC_TrackConveyorBelt_0: MC_TrackConveyorBelt;
 5
 6
          MasterRefPos: MC_LREAL;
 7
          InitialObjectPos: ARRAY[1..4] OF MC LREAL;
 8
     END VAR
 1
     MC_TrackConveyorBelt_0(
 2
         AxesGroup:= AxisGroup,
 3
          ConveyorBelt := ConveyorBelt,
 4
         Execute:= ,
 5
         CoordTransform:= GVL.oidConveyorBelt,
 6
          InitialObjectPos:= ADR(InitialObjectPos),
 7
          InitialObjectPosCount:= SIZEOF(InitialObjectPos)/SIZEOF(InitialObjectPos[1]),
 8
         MasterRefPos:= MasterRefPos,
 9
         Velocity:= MC DEFAULT,
         Acceleration:= MC DEFAULT,
10
         Deceleration:= MC_DEFAULT,
11
12
         Jerk:= MC DEFAULT,
13
          InSync=> ,
14
         Busy=> ,
15
          Active=> ,
16
          CommandAborted=> ,
17
          Error=> ,
18
          ErrorId=> );
```

## 6.7 Background Information

#### Coordinate systems – relationships


- WCS
- World Coordinate System.
- MCS
   Machine Coordinate System.
- UCS

User Coordinate System.

• PCS

Programmed Coordinate System. Workpiece.

#### Pick-and-Place: From warehouse to carrier




The workpieces must be taken from the warehouse and placed in the free carrier positions running on the conveyor belt.

Thereby,

- the storage place is defined within the WCS,
- the robot is located somewhere within the WCS,
- the robot can be controlled within its MCS,
- the conveyor belt is located somewhere in the WCS,
- on the conveyor belt a carrier can be located within the UCS,
- a workpiece can be located within its carrier within the PCS.

### Pick-and-Place: From conveyor belt towards conveyor belt



The workpieces have to be taken from the upper conveyor belt and placed on the lower conveyor belt.

Thereby,

- the robot is located somewhere within the  ${\tt WCS},$
- the robot can be controlled within its  ${\tt MCS},$
- each conveyor belt is located somewhere in the WCS,
- workpieces on the conveyor belt can be located within a UCS.

# 7 PLC Libraries

# 7.1 Tc3\_McCoordinatedMotion

The Tc3\_McCoordinatedMotion library is used for TF5410 TwinCAT 3 Motion Collision Avoidance and also for TF5420 TwinCAT 3 Motion Pick-and-Place.

### Overview

Function block	Description	TF5410 TwinCAT 3 Mo- tion Collision	TF5420 TwinCAT 3 Motion Pick-and- Place		
		Avoidance	MC Group with Pick-and-Place	MC Group Co- ordinated Mo- tion	
	Administrative				
MC_AddAxisToGroup [▶_40]	Adds an axis group.	~	<b>x</b> ( ✓ up to v3.2)	✓	
MC_GroupDisable [▶ 43]	Disables an axis group.	~	<b>★</b> (✓ up to v3.2)	✓	
MC_GroupEnable [▶ 44]	Enables an axis group.	~	( v up to v3.2)	✓	
MC_GroupReadError [▶_45]	Reads the error ID of a group.	~	( ✓ up to v3.2)	✓	
<u>MC_GroupReadStatus</u> [▶_47]	Reads the group status.	~	(✓ up to v3.2)	✓	
<u>MC_GroupReset [▶ 48]</u>	Resets a group.	~	<b>★</b> (✓ up to v3.2)	✓	
MC_GroupSetOverride [▶_50]	Sets the override of a group and returns the actual override value.	×	<b>X</b> ( <b>v</b> up to v3.2)	~	
MC_RemoveAxisFromGrou p_[▶_51]	Removes an axis from a group.	~	<b>★</b> ( ✓ up to v3.2)	~	
MC_SetCoordinateTransfo rm [▶_53]	Activates a reference system.	×	<b>★</b> ( ✓ up to v3.2)	~	
MC_SetCoordinateTransfo rmPreparation [▶_54]	Adds a change of reference system to the list of movement segments.	×	×	~	

Function block	Description	TF5410 TwinCAT 3 Mo- tion Collision	TF5420 TwinCAT 3 Motion Pick-and- Place	
		Avoidance	MC Group with Pick-and-Place	MC Group Co- ordinated Mo- tion
<u>MC_TrackConveyorBelt</u> [▶ <u>55]</u>	Assists in synchronizing velocity to an object moving along a straight line through space.	×	★ ( ✓ up to v3.2)	~
<u>MC_UngroupAllAxes</u> [▶ <u>58]</u>	Disables a group and removes all axes.	~	★ ( ✓ up to v3.2)	~
UDINT_TO_IDENTINGROU P [▶_59]	Converts an integer value to IDENT_IN_GROUP_REF, so axes without special interpretation can be added to a group.	~	×	~
	Motion			
MC_GroupHalt [▶ 60]	Stops a group without locking it for further motion commands.	✓	×	×
MC_GroupStop [▶ 62]	Stops a group and locks it for further motion commands.	~	★ ( ✓ up to v3.2)	~
MC_MoveLinearAbsoluteP reparation [▶ 64]	Adds an absolute linear movement to a list of motion segments.	×	★ ( ✓ up to v3.2)	~
MC_MoveCircularAbsolute Preparation [ 66]	Adds an absolute circular movement to a list of motion segments.	×	★ ( ✓ up to v3.2)	~
MC_MovePath [▶_70]	Executes a list of motion segments.	×	★ ( ✓ up to v3.2)	~
MC_BlockerPreparation [▶_72]	Appends a blocking job to the list of segments in the structure PathData.	×	×	~
MC_ReleaseBlocker [▶_73]	Resolves a blocking job that is blocking further execution of the path.	×	×	✓
MC_GroupReadBlockerSta tus [▶_74]	status.	×	×	✓
MC_DwellTimePreparation	Appends a standstill job with a defined time to the list of segments in the structure PathData.	×	×	~



### Structures and enumerations

Function block	Description	TF5410 TwinCAT 3 Mo- tion Collision	TF5420 TwinCAT 3 Motion Pick-and- Place	
		Avoidance	MC Group with Pick-and-Place	MC Group Co- ordinated Mo- tion
IDENT IN GROUP REF [▶_76]	Defines how an axis is interpreted in a group.	×	<b>★</b> ( ✓ up to v3.2)	~
MC_CIRC_MODE [) 77]	The circle mode defines which definition is used to program a circle.	×	<b>★</b> ( ✓ up to v3.2)	~
<u>MC_CIRC_PATHCHOICE</u> [▶ <u>81]</u>	The data type defines the rotation direction of a circle.	×	<b>★</b> ( ✓ up to v3.2)	~
MC_PATH_DATA_REF [▶_82]	Represents the path to be executed at <u>MC_MovePath [▶ 70]</u> .	×	<b>★</b> ( ✓ up to v3.2)	~
<u>ClearPath [▶ 83]</u>	Resets the path represented by <u>MC_PATH_DATA_REF</u> [▶ <u>82]</u> .	×	<b>★</b> ( ✓ up to v3.2)	~
MC_TRANSITION_MODE	Characterizes the way a segment transition is executed.	×	<b>★</b> ( ✓ up to v3.2)	~
MC_COORD_REF [▶ 85]	Object ID of a coordinate system.	×	<b>★</b> ( ✓ up to v3.2)	~

# 7.1.1 Function Blocks

### 7.1.1.1 Administrative

# 7.1.1.1.1 MC\_AddAxisToGroup

	MC_AddAxisToGroup		
	Execute BOOL	BOOL Done	
	IdentInGroup IDENT_IN_GROUP_REF	BOOL Busy	
$\longrightarrow$	AxesGroup Reference To AXES_GROUP_REF	BOOL Error	
$\rightarrow$	Axis Reference To AXIS_REF	UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
✓	×	✓
	( ✓ up to and including v3.2)	

The function block MC\_AddAxisToGroup adds an axis to a group.

From V3.1.10.1, stationary axes can be added to and removed from a **CA group** in the GroupMoving group state. If a moving axis is added to a group, the command is rejected with an error message (a change of the group state with a moving axis is also rejected).

i

Only axes in GroupDisabled or GroupErrorDisabled state can be added to a **MC group**.

#### 🐔 Inputs

VAR INPUT	
Execute	: BOOL;
IdentInGroup	: IDENT IN GROUP REF;
END VAR	

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
IdentInGroup	IDENT_IN_GROUP_R EF	Defines the interpretation of the axis to be added to the group. For multi-dimensional motions, this can be the Cartesian interpretation. The <u>global variables</u> [▶ <u>76</u> ] (e.g. MCS_X) must be used. For Collision Avoidance the function <u>UDINT_TO_IDENTINGROUP</u> [▶ <u>59</u> ] must be used.
		<b>Notice</b> The use of integer values for the input IdentInGroup is NOT supported and may lead to incompatibility with future releases. If integer values are used, it may no longer be possible to build the project. We recommend using global variables (e.g. MCS_X) or the conversion function UDINT_TO_IDENTINGROUP.

### ✓/Inputs/outputs

VAR_IN_OUT AxesGrouj Axis END_VAR	p : AXES_GR : AXIS_RE	_
Name	Туре	Description
AxesGroup	AXES_GROUP_REF	Reference to a group of axes (see Cyclic Group Interface [ 96]).
Axis	AXIS_REF	Reference to an axis (see AXIS_REF).

### Outputs

VAR	OUTPUT		
-	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed.

Name	Туре	Description
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).

#### Sample for TwinCAT 3 Motion Pick-and-Place

#### **Multi-dimensional movements**

Multi-dimensional movements are only applicable when TF5420 is used.

```
VAR GLOBAL CONSTANT
cAxesCount : UINT := 4;
END VAR
VAR
    stGroupRef: AXES_GROUP_REF; // link to MC GroupstAxis: ARRAY[1..cAxesCount] OF AXIS_REF;fbAddAxis: ARRAY[1..cAxesCount] OF MC_AddAxisTi: UNTR:
                            : ARRAY[1..cAxesCount] OF MC_AddAxisToGroup;
: UINT;
    i
END_VAR
fbAddAxis[1].IdentInGroup := MCS X; //X-Axis
fbAddAxis[2].IdentInGroup := MCS_Y; //Y-Axis
fbAddAxis[3].IdentInGroup := MCS_Z; //Z-Axis
fbAddAxis[4].IdentInGroup := MCS C1;//1st rotation is C-rotation (around Z-Axis)
FOR i:=1 TO cAxesCount DO
    fbAddAxis[i](
    AxesGroup:=stGroupRef,
    Axis := stAxis[i],
    Execute := TRUE);
END FOR
```

#### Sample for TF5410 TwinCAT 3 Motion Collision Avoidance

#### PTP with Collision Avoidance

PTP with Collision Avoidance is only applicable when TF5410 is used. VAR\_GLOBAL CONSTANT cAxesCount : UDINT:=10; END VAR VAR stGroupRef: AXES\_GROUP\_REF; // link to CA GroupstAxis: ARRAY[1...cAxesCount] OF AXIS\_REF;fbAddAxis: ARRAY[1...cAxesCount] OF MC\_AddAxisToGroup; i : UDINT; END VAR FOR i:=1 TO cAxesCount DO fbAddAxis[i]( AxesGroup:=stGroupRef, Axis := stAxis[i], IdentInGroup := UDINT\_TO\_IDENTINGROUP(i), Execute := TRUE);

END\_FOR

### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

### 7.1.1.1.2 MC\_GroupDisable

	MC_GroupDisable	
	Execute BOOL	BOOL Done
$\rightarrow$	AxesGroup Reference To AXES_GROUP_REF	BOOL Busy
		BOOL Error
		UDINT ErrorId

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
✓	×	✓	
	( 💙 up to and including v3.2)		

The function block MC\_GroupDisable disables the group. After successful execution the group changes into group state GroupDisabled (see State diagrams).

As of TF5400 V3.3.72, PTP commands of the Tc2\_MC2 library (e.g. MC\_MoveAbsolute) are permitted on axes of the MC Group Coordinated Motion in the GroupDisabled state.

### NOTICE

### Disabling a Moving Group results in an instant stop.

The sudden stopping of axes is likely to exceed its allowed deceleration limits. Depending on the drive hardware, this could lead to current peaks and runtime errors.

Before executing MC\_GroupDisable, use <u>MC\_GroupHalt [ $\blacktriangleright$  60]</u> or <u>MC\_GroupStop [ $\blacktriangleright$  62]</u> to avoid this situation.

#### 🐔 Inputs

VAR	INPUT		
	Execute	:	BOOL;
END_	VAR		

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

### Inputs/outputs

VAR\_IN\_OUT AxesGroup : AXES\_GROUP\_REF; END\_VAR

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.1.1.1.3 MC\_GroupEnable

	MC_GroupEnable		
	Execute BOOL	BOOL Done	
$\longrightarrow$	AxesGroup Reference To AXES_GROUP_REF	BOOL Busy	
		BOOL Error	
		UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
~	×	✓	
	( 💙 up to and including v3.2)		

The function block MC\_GroupEnable enables the group. If it succeeds and all axes are ready, the group is then in group state GroupStandby (see State diagrams).

An **MC Group** can only be enabled, if all axes were added to the group before.

*	Inputs		
VAR	INPUT		
	Execute	:	BOOL;
END	VAR		

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

### Inputs/outputs

VAR	IN OUT				
	AxesGroup	:	AXES	GROUP	REF;
END	VAR				

Name	Туре	Description
AxesGroup	AXES_GROUP_REF	Reference to a group of axes (see <u>Cyclic group interface [ 96]</u> )

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT
END	VAR		
-			

Name	Туре	Description	
Done	BOOL	This output becomes TRUE when the command was successfully executed.	
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).	

### Requirements

Development environment	3	PLC libraries to include	
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,	
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2	

### 7.1.1.1.4 MC\_GroupReadError

BOOL Valid
BOOL Busy
BOOL Error
UDINT ErrorId
UDINT GroupErrorId

The function block MC\_GroupReadError returns the error code for the group. It does not return any errors for function blocks (e.g. invalid parameterization).

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place MC Group Coordinated Mot		
×	×	✓	
	( 💙 up to and including v3.2)		

### 🔁 Inputs

VAR\_INPUT Enable : BOOL; END\_VAR

Name	Туре	Description
Enable	BOOL	The command is executed as long as Enable is active.

### ✓/Inputs/outputs

VAR\_IN\_OUT AxesGroup : AXES\_GROUP\_REF; END\_VAR

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	<b>5 1 ( ( ) () ( ) ()(</b>

### Outputs

VAR	OUTPUT		
	Valid	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
	GroupErrorId	:	UDINT;
END	VAR		

Name	Туре	Description	
Valid	BOOL	This output indicates that other output values are valid for this function block.	
Busy	BOOL	This output becomes TRUE when the command is started with Enable and remains so as long as the function block executes the command.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).	
GroupErrorId	UDINT	Returns the error ID of the group (see <u>NC error documentation</u> ).	

### Requirements

Development environment	3	PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

# 7.1.1.1.5 MC\_GroupReadStatus

MC_GroupReadStatus	
Enable BOOL	BOOL Valid
AxesGroup Reference To AXES_GROUP_REF	BOOL Busy
	BOOL GroupMoving
	<b>BOOL</b> GroupHoming
	BOOL GroupErrorStop
	BOOL GroupNotReady
	BOOL GroupStandby
	BOOL GroupStopping
	BOOL GroupDisabled
	BOOL AllAxesStanding
	BOOL InPosition
	BOOL Error
	UDINT ErrorId

The function block MC\_GroupReadStatus reads the status of an axis group (see State diagrams).

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
✓	×	✓
	( ✓ up to and including v3.2)	

# 🕫 Inputs

Enable	BOOL	The command is executed as long as Enable is active.
Name	Туре	Description
VAR_INPU Enab END_VAR		: BOOL;

### ✓/Inputs/outputs

VAR_IN_OUT		
AxesGroup	:	AXES_GROUP_REF;
END_VAR		

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

	Outputs
VAR	OUTPUT

Valid	: BOOL;
Busy	: BOOL;
GroupMoving	: BOOL;
GroupHoming	: BOOL;
GroupErrorStop	: BOOL;
GroupNotReady	: BOOL;
GroupStandby	: BOOL;
GroupStopping	: BOOL;
GroupDisabled	: BOOL;
AllAxesStanding	: BOOL;
ConstantVelocity	: BOOL; // hidden
Accelerating	: BOOL; // hidden
Decelerating	: BOOL; // hidden
InPosition	: BOOL;

	Error
	ErrorId
END	VAR

: BOOL; : UDINT;

Name	Туре	Description	
Valid	BOOL	This output indicates that other output values are valid for this function block.	
Busy	BOOL	This output becomes TRUE when the command is started with Enable and remains so as long as the function block executes the command.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).	
GroupMoving	BOOL	The group is in the GroupMoving state (see State diagrams).	
GroupHoming	BOOL	The group is in the GroupHoming state (see State diagrams).	
GroupErrorStop	BOOL	The group is in the GroupErrorStop state (see State diagrams).	
GroupNotReady	BOOL	The group is in the GroupNotReady state (see State diagrams).	
GroupStandby	BOOL	The group is in the GroupStandby state (see State diagrams).	
GroupStopping	BOOL	The group is in the GroupStopping state (see State diagrams).	
GroupDisabled	BOOL	The group is in the GroupDisabled state (see State diagrams).	
AllAxesStanding	BOOL	None of the axes in the group move physically (velocity = 0 and acceleration = 0), regardless of whether a Motion Command exists or not.	
ConstantVelocity	BOOL	Not supported. Not visible as of TF5400 3.2.27.	
Accelerating	BOOL	Not supported. Not visible as of TF5400 3.2.27.	
Decelerating	BOOL	Not supported. Not visible as of TF5400 3.2.27.	
InPosition	BOOL	Not supported.	

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

# 7.1.1.1.6 MC\_GroupReset

MC_GroupReset		
Execute BOOL AxesGroup Reference To AXES_GROUP_REF	BOOL Done BOOL Busy BOOL Error	
	UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
~	×	✓
	( 💙 up to and including v3.2)	

**BECKHOFF** 

The function block MC\_GroupReset resets all internal errors of a group and all axes which are part of the group. If the group was enabled when the error occurred, the group goes into state GroupStandby. If the group was disabled, it goes to state GroupDisabled (see State diagrams).

If this function block is called while there is no error, it has no effect.

### 🐔 Inputs

```
VAR_INPUT
Execute : BOOL;
END VAR
```

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

### ✓/Inputs/outputs

VAR\_IN\_OUT AxesGroup : AXES\_GROUP\_REF; END\_VAR

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment	3	PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2



# 7.1.1.1.7 MC\_GroupSetOverride

MC_GroupSetOverride						
BOOL Enabled						
BOOL Busy						
BOOL Error						
UDINT ErrorId						
LREAL ActualVelFactor						

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place			
	MC Group with Pick-and-Place	MC Group Coordinated Motion		
×	×	✓		
	( ✔ up to and including v3.2)			

The function block MC\_GroupSetOverride changes the override of a group. A change is made with a certain delay. An override input value is valid between 0 [0%] and 1 [100%]. If the value is set outside this range, it is automatically set to the respective limit value.

The behavior for override modifications in relation to the **MC group** can be defined as an axis group parameter, see <u>Time Override Ramp Time</u>.

### 🐔 Inputs

VAR	INPUT					
-	_					
	Enable	•	BO	)T.:		
	LIIGDIC	•	200			
	VelFactor	•	MC	LREAL	• =	1 0 •
	VCIIIUCCOI	•	1.10		•	1.0,
TINT	VAR					
END	VAR					

Name	Туре	Description
Enable	BOOL	The command is executed as long as Enable is active.
VelFactor	MC_LREAL	The override is set to this value (value range between 0 [0 %] and 1 [100 %]).

### Inputs/outputs

VAR_IN_OUT				
AxesGroup	:	AXES	GROUP	REF;
END VAR				

Name	Туре	Description
AxesGro up	AXES_GROUP_R EF	Reference to a group of axes (see <u>Cyclic Group Interface</u> ).

### Outputs

VAR OUTPUT		
Enabled	: BOOL;	
Busy	: BOOL;	
Error	: BOOL;	
ErrorId	: UDINT;	
ActualVelFactor	: UDINT;	
END VAR		

Name	Туре	Description	
Enabled	BOOL	This output signals that the VelFactor has been set successfully. The	
		VelFactor shows the type of an override factor.	

Name	Туре	Description	
Busy	BOOL	This output becomes TRUE when the command is started with Enable and remains so as long as the function block executes the command.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).	
ActualVelFactor	UDINT	Override that is currently active in the group (value range between 0 [0 %] and 1 [100 %]).	

### Sample

```
VAR
stGroupRef : AXES_GROUP_REF;
fbSetOverride : MC_GroupSetOverride;
END_VAR
fbSetOverride(
   AxesGroup:=stGroupRef ,
   Enable:= TRUE ,
   VelFactor:=1.0 , (* 1.0 = 100% *)
);
```

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

### 7.1.1.1.8 MC\_RemoveAxisFromGroup

	MC_RemoveAxisFromGroup		
	Execute BOOL	BOOL Done	
	IdentInGroup IDENT_IN_GROUP_REF	BOOL Busy	
$\rightarrow$	AxesGroup Reference To AXES_GROUP_REF	BOOL Error	
		UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place				
	MC Group with Pick-and-Place MC Group Coordinated Motion				
✓	×	✓			
	( ✓ up to and including v3.2)				

The function block MC\_RemoveAxisFromGroup removes an axis from the axis group.

From TF5400 V3.1.10.1, stationary axes can be added to and removed from a **CA group** in the GroupMoving group state. If a moving axis is added to a group, the command is rejected with an error message (a change of the group state with a moving axis is also rejected).

1

Axes can only be added to an **MC group** if EnableRequested is FALSE, e.g. in the GroupDisabled state.



### Success of the function block

The function block always returns DONE if the axis no longer belongs to the group. This means that DONE is returned even if the axis was not in the group before the function block was called.

### 🔁 Inputs

VAR	INPUT					
	Execute	:	BOOL;			
	IdentInGroup	:	IDENT	ΙN	GROUP	REF;
END	VAR		-			_

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
IdentInGroup	IDENT_IN_GROUP_REF	Defines the interpretation of the axis to be added to the group. For multidimensional motions, this can be the Cartesian interpretation. The global variables (e.g. MCS_X) must be used. For Collision Avoidance the function UDINT_TO_IDENTINGROUP must be used.



### Use of integer values for the input IdentInGroup

The use of integer values for the input IdentInGroup is NOT supported and may lead to incompatibility with future releases. If integer values are used, it may no longer be possible to build the project. We recommend using <u>global variables</u> [▶ <u>76</u>] (e.g. MCS\_X) or the conversion function <u>UDINT\_TO\_IDENTINGROUP</u> [▶ <u>59</u>].

#### ✓/Inputs/outputs

VAR_IN_OUT				
AxesGroup	:	AXES	GROUP	REF;
END VAR				

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		
END	ErrorId		

Name	Туре	Description	
Done	BOOL	This output becomes TRUE when the command was successfully executed.	
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).	

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

### 7.1.1.1.9 MC\_SetCoordinateTransform

MC_SetCoordinateTrans	sform
Execute BOOL	BOOL Done
CoordTransform MC_COORD_REF	BOOL Busy
AxesGroup Reference To AXES_GROUP_REF	BOOL Active
	BOOL CommandAborted
	BOOL Error
	UDINT ErrorId

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	✓
	( ✓ up to and including v3.2)	

The function block MC\_SetCoordinateTransform activates a coordinate transformation for successor movements. The successful activation is indicated by Active or Done.

Decouples the successor movements from a transport system (see MC\_TrackConveyorBelt [ 55]).

Successor movements (e.g. <u>MC\_MovePath [) 70]</u>) take place relative to the coordinate transformation.

### Use case for changing the reference system

The MC group can be decoupled by using MC\_SetCoordinateTransform and changing the reference system.

### 🔁 Inputs

```
VAR_INPUT
Execute : BOOL;
CoordTransform : MC_COORD_REF;
END VAR
```

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
CoordTransform	MC_COORD_REF	Reference to a coordinate system (see <u>MC_COORD_REF</u> $[\blacktriangleright 85]$ ).

### Inputs/outputs

```
VAR_IN_OUT
AxesGroup : AXES_GROUP_REF;
END VAR
```

Name	Туре	Description
AxesGroup	AXES_GROUP_REF	Reference to a group of axes (see Cyclic Group Interface [ 96]).

### Outputs

VAR\_OUTPUT Done : BOOL; Busy : BOOL; Active : BOOL; CommandAborted : BOOL; Error : BOOL; ErrorId : UDINT; END\_VAR

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time, one of the outputs Done, CommandAborted or Error is set.
Active	BOOL	Active indicates that the command is being executed.
		Active indicates that the reference system has been successfully set (MC Coordinated Motion Group only).
		Active indicates a delay in conveyor tracking (MC Coordinated Motion Group only).
		Active becomes FALSE if one of the outputs Done, CommandAborted or Error is set to TRUE.
		Note: According to the PLCopen definition, Active is reset if Done is set to TRUE. In the event of an insignificant or non-existent delay, Active can only be set to TRUE for a short period of time. If the PLC program checks Active, it is therefore advisable to also check Done.
CommandAborted	BOOL	This output becomes TRUE if the command was interrupted by another command.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment	3	PLC libraries to include
TwinCAT V3.1.4022.25 TF5400 Advanced Motion Pack V3.1.6.03	PC or CX (x64)	Tc3_McCoordinatedMotion, Tc2_MC2

# 7.1.1.1.10 MC\_SetCoordinateTransformPreparation

MC_SetCoordinateTransformPreparation	
PathData Reference To MC_PATH_DATA_REF CoordTransform MC_COORD_REF	BOOL Error - UDINT ErrorId -

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
×	×	✓

**BECKHOFF** 

The function block MC\_SetCoordinateTransformPreparation inserts a change of reference system into the table containing the segments of a path.

### 🔁 Inputs

```
VAR_INPUT

PathData : MC_PATH_DATA_REF;

CoordTransform : MC_COORD_REF;

END VAR
```

Name	Туре	Description
PathData		Table containing the segments of a path. The table is written by the function block MCPreparation and executed by MC_MovePath [▶_70].
CoordTransform	MC_COORD_REF [] 85]	Reference to a coordinate system.

### Outputs

```
VAR_OUTPUT
Error : BOOL;
ErrorId : UDINT;
END_VAR
```

Name	Туре	Description
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

#### Requirements

Development environment	Target platform	PLC library to include
TwinCAT V3.1.4024.40	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.3.19		Tc2_MC2

# 7.1.1.1.11 MC\_TrackConveyorBelt

	OL InSync
CoordTransform MC COOPD REF	
	OOL Busy
InitialObjectPos Pointer To MC_LREAL     BC	OOL Active
InitialObjectPosCount UDINT BOOL Comma	ndAborted
MasterRefPos MC_LREAL B	OOL Error
Velocity MC_LREAL UDII	VT ErrorId
Acceleration MC_LREAL	
Deceleration MC_LREAL	
Jerk MC_LREAL	
→ AxesGroup Reference To AXES_GROUP_REF	
← ConveyorBelt Reference To AXIS_REF	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	e
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	✓
	( ✔ up to and including v3.2)	

The function block Mc\_TrackConveyorBelt enables a reference system that is in motion. It synchronizes the AxesGroup with the ConveyorBelt in terms of velocity.

Synchronization with a position requires a motion command.

The function block thus helps to synchronize with an object that moves in a straight line through space. Example: products moving on a conveyor belt or other transport system.

The origin of the conveyor belt is parameterized with a coordinate system (CoordTransform). X is the conveying direction. The detected object position (InitialObjectPos) and the corresponding touch probe position (MasterRefPos) are entered in the function block.

Synchronization dynamics can be entered in the function block.

Movements executed after Active = TRUE are synchronized with the conveyor belt.

When changing the reference system, a conveyor belt can be decoupled.

Use case for changing the reference system

The MC group can be decoupled by using MC\_TrackConveyorBelt and changing the reference system. The reference system can be changed with MC\_SetCoordinateTransform.

# News and optimizations regarding MC\_TrackConveryorBelt with TF5400 V3.2.27 for MC Group Coordinated Motion

- New: Optionally, the override also affects the synchronization phase for the MC\_TrackConveyorBelt. The setting is made in the parameter "Tracking Override Behavior" in the <u>MC Group Coordinated</u> <u>Motion [\b]18]</u>.
- Optimizations to the MC\_TrackConveyorBelt that prevent SAF cycle misalignment between conveyor (master) and slave axis.
- Optimizations of the error reaction for the MC\_TrackConveyorBelt. In the event of a runtime error of the conveyor belt (master), an active MC\_MovePath is not aborted and an error reaction is to be triggered via the PLC.

*	Inp	uts
---	-----	-----

VAR	INPUT		
	Execute	:	BOOL;
	CoordTransform	:	MC COORD REF;
	InitialObjectPos	:	POINTER TO MC LREAL;
	InitialObjectPosCount	:	UDINT;
	MasterRefPos	:	MC LREAL;
	Velocity	:	MC LREAL := MC DEFAULT
	Acceleration	:	MC LREAL := MC DEFAULT
	Deceleration	:	MC LREAL := MC DEFAULT
	Jerk	:	MC LREAL := MC DEFAULT
END	VAR		
_	-		

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

Name	Туре	Description
CoordTransform	MC_COORD_REF	Reference to a coordinate system (see <u>MC_COORD_REF [▶ 85]</u> ).
InitialObjectPos	POINTER TO MC_LREAL	<b>Pointer to array</b> [1InitialObjectPosCount].
InitialObjectPosCount	UDINT	Dimension of the InitialObjectPos vector.
MasterRefPos	MC_LREAL	Touch probe position.
Velocity	MC_LREAL	Velocity for synchronization. The velocity must exceed the conveyor belt velocity. The velocity is not limited by the maximum axis velocity.
Acceleration	MC_LREAL	Used in the Conveyor Tracking object. The acceleration for synchronization. The acceleration is not limited by the maximum axis acceleration. If no value is entered, then the default acceleration of the Conveyor Tracking object is used.
Deceleration	MC_LREAL	Used in the Conveyor Tracking object. The deceleration for synchronization. The deceleration is not limited by the maximum axis deceleration. If no value is entered, then the default deceleration of the Conveyor Tracking object is used.
Jerk	MC_LREAL	The jerk for synchronization. If no value is entered, then the default jerk of the Conveyor Tracking object is used. The maximum jerk is not limited.

# ✓/Imputs/outputs

VAR	IN_OUT		
	AxesGroup	:	AXES GROUP REF;
	ConveyorBelt	:	AXIS REF;
END	VAR		

Name	Туре	Description
AxesGroup		Reference to a group of axes (see <u>Cyclic Group Interface</u> [▶ <u>96]</u> ).
ConveyorBelt	AXIS_REF	Reference to an axis. Reference to the conveyor axis.

### Outputs

VAR OUTPUT		
InSync	: BOOL;	
Busy	: BOOL;	
Active	: BOOL;	
CommandAborted	: BOOL;	
Error	: BOOL;	
ErrorId	: UDINT;	
END_VAR		

Name	Туре	Description
InSync	BOOL	The output InSync becomes TRUE for the first time when the slave is synchronized with the velocity. If the slave dynamics is too low to follow the master movement, the output InSync could be reset to FALSE, after which the slave axis starts synchronizing again.
		<b>Notice</b> Velocity synchronization: Active and InSync - the function block MC_TrackConveyorBelt synchronizes the AxesGroup with the velocity of the ConveyorBelt axis. The function block uses the given parameters for Acceleration, Deceleration and Jerk. When this synchronization movement

Name	Туре	Description
		begins, Active is set to TRUE. When the velocity of the ConveyorBelt is reached, InSync is set to TRUE. The synchronization status is continuously monitored and indicated with InSync.
		<b>Notice</b> Conveyor movement, default tracking behavior and InSync - once the output signal InSync has been set, there are two options to maintain synchronization. mcTrackingBehaviorDynLimited - this behavior is the default (MC_Default) tracking behavior. The AxesGroup maintains velocity synchronization with the ConveyorBelt using the given parameters for Acceleration, Deceleration and Jerk. – mcTrackingBehaviorStayInSync - the AxesGroup maintains the velocity synchronization with the ConveyorBelt with unlimited parameters for Acceleration, Deceleration and Jerk.
		<b>Notice</b> Position synchronization: MasterRefPos and InitialObjectPos - the function blocks MC_TrackConveyorBelt and MC_MovePath should be used together for flexible synchronization with a moving target position. After MC_TrackConveyorBelt.Active is set to TRUE, InitialObjectPos and the distance to MasterRefPos are appended to the next call to MC_MovePath. MC_TrackConveyorBelt.InSync = TRUE and MC_MovePath.Done = TRUE indicate that the synchronized position has been reached.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If BUSY becomes FALSE again, the function block is ready for a new command. At the same time, one of the outputs CommandAborted or Error is set.
Active	BOOL	If Active is TRUE, the function block controls the group.
CommandAbor ted	BOOL	This output becomes TRUE if the command was interrupted by another command.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4022.25 TF5400 Advanced Motion Pack V3.1.6.03	PC or CX (x64)	Tc3_McCoordinatedMotion, Tc2_MC2

# 7.1.1.1.12 MC\_UngroupAllAxes

MC_UngroupAllAxes	
Execute BOOL	BOOL Done
AxesGroup Reference To AXES_GROUP_REF	BOOL Busy
	BOOL Error
	UDINT ErrorId

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place	MC Group Coordinated Motion
✓	×	✓
	( 💙 up to and including v3.2)	

The function block MC\_UngroupAllAxes removes all axes and disables the group. If the function block succeeds, the group is then in group state GroupDisabled (see State diagrams).

### 🔁 Inputs

VAR\_INPUT Execute : BOOL; END VAR

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

### ✓/Inputs/outputs

VAR IN OUT		
AxesGroup	:	AXES GROUP REF;
END VAR		

Name	Туре	Description
	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error</u> <u>documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.1.1.1.13 UDINT\_TO\_IDENTINGROUP

		UDINT_TO_IDENTINGROUP	
_	id UDINT	IDENT_IN_GROUP_REF_UDINT_TO_IDENTINGROUP	_

# RECKHOFE

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place	MC Group Coordinated Motion
✓	×	✓

The function UDINT TO IDENTINGROUP is a conversion function, which converts an integer value to IDENT\_IN\_GROUP\_REF. It is required to add a PTP axis without spatial interpretation to a CA-Group. This conversion function returns a valid input for MC AddAxisToGroup [ + 40] and MC RemoveAxisFromGroup [▶ 51]. For axes intended for multi-dimensional movement (TF5420) see IDENT IN GROUP REF [▶ 76].

### Use of integer values for the input IdentInGroup

The use of integer values for the input IdentInGroup is NOT supported and may lead to incompatibility with future releases. If integer values are used, it may no longer be possible to build the project. We recommend using global variables [▶ 76] (e.g. MCS X) or the conversion function UDINT TO IDENTINGROUP [▶ 59].

### Return value

Name	Туре	Description
UDINT_TO_IDENTINGROUP		Converts an integer value, so a PTP axis can be added to a motion group.

### 🖻 Inputs

VAR	INPUT
-	id
	T 7 7 T

id END_VAR		: UDINT;
Name	Туре	Description
id	UDINT	The unique identifier an axis shall have in the group. This does not have to be the axis ID from the cyclic axis interface.

### **Requirements**

Development environment	arget platform     PLC libraries       to include		
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,	
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2	

#### 7.1.1.2 Motion

#### 7.1.1.2.1 MC\_GroupHalt

	MC_GroupHalt	
	Execute BOOL BOOL Done	
	Deceleration MC_LREAL BOOL Busy	
	Jerk MC_LREAL BOOL Active	
$\longrightarrow$	AxesGroup Reference To AXES_GROUP_REF BOOL CommandAborted	
	BOOL Error	
	UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place					
	MC Group with Pick-and-Place MC Group Coordinated Motion					
✓	×	✓				

The MC\_GroupHalt function block stops a group with a defined deceleration ramp. Unlike "MC GroupStop  $[\blacktriangleright \underline{62}]$ ", the group is not locked for further motion commands. Therefore, the group can be restarted by another command during the deceleration ramp or after stopping.

#### **WARNING**

### Possible delayed axis stop

If Standby Gap Control is active with a CA group and the gap is also less than the minimum, the gap is first extended before the axes can be stopped with an MC GroupHalt.

- Make sure that you actually need the behavior of Standby Gap Control; if not, consider disabling it (default setting).
- Use an MC\_GroupStop instead of an MC\_GroupHalt if the axes need to be stopped without a delay.

### NOTICE

### MC\_GroupHalt not implemented for MC group with pick-and-place

The MC\_GroupHalt function block is only implemented for the MC Group Coordinated Motion and for PTP movements with Collision Avoidance (CA group). When used with another group type, the command is rejected.



Applies to the MC\_Group: MC\_GroupHalt cancels the active coordinate transformation and deletes all jobs in the queue.

### 👻 Inputs

VAR	INPUT		
	Execute	:	BOOL;
	Deceleration	:	MC LREAL := MC DEFAULT,
	Jerk	:	MC LREAL := MC DEFAULT,
END	VAR		

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
Deceleratio n	MC_LREA L	[mm/s <sup>2</sup> ]. The deceleration can be programmed as a scalar value ( $\geq$ 1), or " <u>Special input values</u> [ $\triangleright$ <u>98</u> ]" can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values.
Jerk	MC_LREA L	[mm/s <sup>3</sup> ]. The jerk can be programmed as a scalar value (≥100), or " <u>Special input</u> <u>values [▶ 98]</u> " can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. MC_IGNORE executes the command with unlimited jerk.

### Inputs/outputs

VAR\_IN\_OUT AxesGroup : AXES\_GROUP\_REF; END\_VAR

Name	Туре	Description
AxesGro up	AXES_GROUP_R EF	Reference to a group of axes (see Cyclic Group Interface).

### Outputs

BOOL;
BOOL;
BOOL;
BOOL;
BOOL;
UDINT

Name	Туре	Description	
Done	BOOL	Becomes TRUE when the group has been stopped and has come to a standstill. Once the group has come to a standstill, the group state becomes GroupStandby (see State diagrams).	
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.	
Active	BOOL	Active indicates that the command is being executed. If the command was the queue, it becomes active as soon as an executed command is completed.	
CommandAborted	BOOL	This output becomes TRUE if the command was interrupted by another command.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).	

### Requirements

62

Development environment		PLC libraries to include		
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,		
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2		

# 7.1.1.2.2 MC\_GroupStop

	MC_GroupStop	
	Execute BOOL BOOL Done	
	Deceleration MC_LREAL BOOL Busy	
	Jerk MC_LREAL BOOL Active	-
$\longrightarrow$	AxesGroup Reference To AXES_GROUP_REF BOOL CommandAborted	-
	BOOL Error	-
	UDINT ErrorId	-

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place				
	MC Group with Pick-and-Place MC Group Coordinated Motion				
✓	×	✓			
	( 💙 up to and including v3.2)				

**BECKHOFF** 

The function block MC\_GroupStop stops the group and all associated axes with a defined deceleration ramp and locks the axis for motion commands. While the group is in the GroupStopping state, no other function block can move an axis of the group (see State diagrams).

The group can only be moved again once the signal *Execute* has been set to FALSE after the velocity is 0.



MC\_GroupStop cancels the active coordinate transformation and deletes all jobs in the queue.

#### 🐔 Inputs

VAR	INPUT				
	Execute	:	BOOL;		
	Deceleration	:	MC LREAL	:=	MC DEFAULT;
	Jerk	:	MC LREAL	:=	MC DEFAULT;
END	VAR				

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
Deceleration	MC_LREAL	[mm/s <sup>2</sup> ]. The deceleration can be programmed as a scalar value ( $\geq$ 1), or " <u>Special input values</u> [ $\blacktriangleright$ <u>98</u> ]" can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values.
Jerk	MC_LREAL	[mm/s <sup>3</sup> ]. The jerk can be programmed as a scalar value (≥100), or " <u>Special input values</u> [▶ <u>98</u> ]" can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. MC_IGNORE executes the command with unlimited jerk.

### ✓/Inputs/outputs

VAR_IN_OUT	
AxesGroup	: AXES_GROUP_REF;
END VAR	

Name	Туре	Description
AxesGro	AXES_GROUP_R	Reference to a group of axes (see Cyclic Group Interface).
up	EF	

### Outputs

VAR OUTPU	JT		
Done		:	BOOL;
Busy		:	BOOL;
Activ	ve	:	BOOL;
Comma	andAborted	:	BOOL;
Erro	r	:	BOOL;
Erro	rId	:	UDINT;
END_VAR			

Name	Туре	Description
Done	BOOL	Becomes TRUE when the group has been stopped and has come to a standstill. The group remains in the GroupStopping state while <i>Execute</i> is TRUE, at least until the axes have come to a stop. The group is then in the GroupStandby state (see State diagrams).
Busy	BOOL	Becomes TRUE when the command is started with <i>Execute</i> and remains so as long as the command is executed. If <i>Busy</i> becomes FALSE again, the group is ready for a new command. After the group is stopped, <i>Busy</i> remains TRUE until the group is released with <i>Execute</i> =FALSE.
Active	BOOL	Indicates that the function block controls the group. After the group is stopped, <i>Active</i> remains TRUE until the group is released with Execute=FALSE.

Name	Туре	Description
CommandAborted	BOOL	The command is aborted by disabling MC_Power of at least one axis of the group or if the group is disabled during the command.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment	3	PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.1.1.2.3 MC\_MoveLinearAbsolutePreparation

Position Pointer To MC_LREAL       BOOL Error         PositionCount UDINT       UDINT ErrorId         Velocity MC_LREAL       Acceleration MC_LREAL         Deceleration MC_LREAL       Jerk MC_LREAL         Jerk MC_LREAL       BufferMode MC_BUFFER_MODE         TransitionMode MC_TRANSITION_MODE       TransitionParameter Pointer To MC_LREAL         TransitionParameter Count UDINT       InvokeId UDINT	MC_MoveLinearAbsolutePreparation	
Velocity MC_LREAL Acceleration MC_LREAL Deceleration MC_LREAL Jerk MC_LREAL BufferMode MC_BUFFER_MODE TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	Position Pointer To MC_LREAL	BOOL Error
Acceleration MC_LREAL Deceleration MC_LREAL Jerk MC_LREAL BufferMode MC_BUFFER_MODE TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	PositionCount UDINT	UDINT ErrorId
Deceleration MC_LREAL Jerk MC_LREAL BufferMode MC_BUFFER_MODE TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	Velocity MC_LREAL	
Jerk MC_LREAL BufferMode MC_BUFFER_MODE TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	Acceleration MC_LREAL	
BufferMode MC_BUFFER_MODE TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	Deceleration MC_LREAL	
TransitionMode MC_TRANSITION_MODE TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	Jerk MC_LREAL	
TransitionParameter Pointer To MC_LREAL TransitionParameterCount UDINT	BufferMode MC_BUFFER_MODE	
TransitionParameterCount UDINT	TransitionMode MC_TRANSITION_MODE	
	TransitionParameter Pointer To MC_LREAL	
	TransitionParameterCount UDINT	
	InvokeId UDINT	
DynamicConstraints Reference To IPIcDynamicConstraint	DynamicConstraints Reference To IPIcDynamicConstraint	
PathData Reference To MC_PATH_DATA_REF	PathData Reference To MC_PATH_DATA_REF	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	
	( ✓ up to and including v3.2)		

The function block MC\_MoveLinearAbsolutePreparation adds an absolute linear movement to the table of segments in the PathData structure. After creating a table, it can be executed via MC\_MovePath [▶ 70]. The function block MC\_MoveLinearAbsolutePreparation can be called several times per cycle. A maximum of 30 entries are allowed per PathData table.

🔁 Inputs		
VAR_INPUT Position PositionCount Velocity Acceleration Deceleration Jerk BufferMode TransitionMode TransitionParameter TransitionParameterCount	· · · · · · · · ·	<pre>POINTER TO LREAL; UDINT; MC_LREAL := MC_INVALID; MC_LREAL := MC_DEFAULT; MC_LREAL := MC_DEFAULT; MC_LREAL := MC_DEFAULT; MC_BUFFER_MODE := mcAborting; MC_TRANSITION_MODE := mcTransModeNone; POINTER TO LREAL; UDINT;</pre>

InvokeId : UDINT; DynamicConstraints : REFERENCE TO IPlcDynamicConstraint := 0; END\_VAR

Name	Туре	Description
Position	POINTER TO LREAL	Pointer to an array [1PositionCount] of the target position vector.
PositionCount	UDINT	Dimension of the position vector. Must match the number of axes in the axis convention (see <u>MC Group Coordinated Motion</u> or <u>MC Group</u> <u>with Pick-and-Place</u> ).
Velocity	MC_LREAL	The maximum velocity for the programmed segment. The velocity does not always have to be reached. The velocity must be set >0.
Acceleration	MC_LREAL	Maximum path acceleration for the programmed segment. <u>Special</u> <u>input values [<math>\triangleright</math> 98]</u> can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. The acceleration must be set $\geq$ 1.
Deceleration	MC_LREAL	Maximum path deceleration for the programmed segment. <u>Special</u> <u>input values [▶98]</u> can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. The deceleration must be set ≥1.
Jerk	MC_LREAL	Path jerk for the programmed segment. <u>Special input values</u> [▶ <u>98]</u> can be used. MC_DEFAULT executes the command with default axis values. The jerk must be set ≥100. <b>From TF5400 V3.2.27:</b> MC_MAXIMUM is supported for MC Group Coordinated Motion. Here MC_MAXIMUM = 100 * MC_DEFAULT.
BufferMode	MC_BUFFER_M ODE	Defines how successive motion commands are to be processed (see MC_BUFFER_MODE [ $\blacktriangleright$ 86]).
Transition mode	MC_TRANSITIO N_MODE	Defines the blending mode (see <u>MC_TRANSITION_MODE [▶ 83]</u> ).
TransitionParame ter	POINTER TO LREAL	Pointer to array [1TransitionParameterCount] of blending parameters. Transition parameters define the blending from the last programmed position (see <u>MC_TRANSITION_MODE [▶83]</u> ).
TransitionParame terCount	UDINT	Number of blending parameters (see <u>MC_TRANSITION_MODE</u> [▶ <u>83]</u> ).
Invokeld	UDINT	Segment ID for analysis purposes.
DynamicConstrai nts	REFERENCE TO IPIcDynamicCons	From TF5400 V3.2.27, MC Group Coordinated Motion: Optional input to further limit the allowed values for velocity, acceleration, deceleration or jerk during motion.
	traint	Notice Reference assignment:
		<pre><instanceofmc_movelinearabsolutepreparation>.Dynamic Constraints REF= <instanceofiplcdynamicconstraint>;</instanceofiplcdynamicconstraint></instanceofmc_movelinearabsolutepreparation></pre>

### ✓/Imputs/outputs

VAR	IN_OUT					
	PathData	:	MC	PATH	DATA	REF;
END_	VAR					
	_					

Name	Туре	Description
PathData	MC_PATH_DATA_RE	Table containing the segments of a path. The table is written by
	F	MC_MovePreparation and executed by MC_MovePath [ > 70] (see
		MC_PATH_DATA_REF [▶_82]).



### Resetting a table

A table is not reset during execution. To reset, the method ClearPath() must be called from MC\_PATH\_DATA\_REF.

### Outputs

VAR	OUTPUT		
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error</u> <u>documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

# 7.1.1.2.4 MC\_MoveCircularAbsolutePreparation

MC_MoveCircularAbsolutePreparation	
CircMode MC_CIRC_MODE	BOOL Error
AuxPoint Pointer To MC_LREAL	UDINT ErrorId
AuxPointCount UDINT	
EndPoint Pointer To MC_LREAL	
EndPointCount UDINT	
PathChoice MC_CIRC_PATHCHOICE	
Velocity MC_LREAL	
Acceleration MC_LREAL	
Deceleration MC_LREAL	
Jerk MC_LREAL	
BufferMode MC_BUFFER_MODE	
TransitionMode MC_TRANSITION_MODE	
TransitionParameter Pointer To MC_LREAL	
TransitionParameterCount UDINT	
InvokeId UDINT	
DynamicConstraints Reference To IPIcDynamicConstraint	
PathData Reference To MC_PATH_DATA_REF	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	
	( 💙 up to and including v3.2)		

The function block MC\_MoveCircularAbsolutePreparation adds an absolute circular motion to the table of segments in the PathData structure. After creating a table, it can be executed via MC\_MovePath. The function block MC\_MoveCircularAbsolutePreparation can be called several times per cycle. A maximum of 30 entries are allowed per PathData table.



### Resetting a table

A table is not reset during execution. To reset, the method ClearPath() must be called from MC\_PATH\_DATA\_REF [ 82].

### 🐔 Inputs

VAR_INPUT	
CircMode	: MC CIRC MODE := mcCircModeInvalid;
AuxPoint	: POINTER TO MC_LREAL;
AuxPointCount	: UDINT;
EndPoint	: POINTER TO MC_LREAL;
EndPointCount	: UDINT;
PathChoice	: MC_CIRC_PATHCHOICE := mcCircPathchoiceCounterClockwise;
Velocity	: MC_LREAL := MC_INVALID;
Acceleration	: MC_LREAL := MC_DEFAULT;
Deceleration	: MC_LREAL := MC_DEFAULT;
Jerk	: MC_LREAL := MC_DEFAULT;
BufferMode	: MC_BUFFER_MODE := mcAborting;
TransitionMode	: MC_TRANSITION_MODE := mcTransModeNone;
TransitionParameter	: POINTER TO MC_LREAL;
TransitionParameterCount	: UDINT;
InvokeId	: UDINT;
DynamicConstraints	: REFERENCE TO IPlcDynamicConstraint := 0;
END_VAR	

Name	Туре	Description	
CircMode	MC_CIRC_MOD E	Specifies which circle definition is used to program the circle. Specifies the meaning of the "AuxPoint" input signal (see <u>MC_CIRC_MODE</u> [▶ <u>77]</u> ).	
AuxPoint	POINTER TO MC_LREAL	Pointer to an array [1AuxPointCount] of the AuxPoint vector. The interpretation of the AuxPoint vector depends on the rotation convention (see <u>MC Group Coordinated Motion</u> or <u>MC Group with</u> <u>Pick-and-Place</u> ) and is always (x, y, z).	
AuxPointCount	UDINT	Dimension of the AuxPoint vector. Must be 3. If a 2D rotation convention (see <u>MC Group Coordinated Motion</u> or <u>MC Group with</u> <u>Pick-and-Place</u> ) is used, the input value must also be 3. With a 2D rotation convention and CircMode of <i>mcCircModeBorder</i> or <i>mcCircModeCenter</i> , the component that is independent of the working plane must be set to MC_Ignore (see <u>MC LREAL/Special Input Values</u> [▶ <u>981</u> ).	
EndPoint	POINTER TO MC_LREAL	Pointer to an array [1EndPointCount] of the target position vector.	
EndPointCount	UDINT	Dimension of the EndPoint vector. Must match the number of axes in the axis convention (see <u>MC Group Coordinated Motion</u> or <u>MC Group</u> with Pick-and-Place).	
PathChoice	MC_CIRC_PATH CHOICE	Defines the direction of rotation with respect to the normal vector. The input is ignored if the input <i>CircMode</i> is set to <i>mcCircModeBorder</i> (see MC_CIRC_PATHCHOICE [ $\blacktriangleright$ 81]).	
Velocity	MC_LREAL	The maximum velocity for the programmed segment. The velocity does not always have to be reached. The velocity must be set >0.	
Acceleration	MC_LREAL	Maximum path acceleration for the programmed segment. <u>Special</u> <u>input values [▶ 98]</u> can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. The acceleration must be set ≥1.	

Name	Туре	Description
Deceleration	MC_LREAL	Maximum path deceleration for the programmed segment. <u>Special</u> <u>input values [▶ 98]</u> can be used. MC_DEFAULT executes the command with default axis values. MC_MAXIMUM executes the command with the maximum axis values. The deceleration must be set ≥1.
Jerk	MC_LREAL	Path jerk for the programmed segment. <u>Special input values [▶ 98]</u> can be used. MC_DEFAULT executes the command with default axis values. The jerk must be set ≥100. <b>From TF5400 V3.2.27:</b> MC_MAXIMUM is supported for MC Group Coordinated Motion. Here MC_MAXIMUM = 100 * MC_DEFAULT.
BufferMode	MC_BUFFER_M ODE	Defines how successive motion commands are to be processed (see MC BUFFER MODE [ $\blacktriangleright$ 86]).
Transition mode	MC_TRANSITIO N_MODE	Defines the blending mode (see <u>MC_TRANSITION_MODE</u> [▶ <u>83]</u> ).
TransitionParame ter	POINTER TO MC_LREAL	Pointer to array [1TransitionParameterCount] of blending parameters. Transition parameters define the blending from the last programmed position (see <u>MC_TRANSITION_MODE [▶83]</u> ).
TransitionParame terCount	UDINT	Number of blending parameters.
Invokeld	UDINT	Segment ID for analysis purposes.
DynamicContraint s	REFERENCE TO IPIcDynamicCons	From TF5400 V3.2.27, MC Group Coordinated Motion: Optional input to further limit the allowed values for velocity, acceleration, deceleration or jerk during motion.
	<u>traint</u>	Notice Reference assignment:
		<instanceofmc_movecircularabsolutepreparation>.Dynam icConstraints <b>REF=</b></instanceofmc_movecircularabsolutepreparation>
		<instanceofiplcdynamicconstraint>;</instanceofiplcdynamicconstraint>

# ✓/Imputs/outputs

VAR_IN_OUT	
PathData	: MC_PATH_DATA_REF;
END_VAR	

Name	Туре	Description
	A_REF	Table containing the segments of a path. The table is written by MC_MovePreparation and executed by <u>MC_MovePath [▶ 70]</u> (see <u>MC_PATH_DATA_REF [▶ 82]</u> ).


# Outputs

VAR OUTPUT		
Error	:	BOOL;
ErrorId	:	UDINT;
END VAR		

Name	Туре	Description
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the ADS error documentation or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

### Sample of center point programming

Assuming a path consisting of 4 segments as shown in the figure is to be programmed in mcCircModeCenter mode: the user defines the center of the circle as an auxiliary point ("AuxPoint"). When using mcCircModeCenter, the input MC CIRC PATHCHOICE [▶ 81] determines the direction of rotation. Since the plane is defined by the cross product, mcCircPathchoiceCounterClockwise must be selected for both circle segments N20 and N30.



aTargetPos[1] := 400; := -200; aTargetPos[2] := 0; aTargetPos[3] := 400; := -100; aAuxPoint[1] aAuxPoint[2] := 0; aAuxPoint[3] aTransitionParam[1] := 0; := 0; aTransitionParam[2] fbMoveCircPrep(PathData:= path, PathChoice:= mcCircPathchoiceCounterClockwise, Velocity:= 1000, InvokeId:= 30); aTargetPos[1] := 600; := -200; aTargetPos[2] aTargetPos[3] := 100; aTransitionParam[1] := 0; := 0; aTransitionParam[2] fbMoveLinPrep(PathData:= path, Velocity:= 3000, InvokeId:= 40);

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.2.47	CX (x64)	Tc2_MC2

### 7.1.1.2.5 MC\_MovePath

Execute BOOL BOOL DO	no –
→ AxesGroup Reference To AXES_GROUP_REF BOOL Bu	sy –
→ PathData Reference To MC_PATH_DATA_REF BOOL Activ	ve –
BOOL CommandAborte	ed 🗕
BOOL Err	or –
UDINT Error	Id —

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	
	( 💙 up to and including v3.2)		

The function block MC\_MovePath executes a movement defined in the PathData table by <u>MC\_MoveLinearAbsolutePreparation [▶ 64]</u>, <u>MC\_MoveCircularAbsolutePreparation [▶ 66]</u>, <u>MC\_BlockerPreparation [▶ 72]</u> and <u>MC\_SetCoordinateTransformPreparation [▶ 54]</u>.

### Re-triggering of an FB instance during motion

It is possible to execute different motion commands with one instance of this function block. However, the outputs of the function block only indicate the last command executed. The user loses the ability to diagnose for the previously sent motion commands. Re-triggering of a function block is therefore not recommended.

*	Inputs		
VAR	INPUT		
	Execute	:	BOOL;
END	VAR		

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.

### ✓/Imputs/outputs

VAR IN OUT	
AxesGroup	: AXES_GROUP_REF;
PathData	: MC_PATH_DATA_REF;
END VAR	

Name	Туре	Description
AxesGroup	AXES_GROUP _REF	Reference to a group of axes (see <u>Cyclic group interface [&gt; 96]</u> ).
PathData	MC PATH DAT	Table containing the segments of a path. The table is written by
	A_REF [▶ 82]	MC_MoveLinearAbsolutePreparation [ ] 64],
		MC_MoveCircularAbsolutePreparation [ ] 66], MC_BlockerPreparation [ ] 72]
		and <u>MC_SetCoordinateTransformPreparation [▶ 54]</u> and executed by
		<u>MC_MovePath [▶ 70]</u> .

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Active	:	BOOL;
	CommandAborted	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT
END	VAR		

Name	Туре	Description
Done	BOOL	This output becomes TRUE when the command was successfully executed. This means that the last command defined by the reference variable PathData was executed successfully.
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.
Active	BOOL	If Active is TRUE, the FB controls the axis.
CommandA borted	BOOL	This output becomes TRUE if the command was interrupted by another command.
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

# 7.1.1.2.6 MC\_BlockerPreparation

	MC_BlockerPreparation			
	BlockerId UDINT BO	OL Error —		
	BufferMode MC_BUFFER_MODE UDINT ErrorId			
	InvokeId UDINT			
PathData Reference To MC_PATH_DATA_REF				
TES	5/10 TE5/20			

TwinCAT 3 Motion Collision Avoidance	TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	✓

The function block MC\_BlockerPreparation appends a blocking job to the list of segments in the PathData structure. The PathData table can be executed via <u>MC\_MovePath</u>. The function block MC\_BlockerPreparation can be called several times per cycle. A maximum of 30 entries are allowed per PathData table.

A blocking job is an entry that suspends execution of the path until it is resolved with <u>MC ReleaseBlocker</u> [ $\underbrace{73}$ ]. As long as the blocker is not resolved, the execution of the path is stopped at this segment. Each blocker has an Id so that the individual blockers can be distinguished in the PLC.

When a blocking job is active, the group status is still "moving".

If the override is changed while the blocking job is active, it will take effect for the next moving job. If a new job with BufferMode mcAborting is executed while the blocking job is active, the blocking job is aborted.

If <u>MC GroupHalt [ $\blacktriangleright$  60]</u> or <u>MC GroupStop [ $\blacktriangleright$  62]</u> are executed while the blocking job is active, the path is terminated and the blocking job is automatically released.

# Inputs VAR\_INPUT BlockerId : UDINT; BufferMode : MC\_BUFFER\_MODE := mcBuffered; InvokeId : UDINT; END VAR

Name	Туре	Description
BlockerId	UDINT	Id of the blocker. Can be any UDINT >0.
BufferMode	MC_BUFFER_M ODE	Defines how successive motion commands are to be processed (see <u>MC_BUFFER_MODE [ 86]</u> ). Only mcBuffered and mcAborting are allowed here.
Invokeld	UDINT	Segment ID for analysis purposes.

### 死 🖾 Inputs/outputs

```
VAR_IN_OUT
PathData : MC_PATH_DATA_REF;
END VAR
```

Name	Туре	Description
PathData	A_REF	Table containing the segments of a path. The table is written by the Preparation function blocks, like this one, and executed by <u>MC MovePath</u> (see <u>MC PATH DATA REF</u> ).

#### Outputs

VAR	OUTPUT
	Error
	ErrorId
END	VAR

:	BOOL;
:	UDINT;

Name	Туре	Description
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4024.7	PC or CX (x64)	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1		Tc3_McCoordinatedMotion, Tc2_MC2

### 7.1.1.2.7 MC\_ReleaseBlocker

	MC_ReleaseBlocker	
	Execute BOOL BOOL Done	
	BlockerId UDINT BOOL Busy	
$\rightarrow$	AxesGroup Reference To AXES_GROUP_REF BOOL Error	
	UDINT ErrorId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	

The function block MC\_ReleaseBlocker releases a blocking job that blocks further execution of the path. A blocking job is inserted into the path with MC\_BlockerPreparation [▶ 72].

With the Superpos blending strategy or, from TF5400 3.1.10.63, also with the GeoBlending strategy, the blocker can be resolved before the blocker position is reached. Blending between motion segments surrounding this blocker can be executed if those segments allow it and are still executable at the time the blocking job is released.

#### 🖻 Inputs

VAR\_INPUT Execute : BOOL; BlockerId : UDINT; END VAR

Name	Туре	Description
Execute	BOOL	The command is triggered by a rising edge at this input.
Blockerld	UDINT	Id of the blocker. Can be any UDINT >0.

#### ✓/Inputs/outputs

```
VAR_IN_OUT
AxesGroup : AXES_GROUP_REF;
END_VAR
```

Name	Туре	Description
AxesGroup	AXES_GROUP_ REF	Reference to an axis group (see <u>Cyclic Group Interface [▶ 96]</u> ).

### Outputs

VAR	OUTPUT		
	Done	:	BOOL;
	Busy	:	BOOL;
	Error	:	BOOL;
	ErrorId	:	UDINT;
FND	177 P		

END\_VAR

Name	Туре	Description	
Done	BOOL	This output becomes TRUE when the command was successfully executed.	
Busy	BOOL	This output becomes TRUE when the command is started with Execute and remains so as long as the function block executes the command. If Busy becomes FALSE again, the function block is ready for a new command. At the same time one of the outputs Done, CommandAborted (if available) or Error is set.	
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.	
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).	

#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4024.7	PC or CX (x64)	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1		Tc3_McCoordinatedMotion, Tc2_MC2

## 7.1.1.2.8 MC\_GroupReadBlockerStatus

MC_GroupReadBlockerStatus		
Enable BOOL AxesGroup Reference To AXES_GROUP_REF	BOOL Valid BOOL Blocked UDINT BlockerId	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	

The function block MC\_GroupReadBlockerStatus reads the current blocker status.

🐔 Input	s	
VAR_INPU Enab END_VAR		: BOOL;
Name	Туре	Description
Enable	BOOL	Enables reading of the current blocker status.

### ✓/Inputs/outputs

VAR\_IN\_OUT AxesGroup : AXES\_GROUP\_REF; END\_VAR

Name	Туре	Description
AxesGro	AXES_GROU	Reference to an axis group (see Cyclic Group Interface [ 96]).
up	P_REF	

#### Solution Outputs

VAR	OUTPUT		
_	Valid	:	BOOL;
	Blocked	:	BOOL;
	BlockerId	:	UDINT;
END	VAR		

Name	Туре	Description
Valid		Returns TRUE if a valid group type is used. Only group type MC Group Coordinated Motion is allowed.
Blocked		Returns TRUE if a blocking job is active, i.e. execution of the path is stopped. Returns FALSE if no blocking job is active.
Blockerl d	UDINT	Id of the blocker. Can be any UDINT >0.

#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4024.7	PC or CX (x64)	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1		Tc3_McCoordinatedMotion, Tc2_MC2

### 7.1.1.2.9 MC\_DwellTimePreparation

MC_DwellTimePreparation	
— DwellTime TIME	BOOL Error
BufferMode MC_BUFFER_MODE	UDINT ErrorId
InvokeId UDINT	
PathData Reference To MC_PATH_DATA_REF	

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place		
	MC Group with Pick-and-Place	MC Group Coordinated Motion	
×	×	✓	

The function block MC\_DwellTimePreparation appends a standstill job with a defined time to the table of segments in the PathData structure. The PathData table can be executed via <u>MC\_MovePath</u>. The function block MC\_DwellTimePreparation can be called several times per cycle.

```
Inputs
VAR_INPUT
DwellTime : Time;
BufferMode : MC_BUFFER_MODE := mcBuffered;
InvokeId : UDINT;
END VAR
```

Name	Туре	Description
DwellTime	Time	Time during which the path is stationary at velocity 0. Any timespan >= 0 is allowed. A DwellTime of zero leads to an exact stop, even if the surrounding segments would allow a transition with a velocity > 0.
BufferMode	MC_BUFFER_MODE	Defines how successive motion commands are to be processed (see <u>MC BUFFER MODE [ 86]</u> ). Only mcBuffered and mcAborting are allowed here.
Invokeld	UDINT	Segment ID for analysis purposes.

## ✓/Imputs/outputs

VAR	IN_OUT					
	PathData	:	MC	PATH	DATA	REF;
END	VAR					

Name	Туре	Description
PathData		Table containing the segments of a path. The table is written by thePreparation function blocks, like this one, and executed byMC_MovePath (see MC_PATH_DATA_REF).

#### Outputs

VAR	OUTPUT		
V I II (			
	Error	:	BOOL;
	ErrorId	:	UDINT;
END	VAR		

Name	Туре	Description
Error	BOOL	This output becomes TRUE if an error has occurred during command execution.
Errorld	UDINT	Contains the command-specific error code of the last executed command. Details of the error code can be found in the <u>ADS error</u> <u>documentation</u> or in the <u>NC error documentation</u> (error codes 0x4nnn and 0x8nnn).

#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4024.7	PC or CX (x64)	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1		Tc3_McCoordinatedMotion, Tc2_MC2

## 7.1.2 Datatypes

### 7.1.2.1 IDENT\_IN\_GROUP\_REF

TwinCAT 3 Motion Collision		TF5420 TwinCAT 3 Motion Pick-and-Place	
		MC Group with Pick-and-Place	MC Group Coordinated Motion
	×	✓	<

IDENT\_IN\_GROUP\_REF defines how an axis is interpreted in a group. Global variables can be used for multi-dimensional movements. For PTP collision-avoidance groups, the <u>UDINT\_TO\_IDENTINGROUP</u> [> 59] function must be called.

....

Use of integer values for the input IdentInGroup

The use of integer values for the input IdentInGroup is NOT supported and may lead to incompatibility with future releases. If integer values are used, it may no longer be possible to build the project. We recommend using <u>global variables</u> [▶ <u>76</u>] (e.g. MCS\_X) or the conversion function <u>UDINT\_TO\_IDENTINGROUP</u> [▶ <u>59</u>].

The constants below define axes as Cartesian axes in the machine coordinate system (MCS). A to C define the rotation axis (C: rotation around Z; B: rotation around Y; A: rotation around X). The number determines the rotation order. For example, if one axis is defined as MCS\_C1 and another as MCS\_B2, the system will first rotate around the Z-axis and second around the Y-axis

VAR GLOBAL	
MCS X	: IDENT IN GROUP REF;
MCS Y	: IDENT IN GROUP REF;
MCSZ	: IDENT IN GROUP REF;
—	
MCS A1	: IDENT IN GROUP REF;
MCS A2	: IDENT IN GROUP REF;
MCS A3	: IDENT IN GROUP REF;
—	`
MCS B1	: IDENT IN GROUP REF;
MCS B2	: IDENT IN GROUP REF;
MCS_B3	: IDENT IN GROUP REF;
-	`
MCS C1	: IDENT IN GROUP REF;
MCS_C2	: IDENT IN GROUP REF;
MCS_C3	: IDENT IN GROUP REF;
—	
//new from TF5400 V3.1.10.1,	only compatible with MC Group Coordinated Motion
ADDAX1	: IDENT IN GROUP REF;
ADDAX2	: IDENT IN GROUP REF;
ADDAX3	: IDENT IN GROUP REF;
ADDAX4	: IDENT IN GROUP REF;
// new from TF5400 V3.2.27,	only compatible with MC Group
ADDAX5	: IDENT IN GROUP REF;
ADDAX6	: IDENT IN GROUP REF;
ADDAX7	: IDENT IN GROUP REF;
ADDAX8	: IDENT IN GROUP REF;
END VAR	
	MCS_X MCS_Y MCS_Z MCS_A1 MCS_A2 MCS_A3 MCS_B1 MCS_B2 MCS_B3 MCS_C1 MCS_C2 MCS_C3 //new from TF5400 V3.1.10.1, ADDAX1 ADDAX2 ADDAX3 ADDAX3 ADDAX5 ADDAX5 ADDAX5 ADDAX6 ADDAX7 ADDAX8

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.1.2.2 MC\_CIRC\_MODE

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
×	×	✓
	( 💙 up to and including v3.2)	


The circle mode determines which circle definition is used to program a circle.

TYPE MC\_CIRC\_MODE : ( mcCircModeInvalid := 16#0000, mcCircModeBorder := 16#2000, mcCircModeCenter := 16#2001, mcCircModeRadius := 16#2002 . END\_TYPE

#### mcCircModeInvalid

• This parameter is invalid and will lead to an error where a valid MC\_CIRC\_MODE **Returns errors** argument is required.

#### mcCircModeBorder




StartPoint	<ul><li>The movement starts at the starting point "StartPoint".</li><li>This point is the endpoint of the preceding move command.</li></ul>
EndPoint	<ul><li>The user configures the endpoint "EndPoint".</li><li>The circular movement will end at this point.</li></ul>
AuxPoint	<ul><li>The user configures the auxiliary point "AuxPoint".</li><li>The circular movement will pass through this point.</li></ul>
PathChoice	<ul> <li>The input parameter "PathChoice" and the data type "MC_CIRC_PATHCHOICE" are ignored.</li> </ul>
Applicability	<ul> <li>The mode mcCircModeBorder cannot be used to describe a full circle (i.e. "StartPoint" equals "EndPoint"). This is due to the fact that in this the center point of the circle would be ambiguous.</li> </ul>
	<ul> <li>The mode mcCircModeBorder cannot be used to describe paths with more than one full rotation of the circle.</li> </ul>

BECKHOFF

#### PLC Libraries


# **BECKHOFF**


#### mcCircModeCenter



StartPoint	<ul><li>The movement starts at the starting point "StartPoint".</li><li>This point is the endpoint of the preceding move command.</li></ul>
EndPoint	<ul><li>The user configures the endpoint "EndPoint".</li><li>The circular movement will end at this point.</li></ul>
AuxPoint	<ul> <li>The user configures the auxiliary point "AuxPoint".</li> <li>For the circular movement this auxiliary point will act as the circle center point.</li> <li>The center point is required to have the same distance from "StartPoint" and "EndPoint". If the distances differ only slightly, the center point will be adjusted. If the distances differ significantly, the circle description will not be accepted.</li> </ul>
PathChoice	<ul> <li>There are usually two possible arcs of the circle that can be traversed from starting point "StartPoint" to the endpoint "EndPoint". The "PathChoice" parameter makes the two unique. See MC_CIRC_PATHCHOICE for more information.</li> </ul>
Applicability	<ul> <li>The mode mcCircModeCenter cannot be used to describe a semicircle (i.e. an arc that traverses an angle of 180° or very close to that) or a full circle (i.e. "StartPoint" equals "EndPoint"). This is due to the fact that in these cases starting point, center point and endpoint would be collinear and thus the plane in which the circle lies would be ambiguous.</li> <li>The mode mcCircModeCenter cannot be used to describe paths with more than one</li> </ul>
	full rotation of the circle.

#### mcCircModeRadius





Images	<ul> <li>Four different arcs are distinguished by the orientation of the normal vector and the parameter "PathChoice".</li> </ul>
StartPoint	<ul><li>The movement starts at the starting point "StartPoint".</li><li>This point is the endpoint of the preceding move command.</li><li>The circle to be constructed and its plane contain the starting point.</li></ul>
AuxPoint Normal Vector	<ul> <li>The user configures the parameter "AuxPoint", which in this mode acts as the normal vector of the plane of the circle. Its length is taken as the radius of the circle.</li> </ul>

EndPoint	<ul> <li>The user configures the endpoint "EndPoint".</li> <li>The movement will end at this point.</li> <li>MC group with pick-and-place only: If this point is outside the plane defined by "StartPoint" and the normal vector, movement will follow a helix instead of a circle.</li> </ul>
PathChoice and resulting arc	<ul> <li>The right-hand rule is applied for all "PathChoice" values except mcCircPathchoiceClockwise, which follows the left-hand rule.</li> <li><i>mcCircPathchoiceCounterClockwise</i> and <i>mcCircPathchoiceShortSegment</i> describe an arc that covers an angle &lt;= 180°, <i>mcCircPathchoiceClockwise</i> and <i>mcCircPathchoiceLongSegment</i> describe an arc that covers an angle &gt;= 180°.</li> <li>Which of the 4 possible arcs with a given radius is chosen depends on the "PathChoice" argument and the orientation of the normal vector. See above table for more information.</li> </ul>
Applicability	<ul> <li>The mode mcCircModeRadius can only be used to describe arcs that cover an angle &lt; 360°.</li> <li>The length of the normal vector (i.e. the radius of the circle) must be at least half the distance between starting point and endpoint.</li> </ul>

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.2.47	CX (x64)	Tc2_MC2

## 7.1.2.3 MC\_CIRC\_PATHCHOICE

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	✓
	( 💙 up to and including v3.2)	

The MC\_CIRC\_PATHCHOICE data type defines the direction of rotation of a circle if mcCircModeCenter or mcCircModeRadius is selected from the enumeration <u>MC\_CIRC\_MODE [} 77]</u>.

TYPE MC CIRC PATHCHOICE :	
(	
mcCircPathchoiceClockwise	:= 16#3000,
mcCircPathchoiceCounterClockwise	:= 16#3001
//new from TF5400 V3.1.10.1	
mcCircPathchoiceShortSegment	:= 16#3002,
mcCircPathchoiceLongSegment	:= 16#3003
);	

```
END_TYPE
```

Name	Туре	Description
mcCircPathchoiceClockwise	INT	represents the circle segment with an angle >180°.
mcCircPathchoiceCounterClockwise	INT	represents the circle segment with an angle <180°.
mcCircPathchoiceShortSegment	INT	represents the circle segment with the smaller angle.
mcCircPathchoiceLongSegment	INT	represents the circle segment with the larger angle.

### 7.1.2.4 MC\_PATH\_DATA\_REF

MC_PATH_DAT	A_REF	
	UDINT FilledRows	
L	IDINT OccupiedBuffer	
	1	
TF5410	TF5420	
TwinCAT 3 Motion Collision Avoidance	TwinCAT 3 Motion Pick-and-Pla	ce
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	×
	( 💙 up to and including v3.2)	

MC\_PATH\_DATA\_REF represents the path to be executed by <u>MC\_MovePath []</u> 70], whereby the number of entries is limited to 30. The path to be executed is written by <u>MC\_MoveLinearAbsolutePreparation []</u> 64], <u>MC\_MoveCircularAbsolutePreparation []</u> 66] and <u>MC\_BlockerPreparation []</u> 72]. It is initialized with a pointer to a user-defined buffer. Hereby the user can define the size of the path. The initialization has to be done during declaration. The path table is not reset at execution. To reset, the method <u>ClearPath []</u> 83] must be called.

#### Outputs

VAR	OUTPUT		
_	FilledRows	:	UDINT;
	OccupiedBuffer	:	UDINT;
END	VAR		

Name	Туре	Description
FilledRows	UDIN T	Number of path entries (e.g. path segments).
OccupiedBuffer	UDIN T	Occupied buffer size in byte. By analyzing this output the user can analyze if the end of the defined buffer will be reached.

#### Sample

The sample below shows how to declare a path reference and how to reset an existing path.

```
VAR
buffer : ARRAY[1..4096] OF BYTE;
Path : MC_PATH_DATA_REF(ADR(buffer), SIZEOF(buffer));
END_VAR
//delete all segments of path table
Path.ClearPath();
```



The data type MC\_PATH\_DATA\_REF is part of the Motion Control (MC) library. Use the method ClearPath() to clear path information of type MC\_PATH\_DATA\_REF and thus to reset an existing path. Use only Motion Control functions or Motion Control function blocks on the data type MC\_PATH\_DATA\_REF. In particular, do not use any storage functions such as MEMCMP, MEMCPY, MEMSET or MEMMOVE with data type MC\_PATH\_DATA\_REF.

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.1.2.4.1 ClearPath

ClearPath

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	9
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	<ul> <li>Image: A set of the set of the</li></ul>
	( 💙 up to and including v3.2)	

The method ClearPath resets the path represented by MC\_PATH\_DATA\_REF. The path table is not reset automatically at execution.

### 7.1.2.5 MC\_TRANSITION\_MODE

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Plac	e
	MC Group with Pick-and-Place	MC Group Coordinated Motion
×	×	✓
	( ✓ up to and including v3.2)	

The transition mode characterizes the way a segment transition is executed.

TYPE MC TRANSITION MODE :	
(	
mcTransModeNone	:= 16#1000,
mcTransModeStartVelocity	:= 16#1001,
mcTransModeConstantVelocity	:= 16#1002,
mcTransModeCornerDistance	:= 16#1003,
mcTransModeMaxCornerDeviation	:= 16#1004,
mcTransModeCornerDistanceAdvanced	:= 16#100A
);	
END TYPE	

The following table shows an overview of the implemented transition modes and the number of parameters that must be defined in TransitionParameterCount.

Name	TransitionParameterCount	Description
mcTransModeNone	No effect	No blending
mcTransModeCornerDistance not compatible with MC Group with Pick-and-Place, available from TF5400 V3.1.10.1	1	Transition parameters act as a tolerance sphere in which the path may be left.
mcTransModeCornerDistanceAd vanced	2	Transition parameters act as a tolerance sphere in which the path may be left.

#### mcTransModeNone

No blending is executed. Stop at segment transition.

#### mcTransModeCornerDistance


Blending is executed between the segments. The transition parameters act as tolerance ball in which the programmed path is not followed. The parameter describes the radius on the previous and second segment at which the blending starts and ends.

This mode is only compatible with MC Group Coordinated Motion.

#### mcTransModeCornerDistanceAdvanced

Blending is executed between the segments. The transition parameter act as tolerance ball in which the programmed path is not followed. The first parameter describes the radius on the previous segment at which the blending starts (r\_in). The second parameter describes the radius on the following segment (r\_out) which defines a position for which it is guaranteed that the blending is done. The parameter r\_out is a maximum value. The blending can end before r\_out is reached.

Blending (r\_in) with MC Group with Pick-and-Place is limited to 90 % of previous segment. r\_out is not limited.



Recommended Transition Parameter Relation for Blending with MC Group with Pickand-Place

The graphics sketch a planar movement within two dimensional space. Let two axes be involved in this movement. Assuming that the involved axes exhibit similar dynamics  $r_out$  should measure at least 2 \* r in.

#### Combinations of buffer mode and transition mode

Buffer mode and transition mode are combined only when TF5420 is used.

The following table shows the possible combinations of transition mode and buffer mode and their effect.

TM/PM	mcAborting	mcBuffered	mcBlendingPrevi- ous	Others
mcTransModeNone	The previous command is canceled immediately. A new movement is started. The velocity in transition is 0. This combination is only permitted for the first segment of a path.	Stop at the end of the previous command. The next command is then executed.	Not permissible	Not permissible
mcTransModeCorn erDistance New from TF5400 V3.1.10.1, only compatible with MC Group Coordinated Motion	Blending from the active segment to the first segment of the new command. The intersection of the segments is defined by the distance needed to stop on the active segment. This combination is only permitted for the first segment of a path.	Not permissible	Blending from the last programmed command to the new command	Not permissible
mcTransModeCorn erDistanceAdvance d	Blending from the	Not permissible	Blending from the last programmed command to the new command	Not permissible
Others	Not permissible	Not permissible	Not permissible	Not permissible

#### Requirements

ies
ordinatedMotion,

## 7.1.2.6 MC\_COORD\_REF

TF5410 TwinCAT 3 Motion Collision Avoidance	TF5420 TwinCAT 3 Motion Pick-and-Place	
	MC Group with Pick-and-Place MC Group Coordinated Motion	
×	×	✓
	( 💙 up to and including v3.2)	

Object Id that refers to a node connector.

## 7.2 Tc3\_Mc3Definitions

#### Structures and enumerations

Name	Description		TF5420 TwinCAT 3 Motion Pick- and-Place	
		TF5410 Twin- CAT 3 Motion Collision Avoidance	MC Group with Pick- and-Place	MC Group Coordi- nated Mo- tion
MC_BUFFER_MODE	Defines how successive travel commands are to be processed.	<ul> <li></li> </ul>	~	<ul> <li></li> </ul>
MC_COMPENSATION_T YPE [▶ 89]	The value defines the compensation type.	<ul> <li>Image: A start of the start of</li></ul>	×	×
MC_DIRECTION [▶ 90]	The value determines the direction of the movement.	<ul> <li></li> </ul>	×	×
MC SYNC MODE [▶_91]	The value defines the direction in which synchronization is to be performed.	✓	×	×
MC_SYNC_STRATEGY [▶_91]	Defines the synchronization profile of the slave axis.	<ul> <li></li> </ul>	×	×

## 7.2.1 Datatypes

### 7.2.1.1 MC\_BUFFER\_MODE

The data type MC\_BUFFER\_MODE is used to specify how successive travel commands are to be processed. At least two function blocks are required for buffer mode to have an effect.

```
TYPE MC_BUFFER_MODE :

(

mcAborting := 16#0,

mcBuffered := 16#1,

mcBlendingLow := 16#12,

mcBlendingPrevious := 16#13,

mcBlendingNext := 16#14,

mcBlendingHigh := 16#15


) UINT;

END TYPE
```

	TF5420 sion TwinCAT 3 Motion Pick-and-Place	
Avoidance	MC Group with Pick-and-Place	MC Group Coordinated Motion
✓	✓	✓


#### Example:

In the following example, a move command is used to move a group from position  $P_0$  to  $P_1$  and then to  $P_2$ . The reference point for the different velocity profiles is always  $P_1$ . The mode specifies the velocity  $v_1$  or  $v_2$  at this point.



Since the speed of the first command is lower than the second, the modes BlendingLow/BlendingPrevious and BlendingHigh/BlendingNext have the same result.

If the speed of the second command is lower than the first the modes BlendingLow/BlendingNext and BlendingHigh/BlendingPrevious are equivalent.



#### Combinations of buffer mode and transition mode

#### *Notice* Buffer mode and transition mode are merely combined using TF5420.

The following table shows possible combinations of transition mode and buffer mode and its effect.

ТМ/ВМ	mcAborting	mcBuffered	mcBlendingPrevi- ous	Other
mcTransModeNone	Previous command is aborted immediately. New movement is started. Velocity in transition is 0. This combination is only allowed for the 1 <sup>st</sup> segment of a path.	Stop at the end of previous command. Subsequently next command is executed.	Not allowed	Not allowed
mcTransModeCorn erDistance new from V3.1.10.1, only compatible with MC Group Coordinated Motion	Blending from active segment to first segment of new command. The intersection point of the segments is defined by the distance needed to stop on the active segment. This combination is only allowed for the 1st segment of a path.	Not allowed	Blending from last programmed command to new command	Not allowed
mcTransModeCorn erDistanceAdvance d	Blending from active segment to first segment of new command. The intersection point of the segments is defined by the distance needed to stop on the active segment. This combination is only allowed for the 1 <sup>st</sup> segment of a path.	Not allowed	Blending from last programmed command to new command	Not allowed
Other	Not allowed	Not allowed	Not allowed	Not allowed

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack V3.1.1.17		Tc2_MC2

### 7.2.1.2 MC\_COMPENSATION\_TYPE

The data type MC\_COMPENSATION\_TYPE is used to specify which compensation type is to be used.

```
TYPE MC_COMPENSATION_TYPE:
(
mcTypeInvalidCompensation := 16#0,
mcTypeGeoCompensation := 16#1,
)UINT;
END TYPE
```

TF5410       TF5420         TwinCAT 3 Motion Collision       TwinCAT 3 Motion Pick-and-Place         Avoidance       MC Group with Pick-and-Place		
		MC Group Coordinated Motion
✓	×	×

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCompensations
TF5400 Advanced Motion Pack V3.1.6.07		

### 7.2.1.3 MC\_DIRECTION

```
,
END TYPE
```

TF5410 TwinCAT 3 Motion Collision	TF5420 TwinCAT 3 Motion Pick-and-Place	
Avoidance	MC Group with Pick-and-Place	MC Group Coordinated Motion
✓	×	×

MC\_DIRECTION is used to specify the direction of movement during modulo positioning. Modulo positioning is only applicable to periodic systems. For open systems such as open tracks, only the value mcDirectionNonModulo is accepted.

mcDirectionNonModulo: The position is always interpreted as an absolute position.

mcDirectionPositive: Positive direction of movement

mcDirectionNegative: Negative direction of movement

**mcDirectionShortestWay:** The direction of movement depends on whether the positive direction or the negative direction has the shortest distance to the target position.

In combination with the Tc2\_MC2 or Tc3\_Mc3Definitions library it is possible that the data type cannot be resolved unambiguously (ambiguous use of name 'MC\_Direction'). In this case the namespace must be specified when using the data type (Tc3\_Mc3PlanarMotion.MC\_DIRECTION or Tc3\_Mc3Definitions.MC\_DIRECTION or Tc2\_MC2.MC\_DIRECTION).

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4024.7	PC or	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1	CX (x64)	Tc3_McCoordinatedMotion, Tc2_MC2

### 7.2.1.4 MC\_SYNC\_MODE

(\* Defines the direction of the synchronization position of modulo axes. \*) TYPE MC\_SYNC\_MODE :

(		
	mcSyncModeNonModulo	:= 0, (* SyncSlavePosition is interpreted as absolute position. *)
	mcSyncModePositive	:= 1, (* Synchronizes in positive direction. *)
	mcSyncModeNegative	:= 3 (* Synchronizes in negative direction. *)
)		
END	TYPE	

TF5410 TwinCAT 3 Motion Collision	TF5420 TwinCAT 3 Motion Pick-and-Place	
Avoidance	MC Group with Pick-and-Place MC Group Coordinated Motion	
✓	×	×

The value defines the direction in which synchronization is to be performed. The SyncMode specification is only effective if a modulo coordinate system has been defined for the axis. This can be a closed XTS track or a closed CA group, for example. The value is ignored if there is only one mathematical solution for reaching the synchronous position.

mcSyncModeNonModulo: The SlaveSyncPosition is always interpreted as an absolute position.

mcSyncModePositive: The slave axis synchronizes itself in positive direction of movement.

mcSyncModeNegative: The slave axis synchronizes itself in negative direction of movement.

#### Requirements

Development environment		PLC libraries to include
TwinCAT V3.1.4024.7	PC or	Tc3_McCollisionAvoidance,
TF5400 Advanced Motion Pack V3.1.10.1	CX (x64)	Tc3_McCoordinatedMotion, Tc2_MC2

### 7.2.1.5 MC\_SYNC\_STRATEGY

The data type MC\_SYNC\_STRATEGY defines the synchronization profile of the slave for e.g. a MC\_GearInPosCA command.

```
TYPE MC_SYNC_STRATEGY :
(
mcSyncStrategyLate := 16#1,
mcSyncStrategySlow := 16#2,
mcSyncStrategyEarly := 16#3
```

, END TYPE

TF5410 TwinCAT 3 Motion Collision	TF5420 TwinCAT 3 Motion Pick-and-Place		
Avoidance	MC Group with Pick-and-Place	MC Group Coordinated Motion	
<ul> <li></li> </ul>	×	×	

#### Examples:

The boundary conditions in the following examples are equal:


- The master motion is equal.
- The MasterStartDistance is equal.
- The distances (MasterSyncPosition current master position) and (SlaveSyncPosition current slave position) are in all three examples equal.
- · The slave dynamics are equal.
- · Configuration with one axis in the CA Group, one PTP axis as master.

• A motion command is issued to the master.

#### Example 1: mcSyncStrategyLate

The slave starts the synchronization as late as possible and with full dynamics (according to the input values velocity, acceleration, deceleration, jerk). It reaches the SlaveSyncPosition just in time with the correct gear ratio. The user has to take care that the master does not accelerate once the slave signals StartSync, since the synchronization profile is already planned with the maximal slave dynamics. The slave cannot violate its dynamic restrictions and therefore cannot compensate any master acceleration. This situation will result in an error at the function block.


- 1. Issue the command MC\_GearInPosCA to the axis. The command becomes active while the master is still accelerating.
- ⇒ The slave starts synchronizing as late as possible and with full dynamics, and reached the SlaveSyncPosition when the master reached the MasterSyncPosition (black x-Cursor).



#### Example 2: mcSyncStrateySlow


The slave starts its synchronization in motion as soon as the master passes (MasterSyncPosition - MasterStartDistance) in the right direction if a MasterStartDist was set, otherwise as soon as the function block is Active. The dynamics of the slave are reduced so that the slave reaches the SlaveSyncPos with the right gear factor just in time when the master reaches the MasterSyncPos. The slave can compensate for an acceleration of the master if StartSync is also set, but only until the slave reaches its maximum dynamics.

- 1. Issue the command MC\_GearInPosCA to the axis. The command becomes active while the master is still accelerating.
- The slave starts synchronizing as soon as MC\_GearInPosCA is Active. The dynamics is reduced such that the slave reaches the SlaveSyncPosition at the same time the master reaches the MasterSyncPosition (black x-Cursor).



It is best to use mcSyncStrategyEarly in this case.






#### Example 3: mcSyncStrategyEarly

The slave starts synchronization immediately (if a MasterStartDistance is set: immediately after it was passed) and with full dynamics. The slave signals earlier InSync than demanded by the SlaveSyncPosition, but it is still guaranteed that demanded offset between master and slave (MasterSyncPosition – SlaveSyncPosition) is reached with the correct gear ratio. This strategy can synchronize on a standing master and is best suited if the master velocity is not constant. The slave will constantly try to synchronize. If the boundary conditions do not allow the slave to be InSync at the SlaveSyncPosition, this will not result in an error but the slave constantly tries to synchronize to the master.

- 1. Issue the command MC\_GearInPosCA to the axis. The command becomes active while the master is still accelerating.
- ⇒ The slave starts the synchronization as soon as MC\_GearInPosCA is Active and with full dynamics. The slave is InSync as soon as possible, but still reaches the SlaveSyncPosition at the same time the master reaches the MasterSyncPosition (black x-Cursor).



#### Requirements

Development environment	Target platform	PLC libraries to include
TwinCAT V3.1.4018.26	PC or CX (x64)	Tc3_McCoordinatedMotion,
TF5400 Advanced Motion Pack		Tc2_MC2
V3.1.1.17		

# 8 Samples

#### Multi-dimensional motion

#### PnpSimpleSample

Download: https://infosys.beckhoff.com/content/1033/TF5420\_TC3\_Advanced\_Pick\_And\_Place/Resources/ 9725595531.zip

Description: Project that executes a simple pick and place-movement.

#### PnPSimpleSample with an additional axis and blocking

Download: https://infosys.beckhoff.com/content/1033/TF5420\_TC3\_Advanced\_Pick\_And\_Place/Resources/ 9725597195.zip

Description: Project that contains an additional axis and a blocking job.

# 9 Appendix

## 9.1 Cyclic Group Interface

The cyclic group interface provides the cyclical data exchange between PLC and a NC group object. The group interface contains the directions <u>NcToPlc [ $\blacktriangleright$  96]</u> and <u>PlcToNc [ $\blacktriangleright$  97]</u>. Both direction are divided in common and group specific data.

#### AXES\_GROUP\_REF

```
TYPE AXES_GROUP_REF :

STRUCT

PlcToNc AT %Q* : CDT_PLCTOMC_GROUP;

NcToPlc AT %I* : CDT_MCTOPLC_GROUP;

END_STRUCT

END TYPE
```

**PICTONC**: <u>PICTONC</u>[**>**<u>97</u>] is a data structure that is cyclically exchanged between PLC and NC. Via this data structure the MC function blocks communicate with the motion group and send control information from the PLC to the NC. This data structure is automatically placed in the output process image of the PLC and must be linked with the input process image of a motion group.

**NcToPlc**: <u>NcToPlc</u> [▶ <u>96]</u> is a data structure that is cyclically exchanged between PLC and NC. Via this data structure the MC function blocks communicate with the NC and receive status information from the NC. This data structure is automatically placed in the input process image of the PLC and must be linked in TwinCAT System Manager with the output process image of an NC axis.

## 9.1.1 NcToPlc

The structure is divided into general data and group-specific data.

#### General

GroupOID: TcCOM object ID (OID) of this group.

**GroupType**: Type of this group: 0 = Invalid (mcGroupTypeInvalid), 1 = Collision avoidance (mcGroupTypeCA), 2 = DXD/CNC (mcGroupTypeDxd).

GroupStatus: Contains information about the group status (see <u>GroupStatus [ 96]</u>).

GroupErrorld: Identification of current error (0 = no error).

GroupAxesCount: Number of axes currently belonging to this group (e.g. added via MC\_AddAxisToGroup).

#### GroupStatus:

State: See Group State Diagram.

- 1 = Disabled (mcGroupStateDisabled)
- 2 = Standby (mcGroupStateStandby)
- 3 = Moving (mcGroupStateMoving)
- 4 = Stopping (mcGroupStateStopping)
- 5 = Error Stop (mcGroupStateErrorStop)
- 6 = Homing (mcGroupStateHoming)
- 7 = Not Ready (mcGroupStateNotReady)
- 8 = Suspended (mcGroupStateSuspended)

Flags: Additional optional status information.

IsEnableRequested: Defines whether an activation or deactivation of a group is requested.

#### **Dxd** (multi-dimensional movement)

PathVelo: Velocity on the path without direction.

Invokeld: Segment ID for analysis purposes.

#### CM (MC Group Coordinated Motion)

available from V3.1.10.1

PathVelo: Absolute value of the Cartesian velocity on the path.

Invokeld: Segment ID for analysis purposes.

**IsInBlendingSegment:** Indicates whether a blendig segment is active.

**RemainingTimeActiveJob:** Remaining time of the current segment.

RemainingCartesianDistanceActiveJob: Remaining distance for the current segment.

ActiveBlockerId: Id of the active blocker.

available from V3.1.10.30

**RemainingTimeToSync**: Remaining time until the axis group is synchronized with the conveyor belt during conveyor tracking.

**RemainingCartesianDistanceToSync**: Remaining distance until the axis group is synchronized with the conveyor belt during conveyor tracking.

### 9.1.2 PIcToNc

The structure is divided in a common data and a group specific data.

#### Common

**OverrideFactor**: Desired Override Factor (1.0 = 100%, Default Value is 1.0)

## 9.2 Index Offset Specification for MC Group Parameters

Port 501: AMSPORT R0 NCSAF: UINT := 501;.

The Object ID (OID) of the MC group must be designated as the index group.

Index offset (Hex)	Access	Group type	Data Type		Definition range	Description	Comments
0x5030084	Read	MC Group	LREAL	mm	>=0	distance of the	Only available for MC Group with Pick-and- Place from V3.1.6.27
0x5030085	Read	MC Group	LREAL	S	>=0	time for the	Only available for MC Group with Pick-and- Place from V3.1.6.27

## 9.3 Differences between MC2 and MC3

This chapter lists differences between MC2 and MC3 (as introduced in TF5400 Advanced Motion Pack).

#### Axes

MC2	MC3
l	There are maximum values for velocity, acceleration, deceleration and jerk which limit the values that

MC2	MC3
Acceleration, deceleration and Jerk specified in the axis are default values that only have an effect if no dynamics is specified in FBs.	default dynamics can be selected

#### **PLC Library**

	MC2	MC3
Default values	For dynamics parameters of type LREAL "0" is default value. If "0" is set the default parameters from the axes are used.	The constant MC_Default is introduced (see <u>MC_LREAL/Special</u> <u>Input Values [ &gt; 98]</u> ). "0" is not interpreted as default value but as a normal value which in case of dynamics can be invalid.
Timing of FB outputs	FB returns values that were valid at the start of PLC cycle.	FB returns values that are valid at the moment PLC code is executed. This may lead to timing difference between cyclic interface and FB output.
Decoupling	A special function block can be used (e.g. MC_GearOut/ MC_CamOut)	The slave axis is decoupled by sending another motion command with Buffermode mcAborting.

## 9.4 MC\_LREAL/Special Input Values

Data type MC\_LREAL, is equivalent to data type LREAL. However, there exist a few additional values that have a special signification.

Value	Signification	Example
MC_DEFAULT	The input is executed with default value for this input.	Acceleration, Deceleration, Jerk for all motion commands
MC_MAXIMUM	The command is executed with maximum value for this input.	Generally, from software version 3.1.4.4 on for specific motion commands the value MC_MAXIMUM can be assigned to the inputs Velocity, Acceleration, Deceleration and Jerk. For more detailed information refer to the particular documentation of the function block the input intended to be supplied with the MC_MAXIMUM value belongs to.
MC_IGNORE	The input is ignored.	MC_GearInPosCA.MasterStartDist ance
MC_INVALID	The input must be set by the user, there exists no default or maximum value, nor can the input be ignored.	MC_MoveAbsoluteCA.Position

#### Trademark statements

Beckhoff<sup>®</sup>, TwinCAT<sup>®</sup>, TwinCAT/BSD<sup>®</sup>, TC/BSD<sup>®</sup>, EtherCAT<sup>®</sup>, EtherCAT G<sup>®</sup>, EtherCAT G10<sup>®</sup>, EtherCAT P<sup>®</sup>, Safety over EtherCAT<sup>®</sup>, TwinSAFE<sup>®</sup>, XTS<sup>®</sup> and XPlanar<sup>®</sup> are registered trademarks of and licensed by Beckhoff Automation GmbH.

More Information: www.beckhoff.com/TF5420

Beckhoff Automation GmbH & Co. KG Hülshorstweg 20 33415 Verl Germany Phone: +49 5246 9630 info@beckhoff.com www.beckhoff.com

