

Documentation

KL2692

Watchdog Terminal

Version: 2.0.0
Date: 2017-08-07

BECKHOFF

Table of contents

| | |
|---|-----------|
| 1 Foreword | 5 |
| 1.1 Notes on the documentation | 5 |
| 1.2 Safety instructions | 6 |
| 1.3 Documentation issue status | 7 |
| 2 Product overview | 8 |
| 2.1 Introduction | 8 |
| 2.2 Technical data | 9 |
| 2.3 Basic function principles | 9 |
| 2.4 LEDs | 11 |
| 3 Mounting and wiring | 12 |
| 3.1 Installation on mounting rails | 12 |
| 3.2 Connection | 14 |
| 3.2.1 Connection system | 14 |
| 3.2.2 Wiring | 16 |
| 3.2.3 Connection | 18 |
| 3.3 Application example | 19 |
| 4 KS2000 Configuration Software | 20 |
| 4.1 KS2000 - Introduction | 20 |
| 4.2 Parameterization with KS2000 | 21 |
| 4.3 Register | 23 |
| 4.4 Settings | 24 |
| 4.5 Process data | 24 |
| 5 Access from the user program | 26 |
| 5.1 Process image | 26 |
| 5.2 Control and status byte | 26 |
| 5.3 Register overview | 28 |
| 5.4 Register description | 29 |
| 5.5 Examples of Register Communication | 30 |
| 5.5.1 Example 1: reading the firmware version from Register 9 | 30 |
| 5.5.2 Example 2: Writing to an user register | 30 |
| 6 Appendix | 33 |
| 6.1 Support and Service | 33 |

1 Foreword

1.1 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE®, XFC® and XTS® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, DE102004044764, DE102007017835 with corresponding applications or registrations in various other countries.

The TwinCAT Technology is covered, including but not limited to the following patent applications and patents: EP0851348, US6167425 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 Safety instructions

Safety regulations

Please note the following safety instructions and explanations!
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

Exclusion of liability






All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

Description of symbols

In this documentation the following symbols are used with an accompanying safety instruction or note. The safety instructions must be read carefully and followed without fail!

| | |
|---|---|
|  DANGER | <p>Serious risk of injury! Failure to follow the safety instructions associated with this symbol directly endangers the life and health of persons.</p> |
|  WARNING | <p>Risk of injury! Failure to follow the safety instructions associated with this symbol endangers the life and health of persons.</p> |
|  CAUTION | <p>Personal injuries! Failure to follow the safety instructions associated with this symbol can lead to injuries to persons.</p> |
|  Attention | <p>Damage to the environment or devices Failure to follow the instructions associated with this symbol can lead to damage to the environment or equipment.</p> |
|  Note | <p>Tip or pointer This symbol indicates information that contributes to better understanding.</p> |

1.3 Documentation issue status

| Version | Comment |
|---------|--|
| 2.0.0 | <ul style="list-style-type: none"> • Migration |
| 1.0.1 | <ul style="list-style-type: none"> • Process image corrected • Information on basic function principles expanded |
| 1.0 | Description of KL2692 parameterization with the KS2000 configuration software expanded. |
| 0.2 | Preliminary Version |
| 0.1 | Preliminary version for internal use |

Firmware and hardware versions

| Documentation Version | KL2531 | |
|-----------------------|----------|----------|
| | Firmware | Hardware |
| 2.0.0 | 1C | 04 |
| 1.0.1 | 1B | 01 |
| 1.0 | 1B | 00 |
| 0.2 | - | 00 |
| 0.1 | - | 00 |

The firmware and hardware versions (delivery state) can be taken from the serial number printed on the side of the terminal.

Syntax of the serial number

Structure of the serial number: WW YY FF HH

- WW - week of production (calendar week)
- YY - year of production
- FF - firmware version
- HH - hardware version

Example with ser. No.: 39 04 1B 01:

- 39 - week of production 39
- 04 - year of production 2004
- 1B - firmware version 1B
- 01 - hardware version 01

2 Product overview

2.1 Introduction




Fig. 1: KL2692

The KL2692 Bus Terminal monitors a bit that is toggled by the controller during each cycle. If the toggle signal fails, the terminal switches off two potential-free relays in order to prevent damage to the machine. Failure of the toggle signal may be caused by the PLC cycle stopping, by a fault in the bus cable or connector, or by a fault in a bus device. The cycle monitoring time can be parameterized. The Bus Terminal has an enable input that enables the relay to be switched on if a correct toggle signal is detected.

| | |
|----------------------|--|
| | <p>No personal protection!</p> |
| <p>DANGER</p> | <p>The KL2692 may only be used for cycle monitoring with the purpose of preventing machine damage!</p> <p>The KL2692 must not be used for cycle monitoring for personal protection under any circumstances!</p> <p>The KL2692 must not be used for protection functions such as emergency stop, access protection, secure room monitoring, robot range monitoring, press safety valves etc.!</p> |

2.2 Technical data

| Technical data | KL2692 |
|--|---|
| Number of outputs | 2 potential-free relay outputs (make contacts) |
| Rated load voltage of the outputs | 230 V _{AC} / 30 V _{DC} |
| Ohmic switching current | 5 A _{AC} / 5 A _{DC} |
| Inductive switching current | 2 A _{AC} / 2 A _{DC} |
| Minimum permitted load | 10 mA at 5 V _{DC} |
| Number of inputs | 2 digital inputs (24 V) |
| Rated voltage of the inputs | 24 V _{DC} (-15% / +20%) |
| Signal voltage "0" | -3 V ... 5 V (EN 61131-3, type 1) |
| Signal voltage "1" | 15 V ... 30V (EN 61131-3, Type 1) |
| Input filter | 3.0 ms |
| Input current | typically 5 mA |
| Electrical isolation | 500 V (K-bus/field voltage) |
| Power supply for the electronics | via the K-bus |
| Current consumption from K-bus | typically 165 mA |
| Bit width in the input process image | 2 x 8 bit data, 1 x 8 bit status |
| Bit width in the output process image | 2 x 8 bit data, 1 x 8 bit control |
| Mechanical switching cycles | minimum 2 x 10 ⁷ |
| Electrical switching cycles | minimum 1 x 10 ⁵ (5 A / 30 V _{DC}) |
| Configuration | via the Bus Coupler or the controller |
| Weight | approx. 60 g |
| Permissible ambient temperature range during operation | 0 °C ... + 55 °C |
| Permissible ambient temperature range during storage | -25°C ... + 85 °C |
| Permissible relative air humidity | 95%, no condensation |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm |
| Mounting | on 35 mm mounting rail conforms to EN 60715 |
| Vibration / shock resistance | conforms to EN 60068-2-6 / EN 60068-2-27 |
| EMC immunity / emission | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP20 |
| Installation position | variable |
| Approval | CE |

2.3 Basic function principles

Pulse sequence monitoring (cycle)

1. Monitoring is enabled with a falling edge at *Input 1*.
2. If the pulse sequence is too slow (cycle time t_p too long), the output relays switch off for a minimum switch-off time t_{Amin} . The minimum switch-off time can be specified in register [R36](#) [[29](#)].
3. If a pulse sequence (1 cycle) was recognized as correct, the output relays will only switch on again once monitoring is enabled again. This switching mode ensures that triggering of the watchdog remains recognizable.
4. The two output contacts are looped into the control circuit of the switch-off relay. Automatic self-start is prevented, since the switch-off function block has to be reset through an explicit manual intervention (monitoring enable).



Note

Monitoring enable with falling edge

Monitoring is enabled with a falling edge at *Input 1*. Therefore, monitoring cannot be enabled with a continuous signal (high) at *Input 1*!


Example

Fig. 2: Signal sequence

Sequence

1. Rising edge at input 1
2. Toggle signal on the bus starts to toggle
3. Falling edge at input 1 (monitoring enable)
4. A full toggle cycle after the falling edge switches on the relays (**Start**)
5. Toggle signal on the bus stops toggling and remains in *low* state
6. The relays switch off after a missed toggle cycle (**Stop**)
7. Toggle signal on the bus starts to toggle again
8. Rising edge at input 1
9. Falling edge at input 1 (monitoring enable)
10. A full toggle cycle after the falling edge switches the relays back on again (**Re-start**)
11. Toggle signal on the bus stops toggling and remains in *high* state
12. The relays switch off after a missed toggle cycle (**Stop**)
13. Toggle signal on the bus starts to toggle again
14. Rising edge at input 1
15. Falling edge at input 1 (monitoring enable)
16. A full toggle cycle after the falling edge switches the relays back on again (**Re-start**)

2.4 LEDs




Fig. 3: LEDs

| LED | Display | |
|---------------------|----------------------------------|---|
| Relay 1 (green) | On | Relay contact 13/14 (make contact 1) closed |
| Relay 2 (green) | On | Relay contact 23/24 (make contact 2) closed |
| Watchdog OK (green) | On | The watchdog is triggered on a regular basis. |
| Error (red) | not used | |
| - | not used | |
| - | not used | |
| Input 1 (green) | Status input 1 (watchdog enable) | |
| Input 2 (green) | Status input 2 | |

3 Mounting and wiring

3.1 Installation on mounting rails



WARNING

Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!

Assembly




Fig. 4: Attaching on mounting rail

The Bus Coupler and Bus Terminals are attached to commercially available 35 mm mounting rails (DIN rails according to EN 60715) by applying slight pressure:

1. First attach the Fieldbus Coupler to the mounting rail.
2. The Bus Terminals are now attached on the right-hand side of the Fieldbus Coupler. Join the components with tongue and groove and push the terminals against the mounting rail, until the lock clicks onto the mounting rail.

If the Terminals are clipped onto the mounting rail first and then pushed together without tongue and groove, the connection will not be operational! When correctly assembled, no significant gap should be visible between the housings.



Note

Fixing of mounting rails

The locking mechanism of the terminals and couplers extends to the profile of the mounting rail. At the installation, the locking mechanism of the components must not come into conflict with the fixing bolts of the mounting rail. To mount the mounting rails with a height of 7.5 mm under the terminals and couplers, you should use flat mounting connections (e.g. countersunk screws or blind rivets).

Disassembly




Fig. 5: Disassembling of terminal

Each terminal is secured by a lock on the mounting rail, which must be released for disassembly:

1. Pull the terminal by its orange-colored lugs approximately 1 cm away from the mounting rail. In doing so for this terminal the mounting rail lock is released automatically and you can pull the terminal out of the bus terminal block easily without excessive force.
2. Grasp the released terminal with thumb and index finger simultaneous at the upper and lower grooved housing surfaces and pull the terminal out of the bus terminal block.

Connections within a bus terminal block

The electric connections between the Bus Coupler and the Bus Terminals are automatically realized by joining the components:

- The six spring contacts of the K-Bus/E-Bus deal with the transfer of the data and the supply of the Bus Terminal electronics.
- The power contacts deal with the supply for the field electronics and thus represent a supply rail within the bus terminal block. The power contacts are supplied via terminals on the Bus Coupler (up to 24 V) or for higher voltages via power feed terminals.



Note

Power Contacts

During the design of a bus terminal block, the pin assignment of the individual Bus Terminals must be taken account of, since some types (e.g. analog Bus Terminals or digital 4-channel Bus Terminals) do not or not fully loop through the power contacts. Power Feed Terminals (KL91xx, KL92xx or EL91xx, EL92xx) interrupt the power contacts and thus represent the start of a new supply rail.

PE power contact

The power contact labeled PE can be used as a protective earth. For safety reasons this contact mates first when plugging together, and can ground short-circuit currents of up to 125 A.







Fig. 6: Power contact on left side

| | |
|---|---|
|  <p>Attention</p> | <p>Possible damage of the device</p> <p>Note that, for reasons of electromagnetic compatibility, the PE contacts are capacitatively coupled to the mounting rail. This may lead to incorrect results during insulation testing or to damage on the terminal (e.g. disruptive discharge to the PE line during insulation testing of a consumer with a nominal voltage of 230 V). For insulation testing, disconnect the PE supply line at the Bus Coupler or the Power Feed Terminal! In order to decouple further feed points for testing, these Power Feed Terminals can be released and pulled at least 10 mm from the group of terminals.</p> |
|  <p>WARNING</p> | <p>Risk of electric shock!</p> <p>The PE power contact must not be used for other potentials!</p> |

3.2 Connection

3.2.1 Connection system

| | |
|---|---|
|  <p>WARNING</p> | <p>Risk of electric shock and damage of device!</p> <p>Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!</p> |
|---|---|

Overview

The Bus Terminal system offers different connection options for optimum adaptation to the respective application:

- The terminals of ELxxxx and KLxxxx series with standard wiring include electronics and connection level in a single enclosure.
- The terminals of ESxxxx and KSxxxx series feature a pluggable connection level and enable steady wiring while replacing.
- The High Density Terminals (HD Terminals) include electronics and connection level in a single enclosure and have advanced packaging density.

Standard wiring (ELxxxx / KLxxxx)




Fig. 7: Standard wiring

The terminals of ELxxxx and KLxxxx series have been tried and tested for years. They feature integrated screwless spring force technology for fast and simple assembly.

Pluggable wiring (ESxxxx / KSxxxx)



Fig. 8: Pluggable wiring

The terminals of ESxxxx and KSxxxx series feature a pluggable connection level. The assembly and wiring procedure for the KS series is the same as for the ELxxxx and KLxxxx series. The KS/ES series terminals enable the complete wiring to be removed as a plug connector from the top of the housing for servicing. The lower section can be removed from the terminal block by pulling the unlocking tab. Insert the new component and plug in the connector with the wiring. This reduces the installation time and eliminates the risk of wires being mixed up.

The familiar dimensions of the terminal only had to be changed slightly. The new connector adds about 3 mm. The maximum height of the terminal remains unchanged.

A tab for strain relief of the cable simplifies assembly in many applications and prevents tangling of individual connection wires when the connector is removed.

Conductor cross sections between 0.08 mm² and 2.5 mm² can continue to be used with the proven spring force technology.

The overview and nomenclature of the product names for ESxxxx and KSxxxx series has been retained as known from ELxxxx and KLxxxx series.

High Density Terminals (HD Terminals)



Fig. 9: High Density Terminals

The Bus Terminals from these series with 16 terminal points are distinguished by a particularly compact design, as the packaging density is twice as large as that of the standard 12 mm Bus Terminals. Massive conductors and conductors with a wire end sleeve can be inserted directly into the spring loaded terminal point without tools.



Note

Wiring HD Terminals

The High Density (HD) Terminals of the ELx8xx and KLx8xx series doesn't support pluggable wiring.

Ultrasonically "bonded" (ultrasonically welded) conductors



Note

Ultrasonically "bonded" conductors

It is also possible to connect the Standard and High Density Terminals with ultrasonically "bonded" (ultrasonically welded) conductors. In this case, please note the tables concerning the wire-size width below!

3.2.2 Wiring



WARNING

Risk of electric shock and damage of device!

Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!

Terminals for standard wiring ELxxxx/KLxxxx and for pluggable wiring ESxxxx/KSxxxx




Fig. 10: Connecting a cable on a terminal point

Up to eight terminal points enable the connection of solid or finely stranded cables to the Bus Terminal. The terminal points are implemented in spring force technology. Connect the cables as follows:

1. Open a terminal point by pushing a screwdriver straight against the stop into the square opening above the terminal point. Do not turn the screwdriver or move it alternately (don't toggle).
2. The wire can now be inserted into the round terminal opening without any force.
3. The terminal point closes automatically when the pressure is released, holding the wire securely and permanently.

See the following table for the suitable wire size width.

| | | |
|--|------------------------------|------------------------------|
| Terminal housing | ELxxxx, KLxxxx | ESxxxx, KSxxxx |
| Wire size width (single core wires) | 0.08 ... 2.5 mm ² | 0.08 ... 2.5 mm ² |
| Wire size width (fine-wire conductors) | 0.08 ... 2.5 mm ² | 0,08 ... 2.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 1.5 mm ² | 0.14 ... 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm | 9 ... 10 mm |

High Density Terminals ([HD Terminals \[▶ 15\]](#)) with 16 terminal points

The conductors of the HD Terminals are connected without tools for single-wire conductors using the direct plug-in technique, i.e. after stripping the wire is simply plugged into the terminal point. The cables are released, as usual, using the contact release with the aid of a screwdriver. See the following table for the suitable wire size width.

| | |
|---|-------------------------------|
| Terminal housing | High Density Housing |
| Wire size width (single core wires) | 0.08 ... 1.5 mm ² |
| Wire size width (fine-wire conductors) | 0.25 ... 1.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 0.75 mm ² |
| Wire size width (ultrasonically "bonded" conductors) | only 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm |

3.2.3 Connection





Fig. 11: KL2692 connection

| Terminal point | No. | Connection for |
|---------------------------|-----|--|
| 13 | 1 | Relay contact 13 (NO contact 1) |
| 14 | 2 | Relay contact 14 (NO contact 2) |
| +24 V | 3 | 24 V power contact |
| Input 1 (Watchdog Enable) | 4 | Input 1 (24 V _{DC}), watchdog enabled with negative edge |
| 23 | 5 | Relay contact 23 (NO contact 1) |
| 24 | 6 | Relay contact 24 (NO contact 2) |
| 0 V | 7 | 0 V power contact |
| Input 2 | 8 | Input 2 (24 V _{DC}) |

3.3 Application example



DANGER

No personal protection!

The KL2692 may only be used for cycle monitoring with the purpose of preventing machine damage!

The KL2692 must not be used for cycle monitoring for personal protection under any circumstances!

The KL2692 must not be used for protection functions such as emergency stop, access protection, secure room monitoring, robot range monitoring, press safety valves etc.!

Switching off the voltage for the power contacts

The NO contacts of the KL2692 control a contactor that switches the supply voltage (24 V) for the power contacts..




Fig. 12: Application example

Function

1. Monitoring can be enabled via push button S1 (negative edge) when the watchdog is triggered. The KL2692 relays are switched on, and contactor K1 switches on the supply voltage (24 V) for the power contacts.
2. If the watchdog is not triggered over the watchdog time specified in register [R35](#) (▶ [29](#)), the KL2692 relays are de-energized and contactor K1 switches off the supply voltage for the power contacts.
3. If the watchdog is triggered again, monitoring has to be re-enabled via push button S1, so that the KL2692 relays switch on again!
4. NC contacts S2 and S3 can be used for manually switching off contactor K1 and therefore the supply voltage for the power contacts.

4 KS2000 Configuration Software

4.1 KS2000 - Introduction

The KS2000 configuration software permits configuration, commissioning and parameterization of bus couplers, of the affiliated bus terminals and of Fieldbus Box Modules. The connection between bus coupler / Fieldbus Box Module and the PC is established by means of the serial configuration cable or the fieldbus.



Fig. 13: KS2000 configuration software

Configuration

You can configure the Fieldbus stations with the Configuration Software KS2000 offline. That means, setting up a terminal station with all settings on the couplers and terminals resp. the Fieldbus Box Modules can be prepared before the commissioning phase. Later on, this configuration can be transferred to the terminal station in the commissioning phase by means of a download. For documentation purposes, you are provided with the breakdown of the terminal station, a parts list of modules used and a list of the parameters you have modified. After an upload, existing fieldbus stations are at your disposal for further editing.

Parameterization

KS2000 offers simple access to the parameters of a fieldbus station: specific high-level dialogs are available for all bus couplers, all intelligent bus terminals and Fieldbus Box modules with the aid of which settings can be modified easily. Alternatively, you have full access to all internal registers of the bus couplers and intelligent terminals. Refer to the register description for the meanings of the registers.

Commissioning

The KS2000 software facilitates commissioning of machine components or their fieldbus stations: Configured settings can be transferred to the fieldbus modules by means of a download. After a *login* to the terminal station, it is possible to define settings in couplers, terminals and Fieldbus Box modules directly *online*. The same high-level dialogs and register access are available for this purpose as in the configuration phase.

The KS2000 offers access to the process images of the bus couplers and Fieldbus Box modules.

- Thus, the coupler's input and output images can be observed by monitoring.
- Process values can be specified in the output image for commissioning of the output modules.

All possibilities in the *online mode* can be used in parallel with the actual fieldbus mode of the terminal station. The fieldbus protocol always has the higher priority in this case.

4.2 Parameterization with KS2000

Connect the configuration interface of your fieldbus coupler with the serial interface of your PC via the configuration cable and start the *KS2000* Configuration Software.



Click on the *Login* button. The configuration software will now load the information for the connected fieldbus station.

In the example shown, this is

- a BK9000 Bus Coupler for Ethernet
- a KL1xx2 digital input terminal
- a KL2692 watchdog terminal
- a KL9010 bus end terminal




Fig. 14: Display of the fieldbus station in KS2000

The left-hand KS2000 window displays the terminals of the fieldbus station in a tree structure. The right-hand KS2000 window contains a graphic display of the fieldbus station terminals.

In the tree structure of the left-hand window, click on the plus-sign next to the terminal whose parameters you wish to change (item 2 in the example).




Fig. 15: KS2000 branch for channel 1 of the KL2692

For the KL2692, the branches *Register*, *Settings* and *ProcData* are displayed:

- Register [▶ 23] permits direct access to the registers of the KL2692.
- Under Settings [▶ 24] you find dialog boxes for parameterizing the KL2692.

- ProcData [▶ 24] shows the process data of the KL2692.

4.3 Register

You can access the registers of the KL2692 directly under *Register*. The meaning of the register is explained in the *register overview* [▶ 28].




Fig. 16: Register view in KS2000

4.4 Settings

The dialog mask for the parameterization of the KL2692 can be found under *Settings*.




Fig. 17: Settings via KS2000

Watchdog time (R35 [▶ 29])

This can be used for setting the watchdog time (default: 4 ms). Within the watchdog time, an edge change must occur on the toggle bit of the control bytes (CB.0 [▶ 26]), in order to prevent the drop-out of the output relays.

Minimum switch-off time (R36 [▶ 29])

This can be used for setting the minimum time (default: 50 ms) for which the relays remain switched off after the watchdog has been triggered, even if, after a subsequent monitoring activation, the following pulse sequence is recognized as correct.

4.5 Process data

The Status byte (Status), the Control byte (Ctrl) and the process data (Data) are displayed in a tree structure under *ProcData*.

| Prozessdaten | | | | | | | | |
|--------------|-------------|-----------|--------|----------|-----------|--------|----------|--|
| Pos | Typ | E-Adresse | Wert | Bitlänge | A-Adresse | Wert | Bitlänge | |
| 2 | KL2692-0000 | | | | | | | |
| | Kanal 1 | | | | | | | |
| | Status | 0.0 | 0x00 | 8 | | | | |
| | Data In | 2.0 | 0x0000 | 16 | | | | |
| | Ctrl | | | | 0.0 | 0x00 | 8 | |
| | Data Out | | | | 2.0 | 0x0000 | 16 | |

Fig. 18: ProcData

The reading glasses mark the data that are currently graphically displayed in the *History* field.




Fig. 19: History field

The current input values are displayed numerically in the *Value* field.



Fig. 20: Value field

Output values can be modified through direct input or by means of the fader control.





Fig. 21: Value field

| | |
|---|--|
|  CAUTION | <p>Danger for persons, the environment or devices!</p> <p>Note that changing output values (forcing them) can have a direct effect on your automation application.</p> <p>Only modify these output values if you are certain that the state of your equipment permits it, and that there will be no risk to people or to the machine!</p> |
|---|--|

After pressing the *Settings* button you can set the format of the numerical display to hexadecimal, decimal or binary.




Fig. 22: Settings

5 Access from the user program

5.1 Process image

The KL2692 is represented in the process image with a minimum of 3 bytes of input data and 3 bytes of output data. These are organized as follows:

| Byte offset (without word alignment) | Byte offset (with word alignment*) | Format | Input data | Output data |
|---|---------------------------------------|--------|--------------------|--------------------|
| 0 | 0 | Byte | SB [<u>▶ 26</u>] | CB [<u>▶ 26</u>] |
| 1 | 2 | Word | DataIN | DataOUT |

*) Word alignment: The Bus Coupler places values on even byte addresses

Key

SB: Status byte

CB: Control byte

DataIN: input word

DataOUT: output word



Note

No compact process image

The KL2692 cannot be operated with compact process image (without control and status bytes), since control and status bytes are required for process data operation of the KL2692 to function correctly. Even if your Bus Coupler is set to compact process image, the KL2692 is represented with its complete process image!

5.2 Control and status byte

Process data mode

Control byte (for process data mode)

The control byte (CB) is located in the output image [▶ 26], and is transmitted from the controller to the terminal.

| Bit | CB.7 | CB.6 | CB.5 | CB.4 | CB.3 | CB.2 | CB.1 | CB.0 |
|------|-----------|------|------|------|------|------|------|--------|
| Name | RegAccess | - | - | - | - | - | - | Toggle |

Key

| Bit | Name | Description |
|--------------|-----------|---|
| CB7 | RegAccess | 0 _{bin} Register communication off (process data mode) |
| CB.6 to CB.2 | - | 0 _{bin} reserved |
| CB.0 | Toggle | Toggle bit |

Status byte (for process data mode)

The status byte (SB) is located in the input image [▶ 26], and is transmitted from terminal to the controller.

| Bit | SB.7 | SB.6 | SB.5 | SB.4 | SB.3 | SB.2 | SB.1 | SB.0 |
|------|-----------|------|------|------|------|------|---------|-----------|
| Name | RegAccess | - | - | - | IN_2 | IN_1 | WDT_Run | Toggle_St |

Key

| Bit | Name | Description | |
|--------------|-----------|------------------|---|
| SB.7 | RegAccess | 0 _{bin} | Acknowledgment for process data mode |
| SB.6 to SB.4 | - | 0 _{bin} | reserved |
| SB.3 | IN_2 | | Status input 2 |
| SB.2 | IN_1 | | Status input 1 |
| SB.1 | WDT_Run | 0 _{bin} | Watchdog timer is not triggered. The outputs are not set. |
| | | 1 _{bin} | Watchdog timer is active and locked. The outputs are set. |
| SB.0 | Toggle_St | | This bit follows the toggle bit in the control byte |

Register communication

Control byte (for register communication)

The control byte (CB) is located in the output image [▶ 26], and is transmitted from the controller to the terminal.

| Bit | CB.7 | CB.6 | CB.5 | CB.4 | CB.3 | CB.2 | CB.1 | CB.0 |
|------|-----------|------|----------|------|------|------|------|------|
| Name | RegAccess | R/W | Reg. no. | | | | | |

Key

| Bit | Name | Description | |
|--------------|-----------|---|------------------------------------|
| CB.7 | RegAccess | 1 _{bin} | Register communication switched on |
| CB.6 | R/W | 0 _{bin} | Read access |
| | | 1 _{bin} | Write access |
| CB.5 to CB.0 | Reg. no. | Register number: Enter here the number of the <u>register</u> [▶ 28] that you wish - to read with input data word <u>DataIn</u> [▶ 26], or - to write with output data word <u>DataOut</u> [▶ 26]. | |

Status byte (for register communication)

The status byte (SB) is located in the input image [▶ 26], and is transmitted from terminal to the controller.

| Bit | SB.7 | SB.6 | SB.5 | SB.4 | SB.3 | SB.2 | SB.1 | SB.0 |
|------|-----------|------|----------|------|------|------|------|------|
| Name | RegAccess | R/W | Reg. no. | | | | | |

Key

| Bit | Name | Description | |
|--------------|-----------|--|------------------------------------|
| SB.7 | RegAccess | 1 _{bin} | Acknowledgment for register access |
| SB.6 | R | 0 _{bin} | Read access |
| SB.5 to SB.0 | Reg. no. | Number of the register that was read or written. | |

5.3 Register overview

All registers can be read or written via [register communication \[► 27\]](#). They are used for parameterizing the KL2692.

| Register no. | Comment | Default value | | R/W | Memory |
|--------------|------------------------------------|---------------|--------------------------|-----|--------|
| R0 | reserved | - | - | - | - |
| ... | ... | ... | ... | ... | ... |
| R5 | reserved | - | - | - | - |
| R6 | Diagnostic register (not used) | 0x0000 | 0 _{dec} | R | RAM |
| R7 | Command register (not used) | 0x0000 | 0 _{dec} | R/W | RAM |
| R8 [► 29] | Terminal type | 0x0A84 | 2692 _{dec} | R | ROM |
| R9 [► 29] | Firmware version | e.g. 0x3141 | e.g. 1A _{ASCII} | R | ROM |
| R10 | Multiplex shift register | 0x0118 | 280 _{dec} | R | ROM |
| R11 | Signal channels | 0x0118 | 280 _{dec} | R | ROM |
| R12 | Minimum data length | 0x1818 | 6168 _{dec} | R | ROM |
| R13 | Data structure | 0x0000 | 0 _{dec} | R | ROM |
| R14 | reserved | - | - | - | - |
| R15 | Alignment register | variable | variable | R/W | RAM |
| R16 [► 29] | Hardware version number | e.g. 0x0000 | e.g. 0 _{dec} | R/W | EEPROM |
| R17 | reserved | - | - | - | - |
| ... | ... | - | - | - | - |
| R30 | reserved | - | - | - | - |
| R31 [► 29] | Code word register | 0x0000 | 0 _{dec} | R/W | RAM |
| R32 [► 29] | Feature register | 0x0000 | 0 _{dec} | R/W | EEPROM |
| R33 | reserved | - | - | - | - |
| R34 | reserved | - | - | - | - |
| R35 [► 29] | Watchdog time t_p | 0x0004 | 4 _{dec} | - | EEPROM |
| R36 [► 29] | Minimum switch-off time t_{Amin} | 0x0064 | 100 _{dec} | - | EEPROM |
| R37 | reserved | - | - | - | - |
| ... | ... | ... | ... | ... | ... |
| R63 | reserved | - | - | - | - |

5.4 Register description

All registers can be read or written via [register communication](#) [► 27]. They are used for parameterizing the KL2692.

R8: Terminal description

The description of the terminal is contained in register R8. KL2692: 0x0A84 (2692_{dec})

R9: Firmware version

Register R9 contains the ASCII coding of the terminal's firmware version, e.g. **0x3141** = **'1A'**. The **'0x31'** corresponds here to the ASCII character **'1'**, while the **'0x41'** represents the ASCII character **'A'**. This value can not be changed.

R16: Hardware version number

Register R16 contains the hardware version of the terminal.

R31: Code word register

- If you write values into the user registers without first entering the user code word (0x1235) into the code word register, the terminal will not accept the supplied data.
- If you write values into the user registers and have previously entered the user code word (0x1235) in the code word register, these values are stored in the RAM registers and in the SEEPROM registers and are therefore retained if the terminal is restarted.

The code word is reset if the terminal is restarted.

R32: Feature register

The feature register specifies the configuration of the terminal (in preparation).

R35: Watchdog time t_p

An edge change within the watchdog time is required to prevent the drop-out of the watchdog.

Scaling: 500 μ s / bit

Default value: 8_{dec} (4 ms).

R36: Minimum switch-off time t_{Amin}

Minimum time for which the relays remain switched off after the watchdog has been triggered, even if, after a subsequent monitoring activation, the following pulse sequence is recognized as correct.

Scaling: 500 μ s / bit

Default value: 100_{dec} (50 ms).

5.5 Examples of Register Communication

The numbering of the bytes in the examples corresponds to the display without word alignment.

5.5.1 Example 1: reading the firmware version from Register 9

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0x89 (1000 1001 _{bin}) | 0xXX | 0xXX |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 9 with 00 1001_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access. To change a register, write the required value into the output word.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|---------------------|----------------------------|---------------------------|
| 0x89 | 0x33 | 0x41 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the firmware version 0x3341 in the input data word (byte 1 and byte 2). This is to be interpreted as an ASCII code:
 - ASCII code 0x33 represents the digit 3
 - ASCII code 0x41 represents the letter A
 The firmware version is thus 3A.

5.5.2 Example 2: Writing to an user register



Note

Code word

In normal mode all user registers are read-only with the exception of Register 31. In order to deactivate this write protection you must write the code word (0x1235) into Register 31. If a value other than 0x1235 is written into Register 31, write protection is reactivated. Please note that changes to a register only become effective after restarting the terminal (power-off/power-on).

I. Write the code word (0x1235) into Register 31.

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xDF (1101 1111 _{bin}) | 0x12 | 0x35 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) contains the code word (0x1235) for deactivating write protection.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0xXX | 0xXX |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

II. Read Register 31 (check the set code word)

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0x9F (1001 1111 _{bin}) | 0xXX | 0xXX |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0x12 | 0x35 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the current value of the code word register in the input data word (byte 1 and byte 2).


III. Write to Register 32 (change contents of the feature register)

Output data

| Byte 0: Control byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xE0 (1110 0000 _{bin}) | 0x00 | 0x02 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000_{bin}.
- The output data word (byte 1 and byte 2) contains the new value for the feature register.

| | |
|---|---|
|  CAUTION | <p>Observe the register description!</p> <p>The value of 0x0002 given here is just an example! The bits of the feature register change the properties of the terminal and have a different meaning, depending on the type of terminal. Refer to the description of the feature register of your terminal (chapter <i>Register description</i>) regarding the meaning of the individual bits before changing the values.</p> |
|---|---|

Input data (response from the Bus Terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xA0 (1010 0000 _{bin}) | 0xXX | 0xXX |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

IV. Read Register 32 (check changed feature register)**Output Data**

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xA0 (1010 0000 _{bin}) | 0xXX | 0xXX |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xA0 (1010 0000 _{bin}) | 0x00 | 0x02 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the current value of the feature register in the input data word (byte 1 and byte 2).

V. Write Register 31 (reset code word)**Output Data**

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xDF (1101 1111 _{bin}) | 0x00 | 0x00 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) contains 0x0000 for reactivating write protection.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0xXX | 0xXX |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

6 Appendix

6.1 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for [local support and service](#) on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages:

<http://www.beckhoff.com>

You will also find further [documentation](#) for Beckhoff components there.

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

| | |
|---------|--------------------|
| Phone: | +49(0)5246/963-0 |
| Fax: | +49(0)5246/963-198 |
| e-mail: | info@beckhoff.com |

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

| | |
|----------|----------------------|
| Hotline: | +49(0)5246/963-157 |
| Fax: | +49(0)5246/963-9157 |
| e-mail: | support@beckhoff.com |

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

| | |
|----------|----------------------|
| Hotline: | +49(0)5246/963-460 |
| Fax: | +49(0)5246/963-479 |
| e-mail: | service@beckhoff.com |

List of illustrations

| | | |
|---------|---|----|
| Fig. 1 | KL2692 | 8 |
| Fig. 2 | Signal sequence | 10 |
| Fig. 3 | LEDs | 11 |
| Fig. 4 | Attaching on mounting rail | 12 |
| Fig. 5 | Disassembling of terminal..... | 13 |
| Fig. 6 | Power contact on left side..... | 14 |
| Fig. 7 | Standard wiring..... | 15 |
| Fig. 8 | Pluggable wiring | 15 |
| Fig. 9 | High Density Terminals..... | 15 |
| Fig. 10 | Connecting a cable on a terminal point | 16 |
| Fig. 11 | KL2692 connection | 18 |
| Fig. 12 | Application example..... | 19 |
| Fig. 13 | KS2000 configuration software..... | 20 |
| Fig. 14 | Display of the fieldbus station in KS2000 | 22 |
| Fig. 15 | KS2000 branch for channel 1 of the KL2692..... | 22 |
| Fig. 16 | Register view in KS2000..... | 23 |
| Fig. 17 | Settings via KS2000 | 24 |
| Fig. 18 | ProcData..... | 24 |
| Fig. 19 | History field | 25 |
| Fig. 20 | Value field | 25 |
| Fig. 21 | Value field | 25 |
| Fig. 22 | Settings..... | 25 |