

Documentation

KL4494

**Analog terminal with two input and two output channels,
(-10V...+10V)**

Version: 2.0.0
Date: 2017-09-08

BECKHOFF

1 Foreword

1.1 Notes on the documentation

Intended audience

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with the applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning these components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement.

No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE®, XFC® and XTS® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents: EP1590927, EP1789857, DE102004044764, DE102007017835 with corresponding applications or registrations in various other countries.

The TwinCAT Technology is covered, including but not limited to the following patent applications and patents: EP0851348, US6167425 with corresponding applications or registrations in various other countries.



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 Safety instructions

Safety regulations

Please note the following safety instructions and explanations!
Product-specific safety instructions can be found on following pages or in the areas mounting, wiring, commissioning etc.

Exclusion of liability

All the components are supplied in particular hardware and software configurations appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation and drive engineering who are familiar with the applicable national standards.

Description of symbols

In this documentation the following symbols are used with an accompanying safety instruction or note. The safety instructions must be read carefully and followed without fail!

| | |
|---|---|
|  DANGER | <p>Serious risk of injury! Failure to follow the safety instructions associated with this symbol directly endangers the life and health of persons.</p> |
|  WARNING | <p>Risk of injury! Failure to follow the safety instructions associated with this symbol endangers the life and health of persons.</p> |
|  CAUTION | <p>Personal injuries! Failure to follow the safety instructions associated with this symbol can lead to injuries to persons.</p> |
|  Attention | <p>Damage to the environment or devices Failure to follow the instructions associated with this symbol can lead to damage to the environment or equipment.</p> |
|  Note | <p>Tip or pointer This symbol indicates information that contributes to better understanding.</p> |

1.3 Documentation issue versions

| Version | Comment |
|---------|---|
| 2.0.0 | <ul style="list-style-type: none"> • Migration • Structure update • Update chapter <i>Technical data</i> • Revision status updated • Chapter <i>Notes on ESD protection</i> added • Chapter <i>Installation instructions for enhanced mechanical load capacity</i> added • Chapters <i>ATEX – special conditions (standard temperature range)</i> and <i>ATEX documentation</i> added • Update chapter <i>Connection technology</i> -> <i>Connection</i> |
| 1.1.0 | <ul style="list-style-type: none"> • Description of the KS2000 configuration software expanded • Description of the basic function principles added • Technical data updated • Register overview and register description updated • Firmware and hardware versions updated |
| 1.0 | <ul style="list-style-type: none"> • Description of connection updated • Technical data updated • English version available |
| 0.1 | <ul style="list-style-type: none"> • Preliminary version (only German language available) |

Firmware and hardware versions

| Documentation Version | Firmware | Hardware |
|-----------------------|----------|----------|
| 2.0.0 | 1C | 04 |
| 1.1.0 | 1B | 02 |
| 1.0 | 1B | 01 |
| 0.1 | 1A | 00 |

The firmware and hardware versions (delivery state) can be found in the serial number printed on the side of the terminal.

Syntax of the serial number

Structure of the serial number: WW YY FF HH

WW - week of production (calendar week)

YY - year of production

FF - firmware version

HH - hardware version

Example with ser. no.: 31 05 1B 01:

31 - week of production 31

05 - year of production 2005

1B - firmware version 1B

01 - hardware version 01

2 Product overview

2.1 Introduction




Fig. 1: KL4494

Analog terminal with two input and two output channels, -10 V to 10 V

The KL4494 Bus Terminal combines two analog inputs and two analog outputs in one housing and can process signals in the range -10 V to +10 V. The voltage is digitized to a resolution of 12 bits, and is transmitted, electrically isolated, to the higher-level automation device or to the process level. The input and output channels of the Bus Terminal have a common ground potential that is electrically isolated from the 0 V power contact. The RUN LEDs give an indication of the data exchange with the Bus Coupler.

2.2 Technical data

| Technical data | KL4494 |
|--|---|
| Number of outputs | 2 |
| Number of inputs | 2 (single-ended) |
| Signal voltage | -10 V to +10 V |
| Load of each output | > 5 k Ω |
| Internal resistance of each input | > 130 k Ω |
| Resolution | 12 bit |
| Measuring error (total measuring range) | $\pm 0.3\%$ of the full scale value |
| Conversion time | < 2 ms |
| Bit width in the input process image | 2 data words, 2 status byte |
| Bit width in the output process image | 2 data words, 2 control byte |
| Power supply for the electronics | via the K-bus |
| Current consumption from K-bus | typically 70 mA |
| Electrical isolation | 500 V (signal voltage/K-bus) |
| Connection | spring-loaded system |
| Weight | approx. 55 g |
| Dimensions (W x H x D) | approx. 15 mm x 100 mm x 70 mm (width aligned: 12 mm) |
| <u>Mounting</u> [▶ 11] | on 35 mm mounting rail conforms to EN 60715 |
| Permissible ambient temperature range during operation | 0 °C ... + 55 °C |
| Permissible ambient temperature range during storage | -25 °C ... + 85 °C |
| Permissible relative air humidity | 95 %, no condensation |
| Vibration / shock resistance | conforms to EN 60068-2-6/EN 60068-2-27, see also Installation instructions for enhanced mechanical load capacity [▶ 15] |
| EMC immunity/emission | conforms to EN 61000-6-2 / EN 61000-6-4 |
| Protection class | IP20 |
| Installation position | variable |
| Approval | CE, UL, ATEX [▶ 20] |

2.3 Diagnostic LEDs

The four green RUN LEDs indicated the operating state of the terminal channels.




Fig. 2: KL4494 - LEDs

Meaning of the LED displays

| LED | Color | Channel | State | |
|-----------|-------|----------|------------------|---|
| | | | On | off |
| Run IN 1 | green | Input 1 | normal operation | A watchdog-timer overflow has occurred. The green LEDs go out if no process data are transferred between the controller and the Bus Coupler for more than 100 ms. |
| Run IN 2 | | Input 2 | | |
| Run OUT 1 | | Output 1 | | |
| Run OUT 2 | | Output 2 | | |

2.4 Basic function principles

Analog input channels

The analog input channels of the KL4494 process signals in the range from -10 V to +10 V with 12-bit resolution (4095 steps). The inputs are single-ended inputs with a common ground potential.

Format of the input values

In the delivery state the process data are shown in two's complement form (-1_{integer} corresponds to 0xFFFF). Siemens output format [► 34] can be selected via the feature register R32 as an alternative.

| Measured value | Input data | |
|----------------|------------|-------------|
| | decimal | hexadecimal |
| -10 V | -32768 | 0x8000 |
| -5 V | -16383 | 0xC001 |
| 0 V | 0 | 0x0000 |
| +5 V | 16383 | 0x3FFF |
| +10 V | 32767 | 0x7FFF |

Process data equations

The process data that are transferred to the Bus Coupler are calculated using the following equations:

Neither user nor manufacturer scaling is active

$$Y_a = (B_a + X_{ADC}) \times A_a \tag{1.0}$$

$$Y_{out} = Y_a$$

Manufacturer scaling active (default setting)

$$Y_1 = B_h + A_h \times Y_a \tag{1.1}$$

$$Y_{out} = Y_1$$

User scaling active

$$Y_2 = B_w + A_w \times Y_a \tag{1.2}$$

$$Y_{out} = Y_2$$

Manufacturer and user scaling active

$$Y_1 = B_h + A_h \times Y_a \tag{1.3}$$

$$Y_2 = B_w + A_w \times Y_1 \tag{1.4}$$

$$Y_{out} = Y_2$$

Key

- X_{adc} : Output values of the A/D converter
- Y_{out} : Process data to PLC
- B_a, A_a : Manufacturer gain and offset compensation ([R17 \[▶ 33\]](#), [R18 \[▶ 33\]](#))
- B_h, A_h : Manufacturer scaling (Not implemented)
- B_w, A_w : User scaling ([R33 \[▶ 34\]](#), [R34 \[▶ 35\]](#))

The equations of the straight line are activated via register R32.

Analog output channels

The analog output channels of the KL4494 generate signals in the range from -10 V to +10 V with a resolution of 12 bits (4095 steps). The outputs are single-ended outputs with a common ground potential.

Format of the output values

In the delivery state the process data are shown in two's complement form ($-1_{integer}$ corresponds to 0xFFFF). [Siemens output format \[▶ 34\]](#) can be selected via the feature register R32 as an alternative.

| Output value | | Output voltage |
|--------------|---------|----------------|
| hexadecimal | decimal | |
| 0x8000 | -32768 | -10 V |
| 0xC001 | -16383 | -5 V |
| 0x0000 | 0 | 0 V |
| 0x3FFF | 16383 | +5 V |
| 0x7FFF | 32767 | +10 V |

Process data equations

The process data, which are transferred to the Bus Terminal, are calculated based on the following equations:

Neither user nor manufacturer scaling is active

$$Y_{dac} = X \times A_a + B_a \tag{1.0}$$

Manufacturer scaling active (default setting)

$$Y_1 = B_h + A_h \times X \quad (1.1)$$

$$Y_{\text{dac}} = Y_1 \times A_a + B_a$$

User scaling active

$$Y_2 = B_w + A_w \times X \quad (1.2)$$

$$Y_{\text{dac}} = Y_2 \times A_a + B_a$$

Manufacturer and user scaling active

$$Y_1 = B_h + A_h \times X \quad (1.3)$$

$$Y_2 = B_w + A_w \times Y_1 \quad (1.4)$$

$$Y_{\text{dac}} = Y_2 \times A_a + B_a$$

Key

| | | |
|--------------------|---|---|
| X: | Controller process data | |
| Y_{dac} : | Process data to D/A converter | |
| B_a , A_a : | Manufacturer gain and offset compensation | (R19 [▶ 33] , R20 [▶ 33]) |
| B_h , A_h : | Manufacturer scaling | (Not implemented) |
| B_w , A_w : | User scaling | (R36 [▶ 35] , R37 [▶ 35]) |

The equations of the straight line are activated via register R32.

3 Mounting and wiring

3.1 Instructions for ESD protection

| | |
|--|--|
| | <p>Destruction of the devices by electrostatic discharge possible!</p> <p>The devices contain components at risk from electrostatic discharge caused by improper handling.</p> <ul style="list-style-type: none">✓ Please ensure you are electrostatically discharged and avoid touching the contacts of the device directly.a) Avoid contact with highly insulating materials (synthetic fibers, plastic film etc.).b) Surroundings (working place, packaging and personnel) should be grounded probably, when handling with the devices.c) Each assembly must be terminated at the right hand end with an EL9011 bus end cap, to ensure the protection class and ESD protection. |
|--|--|

Attention




Fig. 3: Spring contacts of the Beckhoff I/O components

3.2 Installation on mounting rails

| | |
|--|---|
| | <p>Risk of electric shock and damage of device!</p> <p>Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!</p> |
|--|---|

WARNING

Assembly




Fig. 4: Attaching on mounting rail

The Bus Coupler and Bus Terminals are attached to commercially available 35 mm mounting rails (DIN rails according to EN 60715) by applying slight pressure:

1. First attach the Fieldbus Coupler to the mounting rail.
2. The Bus Terminals are now attached on the right-hand side of the Fieldbus Coupler. Join the components with tongue and groove and push the terminals against the mounting rail, until the lock clicks onto the mounting rail.

If the Terminals are clipped onto the mounting rail first and then pushed together without tongue and groove, the connection will not be operational! When correctly assembled, no significant gap should be visible between the housings.

**Note****Fixing of mounting rails**

The locking mechanism of the terminals and couplers extends to the profile of the mounting rail. At the installation, the locking mechanism of the components must not come into conflict with the fixing bolts of the mounting rail. To mount the mounting rails with a height of 7.5 mm under the terminals and couplers, you should use flat mounting connections (e.g. countersunk screws or blind rivets).

Disassembly




Fig. 5: Disassembling of terminal

Each terminal is secured by a lock on the mounting rail, which must be released for disassembly:

1. Pull the terminal by its orange-colored lugs approximately 1 cm away from the mounting rail. In doing so for this terminal the mounting rail lock is released automatically and you can pull the terminal out of the bus terminal block easily without excessive force.
2. Grasp the released terminal with thumb and index finger simultaneous at the upper and lower grooved housing surfaces and pull the terminal out of the bus terminal block.

Connections within a bus terminal block

The electric connections between the Bus Coupler and the Bus Terminals are automatically realized by joining the components:

- The six spring contacts of the K-Bus/E-Bus deal with the transfer of the data and the supply of the Bus Terminal electronics.
- The power contacts deal with the supply for the field electronics and thus represent a supply rail within the bus terminal block. The power contacts are supplied via terminals on the Bus Coupler (up to 24 V) or for higher voltages via power feed terminals.



Note

Power Contacts

During the design of a bus terminal block, the pin assignment of the individual Bus Terminals must be taken account of, since some types (e.g. analog Bus Terminals or digital 4-channel Bus Terminals) do not or not fully loop through the power contacts. Power Feed Terminals (KL91xx, KL92xx or EL91xx, EL92xx) interrupt the power contacts and thus represent the start of a new supply rail.

PE power contact

The power contact labeled PE can be used as a protective earth. For safety reasons this contact mates first when plugging together, and can ground short-circuit currents of up to 125 A.




Fig. 6: Power contact on left side

| | |
|---|---|
|  <p>Attention</p> | <p>Possible damage of the device</p> <p>Note that, for reasons of electromagnetic compatibility, the PE contacts are capacitatively coupled to the mounting rail. This may lead to incorrect results during insulation testing or to damage on the terminal (e.g. disruptive discharge to the PE line during insulation testing of a consumer with a nominal voltage of 230 V). For insulation testing, disconnect the PE supply line at the Bus Coupler or the Power Feed Terminal! In order to decouple further feed points for testing, these Power Feed Terminals can be released and pulled at least 10 mm from the group of terminals.</p> |
|  <p>WARNING</p> | <p>Risk of electric shock!</p> <p>The PE power contact must not be used for other potentials!</p> |

3.3 Installation instructions for enhanced mechanical load capacity

| | |
|---|--|
|  WARNING | <p>Risk of injury through electric shock and damage to the device!</p> <p>Bring the Bus Terminal system into a safe, de-energized state before starting mounting, disassembly or wiring of the Bus Terminals!</p> |
|---|--|

Additional checks

The terminals have undergone the following additional tests:

| Verification | Explanation |
|--------------|---|
| Vibration | 10 frequency runs in 3 axes |
| | 6 Hz < f < 60 Hz displacement 0.35 mm, constant amplitude |
| | 60.1 Hz < f < 500 Hz acceleration 5 g, constant amplitude |
| Shocks | 1000 shocks in each direction, in 3 axes |
| | 25 g, 6 ms |

Additional installation instructions

For terminals with enhanced mechanical load capacity, the following additional installation instructions apply:

- The enhanced mechanical load capacity is valid for all permissible installation positions
- Use a mounting rail according to EN 60715 TH35-15
- Fix the terminal segment on both sides of the mounting rail with a mechanical fixture, e.g. an earth terminal or reinforced end clamp
- The maximum total extension of the terminal segment (without coupler) is:
64 terminals (12 mm mounting with) or 32 terminals (24 mm mounting with)
- Avoid deformation, twisting, crushing and bending of the mounting rail during edging and installation of the rail
- The mounting points of the mounting rail must be set at 5 cm intervals
- Use countersunk head screws to fasten the mounting rail
- The free length between the strain relief and the wire connection should be kept as short as possible. A distance of approx. 10 cm should be maintained to the cable duct.

3.4 Connection

3.4.1 Connection system

| | |
|---|---|
|  WARNING | <p>Risk of electric shock and damage of device!</p> <p>Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!</p> |
|---|---|

Overview

The Bus Terminal system offers different connection options for optimum adaptation to the respective application:

- The terminals of ELxxxx and KLxxxx series with standard wiring include electronics and connection level in a single enclosure.
- The terminals of ESxxxx and KSxxxx series feature a pluggable connection level and enable steady wiring while replacing.

- The High Density Terminals (HD Terminals) include electronics and connection level in a single enclosure and have advanced packaging density.

Standard wiring (ELxxxx / KLxxxx)



Fig. 7: Standard wiring

The terminals of ELxxxx and KLxxxx series have been tried and tested for years. They feature integrated screwless spring force technology for fast and simple assembly.

Pluggable wiring (ESxxxx / KSxxxx)



Fig. 8: Pluggable wiring

The terminals of ESxxxx and KSxxxx series feature a pluggable connection level. The assembly and wiring procedure for the KS series is the same as for the ELxxxx and KLxxxx series. The KS/ES series terminals enable the complete wiring to be removed as a plug connector from the top of the housing for servicing.

The lower section can be removed from the terminal block by pulling the unlocking tab. Insert the new component and plug in the connector with the wiring. This reduces the installation time and eliminates the risk of wires being mixed up.

The familiar dimensions of the terminal only had to be changed slightly. The new connector adds about 3 mm. The maximum height of the terminal remains unchanged.

A tab for strain relief of the cable simplifies assembly in many applications and prevents tangling of individual connection wires when the connector is removed.

Conductor cross sections between 0.08 mm² and 2.5 mm² can continue to be used with the proven spring force technology.

The overview and nomenclature of the product names for ESxxxx and KSxxxx series has been retained as known from ELxxxx and KLxxxx series.

High Density Terminals (HD Terminals)



Fig. 9: High Density Terminals

The Bus Terminals from these series with 16 terminal points are distinguished by a particularly compact design, as the packaging density is twice as large as that of the standard 12 mm Bus Terminals. Massive conductors and conductors with a wire end sleeve can be inserted directly into the spring loaded terminal point without tools.

| | |
|--|--|
|  Note | <p>Wiring HD Terminals</p> <p>The High Density (HD) Terminals of the ELx8xx and KLx8xx series doesn't support pluggable wiring.</p> |
|--|--|

Ultrasonically "bonded" (ultrasonically welded) conductors

| | |
|--|--|
|  Note | <p>Ultrasonically "bonded" conductors</p> <p>It is also possible to connect the Standard and High Density Terminals with ultrasonically "bonded" (ultrasonically welded) conductors. In this case, please note the tables concerning the wire-size width below!</p> |
|--|--|

3.4.2 Wiring

| | |
|---|---|
|  WARNING | <p>Risk of electric shock and damage of device!</p> <p>Bring the bus terminal system into a safe, powered down state before starting installation, disassembly or wiring of the Bus Terminals!</p> |
|---|---|

Terminals for standard wiring ELxxx/KLxxx and for pluggable wiring ESxxx/KSxxx




Fig. 10: Connecting a cable on a terminal point

Up to eight terminal points enable the connection of solid or finely stranded cables to the Bus Terminal. The terminal points are implemented in spring force technology. Connect the cables as follows:

1. Open a terminal point by pushing a screwdriver straight against the stop into the square opening above the terminal point. Do not turn the screwdriver or move it alternately (don't toggle).
2. The wire can now be inserted into the round terminal opening without any force.
3. The terminal point closes automatically when the pressure is released, holding the wire securely and permanently.

See the following table for the suitable wire size width.

| Terminal housing | ELxxxx, KLxxxx | ESxxxx, KSxxxx |
|---|------------------------------|------------------------------|
| Wire size width (single core wires) | 0.08 ... 2.5 mm ² | 0.08 ... 2.5 mm ² |
| Wire size width (fine-wire conductors) | 0.08 ... 2.5 mm ² | 0,08 ... 2.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 1.5 mm ² | 0.14 ... 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm | 9 ... 10 mm |

High Density Terminals ([HD Terminals \[► 16\]](#)) with 16 terminal points

The conductors of the HD Terminals are connected without tools for single-wire conductors using the direct plug-in technique, i.e. after stripping the wire is simply plugged into the terminal point. The cables are released, as usual, using the contact release with the aid of a screwdriver. See the following table for the suitable wire size width.

| Terminal housing | High Density Housing |
|--|-------------------------------|
| Wire size width (single core wires) | 0.08 ... 1.5 mm ² |
| Wire size width (fine-wire conductors) | 0.25 ... 1.5 mm ² |
| Wire size width (conductors with a wire end sleeve) | 0.14 ... 0.75 mm ² |
| Wire size width (ultrasonically "bonded" conductors) | only 1.5 mm ² |
| Wire stripping length | 8 ... 9 mm |

3.4.3 Shielding



Note

Shielding

Encoder, analog sensors and actors should always be connected with shielded, twisted paired wires.

3.5 Connection




Fig. 11: KL4494

| Terminal point | No. | Connection for |
|----------------|-----|------------------|
| Input 1 | 1 | input 1, signal |
| GND | 2 | ground* |
| Output 2 | 3 | output 1, signal |
| GND | 4 | ground* |
| Input 2 | 5 | input 2, signal |
| GND | 6 | ground* |
| Output 2 | 7 | output 2, signal |
| GND | 8 | ground* |

*) The input and output channels of the Bus Terminal have a common ground potential that is electrically isolated from the 0 V power contact.

3.6 ATEX - Special conditions (standard temperature range)



WARNING

Observe the special conditions for the intended use of Beckhoff fieldbus components with standard temperature range in potentially explosive areas (directive 94/9/EU)!

- The certified components are to be installed in a suitable housing that guarantees a protection class of at least IP54 in accordance with EN 60529! The environmental conditions during use are thereby to be taken into account!
- If the temperatures during rated operation are higher than 70°C at the feed-in points of cables, lines or pipes, or higher than 80°C at the wire branching points, then cables must be selected whose temperature data correspond to the actual measured temperature values!
- Observe the permissible ambient temperature range of 0 to 55°C for the use of Beckhoff fieldbus components standard temperature range in potentially explosive areas!
- Measures must be taken to protect against the rated operating voltage being exceeded by more than 40% due to short-term interference voltages!
- The individual terminals may only be unplugged or removed from the Bus Terminal system if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The connections of the certified components may only be connected or disconnected if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- The fuses of the KL92xx/EL92xx power feed terminals may only be exchanged if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!
- Address selectors and ID switches may only be adjusted if the supply voltage has been switched off or if a non-explosive atmosphere is ensured!

Standards

The fundamental health and safety requirements are fulfilled by compliance with the following standards:

- EN 60079-0:2012+A11:2013
- EN 60079-15:2010

Marking

The Beckhoff fieldbus components with standard temperature range certified for potentially explosive areas bear one of the following markings:



II 3G KEMA 10ATEX0075 X Ex nA IIC T4 Gc Ta: 0 ... 55°C

or



II 3G KEMA 10ATEX0075 X Ex nC IIC T4 Gc Ta: 0 ... 55°C

3.7 ATEX Documentation



Note

Notes about operation of the Beckhoff terminal systems in potentially explosive areas (ATEX)

Pay also attention to the continuative documentation

Notes about operation of the Beckhoff terminal systems in potentially explosive areas (ATEX)

that is available in the download area of the Beckhoff homepage <http://www.beckhoff.com>!

4 KS2000 Configuration Software

4.1 KS2000 - Introduction

The KS2000 configuration software permits configuration, commissioning and parameterization of bus couplers, of the affiliated bus terminals and of Fieldbus Box Modules. The connection between bus coupler / Fieldbus Box Module and the PC is established by means of the serial configuration cable or the fieldbus.



Fig. 12: KS2000 configuration software

Configuration

You can configure the Fieldbus stations with the Configuration Software KS2000 offline. That means, setting up a terminal station with all settings on the couplers and terminals resp. the Fieldbus Box Modules can be prepared before the commissioning phase. Later on, this configuration can be transferred to the terminal station in the commissioning phase by means of a download. For documentation purposes, you are provided with the breakdown of the terminal station, a parts list of modules used and a list of the parameters you have modified. After an upload, existing fieldbus stations are at your disposal for further editing.

Parameterization

KS2000 offers simple access to the parameters of a fieldbus station: specific high-level dialogs are available for all bus couplers, all intelligent bus terminals and Fieldbus Box modules with the aid of which settings can be modified easily. Alternatively, you have full access to all internal registers of the bus couplers and intelligent terminals. Refer to the register description for the meanings of the registers.

Commissioning

The KS2000 software facilitates commissioning of machine components or their fieldbus stations: Configured settings can be transferred to the fieldbus modules by means of a download. After a *login* to the terminal station, it is possible to define settings in couplers, terminals and Fieldbus Box modules directly *online*. The same high-level dialogs and register access are available for this purpose as in the configuration phase.

The KS2000 offers access to the process images of the bus couplers and Fieldbus Box modules.

- Thus, the coupler's input and output images can be observed by monitoring.
- Process values can be specified in the output image for commissioning of the output modules.

All possibilities in the *online mode* can be used in parallel with the actual fieldbus mode of the terminal station. The fieldbus protocol always has the higher priority in this case.

4.2 Parameterization with KS2000

Connect the configuration interface of your Fieldbus Coupler with the serial interface of your PC via the configuration cable and start the *KS2000* Configuration Software.



Click on the *Login* button. The configuration software will now load the information for the connected fieldbus station.

In the example shown, this is:

- a BK9000 Bus Coupler for Ethernet
- a KL1xx2 digital input terminal,
- a KL4494 analog terminal with 2 input and 2 output channels,
- a KL9010 Bus End Terminal




Fig. 13: Display of the fieldbus station in KS2000

The left-hand KS2000 window displays the terminals of the fieldbus station in a tree structure. The right-hand KS2000 window contains a graphic display of the fieldbus station terminals.

In the tree structure of the left-hand window, click on the plus-sign next to the terminal whose parameters you wish to change (item 2 in the example).




Fig. 14: KS2000 tree branches for channel 1 of the KL4494

For the KL4494, the branches *Register*, *Settings* and *ProcData* are displayed:

- [Register](#) [► 25] enables direct access to the KL4494 registers.

- Dialog masks for the parameterization of the KL4494 can be found under [Settings \[▶ 26\]](#).
- [ProcData \[▶ 27\]](#) displays the KL4494 process data.

4.3 Register

You can access the registers of the KL4494 directly under *Register*. The meaning of the register is explained in the [register overview \[▶ 31\]](#).




Fig. 15: Register view in KS2000

4.4 Settings

The dialog mask for the parameterization of the KL4494 can be found under *Settings*.

Pos.: 2 Channel: 1 Firmware: Version 1 B
 Type: KL4494-0000 (2 channel ana. input, 2 channel ana. output)

Take settings for all channels of this terminal

Operating Mode (Analog input)

- User scaling active
- Manufacturer scaling active
- Watchdog timer active
- Siemens output format

Operating Mode (Analog output)

- User scaling active
- Manufacturer scaling active
- Watchdog timer active
- Siemens output format
- User default value active
Value:

User scaling (Analog input)

Offset:
 Gain:

User scaling (Analog output)

Offset:
 Gain:

Apply
 Cancel

Fig. 16: Settings via KS2000

Operation Mode (analog input)

- **User scaling active** (R32.0 [▶ 34])
You can activate user scaling here (default: deactivated).
- **Manufacturer scaling active** (R32.1 [▶ 34])
You can deactivate manufacturer scaling here (default: activated).
- **Watchdog timer active** (R32.2 [▶ 34])
You can deactivate the watchdog timer here (default: activated).
- **Siemens output format active** (R32.3 [▶ 34])
You can activate Siemens output format [▶ 34] here (default: deactivated).

Operation Mode (analog output)

- **User scaling active** (R32.8 [▶ 34])
You can activate user scaling here (default: deactivated).
- **Manufacturer scaling active** (R32.9 [▶ 34])
You can deactivate manufacturer scaling here (default: activated).
- **Watchdog timer active** (R32.10 [▶ 34])
You can deactivate the watchdog timer here (default: activated).
- **Siemens output format active** (R32.11 [▶ 34])
You can activate Siemens output format here (default: deactivated).
- **User switch-on value active** (R32.12 [▶ 34])
You can activate the user switch-on value here (default: deactivated).

- **User switch-on value (R35 [▶ 35])**
You can specify the user switch-on value here (default: 0).

User scaling (analog input)

- **Offset (R33 [▶ 34])**
You can specify the offset for the user-scaling of the analog input here (default: 0).
- **Gain (R34 [▶ 35])**
You can specify the gain for the user-scaling of the analog input here (default: 256_{dec}, corresponding to a gain factor of 1).

User scaling (analog output)

- **Offset (R36 [▶ 35])**
You can specify the offset for the user-scaling of the analog output here (default: 0).
- **Gain (R37 [▶ 35])**
You can specify the gain for the user-scaling of the analog output here (default: 256_{dec}, corresponding to a gain factor of 1).

4.5 Process data

The Status byte (Status), the Control byte (Ctrl) and the process data (Data) are displayed in a tree structure under *ProcData*.

| Pos | Type | I-Address | Value | Bitsize | O-Address | Value | Bitsize |
|-----|-------------|-----------|--------|---------|-----------|--------|---------|
| 2 | KL4494-0000 | | | | | | |
| | Channel 1 | | | | | | |
| | State | 0.0 | 0x00 | 8 | | | |
| | Data In | 2.0 | 0x0000 | 16 | | | |
| | Ctrl | | | | 0.0 | 0x00 | 8 |
| | Data Out | | | | 2.0 | 0x0000 | 16 |
| | Channel 2 | | | | | | |
| | State | 4.0 | 0x00 | 8 | | | |
| | Data In | 6.0 | 0x0000 | 16 | | | |
| | Ctrl | | | | 4.0 | 0x00 | 8 |
| | Data Out | | | | 6.0 | 0x0000 | 16 |

Fig. 17: Process data field

The spectacles mark the data that are currently graphically displayed in the *History* field.




Fig. 18: History field

The current input value is displayed numerically in the *Value* field.



Fig. 19: Value field – display of the input value

Output values can be modified through direct input or by means of the fader control.



Fig. 20: Value field – input of the initial values



Danger for persons, the environment or equipment

Note that changing initial values (forcing them) can have a direct effect on your automation application.
Only modify these initial values if you are certain that the state of your equipment permits it, and that there will be no risk to people or to the machine!

After pressing the *Settings* button you can set the format of the numerical display to hexadecimal, decimal or binary.




Fig. 21: Setting the display

5 Access from the user program

5.1 Process image

In the process image, the KL4494 is represented with 6 bytes of input data and 6 bytes of output data. These are organized as follows:

| Byte offset (without word alignment) | Byte offset (with word alignment*) | Format | Input data | Output data |
|--------------------------------------|------------------------------------|--------|--------------------------|---------------------------|
| 0 | 0 | Byte | Status byte (SB1 [► 29]) | Control-Byte (CB1 [► 29]) |
| 1 | 2 | Word | DataIN1 | DataOUT1 |
| 3 | 4 | Byte | Status byte (SB2 [► 29]) | Control byte (CB2 [► 29]) |
| 4 | 6 | Word | DataIN2 | DataOUT2 |

*) Word alignment: The Bus Coupler places values on even byte addresses

5.2 Control and status bytes

Channel 1: The control and status bytes for channel 1 are illustrated in the following.

Channel 2: The control and status bytes of channel 2 have the same structure as the control and status bytes of channel 1.

Process data mode

Control byte 1 (CB1) in process data mode

Control byte 1 is located in the output image [► 29], and is transmitted from the controller to the terminal. In process data mode it has no function.

| Bit | CB1.7 | CB1.6 | CB1.5 | CB1.4 | CB1.3 | CB1.2 | CB1.1 | CB1.0 |
|------|-----------|-------|-------|-------|-------|-------|-------|-------|
| Name | RegAccess | - | - | - | - | - | - | - |

Key

| Bit | Name | Description |
|---------------|-----------|---|
| CB1.7 | RegAccess | 0 _{bin} Register communication off (process data mode) |
| CB1.6 - CB1.0 | - | 0 _{bin} reserved |

Status byte 1 (SB1) in process data mode

The status byte 1 is located in the input image [► 29] and is transmitted from terminal to the controller.

| Bit | SB1.7 | SB1.6 | SB1.5 | SB1.4 | SB1.3 | SB1.2 | SB1.1 | SB1.0 |
|------|-----------|-------|--------------------|-------|--------------------|-------|-----------|------------|
| Name | RegAccess | Error | LimitValue 2 State | | LimitValue 1 State | | Overrange | Underrange |

Key

| Bit | Name | Description |
|---------------|--------------------|---|
| SB1.7 | RegAccess | 0 _{bin} Acknowledgment for process data mode |
| SB1.6 | Error | 1 _{bin} General error bit |
| SB1.5 - SB1.4 | LimitValue 2 State | 00 _{bin} Limit value 2 not activated |
| | | 01 _{bin} Process data less than limit value 2 |
| | | 10 _{bin} Process data greater than limit value 2 |
| | | 11 _{bin} Process data equal limit value 2 |
| SB1.3 - SB1.2 | LimitValue 1 State | 00 _{bin} Limit value 1 not activated |
| | | 01 _{bin} Process data less than limit value 1 |
| | | 10 _{bin} Process data greater than limit value 1 |
| | | 11 _{bin} Process data equal limit value 1 |
| SB1.1 | Overrange | 1 _{bin} Permissible measuring range exceeded |
| SB1.0 | Underrange | 1 _{bin} Lower measuring range limit violated |

Register communication

Control byte 1 (CB1) in register communication

Control byte 1 is located in the [output image](#) [[▶ 29](#)], and is transmitted from the controller to the terminal.

| Bit | CB1.7 | CB1.6 | CB1.5 | CB1.4 | CB1.3 | CB1.2 | CB1.1 | CB1.0 |
|------|-----------|-------|----------|-------|-------|-------|-------|-------|
| Name | RegAccess | R/W | Reg. no. | | | | | |

Key

| Bit | Name | Description |
|----------------|-----------|--|
| CB1.7 | RegAccess | 1 _{bin} Register communication switched on |
| CB1.6 | R/W | 0 _{bin} Read access |
| | | 1 _{bin} Write access |
| CB1.5 to CB1.0 | Reg. no. | Register number: Enter the number of the register that you <ul style="list-style-type: none"> • want to read with input data word DataIN1 [▶ 29] or • with the output data word DataOUT1 [▶ 29] |

Status byte 1 (SB1) in register communication

The status byte 1 is located in the [input image](#) [[▶ 29](#)] and is transmitted from terminal to the controller.

| Bit | SB1.7 | SB1.6 | SB1.5 | SB1.4 | SB1.3 | SB1.2 | SB1.1 | SB1.0 |
|------|-----------|-------|----------|-------|-------|-------|-------|-------|
| Name | RegAccess | R/W | Reg. no. | | | | | |

Key

| Bit | Name | Description |
|----------------|-----------|---|
| SB1.7 | RegAccess | 1 _{bin} Acknowledgment for register access |
| SB1.6 | R | 0 _{bin} Read access |
| SB1.5 to SB1.0 | Reg. no. | Number of the register that was read or written. |

5.3 Register overview

The following registers are used for parameterization of the KL4494. Each signal channel of the analog terminal has one register that can be read or written to with the aid of [control \[▶ 30\]](#), [status \[▶ 30\]](#) and [data bytes \[▶ 29\]](#) via [register communication \[▶ 35\]](#).

| Register no. | Comment | Default value | | R/W | Memory |
|----------------------------|---|---------------|---------------------------|-----|---------|
| R0 [▶ 32] | Raw value of the A/D converter (X_R) | - | - | R | RAM |
| R1 | reserved | - | - | - | - |
| ... | ... | ... | ... | ... | ... |
| R5 | reserved | - | - | - | - |
| R6 [▶ 32] | Diagnostic register | - | - | R | RAM |
| R7 [▶ 32] | Command register | 0x0000 | 0 _{dec} | R/W | RAM |
| R8 [▶ 32] | Terminal type | 0x118E | 4494 _{dec} | R | ROM |
| R9 [▶ 32] | Firmware version | e.g. 0x3141 | e.g. 1A _{ASCII} | R | ROM |
| R10 [▶ 32] | Data length (multiplex shift register) | 0x0130 | 304 _{dec} | R | ROM |
| R11 [▶ 32] | Signal channels | 0x0218 | 536 _{dec} | R | ROM |
| R12 [▶ 32] | Minimum data length | 0x9898 | 39064 _{dec} | R | ROM |
| R13 [▶ 32] | Data structure (data type register) | 0x0004 | 4 _{dec} | R | ROM |
| R14 | reserved | - | - | - | - |
| R15 [▶ 33] | Alignment register | e.g. 0x7F80 | e.g. 32640 _{dec} | R/W | RAM |
| R16 [▶ 33] | Hardware version number | e.g. 0x0000 | e.g. 0 _{dec} | R/W | SEEPROM |
| R17 [▶ 33] | Manufacturer scaling, analog input: Offset (B_a) | variable | variable | R/W | SEEPROM |
| R18 [▶ 33] | Manufacturer scaling, analog input: Gain (A_a) | typ. 0x1080 | typ. 4224 _{dec} | R/W | SEEPROM |
| R19 [▶ 33] | Manufacturer scaling, analog output: Offset (B_a) | 0x0800 | 2048 _{dec} | R/W | SEEPROM |
| R20 [▶ 33] | Manufacturer scaling, analog output: Gain (A_a) | typ. 0x7D00 | typ. 32000 _{dec} | R/W | SEEPROM |
| R21 [▶ 33] | Overrange-Limit | 0x0000 | 0 _{dec} | R/W | SEEPROM |
| R22 [▶ 33] | Underrange-Limit | 0x0000 | 0 _{dec} | R/W | SEEPROM |
| R23 | reserved | - | - | - | - |
| ... | ... | ... | ... | ... | ... |
| R30 | reserved | - | - | - | - |
| R31 [▶ 33] | Code word register | 0x0000 | 0 _{dec} | R/W | RAM |
| R32 [▶ 34] | Feature register | 0x0404 | 1028 _{dec} | R/W | SEEPROM |
| R33 [▶ 34] | User scaling, analog input: Offset (B_w) | 0x0000 | 0 _{dec} | R/W | SEEPROM |
| R34 [▶ 35] | User scaling, analog input: Gain (A_w) | 0x0100 | 256 _{dec} | R/W | SEEPROM |
| R35 [▶ 35] | User default value for analog output | 0x0000 | 0 _{dec} | R/W | SEEPROM |
| R36 [▶ 35] | User scaling, analog output: Offset (B_w) | 0x0000 | 0 _{dec} | R/W | SEEPROM |
| R37 [▶ 35] | User scaling, analog output: Gain (A_w) | 0x0100 | 256 _{dec} | R/W | SEEPROM |
| R38 | reserved | - | - | - | - |
| ... | reserved | ... | ... | ... | ... |
| R63 | reserved | - | - | - | - |

5.4 Register description

All registers can be read or written via [register communication](#) [[▶ 35](#)].

R0: Raw value A/D-C

Raw value of the A/D converter (X_R)

R6: Diagnostic register

The [status byte](#) [[▶ 29](#)] is mapped to the low-order byte (bit 7 to bit 0) of register R6. The high-order byte (bit 15 to bit 8) of register R6 is reserved.

R7: Command register

The command register of KL4494 is currently not used.

R8: Terminal description

The terminal description is contained in register R8: 0x118E (4494_{dec})

R9: Firmware version

Register R9 contains the ASCII coding of the terminal's firmware version, e.g. **0x3141 (1A)_{ASCII}**. '0x31' corresponds to the ASCII character '1' and '0x41' to the ASCII character 'A'. This value cannot be changed.

R10: Data length (multiplex shift register)

R10 contains the number of multiplexed shift registers and their length in bits.

R11: Signal channels

Unlike R10, this contains the number of channels that are logically present. Thus for example a shift register that is physically present can perfectly well consist of several signal channels.

R12: Minimum data length

The particular byte contains the minimum data length for a channel that is to be transferred. If the MSB is set, the control and status byte is not necessarily required for the terminal function and is not transferred to the control, if the Bus Coupler is configured accordingly.

R13: Data structure (data type register)

| Data type register | Meaning |
|--------------------|---|
| 0x00 | Terminal with no valid data type |
| 0x01 | Byte-Array |
| 0x02 | Structure: 1 Byte, n Bytes |
| 0x03 | Word array |
| 0x04 | Structure: 1 byte, n words |
| 0x05 | Double word array |
| 0x06 | Structure: 1 byte, n double words |
| 0x07 | Structure: 1 byte, 1 double word |
| 0x08 | Structure: 1 byte, 1 double word |
| 0x11 | Byte array with variable logical channel length |
| 0x12 | Structure: 1 byte, n bytes with variable logical channel length (e.g. 60xx) |
| 0x13 | Word array with variable logical channel length |
| 0x14 | Structure: 1 byte, n words with variable logical channel length |
| 0x15x | Double word array with variable logical channel length |
| 0x16 | Structure: 1 byte, n double words with variable logical channel length |

R15: Alignment register

Via the alignment register bits, the Bus Coupler arranges the address range of an analog terminal such that it starts at a byte boundary.

R16: Hardware version number

Register R16 contains the hardware version of the terminal; this value cannot be changed.

R17: Hardware compensation for analog input - offset (B_a)

This register is used for the offset compensation of the analog input (see equation 1.1).

R18: Hardware compensation for analog input - gain (A_a)

This register is used for the gain compensation of the analog input.

Scaling: Gain factor = $R18 \times 2^{-12}$ (see equation 1.1)

Example: 4096_{dec} (0x1000), equivalent to a gain factor of 1

R19: Hardware compensation for analog output - offset (B_a)

This register is used for the offset compensation of the analog output (see equation 1.1).

R20: Hardware compensation for analog output - gain (A_a)

This register is used for the gain compensation of the analog output.

Scaling: Gain factor = $R20 \times 2^{-15}$ (see equation 1.1)

Example: 32768_{dec} (0x1000), equivalent to a gain factor of 1

R21 Overrange-Limit - OvRL (Y_a)

This limit value limits the maximum measuring range of the input terminal (see equation 1.0). If it is exceeded, the associated status bit is set, and the maximum value is displayed.

R22 Underrange-Limit - UnRL (Y_a)

If the value falls below this limit, the associated status bit is set, and the minimum value is displayed (see equation 1.0).

R31: Code word register

- If you write values into the user registers without first entering the user code word (0x1235) into the code word register, the terminal will not accept the supplied data.
- If you write values into the user registers and have previously entered the user code word (0x1235) in the code word register, these values are stored in the RAM registers and in the SEEPROM registers and are therefore retained if the terminal is restarted.

The code word is reset with each restart of the terminal.

R32: Feature register

The feature register specifies the terminal's configuration. Default: 0x0404 (1028_{dec})

High-Byte: analog output configuration

| Bit | R32.15 | R32.14 | R32.13 | R32.12 | R32.11 | R32.10 | R32.9 | R32.8 |
|------|--------|--------|--------|--------------|-----------|--------|-----------|-----------|
| Name | - | - | - | enUsrDefault | enSiemens | enWDT | enManScal | enUsrScal |

Low-Byte: analog input configuration

| Bit | R32.7 | R32.6 | R32.5 | R32.4 | R32.3 | R32.2 | R32.1 | R32.0 |
|------|-------|-------|-------|-------|-----------|-------|-----------|-----------|
| Name | - | - | - | - | enSiemens | enWDT | enManScal | enUsrScal |

Key

| Bit | Name | Description | default |
|--------|----------------------------|---|------------------|
| R32.15 | - | reserved | 0 _{bin} |
| ... | ... | ... | ... |
| R32.13 | - | reserved | 0 _{bin} |
| R32.12 | enUsrDefault | 1 _{bin} User default value specified via register R35 [► 35] is active | 0 _{bin} |
| R32.11 | enSiemens Analog Output | 0 _{bin} Standard output format | 0 _{bin} |
| | | 1 _{bin} Siemens output format | |
| R32.10 | enWDT | 1 _{bin} Watchdog timer is active | 1 _{bin} |
| R32.9 | enManScal Analog Output | 0 _{bin} Manufacturer scaling is active | 0 _{bin} |
| | | 1 _{bin} Manufacturer scaling is not active | |
| R32.8 | enUsrScal Analog Output | 0 _{bin} User scaling is not active | 0 _{bin} |
| | | 1 _{bin} User scaling is active | |
| R32.7 | - | reserved | 0 _{bin} |
| R32.6 | - | reserved | 0 _{bin} |
| R32.5 | - | reserved | 0 _{bin} |
| R32.4 | - | reserved | 0 _{bin} |
| R32.3 | enSiemens Analog Input | 0 _{bin} Standard output format | 0 _{bin} |
| | | 1 _{bin} Siemens output format: The three bits with the lowest value are used for displaying status information (see below). | |
| R32.2 | enWDT | 1 _{bin} Watchdog timer is active | 1 _{bin} |
| R32.1 | enManScal Analog Input | 0 _{bin} Manufacturer scaling is active | 0 _{bin} |
| | | 1 _{bin} Manufacturer scaling is not active | |
| R32.0 | enUsrScal Analog Input | 0 _{bin} User scaling is not active | 0 _{bin} |
| | | 1 _{bin} User scaling is active | |

Siemens output format

If the Siemens output format is selected, the lowest three bits are used for status evaluation. The process data is represented in bits 15 to 3, with bit 15 representing the sign bit. Scaling of the measured value according to the Siemens standard has to be done via user scaling (R33, R34).

| Measured value | Bit 15 ... 3 | Bit 2 X | Bit 1 Error | Bit 0 Overflow |
|-------------------------------|--------------|------------|----------------|-------------------|
| Measured value < -10 V | | 0 | 0 | 1 |
| -10 V < Measured value < 10 V | Process data | 0 | 0 | 0 |
| Measured value >+10 V | | 0 | 0 | 1 |

R33: User scaling for analog input - offset (B_w)

This register contains the offset of the user scaling for the analog input (default: 0).

User scaling for the analog input can be activated in the feature register via bit R32.0 [► 34].

R34: User scaling for analog input - gain (A_w)

This register contains the gain factor of the user scaling for the analog input (default: 256_{dec}, equivalent to a gain factor of 1).

Scaling: Gain factor = R34 x 2⁻⁸

User scaling for the analog input can be activated in the feature register via bit R32.0 [► 34].

R35: User default value for analog output

Here you can specify the user default value.

R36: User scaling for analog output - offset (B_w)

This register contains the offset of the user scaling for the analog input (default: 0).

User scaling for the analog output can be activated in the feature register via bit R32.8 [► 34].

R37: User scaling for analog output - gain (A_w)

This register contains the gain factor of the user scaling for the analog output (default: 256_{dec}, equivalent to a gain factor of 1).

Scaling: Gain factor = R37 x 2⁻⁸

User scaling for the analog output can be activated in the feature register via bit R32.8 [► 34].

5.5 Examples of Register Communication

The numbering of the bytes in the examples corresponds to the display without word alignment.

5.5.1 Example 1: reading the firmware version from Register 9

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0x89 (1000 1001 _{bin}) | 0xXX | 0xXX |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 9 with 00 1001_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access. To change a register, write the required value into the output word.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|---------------------|----------------------------|---------------------------|
| 0x89 | 0x33 | 0x41 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the firmware version 0x3341 in the input data word (byte 1 and byte 2). This is to be interpreted as an ASCII code:
 - ASCII code 0x33 represents the digit 3
 - ASCII code 0x41 represents the letter A
 The firmware version is thus 3A.

5.5.2 Example 2: Writing to a user register



Note

Code word

In normal mode all user registers are read-only with the exception of Register 31. In order to deactivate this write protection you must write the code word (0x1235) into Register 31. In order to reactivate this write protection you must write a value other than 0x1235 into Register 31, write protection is reactivated. Please note that changes to a register only become effective after restarting the terminal (power-off/power-on).

I. Write the code word (0x1235) into Register 31.

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xDF (1101 1111 _{bin}) | 0x12 | 0x35 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) contains the code word (0x1235) for deactivating write protection.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0xFF | 0xFF |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

II. Read Register 31 (check the set code word)

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0x9F (1001 1111 _{bin}) | 0xFF | 0xFF |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0x12 | 0x35 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.

- The terminal returns the current value of the code word register in the input data word (byte 1 and byte 2).

III. Write to Register 32 (change contents of the feature register)

Output data

| Byte 0: Control byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xE0 (1110 0000 _{bin}) | 0x00 | 0x02 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000_{bin}.
- The output data word (byte 1 and byte 2) contains the new value for the feature register.

| | |
|---|---|
|  CAUTION | <p>Observe the register description!</p> <p>The value of 0x0002 given here is just an example! The bits of the feature register change the properties of the terminal and have a different meaning, depending on the type of terminal. Refer to the description of the feature register of your terminal (chapter <i>Register description</i>) regarding the meaning of the individual bits before changing the values.</p> |
|---|---|

Input data (response from the Bus Terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xA0 (1010 0000 _{bin}) | 0xFF | 0xFF |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

IV. Read Register 32 (check changed feature register)

Output Data

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xA0 (1010 0000 _{bin}) | 0xFF | 0xFF |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 not set means: reading the register.
- Bits 0.5 to 0.0 indicate register number 32 with 10 0000_{bin}.
- The output data word (byte 1 and byte 2) has no meaning during read access.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0xA0 (1010 0000 _{bin}) | 0x00 | 0x02 |

Explanation:

- The terminal returns the value of the control byte as a receipt in the status byte.
- The terminal returns the current value of the feature register in the input data word (byte 1 and byte 2).

V. Write Register 31 (reset code word)**Output Data**

| Byte 0: Control byte | Byte 1: DataOUT1, high byte | Byte 2: DataOUT1, low byte |
|----------------------------------|-----------------------------|----------------------------|
| 0xDF (1101 1111 _{bin}) | 0x00 | 0x00 |

Explanation:

- Bit 0.7 set means: Register communication switched on.
- Bit 0.6 set means: writing to the register.
- Bits 0.5 to 0.0 specify the register number 31 with 01 1111_{bin}.
- The output data word (byte 1 and byte 2) contains 0x0000 for reactivating write protection.

Input Data (answer of the bus terminal)

| Byte 0: Status byte | Byte 1: DataIN1, high byte | Byte 2: DataIN1, low byte |
|----------------------------------|----------------------------|---------------------------|
| 0x9F (1001 1111 _{bin}) | 0xFF | 0xFF |

Explanation:

- The terminal returns a value as a receipt in the status byte that differs only in bit 0.6 from the value of the control byte.
- The input data word (byte 1 and byte 2) is of no importance after the write access. Any values still displayed are invalid!

6 Appendix

6.1 Support and Service

Beckhoff and their partners around the world offer comprehensive support and service, making available fast and competent assistance with all questions related to Beckhoff products and system solutions.

Beckhoff's branch offices and representatives

Please contact your Beckhoff branch office or representative for [local support and service](#) on Beckhoff products!

The addresses of Beckhoff's branch offices and representatives round the world can be found on her internet pages:

<http://www.beckhoff.com>

You will also find further [documentation](#) for Beckhoff components there.

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG

Huelshorstweg 20
33415 Verl
Germany

| | |
|---------|--------------------|
| Phone: | +49(0)5246/963-0 |
| Fax: | +49(0)5246/963-198 |
| e-mail: | info@beckhoff.com |

Beckhoff Support

Support offers you comprehensive technical assistance, helping you not only with the application of individual Beckhoff products, but also with other, wide-ranging services:

- support
- design, programming and commissioning of complex automation systems
- and extensive training program for Beckhoff system components

| | |
|----------|----------------------|
| Hotline: | +49(0)5246/963-157 |
| Fax: | +49(0)5246/963-9157 |
| e-mail: | support@beckhoff.com |

Beckhoff Service

The Beckhoff Service Center supports you in all matters of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

| | |
|----------|----------------------|
| Hotline: | +49(0)5246/963-460 |
| Fax: | +49(0)5246/963-479 |
| e-mail: | service@beckhoff.com |

List of illustrations

| | | |
|---------|---|----|
| Fig. 1 | KL4494 | 6 |
| Fig. 2 | KL4494 - LEDs | 8 |
| Fig. 3 | Spring contacts of the Beckhoff I/O components..... | 11 |
| Fig. 4 | Attaching on mounting rail | 12 |
| Fig. 5 | Disassembling of terminal..... | 13 |
| Fig. 6 | Power contact on left side..... | 14 |
| Fig. 7 | Standard wiring..... | 16 |
| Fig. 8 | Pluggable wiring | 16 |
| Fig. 9 | High Density Terminals..... | 16 |
| Fig. 10 | Connecting a cable on a terminal point | 17 |
| Fig. 11 | KL4494 | 19 |
| Fig. 12 | KS2000 configuration software..... | 22 |
| Fig. 13 | Display of the fieldbus station in KS2000 | 24 |
| Fig. 14 | KS2000 tree branches for channel 1 of the KL4494..... | 24 |
| Fig. 15 | Register view in KS2000..... | 25 |
| Fig. 16 | Settings via KS2000 | 26 |
| Fig. 17 | Process data field | 27 |
| Fig. 18 | History field | 27 |
| Fig. 19 | Value field – display of the input value | 27 |
| Fig. 20 | Value field – input of the initial values..... | 28 |
| Fig. 21 | Setting the display | 28 |