
BECKHOFF New Automation Technology

Manual | EN

MS2620-8001-2255

EtherCAT power infeed, EtherCAT, DC link voltage/20 A, DC link capacity, B23



2026-10-28 | Version: 1.0

Table of contents

1 Foreword 5
1.1 Notes on the documentation 5
1.2 For your safety 6
1.3 Intended use 7
1.4 Warning Signs and Symbols 7
2 Product overview 8
2.1 Product functions 10
2.2 Block diagram 11
2.3 Type key 12
2.4 Status display 13
2.5 Dimensions 15
3 Technical data 16
4 Software functions 17
5 Mechanical installation 19
5.1 Preparation 19
5.2 Placement of the module on the baseplate 20
5.3 Mounting the module 21
6 Connection 22
7 Commissioning and operation 24
8 Decommissioning 25
8.1 Disassembly 25
8.2 Disposal 25
9 Appendix 26
9.1 Manual version history 26
9.2 Accessories 26
9.3 Support and Service 27

1 Foreword

1.1 Notes on the documentation

This description is intended exclusively for trained specialists in control and automation technology who are familiar with the applicable national standards.
The documentation and the following notes and explanations must be complied with when installing and commissioning the components.
The trained specialists must always use the current valid documentation.

The trained specialists must ensure that the application and use of the products described is in line with all safety requirements, including all relevant laws, regulations, guidelines, and standards.

Disclaimer

The documentation has been compiled with care. The products described are, however, constantly under development.
We reserve the right to revise and change the documentation at any time and without notice.
Claims to modify products that have already been supplied may not be made on the basis of the data, diagrams, and descriptions in this documentation.

Trademarks

Beckhoff®, ATRO®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, MX-System®, Safety over EtherCAT®, TC/BSD®, TwinCAT®, TwinCAT/BSD®, TwinSAFE®, XFC®, XPlanar® and XTS® are registered and licensed trademarks of Beckhoff Automation GmbH.
If third parties make use of the designations or trademarks contained in this publication for their own purposes, this could infringe upon the rights of the owners of the said designations.





EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.
The distribution and reproduction of this document, as well as the use and communication of its contents without express authorization, are prohibited.
Offenders will be held liable for the payment of damages. All rights reserved in the event that a patent, utility model, or design are registered.

Third-party trademarks

Trademarks of third parties may be used in this documentation. You can find the trademark notices here: https://www.beckhoff.com/trademarks.

1.2 For your safety

Safety regulations

Read the following explanations for your safety.
Always observe and follow product-specific safety instructions, which you may find at the appropriate places in this document.

Exclusion of liability

All the components are supplied in particular hardware and software configurations which are appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation, and drive technology who are familiar with the applicable national standards.

Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

Personal injury warnings

⚠ DANGER
Hazard with high risk of death or serious injury.

⚠ WARNING
Hazard with medium risk of death or serious injury.

⚠ CAUTION
There is a low-risk hazard that could result in medium or minor injury.

Warning of damage to property or environment

NOTICE
The environment, equipment, or data may be damaged.

Information on handling the product



This information includes, for example:
recommendations for action, assistance or further information on the product.

1.3 Intended use

Intended use of an MX-System

Application in machines and systems in industrial environments and exclusively inside buildings.

The electrical wiring must be permanent wiring.

Improper use

Improper use is not permitted and will result in the exclusion of liability on the part of Beckhoff Automation GmbH & Co. KG.

1.4 Warning Signs and Symbols

Safety symbols, warning labels, and informational symbols are displayed on the product, the packaging, and in the technical documentation. The symbols used may vary depending on the device model and features.

The symbols are used:

- to protect people,
- to prevent damage to property and equipment,
- as well as for technical, safety-relevant, and environmental information.

Safety and information labels must not be removed, covered, or obscured. They must remain readable at all times.

The following section explains the symbols used on the device and in the documentation. These include both safety-relevant warning signs and general information and marking symbols, such as those for electrical labeling, disposal, or intended use.

When a symbol appears, follow the instructions provided in the technical documentation.



High voltage warning

The device contains areas with hazardous electrical voltage. Contacting live electrical parts can result in serious injury or death. Work on the device may only be performed in a de-energized state.



General warning sign

The relevant safety and warning instructions in the technical documentation must be followed. Improper operation or failure to follow the instructions may result in injury, property damage, or damage to the equipment.



Electronic Components/Disposal

Products marked with a crossed-out waste bin must not be disposed of with general waste. Electrical and electronic devices must be disposed of in accordance with applicable national regulations governing waste electrical and electronic equipment.



Read the original operating instructions

Be sure to read the entire operating instructions before commissioning the device. In particular, please observe the general safety instructions as well as the warnings in the individual chapters.




Observe the waiting time!

After all power connections have been disconnected, a dangerous voltage remains present for 10 minutes.


2 Product overview

The MS2620-8001-2255 power infeed module provides 600 V DC and up to 20 A as well as EtherCAT for the system. The power is supplied via a hybrid connector. The module thus enables the integration of a baseplate into an existing EtherCAT topology.

In addition, the MS2620-8001-2255 has integrated DC link capacitance.



Position	Name
1	Fastening screw, captive, 8 x
2	Status display
3	Seal
4	EtherCAT power infeed
5	Module name



Position	Name
1	Fastening screw, captive, 8 x
2	Data connector
3	Power connector
4	Seal

2.1 Product functions

X1 EtherCAT feed-in

An EtherCAT connection can be established with the underlying baseplate and all other connected devices via the X1 interface.


X1 600 V DC supply

The X1 interface allows 600 V DC voltage to be supplied to the MX-System, which can then be used to power MD8xxx drive modules, among other things.


DC link capacitance

The module has an integrated DC capacitance that can be used as a buffer for the DC link, for example.


2.2 Block diagram



2.3 Type key


MS 2620-8001-2255
MS Product group: System modules
2 Category: EtherCAT power infeed
6 Function: EtherCAT + High Power
2 Supply current: 20 A
0
8 Option 1: DC link buffer
0 Option 2: -
0 Additional input voltage: -
1 Number of plugs: 1 plug, only input
2 Size: 240 mm
2 Slot width: 2 slots
5 DC link voltage
5 Plug type: B23 connector


2.4 Status display



LED	State	Meaning
	-	Beckhoff Identification Code as Data Matrix code
DC	off	No additional DC link voltage present.
	lights up green	The additional DC link voltage is present.
	flashes green	• Current Level Warning active • Load Level Warning active • At startup: The channel is currently charging
Back		EtherCAT communication status of the backplane
	off	Initialization Initial state after switching on. The device is detected and initialized; no process data exchange is taking place yet.
	flashes green	Pre-Operational The device is configurable. Mailbox communication (e.g., CoE/ SDO access) is possible, but process data is not yet being transmitted.
	green single flash	Safe-Operational Configuration is complete. The device receives and processes process data; however, the outputs remain in a safe state and are not yet activated.
	lights up green	Operational Normal operating state. Full cyclic process data exchange; inputs and outputs are active.
	flickers green	Bootstrap Special maintenance mode for firmware updates. Normal process data communication is not possible.
L/A	off	No connection on the incoming EtherCAT segment.
	flashes green	Communication is established with the previous EtherCAT device.
	lights up green	The preceding EtherCAT device is connected.
Run	off	EtherCAT communication status: Initialization Initial state after switching on. The device is detected and initialized; no process data exchange is taking place yet.
	flashes green	EtherCAT communication status: Pre-Operational The device is configurable. Mailbox communication (e.g., CoE/ SDO accesses) is possible, but process data is not yet being transmitted.
	green single flash	EtherCAT communication status: Safe-Operational Configuration is now complete. The device receives and processes process data; however, the outputs remain in a safe state and are not yet activated.
	lights up green	EtherCAT communication status: Operational Normal operating state. Full cyclic process data exchange; inputs and outputs are active.
	flickers green	EtherCAT communication status: Bootstrap Special maintenance mode for firmware updates. Normal process data communication is not possible.

2.5 Dimensions

All dimensions in mm



3 Technical data

All values are typical values over the entire temperature range, unless stated otherwise.

Baseplate interface	
Connector	1 data connector 1 power connector
Hot Swap	No
Fieldbus	EtherCAT

Voltage and EtherCAT input X1	
Connection	1 x B23 hybrid connector, 3-pin, 4-pin data element
Rated voltage DC	600 V DC (max. 848 V DC)
Rated current DC	20 A
Integrated capacitance	1645 µF
Fieldbus	EtherCAT
Fieldbus, max. cable length	100 m

Housing data	
Width (slots)	2
Height (rows)	2
Dimensions W × H × D	90 mm × 240 mm × 147 mm 90 mm × 240 mm × 112 mm (housing only)
Material	Zinc die-cast and aluminum die-cast
Cooling	Convection
Installation position	Vertical. See system manual, chapter "Installation conditions".

Standards, approvals	
Device safety	conforms to EN 61010-2-201
EMC immunity/emission	conforms to EN IEC 61000-6-2/EN IEC 61000-6-4
Vibration/shock resistance	conforms to EN 60068-2-6/EN 60068-2-27
Approvals	• CE • UL in preparation

Device safety	
Separation between input and output	Double or reinforced electrical isolation
Protection class	I

Environmental conditions	
Operating temperature	0 … 50 °C
Storage temperature	-25 … +60 °C
Air humidity	95 %, no condensation
Protection rating	IP20 as a separate module
	IP65 / IP67 as part of a fully and correctly assembled MX-System
Pollution degree	2
Overvoltage category	III
Maximum installation altitude	2000 m

4 Software functions

Software functions are the functions of a module's firmware that a controller can access via EtherCAT.

Functionality

The following descriptions document the full range of software functions at the time of publication of this manual. The range of functions that can actually be used depends on the firmware version of a module.

Process data objects

Process data objects (PDOs) are used for the cyclic transmission of process data between the EtherCAT MainDevice and EtherCAT SubDevice. The data is exchanged at fixed intervals as part of the real-time cycle and serves as the basis for control and monitoring of field devices. PDOs typically contain input and output data required for the direct operation of a device. Cyclic transfer ensures a continuous and deterministic data exchange.

Inputs Profile DC

Variable	Type	Description
Power Good	BIT	0 = There is no DC link voltage. 1 = The DC link voltage is present.

WcState

WcState indicates whether an EtherCAT SubDevice correctly participated in the cyclic process data exchange during the last bus cycle.

Variable	Type	Description
WcState	BIT	0 = data is valid 1 = data is invalid
InputToggle	BIT	A 1-bit counter that increments after each cycle

InfoData

InfoData indicates which diagnostic and status information an EtherCAT SubDevice provides.

Variable		Type	Description
State		UINT	0x___1 = EtherCAT SubDevice in INIT state 0x___2 = EtherCAT SubDevice in PREOP state 0x___3 = EtherCAT SubDevice in BOOT state 0x___4 = EtherCAT SubDevice in SAFEOP state 0x___8 = EtherCAT SubDevice in OP state 0x001_ = EtherCAT SubDevice reports an error 0x002_ = Invalid vendor ID, product code x read 0x004_ = Initialization error occurred 0x008_ = EtherCAT SubDevice disabled 0x010_ = EtherCAT SubDevice not present 0x020_ = EtherCAT SubDevice reports a connection error 0x040_ = EtherCAT SubDevice reports no connection 0x080_ = EtherCAT SubDevice reports an unexpected connection 0x100_ = Communication Port A 0x200_ = Communication Port B 0x400_ = Communication Port C 0x800_ = Communication Port D

5 Mechanical installation

Required tools


- Torx T25 screwdriver
- Torque wrench 5 Nm

5.1 Preparation

NOTICE

Check the module for damage

If the seal is worn or damaged, liquids and dirt can penetrate and damage the MX-System. The IP65/IP67 protection rating is not met if the seals are worn or damaged.





1. Check the seal [1] of the module for wear and damage
2. Replace worn and damaged seals

5.2 Placement of the module on the baseplate


The module can be plugged into the following areas marked in green:

MB11xx-0000-0000







MB21xx-0000-0000



MB21xx-0000-x000 → MB21xx-0000-4000
→ MB21xx-0000-6000
→ MB21xx-0000-8000



MB31xx-0000-0000



5.3 Mounting the module

⚠ CAUTION

Danger due to the high weight of an equipped baseplate

First mount the baseplate and then the modules to the baseplate. If you mount the modules on the baseplate first, the total weight of the MX-System will increase. Another person is required to transport and installation an equipped baseplate.

- Wear personal protective equipment.
- The equipped baseplate must be transported and mounted by two people.

NOTICE

Ensure correct installation

If the module is not installed correctly, liquids and dirt may enter and damage the MX-System. The IP65/IP67 protection rating is not met if the installation is incorrect.

NOTICE

Limited number of mating cycles

The module may be plugged in a maximum of 25 times to attach it to the baseplate. If the module is plugged into the baseplate more than 25 times, a secure connection between the module and the baseplate cannot be guaranteed.

- Observe the permissible number of mating cycles.
- Replace the module if the number of mating cycles is exceeded.
- Replace the baseplate if the number of mating cycles is exceeded.

1. Plug the module on the baseplate
2. Tighten all screws
3. Observe tightening torques:

Components	Tightening torque [Nm]
Screws	5

Further information on installation can be found in the system manual in the “Mounting” chapter.

6 Connection

NOTICE

PELV voltage source

The module must be powered by a PELV voltage source.

NOTICE


Cover unused sockets with protective caps


IP67 protection rating is only guaranteed if plugs are connected to all sockets and unused sockets are covered with protective caps.

Tested with a UL-listed circuit breaker (without current limiting) rated at 20 A.

6.1 Power input

The power input is a 3-pin B23 socket (coding 2) with 4-pin data element.



B23 socket, 2-coded	Pin	Symbol	Function
	1	TX+	EtherCAT data line
	2	RX+	EtherCAT data line
	3	RX-	EtherCAT data line
	4	TX-	EtherCAT data line
	5	DC-	negative DC link voltage
	6	PE	Protective earth
	7	DC+	positive DC link voltage

7 Commissioning and operation

⚠ WARNING

Danger to life due to electric shock

After switching on, a life-threatening voltage may be present at open connectors.

- Before switching on, make sure that all components supplied with power voltage are fully and properly installed and correctly wired.
- Before switching on, ensure that unused connectors and other connections are covered with the sealing caps, dummy caps or protective caps provided for this purpose.

NOTICE

Damage to property due to operation in an unsuitable environment

Before commissioning, ensure that the environmental conditions at the place of commissioning and operation are complied with at all times.

1. Plug the module into a baseplate.
2. Screw the module onto the baseplate.
3. Wire the module.
4. Switch on the external supply voltage.

8 Decommissioning

8.1 Disassembly

⚠ WARNING

Danger to life due to electric shock

After disconnecting from the supply voltage, a life-threatening voltage is still present at the contacts of the DC link voltage. Touching the contacts can lead to death or injury from electric shock.

- After disconnecting from the supply network, wait 10 minutes before starting disassembly.

✓ The supply voltage is shut down.

1. Remove cables.
2. Loosen all mounting screws of the module.
3. Take the module off the baseplate.

⇨ The module has been removed correctly.

8.2 Disposal



Products marked with a crossed-out wheeled bin shall not be discarded with the normal waste stream. The device is considered as waste electrical and electronic equipment. The national regulations for the disposal of waste electrical and electronic equipment must be observed.

9 Appendix

9.1 Manual version history

The following table shows the version history of this manual.

Version	Comment
1.0	• First release

9.2 Accessories

Suitable accessories can be found on the product website:

www.beckhoff.com/MS2620-8001-2255

Product	Description
ZMX1000-0010	M5x17.5 combi-TX25 replacement screws for module fastening (PU = 10 pcs.)
ZMX3001-0022	2-row, 2-slot replacement seal for module base
ZMX4001-0002	Replacement cover for potential equalization for 2- and 3-row baseplate with Beckhoff logo
ZMX4001-0003	Replacement cover for MA6060 interface

9.3 Support and Service

Beckhoff Support and Service provides assistance with questions regarding Beckhoff products and system solutions, as well as with their planning, commissioning, and operation.

Beckhoff subsidiaries and representative offices

Please contact your Beckhoff subsidiary or your representative office for local support and service for Beckhoff products. You can find the addresses of Beckhoff subsidiaries and representative offices at: www.beckhoff.com/worldwide.

For Beckhoff products and technologies, we offer Training programs, tutorials, and webinars.

Beckhoff Support

Beckhoff Support provides assistance with technical questions regarding the use, planning, programming, and commissioning of Beckhoff products.

☎ Hotline:	+49 5246 963-157
✉ Email:	support@beckhoff.com, Support form
Web page:	www.beckhoff.com/support

Beckhoff Service

Our service specialists are here to assist you with any questions you may have regarding after-sales service processes, such as replacement parts, repairs, etc.

☎ Hotline:	+49 5246 963-460
✉ Email:	service@beckhoff.com, Service form
Web page:	www.beckhoff.com/service

Download finder

The Download finder serves as a central source for downloadable documents and files related to Beckhoff products, such as application reports, technical documentation, drawings, and configuration files.

Beckhoff Information System

The Beckhoff Information System is the central online documentation resource for Beckhoff products and contains documentation on products and automation topics, as well as sample code.

Beckhoff Headquarters

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl, Germany

☎ Phone:	+49 5246 963-0
✉ Email:	info@beckhoff.com
Web page:	www.beckhoff.com

Trademark statements

Beckhoff®, ATRO®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, MX-System®, Safety over EtherCAT®, TC/BSD®, TwinCAT®, TwinCAT/BSD®, TwinSAFE®, XFC®, XPlanar® and XTS® are registered and licensed trademarks of Beckhoff Automation GmbH.

More Information:
www.beckhoff.com/MS2620-8001-2255

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com