

BECKHOFF New Automation Technology

Manual | EN

TF8310

TwinCAT 3 | Wind Framework




Table of contents

1 Foreword	5
1.1 Notes on the documentation	5
1.2 For your safety	6
1.3 Notes on information security.....	7
2 Product description	8
3 Installation	9
3.1 System requirements	9
3.2 Installation	9
3.3 Licensing.....	12

1 Foreword

1.1 Notes on the documentation

This description is only intended for the use of trained specialists in control and automation engineering who are familiar with applicable national standards.

It is essential that the documentation and the following notes and explanations are followed when installing and commissioning the components.

It is the duty of the technical personnel to use the documentation published at the respective time of each installation and commissioning.

The responsible staff must ensure that the application or use of the products described satisfy all the requirements for safety, including all the relevant laws, regulations, guidelines and standards.

Disclaimer

The documentation has been prepared with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without prior announcement. No claims for the modification of products that have already been supplied may be made on the basis of the data, diagrams and descriptions in this documentation.

Trademarks

Beckhoff®, TwinCAT®, TwinCAT/BSD®, TC/BSD®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, Safety over EtherCAT®, TwinSAFE®, XFC®, XTS® and XPlanar® are registered trademarks of and licensed by Beckhoff Automation GmbH.

Other designations used in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

Patent Pending

The EtherCAT Technology is covered, including but not limited to the following patent applications and patents:

EP1590927, EP1789857, EP1456722, EP2137893, DE102015105702

with corresponding applications or registrations in various other countries.



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1.2 For your safety

Safety regulations

Read the following explanations for your safety.

Always observe and follow product-specific safety instructions, which you may find at the appropriate places in this document.

Exclusion of liability

All the components are supplied in particular hardware and software configurations which are appropriate for the application. Modifications to hardware or software configurations other than those described in the documentation are not permitted, and nullify the liability of Beckhoff Automation GmbH & Co. KG.

Personnel qualification

This description is only intended for trained specialists in control, automation, and drive technology who are familiar with the applicable national standards.

Signal words

The signal words used in the documentation are classified below. In order to prevent injury and damage to persons and property, read and follow the safety and warning notices.

Personal injury warnings

DANGER

Hazard with high risk of death or serious injury.

WARNING

Hazard with medium risk of death or serious injury.

CAUTION

There is a low-risk hazard that could result in medium or minor injury.

Warning of damage to property or environment

NOTICE

The environment, equipment, or data may be damaged.

Information on handling the product



This information includes, for example:
recommendations for action, assistance or further information on the product.

1.3 Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <https://www.beckhoff.com/secguide>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <https://www.beckhoff.com/secinfo>.

2 Product description

The TwinCAT Wind Framework consists of several components, providing essential functionalities for the automation software of wind energy turbines. They are designed to support the development, commissioning and maintenance of a wind turbine control system. The TwinCAT Wind Framework consists of Modules, Libraries and Applications. Modules are providing the essentials functionalities in the real-time context based on the TcCOM-Architecture. By the Libraries API's are provided to access and use the Framework. In addition the Applications are providing tools to interact with the Framework or collaborating systems.



TwinCAT Wind Framework

This public information is only a limited overview about the TwinCAT Wind Framework. Please, do not hesitate to contact us for a full documentation, support or feedback by email:

TcWind@beckhoff.com

Content overview

Modules		
TcWStatus Monitoring Supervision Event-Handling	TcWParameter Settings Adjustments Configurations	TcWCommand Remote Commands Manual Interaction Action Triggering
TcWMean Average Calculation Long-Term Evaluation	TcWCapture Sampling of Values Long-Term Recording	TcWUser User Management Authorization Credentials
TcWConnect ADS Server Diagnostics Online Monitoring	TcWDatabase Database Interface Storage of Data Historical Monitoring	TcWTrace Event-Log High Resolution Pre/Post-Trigger
Programming		
TcWindLib PLC Library Function and Functionblocks	TcWindSDK C++ Interface Header Files and Libraries	
Applications		
TcWindView Engineering Visualization Debugging and Commissioning Tool	TcWindDatabase SQL Database Application Tables, Procedures, Views	
TcWindTurbine Template Fundamental Project Template Module Wind Turbine Application	TcWind ADS / SQL Client C#/.NET Client Applications Interface Demonstration Projects	
TcWindPlcTraining PLC Demonstration Project Modular Cooling Subsystem	TcWindCppTraining C++ Demonstration Project Modular Cooling System	

3 Installation

3.1 System requirements

For first tests with TwinCAT Wind Framework a demonstration setup is available on [Beckhoff website](#).

Technical data	TF8310 TwinCAT 3 Wind Framework
Target system	Windows 7, Windows 8, Windows 10 PC (x86, x64)
Min. TwinCAT version	3.1.4020.0
Min. TwinCAT level	TC1200 TC3 PLC or TC1300 TC3 C++


3.2 Installation

The following section describes how to install the TwinCAT 3 Function for Windows-based operating systems.

- ✓ The TwinCAT 3 Function setup file was downloaded from the Beckhoff website.
- 1. Run the setup file as administrator. To do this, select the command **Run as administrator** in the context menu of the file.
 - ⇒ The installation dialog opens.
- 2. Accept the end user licensing agreement and click **Next**.



3. Enter your user data.



Customer Information

Please enter your information.


User Name:
Max Mustermann

Organization:
Mustermann Inc.

InstallShield

< Back Next > Cancel

4. If you want to install the full version of the TwinCAT 3 Function, select **Complete** as installation type. If you want to install the TwinCAT 3 Function components separately, select **Custom**.



Setup Type

Choose the setup type that best suits your needs.

Please select a setup type.


Complete
All program features will be installed to all installed TwinCAT 3 versions on your system. (Requires the most disk space.)

Custom
Choose which program features you want installed and to which TwinCAT 3 version they will be installed. Recommended for advanced users.

InstallShield


< Back Next > Cancel

5. Select **Next**, then **Install** to start the installation.




⇒ A dialog box informs you that the TwinCAT system must be stopped to proceed with the installation.

6. Confirm the dialog with **Yes**.



7. Select **Finish** to exit the setup.



⇒ The TwinCAT 3 Function has been successfully installed and can be licensed (see [Licensing](#) [▶ 12]).

3.3 Licensing

The TwinCAT 3 function can be activated as a full version or as a 7-day test version. Both license types can be activated via the TwinCAT 3 development environment (XAE).

Licensing the full version of a TwinCAT 3 Function

A description of the procedure to license a full version can be found in the Beckhoff Information System in the documentation "[TwinCAT 3 Licensing](#)".


Licensing the 7-day test version of a TwinCAT 3 Function



A 7-day test version cannot be enabled for a [TwinCAT 3 license dongle](#).


1. Start the TwinCAT 3 development environment (XAE).
2. Open an existing TwinCAT 3 project or create a new project.
3. If you want to activate the license for a remote device, set the desired target system. To do this, select the target system from the **Choose Target System** drop-down list in the toolbar.
 - ⇒ The licensing settings always refer to the selected target system. When the project is activated on the target system, the corresponding TwinCAT 3 licenses are automatically copied to this system.

- In the **Solution Explorer**, double-click **License** in the **SYSTEM** subtree.



⇒ The TwinCAT 3 license manager opens.

- Open the **Manage Licenses** tab. In the **Add License** column, check the check box for the license you want to add to your project (e.g. "TF4100 TC3 Controller Toolbox").



- Open the **Order Information (Runtime)** tab.
 - ⇒ In the tabular overview of licenses, the previously selected license is displayed with the status "missing".

7. Click **7-Day Trial License...** to activate the 7-day trial license.

The screenshot shows the 'License Management' window with the following sections:

- Order Information (Runtime)**: Includes tabs for 'Manage Licenses', 'Project Licenses', and 'Online Licenses'. Below are fields for 'License Device' (set to 'Target (Hardware Id)'), 'System Id' (2DB25408-B4CD-81DF-5488-6A3D9B49EF19), and 'Platform' (other (91)).
- License Request**: Includes a 'Provider' dropdown set to 'Beckhoff Automation', a 'Generate File...' button, and input fields for 'License Id', 'Customer Id', and 'Comment'.
- License Activation**: This section is highlighted with a red box and contains two buttons: '7 Days Trial License...' and 'License Response File...'.

⇒ A dialog box opens, prompting you to enter the security code displayed in the dialog.

The 'Enter Security Code' dialog box contains the following elements:

- Title: Enter Security Code
- Text: Please type the following 5 characters:
- Code display: Kg8T4
- Input field: A two-character input field with a red border, currently empty.
- Buttons: 'OK' (highlighted with a red box) and 'Cancel'.

8. Enter the code exactly as it is displayed and confirm the entry.
9. Confirm the subsequent dialog, which indicates the successful activation.
- ⇒ In the tabular overview of licenses, the license status now indicates the expiry date of the license.
10. Restart the TwinCAT system.
- ⇒ The 7-day trial version is enabled.

More Information:
www.beckhoff.com/tf8310

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

